
PARTS LIST

トーハツ船外機
パーツ　リスト



TOHATSU

MFS 9.9
15
18

OB NO.002-21047-4
0607 MH 2,000

パーツリストのご使用について

1. このパーツリストは、トーハツ船外機を構成している部品を収録したものです。

2. 部品の新設、廃止または、変更が生じた場合は、インフォメーション等にてお知らせ致しますので、その都度、ご訂正ください。

3. アッセンブリまたはキットでの販売部品は、その構成する部品の頭に（＊）印をつけて表しています。

4. 本文中に記載されている記号は、次の様になっています。

STD	：スタンダード	M	：マニュアルスタータタイプ
OPT	：オプション	E	：セルスタータタイプ
O/S	：オーバーサイズ	F	：ティラハンドルタイプ
Ass'y	：アッセンブリ	P	：プレジャータイプ
AR	：必要に応じて選択	PTT	：パワートリム＆チルト

5. オーダー上の注意

塗装部品の注文に当っては、以下に従ってください。

パーツナンバーの 4 桁目が “B”・“Q”・“S”・“W” 記号のものは塗装されています。現在の塗装色はパワーヘッドがブラック(B)、ロワユニットがアクアマリンブルー(Q)、プロペラがホワイト(W)です。

※ロワユニットの旧塗装色は(S)シルバーグレーです。

例示-1：パワーヘッド部品

3H8B01100-1

B ：ブラック

例示-2：ロワユニット部品

3R3Q61020-4

Q ：アクアマリンブルー

6. 備考欄にオールドパーツNo.が記されている部品は、パーツNo.が変更された部品ですが、部品に変更は有りません。

7. 備考欄に“UNIQUE”もしくは “N.A.F.N.” と記されている部品がありますが、特に関係ありません。

HOW TO USE THIS PARTS LIST

1. This Parts List contains the component parts of the Tohatsu outboard motors.

2. Please keep the Parts List updated each time when receiving the Service Bulletin describing the addition, abolition and/or change of parts.

3. Given mark in (∗) to part number shows assembly or kit part.

4. Marks in this Parts List show:

STD	: Standard	M	: Manual Starter Type
OPT	: Optional Parts	E	: Electric Starter Type
O/S	: Over size	F	: Tiller Handle Type
Ass'y	: Assembly	P	: Pleasure Type
AR	: As required	PTT	: Power Trim & Tilt Type

5. Attention to order

   Please order painted parts in accordance with following. The parts that fourth figure of the parts number is "B", "Q" , "S" or "W" have painted.

[Example]

POWER HEAD PARTS
3H8B01001-1
B : Black

PROPELLER
362W64101-0
W : White

LOWER UNIT PARTS
3R3Q61020-4
Q : Aquamarine Blue (present color)

3R3S61020-4
S : Silver gray (old color)


6. Old part numbers written in the Remarks column mean that only part numbers were changed.

7. You don't care that the "UNIQUE" or "N.A.F.N." parts written in the Remarks column.

目　　次
CONTENTS


Fig. 1	シリンダヘッド CYLINDER HERD	1
Fig. 2	シリンダ CYLINDER	3
Fig. 3	ピストン＆クランクシャフト PISTON & CRANKSHAFT	7
Fig. 4	インテークマニホールド＆フュエルポンプ INTAKE MANIFOLD & FUEL PUMP	9
Fig. 5	キャブレタ CARBURETOR	11
Fig. 6	カムシャフト＆オイルポンプ CAMSHAFT & OIL PUMP	15
Fig. 7	インテークバルブ＆エキゾーストバルブ INTAKE VALVE & EXHAUST VALVE	17
Fig. 8	マグネト MAGNETO	19
Fig. 9	エレクトリックパーツ ELECTRIC PARTS	21
Fig. 10	スタータモータ STARTER MOTOR	23
Fig. 11	リコイルスタータ RECOIL STARTER	25
Fig. 12	ティラハンドル（ステアリングハンドル） TILLER HANDLE (STEERING HANDLE)	29
Fig. 13	ドライブシャフトハウジング DRIVE SHAFT HOUSING	31
Fig. 14	ギヤケース GEAR CASE	33
Fig. 15	ドライブシステム＆ウォータポンプ DRIVE SYSTEM & WATER PUMP	35
Fig. 16	シフト＆ストップスイッチ SHIFT & STOP SWITCH	39
Fig. 17	シフト（EPモデル用） SHIFT (for “EP” model)	43
Fig. 18	スイベルブラケット SWIVEL BRACKET	47
Fig. 19	クランプブラケット（スターンブラケット）＆リバースロック CLAMP BRACKET (STERN BRACKET) & REVERSE LOCK	51
Fig. 20	ボトムカウル（モータカバーロワ） BOTTOM COWL (MOTOR COVER LOWER)	55
Fig. 21	トップカウル（モータカバーアッパ） TOP COWL (MOTOR COVER UPPER)	57
Fig. 22	フュエルタンク FUEL TANK	59
Fig. 23	オプショナルパーツ（アクセサリー） OPTIONAL PARTS (ACCESSORIES)	61
Fig. 24	アッセンブリ、キット ASSEMBLY, KIT	63

シリンダヘッド
Fig. 1 CYLINDER HEAD




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
1-1	3H8B01001-1	ｼﾘﾝﾀﾞﾍｯﾄﾞ Cylinder Head	1	1	1	15B # 11421～ 9.9B # 11288～
	3H8B01001-0	ｼﾘﾝﾀﾞﾍｯﾄﾞ Cylinder Head	-	(1)	(1)	15B ～# 11420 9.9B ～# 11287
1-2	3H8-01005-0	ｼﾘﾝﾀﾞﾍｯﾄﾞｶﾞｽｹｯﾄ Cylinder Head Gasket	1	1	1	
1-3	345-01111-0	ﾀﾞｳｴﾙﾋﾟﾝ、6-12 Dowel Pin, 6-12	2	2	2	
1-4	3H8-01013-0	ｼﾘﾝﾀﾞﾍｯﾄﾞﾎﾞﾙﾄ Cylinder Head Bolt	6	6	6	8-60
1-5	916114-0625	ﾎﾞﾙﾄ Bolt	2	2	2	
1-6	916119-0640	ﾎﾞﾙﾄ Bolt	1	1	1	
1-7	940113-0600	ﾜｯｼｬ Washer	3	3	3	
1-8	3H8B01021-0	ｼﾘﾝﾀﾞﾍｯﾄﾞｶﾊﾞｰ Cylinder Head Cover	1	1	1	
1-9	3H8-01024-0	ｼﾘﾝﾀﾞﾍｯﾄﾞｶﾊﾞｰｶﾞｽｹｯﾄ Cylinder Head Cover Gasket	1	1	1	Rubber
1-10	910114-5630	ﾎﾞﾙﾄ Bolt	4	4	4	
1-11	3R0-71015-0	ｴﾝｼﾞﾝｵｲﾙﾌｨﾗｰｷｬｯﾌﾟ Engine Oil Filler Cap	1	1	1	
1-12	3R0-07422-0	O ﾘﾝｸﾞ、3.1-24.4 O-Ring, 3.1-24.4	1	1	1	
1-13	9701-1-1103	ｽﾊﾟｰｸﾌﾟﾗｸﾞ Spark Plug	2	2	2	NGK: DCPR6E

シリンダ
Fig. 2 CYLINDER



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
2-1	3H8B01100-2	ｼﾘﾝﾀﾞｰ･ｸﾗﾝｸｹｰｽ Cylinder-Crank Case	1	1	1	# 000000XE～
	3H8B01100-1	ｼﾘﾝﾀﾞｰ･ｸﾗﾝｸｹｰｽ Cylinder-Crank Case	(1)	(1)	(1)	15B # 11421～ 9.9B # 11288～
	3H8B01100-0	ｼﾘﾝﾀﾞｰ･ｸﾗﾝｸｹｰｽ Cylinder-Crank Case	-	(1)	(1)	15B ～# 11420 9.9B ～# 11287
2-1-1	345-01111-0	ﾀﾞｳｴﾙﾋﾟﾝ、6-12 * Dowel Pin, 6-12	2	2	2	
2-1-2	3H8-01012-0	ﾎﾞﾙﾄ、8-50 * Bolt, 8-50	4	4	4	
2-1-3	916119-0630	ﾎﾞﾙﾄ * Bolt	6	6	6	
2-1-4	940113-0600	ﾜｯｼｬ * Washer	6	6	6	
2-1-5	3H8-02093-0	ﾆｯﾌﾟﾙ、10-32 * Nipple, 10-32	1	1	1	
2-1-6	3H8-07636-0	ｵｲﾙﾌｨﾙﾀﾎﾞﾙﾄ * Oil Filter Bolt	1	1	1	
2-2	3R3B02301-0	ｴｷｿﾞｰｽﾄｶﾊﾞｰ Exhaust Cover	1	1	1	
2-3	3R3-02305-0	ｴｷｿﾞｰｽﾄｶﾊﾞｰｶﾞｽｹｯﾄ Exhaust Cover Gasket	1	1	1	
2-4	910114-5625	ﾎﾞﾙﾄ Bolt	5	5	5	
2-5	3R3-01030-0	ｻｰﾓｽﾀｯﾄ Thermostat	1	1	1	
2-6	3H6B01031-0	ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟ Thermostat Cap	1	1	1	
2-7	346-01032-0	ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟｶﾞｽｹｯﾄ Thermostat Cap Gasket	1	1	1	
2-8	910113-7640	ﾎﾞﾙﾄ Bolt	2	2	2	
2-9	369-60218-1	ｱﾉｰﾄﾞ Anode	1	1	1	
2-10	3H8B01143-0	ｱﾉｰﾄﾞｷｬｯﾌﾟ Anode Cap	1	1	1	
2-11	3R3-01144-0	ｱﾉｰﾄﾞｷｬｯﾌﾟｶﾞｽｹｯﾄ Anode Cap Gasket	1	1	1	
2-12	910103-0616	ﾎﾞﾙﾄ Bolt	1	1	1	
2-13	910113-5620	ﾎﾞﾙﾄ Bolt	2	2	2	
2-14	3V2-07620-0	ﾌﾟﾗﾝｼﾞｬ Plunger	1	1	1	
2-15	98AB-5-0330	ｺﾞﾑﾎｰｽ Rubber Hose	1	1	1	for Tell-Tale
2-16	3R3B07431-0	ﾌﾞﾘｰｻﾞﾁｬﾝﾊﾞｶﾊﾞｰ Breather Chamber Cover	1	1	1	
2-17	3R3-07432-1	ﾌﾞﾘｰｻﾞﾁｬﾝﾊﾞｶﾊﾞｰｶﾞｽｹｯﾄ Breather Chamber Cover Gasket	1	1	1	
2-18	3R3-07430-0	ｽｸﾘｭ、6-20 ﾌﾟﾚｺｰﾄ Screw, 6-20 Pre-Coated	4	4	4	
2-19	398-06972-0	ｸﾗﾝﾌﾟ、6.5-67P Clamp, 6.5-67P	1	1	1	
2-20	309-06972-0	ｸﾗﾝﾌﾟ、6.5-47.5P Clamp, 6.5-47.5P	1	1	1	
2-21	910113-0612	ﾎﾞﾙﾄ Bolt	1	1	1	
2-22	99AA-2-0110	ｺﾞﾑﾎｰｽ Rubber Hose	1	1	1	15B # 11421～ 9.9B # 11288～

シリンダ
Fig. 2 CYLINDER




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
2-22	98AB-5-0130	ｺﾞﾑﾎｰｽ Rubber Hose	-	(1)	(1)	15B ～# 11420 9.9B ～# 11287
2-23	338-01133-0	ｸﾘｯﾌﾟ、φ7 Clip, φ7	2	2	2	15B # 11421～ 9.9B # 11288～
	338-02215-0	ｸﾘｯﾌﾟ、φ10 Clip, φ10	-	(2)	(2)	15B ～# 11420 9.9B ～# 11287
2-24	3R3-07421-2	ｵｲﾙﾚﾍﾞﾙｹﾞｰｼﾞ Oil Level Gauge	1	1	1	
2-25	3R0-07615-0	ｵｲﾙﾌｨﾙﾀ Oil Filter	1	1	1	
2-26	3R3-07410-0	ｵｲﾙｽﾄﾚｰﾅ Oil Strainer	1	1	1	
2-27	98AH10-0200	ﾎｰｽ Hose	1	1	1	
2-28	369-84398-0	ﾘｰﾄﾞﾜｲﾔﾊﾞﾝﾄﾞ、158 Lead Wire Band, 158	2	2	2	
2-29	3R3-07441-1	ｵｲﾙﾊﾟﾝﾌﾟﾚｰﾄ Oil Pan Plate	(1)	(1)	(1)	※ 2 Old
2-30	3V9-07402-1	ｵｲﾙﾊﾟﾝｶﾞｽｹｯﾄ Oil Pan Gasket	1	1	1	※ 1 New
2-30A	3R3-07442-2	ｵｲﾙﾊﾟﾝﾌﾟﾚｰﾄｶﾞｽｹｯﾄ Oil Pan Plate Gasket	(2)	(2)	(2)	※ 2 Old
2-31	3R3-61017-0	ﾎﾞﾙﾄ、8-35 Bolt, 8-35	6	6	6	
2-32	3H8-07629-0	ﾌﾟﾗﾝｼﾞｬｶﾊﾞｰ Plunger Cover	1	1	1	
2-33	3C7-01513-1	ﾊﾝｶﾞ Hanger	1	1	1	
2-34	910114-5820	ﾎﾞﾙﾄ Bolt	2	2	2	
2-35	3V9-07440-0	ｶﾞｲﾄﾞﾌﾟﾚｰﾄ Guide Plate	1	1	1	※ 2 New
2-36	910113-5612	ﾎﾞﾙﾄ Bolt	1	1	1	New

※ 1. 旧型のドライブシャフトハウジングに、新オイルパンガスケット(3V9-07402-1) の使用は、禁止します。
※ 2. ガイドプレート (3V9-07440-0) が、取付けられていないドライブシャフトハウジングには必ず旧型の
オイルパンプレート (3R3-07441-1) と オイルパンプレートガスケット (3R3-07442-2) を使用して下さい。

※ 1: Do not use new oil pan gasket (3V9-07402-1) to old drive shaft housing.
※ 2: Use old oil pan plate (3R3-07441-1) and old oil pan plate gasket (3R3-07442-2) to a drive shaft
housing which a guide plate (3V9-07440-0) is not installed.


ピストン＆クランクシャフト
Fig. 3 PISTON & CRANKSHAFT



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
3-1	3R3-00030-0	ｸﾗﾝｸｼｬﾌﾄｱｯｼ Crankshaft Ass'y	1	1	1	
3-2	3H8-07407-0	ﾒﾀﾙ (ﾌﾞﾗｯｸ) Bearing (Black)	4	4	4	0 t=1.5 -0.006
	3H8-07408-0	ﾒﾀﾙ (ﾌﾞﾗｳﾝ) Bearing (Brown)	4	4	4	-0.006 t=1.5 -0.012
3-3	3H8-00001-0	ﾋﾟｽﾄﾝ Piston	2	2	2	
	3H8-00004-0	ﾋﾟｽﾄﾝ (0.5mm O/S) Piston (0.5mm O/S)	2	2	2	ｵﾌﾟｼｮﾝ Option
3-4	3H6-00011-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞﾄｯﾌﾟ Piston Ring Top	2	2	2	
	3H6-00014-0	ﾋﾟｽﾄﾝﾘﾝｸﾞﾄｯﾌﾟ (0.5mm O/S) Piston Ring Top (0.5mm O/S)	2	2	2	ｵﾌﾟｼｮﾝ Option
3-5	3H6-00012-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ 2nd Piston Ring 2nd	2	2	2	
	3H6-00015-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ 2nd (0.5mm O/S) Piston Ring 2nd (0.5mm O/S)	2	2	2	ｵﾌﾟｼｮﾝ Option
3-6	3H6-00013-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ ｵｲﾙ Piston Ring Oil	2	2	2	
	3H6-00016-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ ｵｲﾙ (0.5mm O/S) Piston Ring Oil (0.5mm O/S)	2	2	2	ｵﾌﾟｼｮﾝ Option
3-7	3H6-00021-0	ﾋﾟｽﾄﾝﾋﾟﾝ Piton Pin	2	2	2	
3-8	3H6-00024-0	ﾋﾟｽﾄﾝﾋﾟﾝｸﾘｯﾌﾟ Piton Pin Clip	4	4	4	
3-9	3R0-00040-0	ｺﾝﾛｯﾄﾞ Connecting Rod	2	2	2	
3-9-1	3H6-00059-0	ｺﾝﾛｯﾄﾞﾎﾞﾙﾄ * Connecting Rod Bolt	4	4	4	
3-10	3T5-10131-0	ｷｰ Key	2	2	2	
3-11	3H8-00121-0	ｵｲﾙｼｰﾙ、32-48-8 Oil Seal, 32-48-8	1	1	1	
3-12	3R3-00121-0	ｵｲﾙｼｰﾙ、32-44-9 Oil Seal, 32-44-9	1	1	1	


インテークマニホルド＆フュエルポンプ

Fig. 4 INTAKE MANIFOLD & FUEL PUMP




見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
4-1	3R3-02010-1	ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞ Intake Manifold	1	1	1	18B # 01285～ 15B # 11840～ 9.9B # 11775～
4-2	3R3-02104-1	ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｶﾞｽｹｯﾄ Intake Manifold Gasket	1	1	1	
4-3	345-01111-0	ﾀﾞｳｴﾙﾋﾟﾝ、6-12 Dowel Pin, 6-12	2	2	2	
4-4	916114-0645	ﾎﾞﾙﾄ Bolt	4	4	4	
4-5	940113-0600	ﾜｯｼｬ Washer	4	4	4	
4-6	345-06915-0	ｸﾗﾝﾌﾟ、6.5-14L Clamp, 6.5-14L	1	1	1	
4-7	3R0-02011-0	ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ Carburetor Gasket	2	2	2	
4-8	3R0-03952-0	ｲﾝｼｭﾚｰﾀ Insulator	1	1	1	
4-9	3V9-02410-0	ｲﾝﾃｰｸｻｲﾚﾝｻ Intake Silencer	1	-	-	
	3H8-02410-0	ｲﾝﾃｰｸｻｲﾚﾝｻ Intake Silencer	-	1	1	with Collars
4-9-1	3A0-76079-0	ｶﾗｰ、6.2-9-7.4 ＊ Collar, 6.2-9-7.4	2	-	-	
4-10	3F3-02012-0	O ﾘﾝｸﾞ 1.9-38.8 O-Ring, 1.9-38.8	1	1	1	
4-11	3R0-03215-0	ﾎﾞﾙﾄ、6-100 Bolt, 6-100	2	2	2	
4-12	3R0-66308-0	ﾜｯｼｬ、6-16-1.5 Washer, 6-16-1.5	2	-	-	
	940113-0600	ﾜｯｼｬ Washer	-	2	2	
4-13	98AB-7-0110	ｺﾞﾑﾎｰｽ Rubber Hose	1	1	1	for Breather
4-14	3C7-02215-0	ｸﾘｯﾌﾟ、φ12 Clip, φ12	2	2	2	
4-15	3H8-04000-1	ﾌｭｴﾙﾎﾟﾝﾌﾟ Fuel Pump	1	1	1	
4-16	345-62415-0	O ﾘﾝｸﾞ、3.5-25.7 O-Ring, 3.5-25.7	1	1	1	
4-17	910113-5625	ﾎﾞﾙﾄ Bolt	2	2	2	or 910103-5625
4-18	98AB-5-0260	ｺﾞﾑﾎｰｽ Rubber Hose	1	1	1	
4-19	98AB-5-0150	ｺﾞﾑﾎｰｽ Rubber Hose	1	1	1	
4-20	369-02230-0	ﾌｭｴﾙﾌｨﾙﾀ Fuel Filter	1	1	1	
4-21	338-02215-0	ｸﾘｯﾌﾟ φ10 Clip φ10	4	4	4	

キャブレタ
Fig. 5 CARBURETOR




見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
5-1	3V9-03500-2	ｷｬﾌﾞﾚﾀ Carburetor	1	-	-	3V9B 18B2 #01549～
	3V9-03500-0	ｷｬﾌﾞﾚﾀ Carburetor	(1)	-	-	3V9A 18B #00001～#01548
	3DU-03500-0	ｷｬﾌﾞﾚﾀ (EU) Carburetor (for EU)	1	-	-	for EU (3DUA) use with Camshaft (3DU-07010-0)
	3R3-03500-2	ｷｬﾌﾞﾚﾀ (EU) Carburetor	-	1	-	3R3G 15B2 #12011～
	3R3-03200-1	ｷｬﾌﾞﾚﾀ Carburetor	-	(1)	-	3R3F 15B #10001～#12010
	3DT-03500-0	ｷｬﾌﾞﾚﾀ (EU) Carburetor (for EU)	-	1	-	3DTA for EU
	3H8-03500-0	ｷｬﾌﾞﾚﾀ Carburetor	-	-	1	3H8F or 3H8-03200-1
5-1-1	3V9-03220-0	ﾌﾛｰﾄﾁｬﾝﾊﾞ * Float Chamber	1	(1)	-	15B #10001～#12010 Old Part No.3R3-03221-0
	3R3-03221-1	ﾌﾛｰﾄﾁｬﾝﾊﾞ * Float Chamber	-	1	-	15B2 #12011～
	3H8-03221-0	ﾌﾛｰﾄﾁｬﾝﾊﾞ * Float Chamber	-	-	1	
5-1-1-1	3R3-03222-0	ﾌﾛｰﾄﾁｬﾝﾊﾞ O ﾘﾝｸﾞ ** Float Chamber O-Ring	1	1	1	
5-1-1-2	3R3-03315-1	ﾌﾟﾗﾝｼﾞｬｺﾝﾌﾟﾘｰﾄ ** Plunger Comp.	-	1	-	H=11.9 15B2 #12011～
	3V9-03315-0	ﾌﾟﾗﾝｼﾞｬｺﾝﾌﾟﾘｰﾄ ** Plunger Comp.	1	(1)	-	H=9.6　15B#10001～#12010 Old Part No.3R3-03315-0
5-1-1-3	3R3-03314-0	ｺｲﾙｽﾌﾟﾘﾝｸﾞ ** Coil Spring	1	1	-	
5-1-1-4	3R3-03316-0	ｽｸﾘｭ ** Screw	1	1	-	
5-1-2	922503-6414	ｽｸﾘｭ * Screw	4	4	4	
5-1-3	369-03186-0	ｽｸﾘｭ * Screw	3	3	3	
5-1-4	3R3-03231-0	ﾌﾛｰﾄ * Float	1	1	1	
5-1-5	3F3-03232-0	ﾌﾛｰﾄｱｰﾑﾋﾟﾝ * Float Arm Pin	1	1	1	
5-1-6	3R3-03239-0	ﾌﾛｰﾄﾊﾞﾙﾌﾞ * Float Valve	1	1	1	with Valve Pin
5-1-7	344-03244-0	ｸﾘｯﾌﾟ * Clip	1	1	1	
5-1-8	3R3-03234-0	ｽｸﾘｭ * Screw	1	1	1	
5-1-9	3R3-03252-0	ﾒｲﾝﾉｽﾞﾙ * Main Nozzle	1	1	-	
	3H8-03252-0	ﾒｲﾝﾉｽﾞﾙ * Main Nozzle	-	-	1	
5-1-10	3V9-03251-0	ﾒｲﾝｼﾞｪｯﾄ #108 * Main Jet #108	1	-	-	
	3R3-03251-0	ﾒｲﾝｼﾞｪｯﾄ #105 * Main Jet #105	-	1	-	
	3H8-03251-0	ﾒｲﾝｼﾞｪｯﾄ #68 * Main Jet #68	-	-	1	
5-1-11	3V9-03255-0	ｽﾛｰｼﾞｪｯﾄ #58 * Slow Jet #58	1	-	-	
	3R3-03255-0	ｽﾛｰｼﾞｪｯﾄ #50 * Slow Jet #50	-	1	-	
	3H8-03255-0	ｽﾛｰｼﾞｪｯﾄ #42 * Slow Jet #42	-	-	1	

キャブレタ
Fig. 5 CARBURETOR




見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
5-1-12	346-03256-0	ﾗﾊﾞｰｷｬｯﾌﾟ * Rubber Cap	1	1	1	
5-1-13	3R3-03180-0	ｽｸﾘｭ * Screw	1	1	1	
5-1-15	3R3-03292-0	ﾄﾞﾚﾝｽｸﾘｭ * Drain Screw	1	1	1	
5-1-16	3R3-03293-0	ｶﾞｽｹｯﾄ * Gasket	1	1	1	
5-1-17	3R3-03181-0	ｷｬﾌﾞﾚﾀｶﾊﾞｰ * Carburetor Cover	1	1	1	
5-1-18	3R3-03182-0	ｷｬﾌﾞﾚﾀｶﾊﾞｰｶﾞｽｹｯﾄ * Carburetor Cover Gasket	1	1	1	
5-1-19	346-03265-0	ｽﾄｯﾌﾟｽｸﾘｭ * Stop Screw	1	1	1	
5-1-20	3R3-03267-0	ｽﾌﾟﾘﾝｸﾞ A * Spring "A"	1	1	1	
5-1-21	3R3-03410-0	ｵｰﾄﾊﾞｲｽﾀｰﾀ * Auto-By-Starter	1	1	1	with O-Ring
5-1-22	3R3-03411-0	ﾎﾙﾀﾞ * Holder	1	1	1	
5-1-23	369-03186-0	ｽｸﾘｭ * Screw	1	1	1	
5-1-24	3R3-03311-1	ﾗﾊﾞｰﾌﾞｰﾂ * Rubber Boot	1	1	-	# 043679XD～
5-1-25	3R3-03312-0	ﾘﾝｸﾛｯﾄﾞ * Link Rod	1	1	-	

カムシャフト＆オイルポンプ
Fig. 6 CAMSHAFT & OIL PUMP




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
6-1	3V9-07010-0	カムシャフト Camshaft	1	-	-	
	3DU-07010-0	カムシャフト (EU) Camshaft (for EU)	1	-	-	for EU use with Carburetor(3DU-03500-0)
	3R3-07010-0	カムシャフト Camshaft	-	1	1	
6-2	3H8-07600-0	オイルポンプ Oil Pump	1	1	1	
6-3	3H8-07639-0	オイルポンプ O リング Oil Pump O-Ring	1	1	1	incl. Oil Pump
6-4	3H8-07635-0	O リング、1.5-15.5 O-Ring, 1.5-15.5	2	2	2	
6-5	3H8-07632-0	O リング、1.5-10.7 O-Ring, 1.5-10.7	1	1	1	
6-6	3H8-07631-0	O リング、1.5-8.5 O-Ring, 1.5-8.5	1	1	1	
6-7	910114-5635	ボルト Bolt	3	3	3	
6-8	3H8-07025-0	オイルシール、18-35-8 Oil Seal, 18-35-8	1	1	1	
6-9	3H8-10062-2	ドリブンプーリ Driven Pulley	1	1	1	Camshaft Pulley (Black) # 024197XC～
6-10	309-00131-0	キー Key	1	1	1	
6-11	3AA-60108-0	ボルト、6-20 プレコート Bolt, 6-20 Pre-Coated	1	1	1	
6-12	3H8-10066-0	ワッシャ、6.5-19-3.2 Washer, 6.5-19-3.2	1	1	1	
6-13	3H8-10060-0	ドライブプーリ Drive Pulley	1	1	1	Timing Pulley
6-14	3H8-10063-0	ベルトガイド Belt Guide	2	2	2	
6-15	3H8-10068-0	ナット Nut	1	1	1	
6-16	3H8-10069-0	ロックワッシャ Lock Washer	1	1	1	
6-17	3H8-10061-0	タイミングベルト Timing Belt	1	1	1	
6-18	3H8-10062-1	ドリブンプーリ Driven Pulley	(1)	(1)	(1)	Camshaft Pulley (Gray) Old ～#020106XC
6-19	3R3-10067-0	ワッシャ、14.2-25-2.5 Washer, 14.2-25-2.5	(1)	(1)	(1)	

インテークバルブ＆エキゾストバルブ
Fig. 7 INTAKE VALVE & EXHAUST VALVE




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
7-1	3R3-07201-0	ｲﾝﾃｰｸﾊﾞﾙﾌﾞ Intake Valve	2	2	2	
7-2	3R0-07202-0	ｴｷｿﾞｰｽﾄﾊﾞﾙﾌﾞ Exhaust Valve	2	2	2	
7-3	3R3-07204-0	ｲﾝﾃｰｸﾊﾞﾙﾌﾞｽﾃﾑｼｰﾙ Intake Valve Stem Seal	2	2	2	Black
7-4	3R3-07206-0	ｴｷｿﾞｰｽﾄﾊﾞﾙﾌﾞｽﾃﾑｼｰﾙ Exhaust Valve Stem Seal	2	2	2	Green
7-5	3H6-07203-1	ﾊﾞﾙﾌﾞｽﾌﾟﾘﾝｸﾞ Valve Spring	4	4	4	L=35
7-6	3H6-07205-0	ﾊﾞﾙﾌﾞｽﾌﾟﾘﾝｸﾞｼｰﾄ Valve Spring Seat	4	4	4	
7-7	3H6-07221-0	ﾘﾃｰﾅ Retainer	4	4	4	
7-8	3H6-07223-0	ｺｯﾀｰ Cotter	8	8	8	
7-9	3AE-07235-0	ﾛｯｶｰｱｰﾑ (t=17) Rocker Arm (t=17)	4	4	4	18B#00001～,15B# 11371～ 9.9B # 11275～
	3H8-07235-0	ﾛｯｶｰｱｰﾑ (t=16) Rocker Arm (t=16)	-	(4)	(4)	15B ～# 11370 9.9B ～# 11274
7-10	3R0-07238-0	ｱｼﾞｬｽﾄｽｸﾘｭ Adjusting Screw	4	4	4	18B#00001～,15B# 11371～ 9.9B # 11275～
	3H8-07238-0	ｱｼﾞｬｽﾄｽｸﾘｭ Adjusting Screw	-	(4)	(4)	15B ～# 11370 9.9B ～# 11274
7-11	3H8-07237-0	ｱｼﾞｬｽﾄﾅｯﾄ Adjusting Nut	4	4	4	
7-12	3H8-07226-0	ﾛｯｶｰｱｰﾑｼｬﾌﾄ Rocker Arm Shaft	2	2	2	
7-13	3H8-07239-0	ｶﾗｰ、13.1-15.9-22.5 Collar, 13.1-15.9-22.5	3	3	3	
7-14	3H8-07225-0	ﾛｯｶｰｼｬﾌﾄｽﾌﾟﾘﾝｸﾞ Rocker Shaft Spring	3	3	3	L=30
7-15	3H8-07229-0	ﾛｯｶｰｼｬﾌﾄｽﾌﾟﾘﾝｸﾞ Rocker Shaft Spring	1	1	1	L=51
7-16	3R3-07227-0	ﾜｯｼｬ、13.2-21.7-2 Washer, 13.2-21.7-2	1	1	1	
7-17	3H8-07227-0	ﾜｯｼｬ (t=0.5) Washer (t=0.5)	-	(8)	(8)	廃止　15B ～# 11370 Disused　9.9B～# 11274

マグネト
Fig. 8 MAGNETO




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
8-1	3H8-06096-0	ﾌﾗｲﾎｲﾙｶｯﾌﾟ(ﾘﾝｸﾞｷﾞﾔ付) Flywheel Cup (with Ring Gear)	1	1	1	FF-51
8-2	931121-1600	ﾅｯﾄ、16-P1.5 Nut, 16-P1.5	1	1	1	
8-3	3H8-00133-0	ﾜｯｼｬ、16-27-3.2 Washer, 16-27-3.2	1	1	1	
8-4	3H8-06023-0	ｵﾙﾀﾈｰﾀ Alternator	1	1	1	
8-5	921503-6630	ｽｸﾘｭ Screw	3	3	3	
8-6	940203-0600	ﾜｯｼｬ Washer	3	3	3	
8-7	345-06915-0	ｸﾗﾝﾌﾟ、6.5-14L Clamp, 6.5-14L	1	1	1	
8-8	921513-0616	ｽｸﾘｭ Screw	1	1	1	
8-9	3V6-06008-0	ｺｲﾙﾌﾞﾗｹｯﾄ Coil Bracket	1	1	1	New
	3H8-06008-0	ｺｲﾙﾌﾞﾗｹｯﾄ Coil Bracket	(1)	(1)	(1)	Old
8-10	910113-7625	ﾎﾞﾙﾄ Bolt	3	3	3	
8-11	345-01111-0	ﾀﾞｳｴﾙﾋﾟﾝ、6-12 Dowel Pin, 6-12	2	2	2	
8-12	3H8-06071-0	ﾊﾟﾙｻｺｲﾙ Pulser Coil	1	1	1	
8-13	921503-6516	ｽｸﾘｭ Screw	2	2	2	
8-14	3V9-06060-2	C.D. ﾕﾆｯﾄ (CU7241) C.D. Unit (CU7241)	1	1	1	18B2#01549～,15B2#12011～ 9.9B2#11891～
	3V9-06060-0	C.D. ﾕﾆｯﾄ (CU7220) C.D. Unit (CU7220)	(1)	(1)	(1)	18B#00001～18B2#01548 15B#11012～15B2#12010 9.9B#11205～9.9B2#11890
8-15	910113-0620	ﾎﾞﾙﾄ Bolt	2	2	2	
8-16	3R0-66308-0	ﾜｯｼｬ、6-16-1.5 Washer, 6-16-1.5	10	10	10	
8-17	3V9-06167-0	C.D. ﾕﾆｯﾄｺｰﾄﾞｱｯｼ C.D. Unit Cord Ass'y	1	1	1	18B#00001～, 15B # 11205～ 9.9B # 11012～
8-17-1	3H8-06167-0	C.D. ﾕﾆｯﾄｺｰﾄﾞｱｯｼ C.D. Unit Cord Ass'y	-	(1)	(1)	15B ～# 11011 9.9B ～# 11204
8-18	3H8-06901-1	ｴﾚｸﾄﾘｯｸﾌﾞﾗｹｯﾄ Electric Bracket	1	1	1	
8-19	3F3-06920-0	ﾗﾊﾞｰﾏｳﾝﾄ、8.5-12-2 Rubber Mount, 8.5-12-2	3	3	3	
8-20	353-76079-0	ｶﾗｰ、6.2-9-9.3 Collar, 6.2-9-9.3	3	3	3	
8-21	910103-0625	ﾎﾞﾙﾄ Bolt	3	3	3	
8-22	3T5-06920-0	ﾗﾊﾞｰﾏｳﾝﾄ、8.5-18-7 Rubber Mount, 8.5-18-7	3	3	3	
8-23	3V9-06973-0	ｸﾗﾝﾌﾟ Clamp	1	1	1	
8-24	3H8-06040-0	ｲｸﾞﾆｯｼｮﾝｺｲﾙ Ignition Coil	1	1	1	
8-24-1	3H6-06999-0	ﾌﾟﾗｸﾞｷｬｯﾌﾟ(ﾚｼﾞｽﾀﾝｽ) * Plug Cap (with Resistance)	2	2	2	Old Part No.3H6-06921-0
8-25	910103-5625	ﾎﾞﾙﾄ Bolt	2	2	2	
8-26	3A3-76037-0	ｹｰﾌﾞﾙﾀｰﾐﾅﾙﾌﾟﾗｸﾞ Cable Terminal Plug	4	4	4	4 for MF 2 for EP & EF

エレクトリックパーツ
Fig. 9 ELECTRIC PARTS




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
9-1	3C8-76010-1	ｽﾀｰﾀﾓｰﾀ Starter Motor	1	1	1	for EP & EF　Fig. 10
9-2	910103-5825	ﾎﾞﾙﾄ Bolt	2	2	2	for EP & EF
9-3	3R3-76009-0	ｽﾀｰﾀﾓｰﾀﾊﾞﾝﾄﾞ Starter Motor Band	1	1	1	for EP & EF
9-4	3C8-76007-0	ｽﾀｰﾀﾓｰﾀﾀﾞﾝﾊﾟ Starter Motor Damper	1	1	1	for EP & EF
9-5	910113-5818	ﾎﾞﾙﾄ Bolt	2	2	2	for EP & EF
9-6	3H8-76040-0	ｽﾀｰﾀｿﾚﾉｲﾄﾞ Starter Solenoid	1	1	1	for EP & EF
9-7	3V9-76060-0	ﾚｸﾁﾌｧｲﾔ Rectifier	1	1	1	# 032049XD～ for EP & EF
9-8	910103-5625	ﾎﾞﾙﾄ Bolt	2	2	2	for EP & EF
9-9	3V1-76120-1	ﾊﾞｯﾃﾘｺｰﾄﾞ Battery Cable	1	1	1	L=2500　# 037589XD～ for EP & EF
9-10	3B7-76145-0	ﾀｰﾐﾅﾙｷｬｯﾌﾟ Terminal Cap	1	1	1	for EP & EF
9-11	3R3-76141-0	ｽﾀｰﾀｺｰﾄﾞ Starter Cable	1	1	1	L=270 for EP & EF
9-12	3A3-76145-0	ﾀｰﾐﾅﾙｷｬｯﾌﾟ Terminal Cap	2	2	2	for EP & EF
9-13	3V9-76062-0	ﾋｭｰｽﾞｺｰﾄﾞ Fuse Cable	1	1	1	L=450 for EP & EF
9-14	353-76213-0	ﾋｭｰｽﾞ (20A) Fuse (20A)	1	1	1	for EP & EF
9-15	3R3-71040-0	ﾜｰﾆﾝｸﾞﾗﾝﾌﾟ Warning Lamp	1	1	1	
9-16	3H6-07611-0	ｵｲﾙﾌﾟﾚｯｼｬｽｲｯﾁ Oil Pressure Switch	1	1	1	
9-17	3H8-07613-0	ﾌﾟﾚｯｼｬｽｲｯﾁﾘｰﾄﾞﾜｲﾔ Pressure Switch Lead Wire	1	1	1	L=170 with Grommet
9-18	3V5-72678-0	ｾﾊﾟﾚｰﾄｺｰﾄﾞ (ﾌﾞﾗｯｸ) Separate Cord (Black)	1	1	1	
9-19	3A3-76037-0	ｹｰﾌﾞﾙﾀｰﾐﾅﾙﾌﾟﾗｸﾞ Cable Terminal Plug	1	1	1	
9-20	345-06915-0	ｸﾗﾝﾌﾟ、6.5-14L Clamp, 6.5-14L	1	1	1	
9-21	910103-0616	ﾎﾞﾙﾄ Bolt	1	1	1	
9-22	910103-6612	ﾎﾞﾙﾄ Bolt	1	1	1	for EP & EF
9-23	353-06972-0	ｸﾗﾝﾌﾟ、7-80P Clamp, 7-80P	1	1	1	
9-24	910113-5620	ﾎﾞﾙﾄ Bolt	1	1	1	

スタータモータ
Fig. 10 STARTER MOTOR




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
10-1	3C8-76010-1	ｽﾀｰﾀﾓｰﾀ Starter Motor	1	1	1	
10-1-1	3C8-76015-0	ﾋﾟﾆｵﾝ * Pinion	1	1	1	
10-1-2	3C8-75015-0	ﾜｯｼｬ * Washer	1	1	1	
10-1-3	3C8-75014-0	ﾌﾞﾗｼﾎﾙﾀﾞ * Brush Holder	1	1	1	
10-1-4	921521-6408	ｽｸﾘｭ * Screw	2	2	2	
10-1-5	3C8-75016-0	ﾌﾞｯｼﾝｸﾞ 1 * Bushing 1	1	1	1	
10-1-6	3C8-75017-0	ﾌﾞｯｼﾝｸﾞ 2 * Bushing 2	1	1	1	
10-1-7	3C8-75018-0	O ﾘﾝｸﾞ * O-Ring	1	1	1	
10-1-8	940103-0600	ﾜｯｼｬ * Washer	1	1	1	
10-1-9	941303-0600	ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ * Spring Washer	2	2	2	
10-1-10	930203-0600	ﾅｯﾄ * Nut	2	2	2	
10-1-11	3C8-75019-0	ﾎﾞﾙﾄ * Bolt	2	2	2	
10-1-12	941321-0500	ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ * Spring Washer	2	2	2	
10-1-13	940221-0500	ﾜｯｼｬ * Washer	2	2	2	

リコイルスタータ
Fig. 11 RECOIL STARTER



見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
11-1	3R3-05090-1	ﾘｺｲﾙｽﾀｰﾀ Recoil Starter	1	1	1	
11-1-1	3H8-05105-0	ｽﾀｰﾀｹｰｽ * Starter Case	1	1	1	
11-1-2	3H8-05004-0	ｽﾀｰﾀｽﾌﾟﾘﾝｸﾞ * Starter Spring	1	1	1	
11-1-3	3R3-05106-0	ﾘｰﾙ * Reel	1	1	1	
11-1-4	3R3-05003-0	ﾗﾁｪｯﾄ * Ratchet	1	1	1	
11-1-5	3R3-05011-0	E ﾘﾝｸﾞ、d=10 * E-Ring, d=10	1	1	1	
11-1-6	3R3-05012-0	ﾘﾀｰﾝｽﾌﾟﾘﾝｸﾞ * Return Spring	1	1	1	
11-1-7	3H8-05123-1	ﾗﾁｪｯﾄｶﾞｲﾄﾞ * Ratchet Guide	1	1	1	
11-1-8	3R3-05007-0	ﾌﾘｸｼｮﾝｽﾌﾟﾘﾝｸﾞ * Friction Spring	1	1	1	
11-1-9	3R3-05006-0	ﾌﾘｸｼｮﾝﾌﾟﾚｰﾄ * Friction Plate	1	1	1	
11-1-10	3R3-05138-0	ｽﾀｰﾀｼｬﾌﾄﾎﾞﾙﾄ * Starter Shaft Bolt	1	1	1	
11-1-11	3R3-05013-0	ｽﾀｰﾀﾛｰﾌﾟ * Starter Rope	1	1	1	ϕ5-1800
11-1-12	3C8-05019-0	ｽﾀｰﾀﾊﾝﾄﾞﾙ * Starter Handle	1	1	1	
11-1-13	3R3-05131-0	ｽﾀｰﾀﾊﾝﾄﾞﾙｷｬｯﾌﾟ * Cap, Starter Handle Cap	1	1	1	
11-1-14	3R3-05252-0	ｽﾀｰﾀﾛｯｸ * Starter Lock	1	1	1	
11-1-15	3R3-05216-0	ｽﾌﾟﾘﾝｸﾞ * Spring	1	1	1	
11-2	3R3-67503-0	ｽﾀｰﾀｼｰﾙ Starter Seal	1	1	1	
11-3	910113-0620	ﾎﾞﾙﾄ Bolt	2	2	2	1 for EF
	910113-0630	ﾎﾞﾙﾄ Bolt	1	1	1	2 for EF
11-4	3R0-66308-0	ﾜｯｼｬ、6.5-16-1.5 Washer, 6.5-16-1.5	3	3	3	
11-5	3R3-05258-0	ｱｰﾑｽﾌﾟﾘﾝｸﾞ Arm Spring	1	1	1	
11-6	3R3-06308-0	ﾍﾞﾙﾄｶﾊﾞｰ Belt Cover	1	1	1	
11-7	3F3-76042-1	ﾅｯﾄ Nut	2	2	2	
11-8	3R3-06303-0	ｶﾗｰ、6.2-9-21 Collar, 6.2-9-21	2	2	2	
11-9	3R3-06302-0	ﾗﾊﾞｰﾏｳﾝﾄ Rubber Mount	2	2	2	
11-10	910113-0630	ﾎﾞﾙﾄ Bolt	2	2	2	
11-11	3R0-66308-0	ﾜｯｼｬ、6.5-16-1.5 Washer, 6.5-16-1.5	4	4	4	
11-12	3A0-76079-0	ｶﾗｰ、6.2-9-7.4 Collar, 6.2-9-7.4	2	2	2	
11-13	910113-0620	ﾎﾞﾙﾄ Bolt	2	2	2	
11-14	309-06972-0	ｸﾗﾝﾌﾟ、6.5-47.5P Clamp, 6.5-47.5P	1	1	1	


リコイルスタータ
Fig. 11 RECOIL STARTER



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
11-15	398-06972-0	ｸﾗﾝﾌﾟ、6.5-67P Clamp, 6.5-67P	1	1	1	EF only
11-16	3H6-63619-1	ｶﾗｰ、6.5-10.5-10 Collar, 6.5-10.5-10	1	1	1	2 for EF
11-17	3H6-72026-0	ｽﾊﾟｰｸﾌﾟﾗｸﾞﾃﾞｶﾙ (ﾚｼﾞｽﾀﾝｽ) Spark Plug Decal (with Resistance)	1	1	1	
11-18	3R0-72181-0	ｺｰｼｮﾝﾃﾞｶﾙ B Caution Decal “B”	1	1	1	

ステアリングハンドル（ティラハンドル）


Fig. 12 STEERING HANDLE (TILLER HANDLE)



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
12-1	3R3Q63011-0	ﾃｨﾗﾊﾝﾄﾞﾙ Tiller Handle	1	1	1	for MF & EF
12-2	3R3-63102-0	ﾃｨﾗﾊﾝﾄﾞﾙﾌﾞｯｼﾝｸﾞ Tiller Handle Bushing	1	1	1	for MF & EF
12-3	3R3-63108-0	ﾜｯｼｬ、39-52-1 Washer, 39-52-1	1	1	1	for MF & EF
12-4	3R3-63109-0	ｳｴｰﾌﾞﾜｯｼｬ、39.5-52-1.2 Wave Washer, 39.5-52-1.2	1	1	1	for MF & EF
12-5	3R3-63107-0	ﾃｨﾗﾊﾝﾄﾞﾙｶﾊﾞｰ Tiller Handle Cover	1	1	1	for MF & EF
12-6	3B2-63104-1	ｽﾀｯﾄﾞﾎﾞﾙﾄ Stud Bolt	2	2	2	for MF & EF
12-7	941303-0600	ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ Spring Washer	2	2	2	for MF & EF
12-8	930113-0600	ﾅｯﾄ Nut	2	2	2	for MF & EF
12-9	3R3-63012-0	ｸﾞﾘｯﾌﾟ Grip	1	1	1	for MF & EF
12-10	3R3-63041-0	ｽﾛｯﾄﾙｼｬﾌﾄ Throttle Shaft	1	1	1	for MF & EF
12-11	345-63048-0	ｽﾛｯﾄﾙｼｬﾌﾄﾀﾞﾝﾊﾟ Throttle Shaft Damper	1	1	1	for MF & EF
12-12	350-63046-0	ﾌﾞｯｼﾝｸﾞ、8.4-10-11 Bushing, 8.4-10-11	1	1	1	for MF & EF
12-13	921813-0518	ｽｸﾘｭ Screw	1	1	1	for MF & EF
12-14	3B2-63063-0	ｽﾛｯﾄﾙｼｬﾌﾄｻﾎﾟｰﾀ Throttle Shaft Supporter	1	1	1	for MF & EF
12-15	921513-0612	ｽｸﾘｭ Screw	1	1	1	for MF & EF
12-16	3B2-63035-1	ﾌﾘｸｼｮﾝﾋﾟｰｽ Friction Piece	1	1	1	for MF & EF
12-17	3B2-63034-0	ｱｼﾞｬｽﾄｽｸﾘｭ Adjusting Screw	1	1	1	for MF & EF
12-18	940113-0600	ﾜｯｼｬ Washer	1	1	1	for MF & EF
12-19	930113-0600	ﾅｯﾄ Nut	1	1	1	for MF & EF
12-20	3R3-63600-0	ｽﾛｯﾄﾙﾜｲﾔ Throttle Cable	2	2	2	for MF & EF
12-21	3V9-72019-0	ｽﾛｯﾄﾙﾃﾞｶﾙ Throttle Decal	1	1	1	for MF & EF
12-22	350-67154-0	ﾌﾟﾗｽﾁｯｸﾘﾍﾞｯﾄ、6.5 Plastic Rivet, 6.5	1	1	1	for MF & EF
12-23	3R3Q62001-0	ｽﾃｱﾘﾝｸﾞﾌﾞﾗｹｯﾄ Steering Bracket	1	1	1	for MF & EF
12-24	3R3-62094-1	ﾎﾞﾙﾄ、10-80 P1.5 Bolt, 10-80 P1.5	2	2	2	for MF & EF
12-25	940113-1000	ﾜｯｼｬ Washer	2	2	2	for MF & EF


ドライブシャフトハウジング

Fig. 13 DRIVE SHAFT HOUSING



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
13-1	3R3Q61020-4	ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞ S Drive Shaft Housing "S"	1	1	1	Ref. No. 13 ※ 3 Ref. No. 18 ※ 5
	3R3S61020-3	ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞ S Drive Shaft Housing "S"	(1)	(1)	(1)	Ref. No. 13 ※ 3 Ref. No. 18 ※ 6
	3R3S61020-2	ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞ S Drive Shaft Housing "S"	(1)	(1)	(1)	Ref. No. 13 ※ 4 Ref. No. 18 ※ 6
	3R3Q61030-5	ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞ L Drive Shaft Housing "L"	1	1	1	Ref. No. 13 ※ 3 Ref. No. 18 ※ 5
	3R3S61030-2	ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞ L Drive Shaft Housing "L"	(1)	(1)	(1)	Ref. No. 13 ※ 4 Ref. No. 18 ※ 6
13-2	3R3-61301-1	ﾗﾊﾞｰﾏｳﾝﾄ (ｱｯﾊﾟｰ) Rubber Mount (Upper)	2	2	2	
13-3	910113-5830	ﾎﾞﾙﾄ Bolt	4	4	4	
13-4	3R3-67017-0	ｵｲﾙﾄﾞﾚﾝｸﾞﾛﾒｯﾄ Oil Drain Grommet	1	1	1	
13-5	3R3-07406-0	ﾜｯｼｬ、14.5-24-1 Washer, 14.5-24-1	1	1	1	
13-6	3R3-07405-1	ﾄﾞﾚﾝﾎﾞﾙﾄ Drain Bolt	1	1	1	
13-7	3R3-61208-0	ｱｲﾄﾞﾙｴｷｿﾞｰｽﾄﾎﾟｰﾄｶﾊﾞｰ Idle Exhaust Port Cover	1	1	1	
13-8	3R3-61207-0	ｱｲﾄﾞﾙｴｷｿﾞｰｽﾄﾎﾟｰﾄｶﾊﾞｰｶﾞｽｹｯﾄ Idle Exhaust Port Cover Gasket	1	1	1	
13-9	910114-7616	ﾎﾞﾙﾄ Bolt	8	8	8	
13-10	3R3-65204-0	ｳｫｰﾀﾊﾟｲﾌﾟｵｰｸﾞｼﾞｭｱﾘｰﾏｳﾝﾄ Water Pipe Auxiliary Mount	1	1	1	ｳｫｰﾀﾊﾟｲﾌﾟｶﾞｲﾄﾞﾗﾊﾞｰ Water Pipe Guide Rubber
13-11	3H8-65100-0	ｳｫｰﾀﾊﾟｲﾌﾟ S Water Pipe "S"	1	1	1	Short
	3H8-65110-0	ｳｫｰﾀﾊﾟｲﾌﾟ L Water Pipe "L"	1	1	1	Long
13-12	3R3-65206-1	ｳｫｰﾀﾊﾟｲﾌﾟｼｰﾙ (ｱｯﾊﾟｰ) Water Pipe Seal (Upper)	1	1	1	
13-13	350-01215-1	ｵｲﾙｼｰﾙ、12.8-25-7 Oil Seal, 12.8-25-7	1	1	1	
13-14	3R3-67116-0	ｴﾝｼﾞﾝﾍﾞｰｽｼｰﾙ Engine Basement Seal	1	1	1	
13-15	3R3-65205-0	ｳｫｰﾀﾊﾟｲﾌﾟﾛｯｸﾌﾟﾚｰﾄ Water Pipe Lock Plate	1	1	1	
13-16A	3R3Q67004-1	ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾊﾞｰ L Drive Shaft Housing Cover "L"	1	1	1	for ※ 3 Tapping Screw Type
13-16B	3R3S67004-0	ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾊﾞｰ L Drive Shaft Housing Cover "L"	(1)	(1)	(1)	for ※ 4 Screw & Nut Type
13-17	3R3Q67003-1	ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾊﾞｰ R Drive Shaft Housing Cover "R"	1	1	1	Mark "1"
13-18A	3R0-61217-0	ﾀｯﾋﾟﾝｸﾞｽｸﾘｭ、6-60 Tapping Screw, 6-60	4	4	4	for 3R3Q67004-1
13-18B	922513-5655	ｽｸﾘｭ Screw	(4)	(4)	(4)	for 3R3S67004-0
13-19	930113-0600	ﾅｯﾄ Nut	(4)	(4)	(4)	
13-20	3R3-61213-0	ｴﾌﾟﾛﾝｼｰﾙ Apron Seal	2	2	2	
13-21	3R3-61212-0	ｱｲﾄﾞﾙｴｷｿﾞｰｽﾄﾎﾟｰﾄｸﾞﾛﾒｯﾄ Idle Exhaust Port Grommet	1	1	1	
13-22	345-01111-0	ﾀﾞｳｴﾙﾋﾟﾝ、6-12 Dowel Pin, 6-12	2	2	2	
13-23	3H6-07257-0	ｴｷｿﾞｰｽﾄﾌﾟﾗｸﾞ Exhaust Plug	1	1	1	


ギヤケース
Fig. 14 GEAR CASE



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
14-1	3V9Q60000-0	ｷﾞﾔｹｰｽ Gear Case	1	1	1	(# 023985XD～Silver Gray)
	398S60000-0	ｷﾞﾔｹｰｽ Gear Case	(1)	(1)	(1)	#～019256XD
14-1-1	350-60211-0	ﾆｰﾄﾞﾙﾍﾞｱﾘﾝｸﾞ、16-24-20 * Needle Bearing, 16-24-20	1	1	1	
14-2	369-60206-0	ｻﾌﾞｳｫｰﾀｽﾄﾚｰﾅ Sub Water Strainer	1	1	1	
14-3	921813-0620	ｽｸﾘｭ Screw	1	1	1	or 921803-0620
14-4	362-60206-0	ｳｫｰﾀｽﾄﾚｰﾅ Water Strainer	2	2	2	
14-5	921513-0430	ｽｸﾘｭ Screw	1	1	1	or 921503-0430
14-6	930403-0400	ﾅｲﾛﾝﾅｯﾄ、4P-0.7 Nylon Nut, 4P-0.7	1	1	1	
14-7	332-60005-2	ｵｲﾙﾌﾟﾗｸﾞ Oil Plug	2	2	2	
14-8	332-60005-2	ｳｫｰﾀﾌﾟﾗｸﾞ Water Plug	1	1	1	
14-9	332-60006-0	ｶﾞｽｹｯﾄ、8.1-15-1 Gasket, 8.1-15-1	3	3	3	
14-10	3V1-60217-0	ﾄﾘﾑﾀﾌﾞ Trim Tab	1	1	1	# 023985XD～
	3V9-60218-0	ｱﾉｰﾄﾞ Anode	(1)	(1)	(1)	# 019935XC～# 019256XD
14-11	910103-5620	ﾎﾞﾙﾄ Bolt	1	1	1	# 023985XD～
	910103-0616	ﾎﾞﾙﾄ Bolt	(1)	(1)	(1)	# 019935XC～# 019256XD
14-12	915313-0825	ｽﾀｯﾄﾞﾎﾞﾙﾄ Stud Bolt	4	4	4	
14-13	930113-0800	ﾅｯﾄ Nut	4	4	4	
14-14	3P0-66233-0	ﾜｯｼｬ、8.1-16-1.5 Washer, 8.1-16-1.5	4	4	4	
14-15	9601-0-6205	ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ、6205 Ball Bearing, 6205	2	2	2	
14-16	362Q60101-1	ﾌﾟﾛﾍﾟﾗｼｬﾌﾄﾊｳｼﾞﾝｸﾞ Propeller Shaft Housing	1	1	1	
14-17	910113-5625	ﾎﾞﾙﾄ Bolt	2	2	2	
14-18	362-60211-0	ﾆｰﾄﾞﾙﾍﾞｱﾘﾝｸﾞ、17-24-20 Needle Bearing, 17-24-20	1	1	1	
14-19	121-32071-0	O ﾘﾝｸﾞ、2.4-59.6 O-Ring, 2.4-59.6	1	1	1	
14-20	346-65013-0	ｵｲﾙｼｰﾙ、17-30-9 Oil Seal, 17-30-9	1	1	1	
14-21	398Q60100-1	ﾌﾟﾛﾍﾟﾗｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ Propeller Shaft Housing Ass'y	1	1	1	Old Part No. 362S87323-0

ドライブシステム＆ウォータポンプ


Fig. 15 DRIVE SYSTEM & WATER PUMP



見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
15-1	3H8-64301-0	ﾄﾞﾗｲﾌﾞｼｬﾌﾄ S Drive Shaft "S"	1	1	1	Short
	3H8-64302-0	ﾄﾞﾗｲﾌﾞｼｬﾌﾄ L Drive Shaft "L"	1	1	1	Long
15-2	9601-0-6302	ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ、6302 Ball Bearing, 6302	1	1	1	
15-3	3H8-64010-0	ﾍﾞﾍﾞﾙｷﾞﾔ A Bevel Gear "A"	1	1	1	
15-4	3H8-64020-0	ﾍﾞﾍﾞﾙｷﾞﾔ B Bevel Gear "B"	1	1	1	
15-5	346-64027-1	ﾍﾞﾍﾞﾙｷﾞﾔ B ﾅｯﾄ Bevel Gear "B" Nut	1	1	1	
15-6	3H8-64030-0	ﾍﾞﾍﾞﾙｷﾞﾔ C Bevel Gear "C"	1	1	1	
15-7	350-64032-0	ﾜｯｼｬ、17-22-1.5 Washer, 17-22-1.5	1	1	1	
15-8	346-64081-0	ｼﾑ、35-41.9-0.1 Shim, 35-41.9-0.1	AR	AR	AR	
	346-64082-0	ｼﾑ、35-41.9-0.15 Shim, 35-41.9-0.15	AR	AR	AR	
	346-64083-0	ｼﾑ、35-41.9-0.3 Shim, 35-41.9-0.3	AR	AR	AR	
	346-64084-0	ｼﾑ、35-41.9-0.5 Shim, 35-41.9-0.5	AR	AR	AR	
15-9	362W64107-0	ﾌﾟﾛﾍﾟﾗ (6)、3×234×155 Propeller (6), 3×9.2×6.1	1	1	1	
	362W64105-0	ﾌﾟﾛﾍﾟﾗ (7)、3×234×174 Propeller (7), 3×9.2×6.6	1	1	1	
	362W64103-0	ﾌﾟﾛﾍﾟﾗ (8)、3×234×199 Propeller (8), 3×9.2×7.8	1	1	1	
	362W64102-0	ﾌﾟﾛﾍﾟﾗ (8.5)、3×234×214 Propeller (8.5), 3×9.2×8.4	1	1	1	STD: 9.9B2 "L"
	362W64101-0	ﾌﾟﾛﾍﾟﾗ (9)、3×234×231 Propeller (9), 3×9.2×9.1	1	1	1	STD: 9.9B2 "S" STD: 15B2 & 18B2 "L"
	362W64108-0	ﾌﾟﾛﾍﾟﾗ (10)、3×234×250 Propeller (10), 3×9.2×9.8	1	1	1	STD: 15B2 & 18B2 "S"
15-10	362-64231-0	ﾌﾟﾛﾍﾟﾗｽﾗｽﾄﾎﾙﾀﾞ Propeller Thrust Holder	1	1	1	
15-11	346-64124-5	ﾜｯｼｬ、12.5-32-2.5 Washer, 12.5-32-2.5	1	1	1	
15-12	346-64121-5	ﾌﾟﾛﾍﾟﾗﾅｯﾄ Propeller Nut	1	1	1	
15-13	951503-0322	ｽﾌﾟﾘｯﾄﾋﾟﾝ、3-22 Split Pin, 3-22	1	1	1	
15-14	362-64211-1	ﾌﾟﾛﾍﾟﾗｼｬﾌﾄ Propeller Shaft	1	1	1	
15-15	362-64215-0	ｸﾗｯﾁ Clutch	1	1	1	
15-16	350-64218-0	ｸﾗｯﾁﾋﾟﾝ Clutch Pin	1	1	1	φ5-30mm
15-17	350-64219-0	ｸﾗｯﾁﾋﾟﾝｽﾅｯﾌﾟ Clutch Pin Snap	1	1	1	
15-18	332-64221-0	ｸﾗｯﾁｽﾌﾟﾘﾝｸﾞ Clutch Spring	1	1	1	
15-19	350-64222-0	ｸﾗｯﾁｽﾌﾟﾘﾝｸﾞﾘﾃｰﾅ Clutch Spring Retainer	1	1	1	
15-20	350-64223-1	ｸﾗｯﾁﾌﾟｯｼｭﾛｯﾄﾞ Clutch Push Rod	1	1	1	
15-21	334-65021-0	ｳｫｰﾀﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ Water Pump Impeller	1	1	1	


ドライブシステム＆ウォータポンプ

Fig. 15 DRIVE SYSTEM & WATER PUMP



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
15-22	350-65022-0	ｳｫｰﾀﾎﾟﾝﾌﾟｲﾝﾍﾟﾗｷｰ Water Pump Impeller Key	1	1	1	
15-23	350-65016-1	ﾎﾟﾝﾌﾟｹｰｽ (ｱｯﾊﾟｰ) Pump Case (Upper)	1	1	1	
15-24	350-65011-1	ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ Pump Case Liner	1	1	1	
15-25	350-65017-0	ﾎﾟﾝﾌﾟｹｰｽ (ﾛﾜ) Pump Case (Lower)	1	1	1	
15-26	332-60223-0	ｵｲﾙｼｰﾙ、13.8-26-9.5 Oil Seal, 13.8-26-9.5	1	1	1	
15-27	336-62415-0	O ﾘﾝｸﾞ、3.5-36 O-Ring, 3.5-36	1	1	1	
15-28	350-65025-0	ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ Water Pump Guide Plate	1	1	1	
15-29	910113-5652	ﾎﾞﾙﾄ Bolt	3	3	3	
15-30	350-65014-0	ｳｫｰﾀﾊﾟｲﾌﾟｼｰﾙ (ﾛﾜ) Water Pipe Seal (Lower)	1	1	1	
15-31	3C8-66011-0	ｸﾗｯﾁｶﾑ Clutch Cam	1	1	1	
15-32	3H8-66012-1	ｶﾑﾛｯﾄﾞ S Cam Rod "S"	1	1	1	for Transom "S"
	3H8-66013-1	ｶﾑﾛｯﾄﾞ L Cam Rod "L"	1	1	1	for Transom "L"
15-33	951407-0312	ｽﾌﾟﾘｸﾞﾋﾟﾝ、3-12 Spring Pin, 3-12	2	2	2	
15-34	398-66031-0	ｶﾑﾛｯﾄﾞﾌﾞｯｼﾝｸﾞ Cam Rod Bushing	1	1	1	
15-35	332-66021-0	O ﾘﾝｸﾞ、2.4-5.8 O-Ring, 2.4-5.8	2	2	2	
15-36	336-62415-0	O ﾘﾝｸﾞ、3.5-36 O-Ring, 3.5-36	1	1	1	
15-37	332-66033-0	ｶﾑﾛｯﾄﾞﾌﾞｯｼﾝｸﾞｽﾄｯﾊﾟ Cam Rod Bushing Stopper	1	1	1	
15-38	910113-6512	ﾎﾞﾙﾄ Bolt	1	1	1	
15-39	3H8-66215-1	ｼﾌﾄﾛｯﾄﾞ Shift Rod	1	1	1	
15-40	3C8-66241-0	ｼﾌﾄﾛｯﾄﾞｼﾞｮｲﾝﾄ Shift Rod Joint	1	1	1	
15-41	951403-0312	ｽﾌﾟﾘｸﾞﾋﾟﾝ、3-12 Spring Pin, 3-12	2	2	2	
15-42	3R3-66226-0	ｼﾌﾄﾛｯﾄﾞｸﾞﾛﾒｯﾄ Shift Rod Grommet	1	1	1	
15-43	3V9-87326-0	ﾌﾟﾛﾍﾟﾗﾊｰﾄﾞｳｴｱｷｯﾄ Propeller Hard Wear Kit	1 set	1 set	1 set	


シフト＆ストップスイッチ
Fig. 16 SHIFT & STOP SWITCH



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
16-1	3R3-67481-0	ｼﾌﾄﾚﾊﾞｰﾌﾞﾗｹｯﾄｶﾊﾞｰ Shift Lever Bracket Cover	1	1	1	for MF & EF
16-2	922513-5630	ｽｸﾘｭ Screw	1	1	1	for MF & EF
16-3	3V9-67578-0	ｼﾌﾄﾃﾞｶﾙ (F, N, R) Shift Decal (F, N, R)	1	1	1	for MF & EF
16-4	910113-5620	ﾎﾞﾙﾄ Bolt	2	2	2	or 910103-5620 for MF & EF
16-5	3R3-63508-0	ｽﾛｯﾄﾙﾜｲﾔﾌﾞﾗｹｯﾄ Throttle Cable Bracket	1	1	1	for MF & EF
16-6	910113-5625	ﾎﾞﾙﾄ Bolt	1	1	1	or 910103-5625 for MF & EF
16-7	3R3-63611-0	ｽﾛｯﾄﾙﾄﾞﾗﾑ Throttle Dram	1	1	1	for MF & EF
16-8	3A0-76079-0	ｶﾗｰ、6.2-9-7.4 Collar, 6.2-9-7.4	1	1	1	for MF & EF
16-9	3R0-66308-0	ﾜｯｼｬ、6.5-16-1.5 Washer, 6.5-16-1.5	1	1	1	for MF & EF
16-10	910113-0620	ﾎﾞﾙﾄ Bolt	1	1	1	or 910103-0620 for MF & EF
16-11	346-67196-1	ﾛｯﾄﾞｽﾅｯﾌﾟ、3-B Rod Snap, 3-B	1	1	1	for MF & EF
16-12	3R3-63617-1	ｽﾛｯﾄﾙﾛｯﾄﾞ Throttle Rod	1	1	1	for MF & EF
16-13	3R3Q67480-0	ｼﾌﾄﾚﾊﾞｰﾌﾞﾗｹｯﾄ Shift Lever Bracket	1	1	1	for MF & EF
16-14	3R3-66260-0	ｼﾌﾄﾚﾊﾞｰﾛｯﾄﾞｸﾞﾛﾒｯﾄ Shift Lever Rod Grommet	1	1	1	for MF & EF
16-15	3R3-66110-0	ｼﾌﾄﾚﾊﾞｰ Shift Lever	1	1	1	for MF & EF
16-16	3R3-66124-0	ｶﾗｰ、6.5-10.5-22.6 Collar, 6.5-10.5-22.6	1	1	1	for MF & EF
16-17	910113-5635	ﾎﾞﾙﾄ Bolt	1	1	1	or 910103-5635 for MF & EF
16-18	3R3-66135-1	ｼﾌﾄﾚﾊﾞｰﾛｯﾄﾞ Shift Lever Rod	1	1	1	for MF & EF
16-19	3R3-66122-0	ｼﾌﾄｱｰﾑ Shift Arm	1	1	1	for MF & EF
16-20	3R3-66130-0	ｼﾌﾄﾚﾊﾞｰｼｬﾌﾄ Shift Lever Shaft	1	1	1	
16-21	3C8-66112-0	ｼﾌﾄﾚﾊﾞｰｽﾄｯﾊﾟ Shift Lever Stopper	1	1	1	
16-22	3C8-66116-0	ｼﾌﾄﾚﾊﾞｰｽﾄｯﾊﾟﾌﾟﾚｰﾄ Shift Lever Stopper Plate	1	1	1	
16-23	910113-5614	ﾎﾞﾙﾄ Bolt	1	1	1	or 910103-5614
16-24	3R3-66145-0	ｼﾌﾄﾚﾊﾞｰｼｬﾌﾄﾎﾙﾀﾞ Shift Lever Shaft Holder	1	1	1	
16-25	910113-5616	ﾎﾞﾙﾄ Bolt	3	3	3	or 910103-5616
16-26	3R3-67484-0	ｼﾌﾄﾚﾊﾞｰﾌﾞﾗｹｯﾄｼｰﾙ Shift Lever Bracket Seal	1	1	1	
16-27	398-06830-0	ｽﾄｯﾌﾟｽｲｯﾁ Stop Switch	1	1	1	for MF & EF
16-27-1	353-06821-0	ｽﾄｯﾌﾟｽｲｯﾁﾛｯｸ (ﾛｰﾌﾟ付) * Stop Switch Lanyard	1	1	1	for MF & EF
16-28	3R3-05217-0	ｽﾀｰﾀﾛｯｸｹｰﾌﾞﾙ Starter Lock Cable	1	1	1	
16-29	3R3-76081-0	ﾆｭｰﾄﾗﾙｽｲｯﾁﾌﾞﾗｹｯﾄ Neutral Switch Bracket	1	1	1	

シフト＆ストップスイッチ


Fig. 16 SHIFT & STOP SWITCH



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
16-30	398-76080-0	ニュートラルスイッチ Neutral Switch	1	1	1	for EF
16-31	398-76083-0	ニュートラルスイッチアクチュエータ Neutral Switch Actuator	1	1	1	for EF
16-32	361-76026-0	メインスイッチ Main Switch	1	1	1	for EF

シフト（EPモデル用）


Fig. 17　SHIFT (For EP)



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
17-1	3R3Q67482-0	ﾘﾓｰﾄｺﾝﾄﾛｰﾙｽﾃｰ Remote Control Stay	1	1	1	for EP
17-2	3R3-67483-0	ﾘﾓｰﾄｺﾝﾄﾛｰﾙｽﾃｰｶﾊﾞｰ Remote Control Stay Cover	1	1	1	for EP
17-3	922513-5630	ｽｸﾘｭ Screw	2	2	2	for EP
17-4	3R3-83732-0	ｹｰﾌﾞﾙｸﾞﾛﾒｯﾄ Cable Grommet	1	1	1	for EP
17-5	3R3-83820-0	ｹｰﾌﾞﾙｸﾘｯﾌﾟ Cable Clip	1	1	1	for EP
17-6	910113-5616	ﾎﾞﾙﾄ Bolt	1	1	1	for EP
17-7	3R3-66128-0	ｼﾌﾄｱｰﾑ (ﾘﾓｰﾄｺﾝﾄﾛｰﾙ) Shift Arm (Remote Control)	1	1	1	for EP
17-8	3R3-66134-1	ｼﾌﾄﾚﾊﾞｰﾛｯﾄﾞ Shift Lever Rod	1	1	1	for EP
17-9	930103-0500	ﾅｯﾄ Nut	1	1	1	for EP
17-10	3B7-83715-1	ｹｰﾌﾞﾙｼﾞｮｲﾝﾄ Cable Joint	3	3	3	for EP
17-11	3AA-83719-0	ﾜｯｼｬ、8.5-18-1.6 Washer, 8.5-18-1.6	3	3	3	or 353-83719-0 for EP
17-12	951603-0800	ｽﾅｯﾌﾟﾋﾟﾝ、d=8 Snap Pin, d=8	3	3	3	for EP
17-13	3R3-66129-0	ｼﾌﾄﾚﾊﾞｰ (ﾘｰﾓﾄｺﾝﾄﾛｰﾙ) Shift Lever (Remote Control)	1	1	1	for EP
17-14	910113-0625	ﾎﾞﾙﾄ Bolt	1	1	1	for EP
17-15	3R0-66308-0	ﾜｯｼｬ、6-16-1.5 Washer, 6-16-1.5	2	2	2	for EP
17-16	353-76079-0	ｶﾗｰ、6.2-9-9.3 Collar, 6.2-9-9.3	1	1	1	for EP
17-17	3C8-63733-0	ﾛｯﾄﾞｽﾅｯﾌﾟ、5-3 Rod Snap, 5-3	1	1	1	for EP
17-18	3R3-63709-0	ｽﾛｯﾄﾙﾛｯﾄﾞ (ﾘﾓｰﾄｺﾝﾄﾛｰﾙ) Throttle Rod (Remote Control)	1	1	1	for EP
17-19	346-67196-1	ﾛｯﾄﾞｽﾅｯﾌﾟ、φ3-B Rod Snap, φ3-B	1	1	1	for EP
17-20	3R3-83910-0	ｽﾛｯﾄﾙﾚﾊﾞｰ (ﾘﾓｰﾄｺﾝﾄﾛｰﾙ) Throttle Lever (Remote Control)	1	1	1	for EP
17-21	910113-0645	ﾎﾞﾙﾄ Bolt	1	1	1	for EP
17-22	3R0-66308-0	ﾜｯｼｬ、6-16-1.5 Washer, 6-16-1.5	2	2	2	for EP
17-23	3R3-83913-0	ｶﾗｰ、6.2-9-30.8 Collar, 6.2-9-30.8	1	1	1	for EP
17-24	3R3-83914-0	ｽﾛｯﾄﾙﾚﾊﾞｰｽﾄｯﾊﾟ Throttle Lever Stopper	1	1	1	for EP
17-25	910113-5616	ﾎﾞﾙﾄ Bolt	1	1	1	for EP
17-26	3V5Q62001-0	ｽﾃｱﾘﾝｸﾞﾌﾞﾗｹｯﾄ Steering Bracket	1	1	1	for EP
17-27	916113-1045	ﾎﾞﾙﾄ Bolt	2	2	2	for EP
17-28	940113-1000	ﾜｯｼｬ Washer	2	2	2	for EP
17-29	3R3-76110-0	ｺｰﾄﾞｱｯｼ A Cord Ass'y "A"	1	1	1	for EP
17-30	3B7Q84340-2	ﾘﾓｰﾄｺﾝﾄﾛｰﾙﾎﾞｯｸｽ (RC5B) Remote Control Box (RC5B)	1	1	1	UNIQUE for EP


シフト（EPモデル用）

Fig. 17　SHIFT (For EP)




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
17-31	3E0-84905-0	ﾄﾞﾗｯｸﾘﾝｸ H Drag Link "H"	1	1	1	for EP
17-31-1	3E0-84914-0	ﾄﾞﾗｯｸﾘﾝｸｽﾍﾟｰｻ * Drag Link Spacer	1	1	1	for EP
17-31-2	3E0-84917-0	ﾎﾞﾙﾄ、3/8-50 * Bolt, 3/8-50	1	1	1	for EP
17-31-3	353-84918-0	ﾅｲﾛﾝﾅｯﾄ、3/8 * Nylon Nut, 3/8	2	2	2	for EP
17-31-4	353-84916-0	ﾜｯｼｬ、9.6-18-2 * Washer, 9.6-18-2	3	3	3	for EP
17-31-5	3F3-84908-0	ﾄﾞﾗｯｸﾘﾝｸｼｰﾙﾘﾝｸﾞ * Drag Link Seal Ring	1	1	1	for EP

スイベルブラケット
Fig. 18 SWIVEL BRACKET



見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
18-1	3V6Q62310-0	スイベルブラケット Swivel Bracket	1	1	1	New for 3V6 Type Clamp Bracket
	3R3Q62310-1	スイベルブラケット Swivel Bracket	(1)	(1)	(1)	Old for 3G2 Type Clamp Bracket
18-2	3R3-62417-0	ブッシング、28-31-35 Busing, 28-31-35	2	2	2	
18-3	3H8-62423-1	スラストプレート、28.5-48-1 Thrust Plate, 28.5-48-1	2	2	2	
18-4	3H8-62415-0	O リング、3.5-25.7 O-Ring, 3.5-25.7	1	1	1	
18-5	344-67177-0	グリスニップル Grease Fitting	3	3	3	
18-6	3R3-62445-0	コパイロットボルト Co-Pilot Bolt	1	1	1	for MF & EF
18-7	3R3-62449-0	コパイロットディスク Co-Pilot Disk	2	2	2	for MF & EF
18-8	3R3-62447-0	コパイロットプレート Co-Pilot Plate	1	1	1	for MF & EF
18-9	910113-5616	ボルト Bolt	2	2	2	for MF & EF
18-10	3R3-62448-1	コパイロットワッシャ Co-Pilot Washer	1	1	1	for MF & EF
18-11	3R3-62443-0	ワッシャ、8.1-20-0.8 Washer, 8.1-20-0.8	1	1	1	for MF & EF
18-12	3R3-62441-0	コパイロットハンドル Co-Pilot Handle	1	1	1	for MF & EF
18-13	3V5-62442-0	ナイロンナット (2T)、M8-P1.25 Nylon Nut (2T), M8-P1.25	1	1	1	for MF & EF
18-14	3R3Q62010-1	ステアリングシャフト Steering Shaft	1	1	1	
18-15	3R3-61313-1	スタッドボルト、10-95 Stud Bolt, 10-95	2	2	2	
18-16	940113-1000	ワッシャ Washer	2	2	2	
18-17	930403-1000	ナイロンナット Nylon Nut	2	2	2	
18-18A	3V1-61302-0	ラバーマウント (ロワ) Rubber Mount (Lower)	2	2	2	for ※ 5 (Page 32) New
18-18B	3R3-61302-0	ラバーマウント (ロワ) Rubber Mount (Lower)	(2)	(2)	(2)	for ※ 6 (Page 32) Old
18-19A	3H8Q61401-2	マウントブラケット (ライト) Mount Bracket (Right)	1	1	1	for ※ 5 (Page 32) for 3V1-61302-0 Rubber
18-19B	3H8Q61401-0	マウントブラケット (ライト) Mount Bracket (Right)	(1)	(1)	(1)	for ※ 6 (Page 32) for 3R3-61302-0 Rubber
18-20A	3H8Q61402-2	マウントブラケット (レフト) Mount Bracket (Left)	1	1	1	for ※ 5 (Page 32) for 3V1-61302-0 Rubber
18-20B	3H8Q61402-0	マウントブラケット (レフト) Mount Bracket (Left)	(1)	(1)	(1)	for ※ 6 (Page 32) for 3R3-61302-0 Rubber
18-21	916113-0885	ボルト Bolt	2	2	2	
18-22	916113-0855	ボルト Bolt	1	1	1	
18-23	3P0-66233-0	ワッシャ、8.1-16-1.5 Washer, 8.1-16-1.5	3	3	3	
18-24	930113-0800	ナット Nut	3	3	3	
18-25	338-60218-2	アノード Anode	1	1	1	
18-26	910103-5620	ボルト Bolt	1	1	1	


スイベルブラケット
Fig. 18 SWIVEL BRACKET



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
18-27	398-62396-1	ｱｰｽﾜｲﾔ Ground Cable	3	3	3	L=130
18-28	910103-5610	ﾎﾞﾙﾄ Bolt	2	2	2	
18-29	921503-0610	ｽｸﾘｭ Screw	1	1	1	Swivel Bracket
18-30	910103-5612	ﾎﾞﾙﾄ Bolt	1	1	1	Clamp Bracket "R"

クランプブラケット＆リバースロック


Fig. 19 CLAMP BRACKET & REVERSE LOCK



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
19-1	3V6Q62112-0	ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (ﾗｲﾄ) Clamp Bracket (Right)	1	1	1	New Starboard
19-1A	3G2Q62112-1	ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (ﾗｲﾄ) Clamp Bracket (Right)	(1)	(1)	(1)	Old Starboard
19-2	3V6Q62113-0	ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (ﾚﾌﾄ) Clamp Bracket (Left)	1	1	1	New Port
19-2A	3G2Q62113-1	ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (ﾚﾌﾄ) Clamp Bracket (Left)	(1)	(1)	(1)	Old Port
19-3	3AC-62191-0	ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄｼｬﾌﾄ Swivel Bracket Shaft	1	1	1	Bracket Bolt or 346-62191-0
19-4	346-62124-1	ﾅｲﾛﾝﾅｯﾄ、7/8 Nylon Nut, 7/8	1	1	1	
19-5	349-62126-0	ﾌﾞﾗｹｯﾄｼｬﾌﾄﾌﾞｯｼﾝｸﾞ Bracket Shaft Bushing	2	2	2	
19-6	346-62127-0	ﾌﾞﾗｹｯﾄｼｬﾌﾄｷｬｯﾌﾟ Bracket Shaft Cap	2	2	2	MF & EF
19-7A	3V6-62117-0	ﾃﾞｨｽﾀﾝｽﾋﾟｰｽ Distance Piece	1	1	1	New for 3V6 Type Clamp Bracket
19-7B	350-62117-1	ﾃﾞｨｽﾀﾝｽﾋﾟｰｽ Distance Piece	(1)	(1)	(1)	Old for 3G2 Type Clamp Bracket
19-8	940113-0600	ﾜｯｼｬ Washer	4	4	4	
19-9	930113-0600	ﾅｯﾄ Nut	2	2	2	
19-10	350-62121-1	ｽﾗｽﾄﾛｯﾄﾞ Thrust Rod	1	1	1	
19-11	369-62122-2	ｽﾗｽﾄﾛｯﾄﾞｽﾌﾟﾘﾝｸﾞ Thrust Rod Spring	1	1	1	
19-12	398Q62100-0	ｸﾗﾝﾌﾟｽｸﾘｭｱｯｼ Clamp Screw Ass'y	2	2	2	
19-12-1	398-62103-0	ｸﾗﾝﾌﾟｽｸﾘｭ * Clamp Screw	2	2	2	
19-12-2	332Q62102-1	ｸﾗﾝﾌﾟｽｸﾘｭﾊﾝﾄﾞﾙ * Clamp Screw Handle	2	2	2	
19-12-3	3C8-62104-1	ﾘﾍﾞｯﾄ、3-22 * Rivet, 3-22	2	2	2	
19-13	332-62101-0	ｸﾗﾝﾌﾟｽｸﾘｭﾊﾟｯﾄﾞ Clamp Screw Pad	2	2	2	
19-14	3G2Q62431-0	ﾁﾙﾄｽﾄｯﾊﾟ Tilt Stopper	1	1	1	
19-15	951403-0535	ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ、5-35 Spring Pin, 5-35	1	1	1	
19-16	350-62437-0	ﾌﾞｯｼﾝｸﾞ、8.2-10-26.5 Bushing, 8.2-10-26.5	1	1	1	
19-17	350-62439-1	ﾁﾙﾄｽﾄｯﾊﾟｾｯﾄﾌﾟﾚｰﾄ Tilt Stopper Set Plate	1	1	1	
19-18	910113-5818	ﾎﾞﾙﾄ Bolt	2	2	2	
19-19	3C8-62421-1	ﾁﾙﾄｽﾄｯﾊﾟﾌﾘｸｼｮﾝｽﾌﾟﾘﾝｸﾞ Tilt Stopper Friction Spring	1	1	1	
19-20	346-62438-0	ｾｯﾄﾋﾟｰｽ Set Piece	1	1	1	
19-21	3G2-66351-0	ﾘﾊﾞｰｽﾛｯｸ A Reverse Lock "A"	1	1	1	
19-22	3G2-66313-1	ﾘﾊﾞｰｽﾛｯｸｱｰﾑ Reverse Lock Arm	1	1	1	
19-23	3G2-66319-1	ﾘﾊﾞｰｽﾛｯｸｼｬﾌﾄ A Reverse Lock Shaft "A"	1	1	1	
19-24	945303-0600	E ﾘﾝｸﾞ、d=6 E-Ring, d=6	2	2	2	


クランプブラケット＆リバースロック

Fig. 19 CLAMP BRACKET & REVERSE LOCK




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
19-25	3G2-66321-0	ﾘﾊﾞｰｽﾛｯｸﾛｯﾄﾞ A Reverse Lock Rod "A"	1	1	1	
19-26	951503-0212	ｽﾌﾟﾘｯﾄﾋﾟﾝ、2-12 Split Pin, 2-12	1	1	1	
19-27	3G2-66312-0	ﾘﾊﾞｰｽﾛｯｸﾘﾝｸ A Reverse Lock Link "A"	2	2	2	
19-28	3G2-66331-0	ﾘﾊﾞｰｽﾛｯｸｽﾌﾟﾘﾝｸﾞ Reverse Lock Spring	2	2	2	
19-29	350-66315-0	ﾘﾊﾞｰｽﾛｯｸﾘﾝｸｽﾌﾟﾘﾝｸﾞ Reverse Lock Link Spring	1	1	1	
19-30	3G2-66311-0	ﾘﾊﾞｰｽﾛｯｸﾘﾝｸﾚﾊﾞｰ Reverse Lock Link Lever	1	1	1	
19-31	3V9-05254-0	ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰｼｬﾌﾄ Reverse Lock Lever Shaft	1	1	1	
19-32	941403-0800	ｳｪｰﾌﾞﾜｯｼｬ、d=8 Wave Washer, d=8	1	1	1	
19-33	3R0-66308-0	ﾜｯｼｬ、6-16-1.5 Washer, 6-16-1.5	1	1	1	
19-34	346-66333-0	ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰｸﾞﾘｯﾌﾟ Reverse Lock Lever Grip	1	1	1	
19-35	346-66334-0	ｸﾞﾘｯﾌﾟｽﾄｯﾊﾟ Grip Stopper	1	1	1	
19-36	338-60218-2	ｱﾉｰﾄﾞ Anode	1	1	1	
19-37	910103-5620	ﾎﾞﾙﾄ Bolt	1	1	1	
19-38	3H8-72049-0	ｺ ﾊﾟｲﾛｯﾄﾃﾞｶﾙ Co-Pilot Decal	1	1	1	
19-39	916113-0885	ﾎﾞﾙﾄ Bolt	2	2	2	ｵﾌﾟｼｮﾝ Option
19-40	940113-0800	ﾜｯｼｬ Washer	4	4	4	ｵﾌﾟｼｮﾝ Option
19-41	930113-0800	ﾅｯﾄ Nut	2	2	2	ｵﾌﾟｼｮﾝ Option

ボトムカウル
Fig. 20 BOTTOM COWL



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
20-1	3R3Q67100-0	ﾎﾞﾄﾑｶｳﾙ Bottom Cowl	1	1	1	ﾓｰﾀｶﾊﾞｰ (ﾛﾜ) Motor Cover (Lower)
20-2	346-67113-0	ﾗﾊﾞｰﾏｳﾝﾄ、8.5-14-2.5 Rubber Mount, 8.5-14-2.5	8	8	8	
20-3	346-67114-0	ｽﾍﾟｰｻ、6.2-9-15.7 Spacer, 6.2-9-15.7	4	4	4	
20-4	910113-0630	ﾎﾞﾙﾄ Bolt	4	4	4	
20-5	346-67115-0	ﾜｯｼｬ、6.5-21-1 Washer, 6.5-21-1	4	4	4	
20-6	353-01138-0	ｳｫｰﾀﾆｯﾌﾟﾙ Water Nipple	1	1	1	
20-7	3R3Q67141-0	ﾌｯｸﾚﾊﾞｰ Hook Lever	1	1	1	
20-8	338-67147-0	ﾌｯｸﾚﾊﾞｰｼｰﾙﾘﾝｸﾞ Hook Lever Seal Ring	1	1	1	
20-9	350-67105-0	ﾌﾞｯｼﾝｸﾞ、14-16.5-17.7 Bushing, 14-16.5-17.7	1	1	1	
20-10	941403-1400	ｳｪｰﾌﾞﾜｯｼｬ、d=14 Wave Washer, d=14	1	1	1	
20-11	3R3-67142-0	ｶﾊﾞｰﾌｯｸ Cover Hook	1	1	1	
20-12	910113-6612	ﾎﾞﾙﾄ Bolt	1	1	1	
20-13	3R0-66308-0	ﾜｯｼｬ、6-16-1.5 Washer, 6-16-1.5	1	1	1	
20-14	394-70260-0	ﾌｭｴﾙｺﾈｸﾀ (ｴﾝｼﾞﾝ、ﾒｰﾙ) Fuel Connector (Engine, Male)	1	1	1	
20-15	910113-5625	ﾎﾞﾙﾄ Bolt	1	1	1	
20-16	98AB-5-0350	ｺﾞﾑﾎｰｽ Rubber Hose	1	1	1	
20-17	338-02215-0	ｸﾘｯﾌﾟ φ10 Clip φ10	2	2	2	
20-18	3R3-67082-0	ﾌｭｴﾙｺﾈｸﾀｸﾞﾛﾒｯﾄ Fuel Connector Grommet	1	1	1	
20-19	3B2-63624-0	ｸﾞﾛﾒｯﾄ Grommet	1	1	1	
20-20	345-67117-0	ｸﾞﾛﾒｯﾄ、17-2.7 Grommet, 17-2.7	1	1	1	2 for EP
20-21	3R3-67162-0	ﾊﾞｯﾃﾘｺｰﾄﾞｸﾞﾛﾒｯﾄ Battery Cable Grommet	1	1	1	
20-22	3H6-67572-0	ｽﾄｰﾘｯｼﾞﾃﾞｶﾙ Storage Decal	1	1	1	


トップカウル
Fig. 21 TOP COWL



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
		ﾄｯﾌﾟｶｳﾙ				Motor Cover (Upper)
21-1	3V9Q67500-1	Top Cowl	1	1	1	UNIQUE
		ﾄｯﾌﾟｶｳﾙｼｰﾙ				
21-1-1	3S9-67501-0	* Top Cowl Seal	1	1	1	
		ﾛｰﾗ、6.5-11-14				
21-1-2	3R3-67517-0	* Roller, 6.5-11-14	1	1	1	
		ﾜｯｼｬ、6-16-1.5				
21-1-3	3R0-66308-0	* Washer, 6-16-1.5	1	1	1	
		E ﾘﾝｸﾞ、d=5				
21-1-4	945303-0500	* E-Ring, d=5	1	1	1	
		ﾁﾙﾄﾊﾝﾄﾞﾙ				
21-1-5	3R3Q67521-0	* Tilt Handle	1	1	1	
		ﾜｯｼｬ、6-16-1.5				
21-1-6	3R0-66308-0	* Washer, 6-16-1.5	4	4	4	
		ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ				
21-1-7	941303-0600	* Spring Washer	4	4	4	
		ﾅｯﾄ				
21-1-8	930113-0600	* Nut	4	4	4	
		ﾃﾞｶﾙｾｯﾄ				
21-2	3V9Q87801-1	Decal Set	1	-	-	UNIQUE
		ﾃﾞｶﾙｾｯﾄ				
	3V6Q87801-0	Decal Set	-	1	-	UNIQUE
		ﾃﾞｶﾙｾｯﾄ				
	3V5Q87801-0	Decal Set	-	-	1	UNIQUE
		ｺｰｼｮﾝﾃﾞｶﾙ A				
21-3	3R0-72180-0	Caution Decal “A”	1	1	1	
		ｵｲﾙﾌﾟﾚｯｼｬﾃﾞｶﾙ				
21-4	3H6-76199-0	Oil Pressure Decal	1	1	1	

セパレートフュエルタンク


Fig. 22 SEPARATE FUEL TANK



見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
22-1	3B2-70167-0	ﾌｭｴﾙﾀﾝｸ (12L、ﾌﾟﾗｽﾁｯｸ) Fuel Tank (12L, Plastic)	1	1	1	UNIQUE
22-1-1	3B2-70050-0	ﾌｭｴﾙｹﾞｰｼﾞﾍﾞﾝﾃｨﾄﾞｷｬｯﾌﾟ * Fuel Gauge Vented Cap	1	1	1	
22-1-2	3C7-70021-0	ﾀﾝｸｷｬｯﾌﾟｶﾞｽｹｯﾄ * Tank Cap Gasket	1	1	1	
22-1-3	3E0-70270-0	ﾒｲﾙｸｲｯｸｺﾈｸﾀ * Male Quick Connector	1	1	1	
22-1-4	3B2-70155-0	ﾌｭｴﾙﾋﾟｯｸｱｯﾌﾟｴﾙﾎﾞ * Elbow Tubing and Clamp Ass'y	1	1	1	
22-1-5	3C7-70199-0	O ﾘﾝｸﾞ * O-Ring	1	1	1	
22-1-6	3C7-70113-0	ﾌｨﾙﾀ * Filter	1	1	1	
22-2	3H6-70200-0	ﾌﾟﾗｲﾏﾊﾞﾙﾌﾞｱｯｼ Primer Bulb Ass'y	1	1	1	
22-2-1	98AB-7-1600	ｺﾞﾑﾎｰｽ * Rubber Hose	1	1	1	
22-2-2	3B2-70281-0	ﾌｭｴﾙｺﾈｸﾀ (ﾀﾝｸ、ﾌｨﾒｰﾙ) * Fuel Connector (Tank side, Female)	1	1	1	
22-2-3	98AB-7-0700	ｺﾞﾑﾎｰｽ * Rubber Hose	1	1	1	
22-2-4	332-70201-0	ｸﾗﾝﾌﾟ * Clamp	4	4	4	
22-2-5	3C7-70211-0	ﾌﾟﾗｲﾏﾊﾞﾙﾌﾞ * Primer Bulb	1	1	1	
22-2-6	3C7-70217-0	ｸﾗﾝﾌﾟ * Clamp	2	2	2	
22-2-7	3C7-70220-1	ｼﾞｮｲﾝﾄｱｯｼ IN * Joint Ass'y (Inlet)	1	1	1	
22-2-8	3C7-70224-1	ｼﾞｮｲﾝﾄｱｯｼ OUT * Joint Ass'y (Outlet)	1	1	1	
22-2-9	394-70250-0	ﾌｭｴﾙｺﾈｸﾀ (ｴﾝｼﾞﾝ、ﾌｨﾒｰﾙ) * Fuel Connector (Engine side, Female)	1	1	1	
22-3	3H6-72100-0	ﾂｰﾙ Tool	1	1	1	
22-4	3B7-72201-0	ﾛｰﾌﾟ Rope	1	1	1	φ6-1600


オプショナルパーツ（アクセサリー）


Fig. 23 OPTIONAL PARTS (ACCESSORIES)




見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
23-1	3R3-76160-0	ﾚｸﾁﾌｧｲﾔｷｯﾄ Rectifier Kit	1 set	1 set	1 set	
23-1-1	3V9-76060-0	ﾚｸﾁﾌｧｲﾔ * Rectifier	1	1	1	
23-1-2	910103-5625	ﾎﾞﾙﾄ * Bolt	2	2	2	
23-1-3	3A3-76037-0	ｹｰﾌﾞﾙﾀｰﾐﾅﾙﾌﾟﾗｸﾞ * Cable Terminal Plug	1	1	1	
23-1-4	361-76161-0	ｴｸｽﾃﾝｼｮﾝｺｰﾄﾞ * Extension Cord	1	1	1	L=2150
23-1-4-1	346-76212-0	ﾋｭｰｽﾞ (15A) ** Fuse (15A)	1	1	1	
23-2	3N8-72640-1	ﾀｺﾒｰﾀ (ｵｲﾙﾗﾝﾌﾟ付) Tachometer (with Oil Lamp)	1	1		Selector "12P" for EP
23-2-1	3B7-72658-0	ｵｲﾙﾊﾞﾙﾌﾞ、12V-1.7W * Oil Bulb, 12V-1.7W	1	1	1	for EP
23-2-2	3B7-72659-0	ﾒｰﾀﾊﾞﾙﾌﾞ、12V-1.7W * Meter Bulb, 12V-1.7W	1	1	1	for EP
23-2-3	3B7-72656-0	ﾒｰﾀﾀﾞﾝﾊﾟ * Meter Damper	1	1	1	for EP
23-2-4	3B7-72661-0	ﾌｨﾃｨﾝｸﾞﾌﾟﾚｰﾄ * Fitting Plate	1	1	1	for EP
23-2-5	930203-0500	ﾅｯﾄ * Nut	2	2	2	for EP
23-2-6	941303-0500	ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ * Spring Washer	2	2	2	for EP
23-3	3A3-72537-0	ﾒｰﾀﾘｰﾄﾞﾜｲﾔ Meter Lead Cable	1	1	1	L=2000 for EP
23-4	353-76037-0	ｹｰﾌﾞﾙﾀｰﾐﾅﾙﾌﾟﾗｸﾞ Cable Terminal Plug	1	1	1	for EP
23-5	3B7-72530-2	ﾀｺﾒｰﾀ (ｵｲﾙﾗﾝﾌﾟ無) Tachometer (with out Oil Lamp)	1	1	1	Selector "12P" for MF & EF
23-5-1	3B7-72659-0	ﾒｰﾀﾊﾞﾙﾌﾞ、12V-1.7W * Meter Bulb, 12V-1.7W	1	1	1	for MF & EF
23-6	361-72539-0	ﾀｺﾒｰﾀﾘｰﾄﾞﾜｲﾔ Tachometer Lead Cable	1	1	1	L=6000 for MF & EF
23-7	336-60007-0	ﾌﾗｯｼﾝｸﾞｱﾀｯﾁﾒﾝﾄ Flushing Attachment	1	1	1	
23-8	3F3-72540-0	ｽﾊﾟｰｸﾃｽﾀ Spark Tester	1	1	1	
23-9	362-64111-0	ﾃｽﾄﾌﾟﾛﾍﾟﾗ Test Propeller	1	1	1	
23-10	3AC-72300-0	ｴﾝｼﾞﾝｵｲﾙ (1L) Engine Oil (1L)	1	1	1	N.A.F.N.
23-11	332-72306-0	ｷﾞﾔｵｲﾙ (500mL) Gear Oil (500mL)	1	1	1	20 tubes/case N.A.F.N.
23-12	332-72309-0	ｸﾞﾘｽ (250g) Grease (250g)	1	1	1	24 tubes/case N.A.F.N.
23-13	3AC-72326-0	ｽﾌﾟﾚｰ (ｱｸｱﾏﾘﾝﾌﾞﾙｰ) Touch-up Paint (Aquamarine Blue)	1	1	1	N.A.F.N.
23-14	334-72312-0	ﾋﾞﾆｰﾙﾓｰﾀｶﾊﾞｰ (L) Vinyl Motor Cover (L)	1	1	1	UNIQUE

アッセンブリ、キット
Fig. 24 ASSEMBLY, KIT








ピストンリングセット
Piston Ring Set — 2


キャブレタリペアキット
Carburetor Repair Kit — 3

パワーヘッドガスケットセット
Power Head Gasket Set — 4

ロワユニットガスケットセット
Lower Unit Gasket Set — 5



Cylinder



ウォータポンプリペアキット
Water Pump Repair Kit — 9

クロムメッキウォータポンプキット
Chrome Plate Water Pump Kit — 10

エレクトロスタータキット（F タイプ）
Electric Starter Kit (F type) — 11

リモコンフィッティングパーツアッシ
R. C. Fitting Parts Ass'y — 12

見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
24-1	3V9B87100-1	ｴﾝｼﾞﾝｼｮｰﾄﾌﾞﾛｯｸ Engine Short Block	1	-	-	use with Coil Bracket (3V6-006008-0)
	3DUB87100-0	ｴﾝｼﾞﾝｼｮｰﾄﾌﾞﾛｯｸ (EU) Engine Short Block (for EU)	1	-	-	for EU with Camshaft 3DU-07010-0 Type
	3H8B87100-2	ｴﾝｼﾞﾝｼｮｰﾄﾌﾞﾛｯｸ Engine Short Block	-	1	1	use with Coil Bracket (3V6-006008-0)
24-2	3H6-87123-0	ﾋﾟｽﾄﾝﾘﾝｸﾞｾｯﾄ (STD) Piston Ring Set (STD)	1 set	1 set	1 set	
	3H6-00011-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞﾄｯﾌﾟ * Piston Ring Top	2	2	2	
	3H6-00012-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ 2nd * Piston Ring 2nd	2	2	2	
	3H6-00013-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ ｵｲﾙ * Piston Ring Oil	2	2	2	
24-2	3H6-87124-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ ｾｯﾄ (0.5mm O/S) Piston Ring Set (0.5mm O/S)	1 set	1 set	1 set	
	3H6-00014-0	ﾋﾟｽﾄﾝﾘﾝｸﾞﾄｯﾌﾟ (0.5mm O/S) * Piston Ring Top (0.5mm O/S)	2	2	2	
	3H6-00015-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ 2nd (0.5mm O/S) * Piston Ring 2nd (0.5mm O/S)	2	2	2	
	3H6-00016-0	ﾋﾟｽﾄﾝ ﾘﾝｸﾞ ｵｲﾙ (0.5mm O/S) * Piston Ring Oil (0.5mm O/S)	2	2	2	
24-3	3R3-87122-1	ｷｬﾌﾞﾚﾀﾘﾍﾟｱｷｯﾄ Carburetor Repair Kit	1 set	1 set	1 set	
	3R3-03222-0	ﾌﾛｰﾄﾁｬﾝﾊﾞ O ﾘﾝｸﾞ * Float Chamber O-Ring	1	1	1	Fig. 5-1-1-1
	922503-6414	ｽｸﾘｭ * Screw	4	4	4	Fig. 5-1-2
	369-03186-0	ｽｸﾘｭ * Screw	3	3	3	Fig. 5-1-3
	3R3-03231-0	ﾌﾛｰﾄ * Float	1	1	1	Fig. 5-1-4
	3F3-03232-0	ﾌﾛｰﾄｱｰﾑﾋﾟﾝ * Float Arm Pin	1	1	1	Fig. 5-1-5
	3R3-03239-0	ﾌﾛｰﾄﾊﾞﾙﾌﾞ * Float Valve	1	1	1	with Valve Pin Fig. 5-1-6
	344-03244-0	ｸﾘｯﾌﾟ * Clip	1	1	1	Fig. 5-1-7
	3R3-03234-0	ｽｸﾘｭ * Screw	1	1	1	Fig. 5-1-8
	346-03256-0	ﾗﾊﾞｰｷｬｯﾌﾟ * Rubber Cap	1	1	1	Fig. 5-1-12
	3R3-03293-0	ﾄﾞﾚﾝｽｸﾘｭｶﾞｽｹｯﾄ * Drain Screw Gasket	1	1	1	Fig. 5-1-16
	3R3-03182-0	ｷｬﾌﾞﾚﾀｶﾊﾞｰｶﾞｽｹｯﾄ * Carburetor Cover Gasket	1	1	1	Fig. 5-1-18
	3R3-03311-1	ﾗﾊﾞｰﾌﾞｰﾂ * Rubber Boot	1	1	-	Fig. 5-1-24
24-4A	3V9-87121-1	ﾊﾟﾜｰﾍｯﾄﾞｶﾞｽｹｯﾄｾｯﾄ Power Head Gasket Set	1 set	1 set	1 set	New
24-4B	3H8-87121-2	ﾊﾟﾜｰﾍｯﾄﾞｶﾞｽｹｯﾄｾｯﾄ Power Head Gasket Set	(1) set	(1) set	(1) set	Old
	3H8-01005-0	ｼﾘﾝﾀﾞｰﾍｯﾄﾞｶﾞｽｹｯﾄ * Cylinder Head Gasket	1	1	1	

見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
24-4	3H8-01024-0	ｼﾘﾝﾀﾞﾍｯﾄﾞｶﾊﾞｰｶﾞｽｹｯﾄ * Cylinder Head Cover Gasket	1	1	1	
	3R0-07422-0	O ﾘﾝｸﾞ、3.1-24.4 * O-Ring, 3.1-24.4	1	1	1	Filler Cap
	3R3-02305-0	ｴｷｿﾞｰｽﾄｶﾊﾞｰｶﾞｽｹｯﾄ * Exhaust Cover Gasket	1	1	1	
	346-01032-0	ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟｶﾞｽｹｯﾄ * Thermostat Cap Gasket	1	1	1	
	3R3-01144-0	ｱﾉｰﾄﾞｷｬｯﾌﾟｶﾞｽｹｯﾄ * Anode Cap Gasket	1	1	1	
	3R3-07432-1	ﾌﾞﾘｰｻﾞﾁｬﾝﾊﾞｶﾊﾞｰｶﾞｽｹｯﾄ * Breather Chamber Cover Gasket	1	1	1	
24-4A	3V9-07402-1	ｵｲﾙﾊﾟﾝｶﾞｽｹｯﾄ * Oil Pan Gasket	1	1	1	New Fig. 2-30
24-4B	3R3-07442-2	ｵｲﾙﾊﾟﾝﾌﾟﾚｰﾄｶﾞｽｹｯﾄ * Oil Pan Plate Gasket	(2)	(2)	(2)	Old Fig. 2-30A
	3H8-00121-0	ｵｲﾙｼｰﾙ、32-48-8 * Oil Seal, 32-48-8	1	1	1	Upper
	3R3-00121-0	ｵｲﾙｼｰﾙ、32-44-9 * Oil Seal, 32-44-9	1	1	1	Lower
	3R3-02104-1	ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｶﾞｽｹｯﾄ * Intake Manifold Gasket	1	1	1	
	3R0-02011-0	ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ * Carburetor Gasket	2	2	2	
	3F3-02012-0	O ﾘﾝｸﾞ、1.9-38.8 * O-Ring, 1.9-38.8	1	1	1	Carburetor
	345-62415-0	O ﾘﾝｸﾞ、3.5-25.7 * O-Ring, 3.5-25.7	1	1	1	Fuel Pump
	3H8-07639-0	ｵｲﾙﾎﾟﾝﾌﾟ O ﾘﾝｸﾞ * Oil Pump O-Ring	1	1	1	
	3H8-07635-0	O ﾘﾝｸﾞ、1.5-15.5 * O-Ring, 1.5-15.5	2	2	2	Oil Pump
	3H8-07632-0	O ﾘﾝｸﾞ、1.5-10.7 * O-Ring, 1.5-10.7	1	1	1	Oil Pump
	3H8-07631-0	O ﾘﾝｸﾞ、1.5-8.5 * O-Ring, 1.5-8.5	1	1	1	Oil Pump
	3H8-07025-0	ｵｲﾙｼｰﾙ、18-35-8 * Oil Seal, 18-35-8	1	1	1	Camshaft
	350-01215-1	ｵｲﾙｼｰﾙ、12.8-25-7 * Oil Seal, 12.8-25-7	1	1	1	Drive Shaft
24-5	398-87321-1	ﾛﾜﾕﾆｯﾄｶﾞｽｹｯﾄｾｯﾄ Lower Unit Gasket Set	1 set	1 set	1 set	
	332-60006-0	ｶﾞｽｹｯﾄ、8.2-14-1 * Gasket, 8.2-14-1	3	3	3	
	121-32071-0	O ﾘﾝｸﾞ、2.4-59.6 * O-Ring, 2.4-59.6	1	1	1	Propeller Shaft
	346-65013-0	ｵｲﾙｼｰﾙ、17-30-9 * Oil Seal, 17-30-9	1	1	1	Propeller Shaft
	332-60223-0	ｵｲﾙｼｰﾙ、13.8-26-9.5 * Oil Seal, 13.8-26-9.5	1	1	1	Pump Case Lower
	336-62415-0	O ﾘﾝｸﾞ、3.5-36 * O-Ring, 3.5-36	2	2	2	Pump Case Lower Cam Rod Bussing
	332-66021-0	O ﾘﾝｸﾞ、2.4-5.8 * O-Ring, 2.4-5.8	2	2	2	Cam Rod
	362-02312-1	ｴｷｿﾞｰｽﾄﾊﾟｲﾌﾟｶﾞｽｹｯﾄ * Exhaust Pipe Gasket	1	1	1	Don't Use for 4-stroke Engine

見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
24-6	3R3Q63003-0	ﾃｨﾗﾊﾝﾄﾞﾙｱｯｼ Tiller Handle Ass'y	1	1	1	
24-7	3R3Q87301-1	ﾛﾜﾕﾆｯﾄｱｯｼ S Lower Unit Ass'y "S"	1	1	1	for transom "S"
	3R3Q87302-1	ﾛﾜﾕﾆｯﾄｱｯｼ L Lower Unit Ass'y "L"	1	1	1	for transom "L"
24-8	398Q60100-1	ﾌﾟﾛﾍﾟﾗｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ Propeller Shaft Housing Ass'y	1	1	1	Old Part No. 362S87323-0
24-9	362-87322-0	ｳｫｰﾀﾎﾟﾝﾌﾟﾘﾍﾟｱｷｯﾄ Water Pump Repair Kit	1 set	1 set	1 set	
	334-65021-0	ｳｫｰﾀﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ * Water Pump Impeller	1	1	1	
	350-65022-0	ｳｫｰﾀﾎﾟﾝﾌﾟｲﾝﾍﾟﾗｷｰ * Water Pump Impeller Key	1	1	1	
	350-65011-1	ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ * Pump Case Liner	1	1	1	
	350-65025-0	ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ * Water Pump Guide Plate	1	1	1	
	910113-5652	ﾎﾞﾙﾄ * Bolt	3	3	3	
24-10	362-65231-0	ｳｫｰﾀﾎﾟﾝﾌﾟｷｯﾄ (ｸﾛﾑﾒｯｷ) Water Pump Kit (Chrome Plated)	1 set	1 set	1 set	
	334-65021-0	ｳｫｰﾀﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ * Water Pump Impeller	1	1	1	
	362-65238-0	ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ (ｸﾛﾑﾒｯｷ) * Pump Case Liner (Chrome Plated)	1	1	1	
	362-65239-0	ﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ (ｸﾛﾑﾒｯｷ) * Pump Guide Plate (Chrome Plated)	1	1	1	
24-11	3R3-76300-2	ｴﾚｸﾄﾘｯｸｽﾀｰﾀｷｯﾄ (F ﾀｲﾌﾟ) Electric Starter Kit ("F" Type)	1 set	1 set	1 set	
	3C8-76010-1	ｽﾀｰﾀﾓｰﾀ * Starter Motor	1	1	1	Fig. 9-1
	910103-5825	ﾎﾞﾙﾄ * Bolt	2	2	2	Fig. 9-2
	3R3-76009-0	ｽﾀｰﾀﾓｰﾀﾊﾞﾝﾄﾞ * Starter Motor Band	1	1	1	Fig. 9-3
	3C8-76007-0	ｽﾀｰﾀﾓｰﾀﾀﾞﾝﾊﾟ * Starter Motor Damper	1	1	1	Fig. 9-4
	910103-5818	ﾎﾞﾙﾄ * Bolt	1	1	1	Fig. 9-5
	3H8-76040-0	ｽﾀｰﾀｿﾚﾉｲﾄﾞ * Starter Solenoid	1	1	1	Fig. 9-6
	3V9-76060-0	ﾚｸﾁﾌｧｲﾔ * Rectifier	1	1	1	Fig. 9-7
	910103-5625	ﾎﾞﾙﾄ * Bolt	2	2	2	Fig. 9-8
	3V1-76120-1	ﾊﾞｯﾃﾘｺｰﾄﾞ * Battery Cable	1	1	1	Fig. 9-9 L=2500
	3B7-76145-0	ﾀｰﾐﾅﾙｷｬｯﾌﾟ * Terminal Cap	1	1	1	Fig. 9-10

見出番号 Ref. No.	部品番号 Part No.	部品名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備考 Remarks
24-11	3R3-76141-0	ｽﾀｰﾀｺｰﾄﾞ * Starter Cord	1	1	1	Fig. 9-11 L=270
	3A3-76145-0	ﾀｰﾐﾅﾙｷｬｯﾌﾟ * Terminal Cap	2	2	2	Fig. 9-12
	3V9-76062-0	ﾋｭｰｽﾞｺｰﾄﾞ * Fuse Cable	1	1	1	Fig. 9-13 L=450
	910103-6612	ﾎﾞﾙﾄ * Bolt	1	1	1	Fig. 9-22 Starter Motor
	910113-0630	ﾎﾞﾙﾄ * Bolt	1	1	1	Fig. 11-3 Recoil Starter
	398-06972-0	ｸﾗﾝﾌﾟ、6.5-67P * Clamp, 6.5-67P	1	1	1	Fig. 11-15 Recoil Starter
	3H6-63619-1	ｶﾗｰ、6.5-10.5-10 * Collar, 6.5-10.5-10	1	1	1	Fig. 11-16 Recoil Starter
	398-76080-0	ﾆｭｰﾄﾗﾙｽｲｯﾁ * Neutral Switch	1	1	1	Fig. 16-30
	398-76083-0	ﾆｭｰﾄﾗﾙｽｲｯﾁｱｸﾁｭｴｰﾀ * Neutral Switch Actuator	1	1	1	Fig. 16-31
	361-76026-0	ﾒｲﾝｽｲｯﾁ * Main Switch	1	1	1	Fig. 16-32
24-12	3R3Q83880-0	ﾘﾓｺﾝﾌｨﾃﾝｸﾞﾊﾟｰﾂ Remote Control Fitting Parts	1 set	1 set	1 set	
	3R3Q67482-0	ﾘﾓｰﾄｺﾝﾄﾛｰﾙｽﾃｰ * Remote Control Stay	1	1	1	Fig. 17-1
	910103-5620	ﾎﾞﾙﾄ * Bolt	3	3	3	Fig. 16-4 or 910113-5620
	3R3-67483-0	ﾘﾓｰﾄｺﾝﾄﾛｰﾙｽﾃｰｶﾊﾞｰ * Remote Control Stay Cover	1	1	1	Fig. 17-2
	922513-5630	ｽｸﾘｭ * Screw	2	2	2	Fig. 17-3
	3R3-83732-0	ｹｰﾌﾞﾙｸﾞﾛﾒｯﾄ * Cable Grommet	1	1	1	Fig. 17-4
	3R3-83820-0	ｹｰﾌﾞﾙｸﾘｯﾌﾟ * Cable Clip	1	1	1	Fig. 17-5
	910103-5616	ﾎﾞﾙﾄ * Bolt	1	1	1	Fig. 17-6 or 910113-5616
	3R3-66128-0	ｼﾌﾄｱｰﾑ (ﾘﾓｰﾄｺﾝﾄﾛｰﾙ) * Shift Arm (Remote Control)	1	1	1	Fig. 17-7
	3R3-66134-1	ｼﾌﾄﾚﾊﾞｰﾛｯﾄﾞ * Shift Lever Rod	1	1	1	Fig. 17-8
	930103-0500	ﾅｯﾄ * Nut	1	1	1	Fig. 17-9 or 930103-0500
	3B7-83715-1	ｹｰﾌﾞﾙｼﾞｮｲﾝﾄ * Cable Joint	3	3	3	Fig. 17-10
	3AA-83719-0	ﾜｯｼｬ、8.5-18-1.6 * Washer, 8.5-18-1.6	3	3	3	Fig. 17-11 or 353-83719-0
	951603-0800	ｽﾅｯﾌﾟﾋﾟﾝ、d=8 * Snap Pin, d=8	3	3	3	Fig. 17-12
	3R3-66129-0	ｼﾌﾄﾚﾊﾞｰ (ﾘﾓｰﾄｺﾝﾄﾛｰﾙ) * Shift Lever (Remote Control)	1	1	1	Fig. 17-13
	910103-0625	ﾎﾞﾙﾄ * Bolt	1	1	1	Fig. 17-14 Cylinder mark "C"
	3R0-66308-0	ﾜｯｼｬ、6-16-1.5 * Washer, 6-16-1.5	4	4	4	Fig. 17-15, 22 or 3C8-66308-0
	353-76079-0	ｶﾗｰ、6.2-9-9.3 * Collar, 6.2-9-9.3	1	1	1	Fig. 17-16
	3C8-63733-0	ﾛｯﾄﾞｽﾅｯﾌﾟ、5-3 * Rod Snap, 5-3	1	1	1	Fig. 17-17

見出番号 Ref. No.	部品番号 Part No.	部　品　名 Description	個数 Q'ty F 18 B2	F 15 B2	F 9.9 B2	備　考 Remarks
24-12	3R3-63709-0	ｽﾛｯﾄﾙﾛｯﾄﾞ (ﾘﾓｰﾄｺﾝﾄﾛｰﾙ) * Throttle Rod (Remote Control)	1	1	1	Fig. 17-18
	346-67196-1	ﾛｯﾄﾞｽﾅｯﾌﾟ、φ 3B * Rod Snap, φ 3B	1	1	1	Fig. 17-19
	3R3-83910-0	ｽﾛｯﾄﾙﾚﾊﾞｰ (ﾘﾓｰﾄｺﾝﾄﾛｰﾙ) * Throttle Lever (Remote Control)	1	1	1	Fig. 17-20
	910103-0645	ﾎﾞﾙﾄ * Bolt	1	1	1	Fig. 17-21 Cylinder mark "B"
	3R3-83913-0	ｶﾗｰ、6.2-9-30.8 * Collar, 6.2-9-30.8	1	1	1	Fig. 17-23
	3R3-83914-0	ｽﾛｯﾄﾙﾚﾊﾞｰｽﾄｯﾊﾟ * Throttle Lever Stopper	1	1	1	Fig. 17-24
	910113-5616	ﾎﾞﾙﾄ * Bolt	1	1	1	Fig. 17-25 Cylinder mark "A"
	3V5Q62001-0	ｽﾃｱﾘﾝｸﾞﾌﾞﾗｹｯﾄ * Steering Bracket	1	1	1	Fig. 17-26
	916113-1045	ﾎﾞﾙﾄ * Bolt	2	2	2	Fig. 17-27
	940113-1000	ﾜｯｼｬ * Washer	2	2	2	Fig. 17-28

Copyright © 2007 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any from or by any means without the express written permission of Tohatsu Corporation.

TOHATSU

トーハツ船外機
パーツ リスト

PARTS LIST

MFS 9.9
15
18

TOHATSU CORPORATION
Address : 5-4,3-chome,Azusawa,Itabashi-ku,
TOKYO,174-0051 JAPAN
Phone : TOKYO (03)3966-3117
FAX : TOKYO (03)3966-2951
E-mail : www.tohatsu.co.jp

本　　社	〒174-0051	東京都板橋区小豆沢3-5-4	03 (3966) 3116
マリン九州	〒816-0092	福岡市博多区東那珂2-10-55	092 (411) 8770
マリン関西	〒530-0043	大阪市北区天満 1-8-27	06 (6358) 2971
マリン中部	〒440-0069	愛知県豊橋市御園町7-12	0532 (54) 5551
マリン関東	〒174-0051	東京都板橋区小豆沢3-5-4	03 (3966) 2222
マリン東北	〒981-1106	仙台市太白区柳生2-23-1	022 (306) 9131
マリン北海道	〒060-0031	札幌市中央区北一条東11丁目22-41	011 (241) 8301

002-21047-4
0607-MH2000