
PARTS CATALOG

トーハツ船外機
パーツ カタログ

TOHATSU



MFS 2B
2.5B
3.5B

2012
Serial Number 000001AB~

OB NO.002-21052-5
1203


パーツカタログのご使用について

1. このパーツカタログは、2012 年 1 月現在で編集しております。

2. 新設、廃止または、変更が生じた場合は、サービスブルテン等にてお知らせ致しますので、その都度、ご訂正ください。

3. イラストレーション（部品図）は部品検査の目安として記載していますので現品と形状が異なる場合があります。

4. イラストが一つに対して複数の品番がありますので枝番、適用モデル、備考を確認してからご注文願います。



5. アッセンブリまたは、キットでの販売部品は、その構成する部品の頭に（＊）印をつけて表しています。

6. 本文中に記載されている記号は、次の様になっています。

STD	: スタンダード	OPT	: オプション
O/S	: オーバーサイズ	ASSY	: アッセンブリ
DO	: 日本国内向け	EX	: 海外輸出向け
A	: 必要に応じて選択	EU	: 欧州連合

7. オーダー上の注意
塗装部品の注文に当っては、以下に従ってください。
パーツナンバーの 4 桁目が “B”・“Q” 記号のものは塗装されています。
現在の塗装色はパワーヘッドがブラック（B)、ロワユニットがアクアマリンブルー(Q)、プロペラがブラック（B）です。
[例示]

エンジンショートブロックキット	ロワユニットアッシ（L）
3GTB87090-3	3BMQ87302-1
B: ブラック	Q: アクアマリンブルー

8. ボルト・ナット・ワッシャのサイズ記号に付いて

ボルト 9101F4 - 5635
- 首下長さ
- 径
- 座付き (0) : 座なし

ナット・ワッシャ 9401E3 - 0600
- 径

9. 標準部品のホースは、長巻（備考を参照）に代替されます。

ホース 98AB - 50 - 080
- 長さ
- 径


HOW TO USE THIS PARTS CATALOG

1. This Parts Catalog provides information available as of the end of January, 2012.

2. Please keep the Parts Catalog updated each time when receiving the Service Bulletin describing the addition, abolition and/or change of parts.

3. Actual shapes of parts may be different from the illustrations shown in this Parts Catalog because they are described only as a guide for searching parts.

4. One illustration is given more than one article number. Please confirm the sub-number and applicable model before ordering parts.



5. Given mark in (∗) to part number shows assembly or kit part.

6. Marks in this Parts Catalog show.

STD	: Standard	OPT	: Optional Parts
O/S	: Over size	ASSY	: Assembly
DO	: Domestic Model	EX	: Export Model
A	: As required	EU	: European Union

7. Attention to order
   Please order painted parts in accordance with following.
   The parts that fourth figure of the parts number is (B), (Q) have painted.
   Present coloring of power head is black (B), lower unit is aqua marine blue (Q) and propeller is black (B).
   [Example]

ENGINE SHORT BLOCK KIT	LOWER UNIT ASSY (L)
3GTB87090-3	3BMQ87302-1
B: Black	Q: Aquamarine Blue

8. About dimensional identification of bolts, nuts and washers.
   BOLT 9101F4 - 5635
   - Length below neck
   - Diameter
   - Washer based (0) : No washer

   NUTS & WASHERS 9401E3 - 0600
   - Diameter

9. Hose, that is a standard part, is replaced with long hose.
   HOSE 98AB - 50 - 080
   - Length
   - Diameter

CONTENTS
目　　次

Fig. 1 CYLINDER・CRANK CASE ····· 1
シリンダ・クランクケース

Fig. 2 PISTON・CRANK SHAFT ····· 5
ピストン・クランクシャフト

Fig. 3 OIL PAN ····· 7
オイルパン

Fig. 4 INTAKE MANIFOLD・CARBURETOR ····· 9
インテークマニホールド・キャブレタ

Fig. 5 THROTTLE ····· 13
スロットル

Fig. 6 RECOIL STARTER ····· 15
リコイルスタータ

Fig. 7 MAGNETO ····· 17
マグネト

Fig. 8 DRIVE SHAFT HOUSING ····· 19
ドライブシャフトハウジング

Fig. 9 SHIFT ····· 21
シフト

Fig. 10 GEAR CASE ····· 23
ギヤケース

Fig. 11 CLAMP BRACKET・SWIVEL BRACKET ····· 27
クランプブラケット・スイベルブラケット

Fig. 12 TILLER HANDLE ····· 31
ティラハンドル

Fig. 13 BOTTOM COWL ····· 33
ボトムカウル

Fig. 14 TOP COWL ····· 35
トップカウル

Fig. 15 FUEL TANK ····· 37
フュエルタンク

Fig. 16 OPTIONAL PARTS (ACCESSORIES) ····· 39
オプショナルパーツ（アクセサリ）

Fig. 17 ASSEMBLY・KIT PARTS ····· 41
アッセンブリ・キットパーツ

索引 ····· 47

INDEX ····· 50

INDEX (Parts Number) ····· 52

Fig. 1 CYLINDER・CRANK CASE
シリンダ・クランクケース




Fig. 2 PISTON・CRANK SHAFT
ピストン・クランクシャフト




Fig. 3 OIL PAN
オイルパン




Fig. 4 INTAKE MANIFOLD・CARBURETOR
インテークマニホールド・キャブレタ




Fig. 5 THROTTLE
スロットル




Fig. 6 RECOIL STARTER
リコイルスタータ




Fig. 7 MAGNETO
マグネト




Fig. 8 DRIVE SHAFT HOUSING
ドライブシャフトハウジング




Fig. 9 SHIFT
シフト




Fig. 10 GEAR CASE
ギヤケース




Fig. 11 CLAMP BRACKET・SWIVEL BRACKET
クランプブラケット・スイベルブラケット




Fig. 12 TILLER HANDLE
ティラハンドル




Fig. 13 BOTTOM COWL
ボトムカウル




Fig. 14 TOP COWL
トップカウル




Fig. 15 FUEL TANK
フュエルタンク




Fig. 16 OPTIONAL PARTS (ACCESSORIES)
オプショナルパーツ（アクセサリ）




Fig. 17 ASSEMBLY・KIT PARTS
アッセンブリ・キットパーツ






Fig. 1 CYLINDER・CRANK CASE
シリンダ・クランクケース




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
1-1	3GTB01100-2	CYL BLOCK & CRANKCASE ASSY ｼﾘﾝﾀﾞﾌﾞﾛｯｸ&ｸﾗﾝｸｹｰｽｱｯｼ	1	1	1	Nipple
1-2	3R3-07204-0	* INTAKE VALVE STEM SEAL * ｲﾝﾃｰｸﾊﾞﾙﾌﾞｽﾃﾑｼｰﾙ	1	1	1	Black
1-3	3R3-07206-0	* EXHAUST VALVE STEM SEAL * ｴｷｿﾞｰｽﾄﾊﾞﾙﾌﾞｽﾃﾑｼｰﾙ	1	1	1	Green
1-4	345-01111-0	* DOWEL PIN 6-12 * ﾀﾞｳｪﾙﾋﾟﾝ 6-12	3	3	3	
1-5	9101F4-5635	* BOLT * ﾎﾞﾙﾄ	6	6	6	
1-6	9161F9-0675	* BOLT * ﾎﾞﾙﾄ	2	2	2	
1-7	9401E3-0600	* WASHER * ﾜｯｼｬ	2	2	2	
1-8	3R0-71015-1	OIL FILLER CAP ｵｲﾙﾌｨﾗｷｬｯﾌﾟ	1	1	1	
1-9	3R0-07422-0	O-RING 3.1-24.4 Oﾘﾝｸﾞ 3.1-24.4	1	1	1	
1-10	3GT-07810-0	CAMSHAFT ASSY ｶﾑｼｬﾌﾄｱｯｼ	1	1	1	
1-11	3AB-07201-0	INTAKE VALVE ｲﾝﾃｰｸﾊﾞﾙﾌﾞ	1	1	1	
1-12	3V1-07202-0	EXHAUST VALVE ｴｷｿﾞｰｽﾄﾊﾞﾙﾌﾞ	1	1	1	
1-13	3AE-07203-0	VALVE SPRING L=35 ﾊﾞﾙﾌﾞｽﾌﾟﾘﾝｸﾞ L=35	2	2	2	
1-14	3V1-07221-0	RETAINER ﾘﾃｰﾅ	2	2	2	
1-15	3H6-07223-0	COTTER ｺｯﾀ	4	4	4	
1-16	3H6-07205-0	VALVE SPRING SEAT ﾊﾞﾙﾌﾞｽﾌﾟﾘﾝｸﾞｼｰﾄ	2	2	2	
1-17	3AB-07231-0	LIFTER ﾘﾌﾀ	2	2	2	
1-18	3H6-07232-0	PUSH ROD ﾌﾟｯｼｭﾛｯﾄﾞ	2	2	2	
1-19	3AB-07233-0	PLATE ﾌﾟﾚｰﾄ ﾌﾟｯｼｭﾛｯﾄﾞ	1	1	1	
1-20	3H6-07234-0	PIVOT BOLT ﾋﾟﾎﾞｯﾄﾎﾞﾙﾄ	2	2	2	
1-21	3AB-07235-0	ROCKER ARM ﾛｯｶｱｰﾑ	2	2	2	
1-22	3H6-07236-0	PIVOT ﾋﾟﾎﾞｯﾄ ﾛｯｶｱｰﾑ	2	2	2	
1-23	3H6-07937-0	ADJUSTING NUT ｱｼﾞｬｽﾄﾅｯﾄ	2	2	2	
1-24	3ABB01021-0	CYLINDER HEAD COVER ｼﾘﾝﾀﾞﾍｯﾄﾞｶﾊﾞｰ	1	1	1	
1-25	3AB-01024-1	CYLINDER HEAD COVER GASKET ｼﾘﾝﾀﾞﾍｯﾄﾞｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	1	
1-26	910121-0616	BOLT ﾎﾞﾙﾄ	4	4	4	
1-27	3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	4	4	4	
1-28	3H6-01030-0	THERMOSTAT ｻｰﾓｽﾀｯﾄ	1	1	1	Mark 52B PRV
1-29	3ABB01031-0	THERMOSTAT CAP ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟ	1	1	1	STD

Fig. 1 **CYLINDER・CRANK CASE**
シリンダ・クランクケース




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
1-30	3GTB01031-0	THERMOSTAT CAP ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟ		1	1	for USA Model
1-31	3AB-01032-0	THERMOSTAT CAP GASKET ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	1	
1-32	398-06972-0	CLAMP 6.5-67P ｸﾗﾝﾌﾟ 6.5-67P	1	1	1	
1-33	9101E3-5630	BOLT ﾎﾞﾙﾄ	2	2	2	
1-34	3AB-07431-0	BREATHER CHAMBER COVER ﾌﾞﾘｰｻﾞﾁｬﾝﾊﾞｶﾊﾞｰ	1	1	1	
1-35	3AB-07432-0	GASKET ｶﾞｽｹｯﾄ ﾌﾞﾘｰｻﾞﾁｬﾝﾊﾞｶﾊﾞｰ	1	1	1	
1-36	9101E3-5616	BOLT ﾎﾞﾙﾄ	2	2	2	
1-37	3AB-07640-0	SLINGER ｽﾘﾝｶﾞ	1	1	1	
1-38	9701-1-1103	SPARK PLUG (DCPR6E) ｽﾊﾟｰｸﾌﾟﾗｸﾞ (DCPR6E)	1	1	1	NGK

Fig. 2 PISTON・CRANK SHAFT
ピストン・クランクシャフト




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数 MFS2B	 MFS2.5B	 MFS3.5B	Remarks 備 考
2-1		3AB-00070-0	CRANKSHAFT ASSY W/GEAR ｸﾗﾝｸｼｬﾌﾄｱｯｼ W/ｷﾞﾔ	1	1	1	
2-2		9603-3-6204	* BALL BEARING 6204 *ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6204	2	2	2	
2-3		3AB-00115-0	THRUST PLATE 20.2-32-1 ｽﾗｽﾄﾌﾟﾚｰﾄ 20.2-32-1	1	1	1	
2-4		3AB-00121-0	OIL SEAL 20-35-7 ｵｲﾙｼｰﾙ 20-35-7	2	2	2	
2-5		3AB-00040-0	CONNECTING ROD ASSY ｺﾝﾛｯﾄﾞｱｯｼ	1	1	1	
2-6		3AB-00059-0	* CONNECTING ROD BOLT *ｺﾝﾛｯﾄﾞﾎﾞﾙﾄ	2	2	2	
2-7		3AB-00001-1	PISTON ﾋﾟｽﾄﾝ	1	1	1	
2-8		332-00021-1	PISTON PIN ﾋﾟｽﾄﾝﾋﾟﾝ	1	1	1	
2-9		350-00024-1	PISTON PIN CLIP ﾋﾟｽﾄﾝﾋﾟﾝｸﾘｯﾌﾟ	2	2	2	
2-10		309-00131-0	KEY ｷｰ ﾏｸﾞﾈﾄ	1	1	1	Magneto
2-11		3FK-87123-0	PISTON RING SET ﾋﾟｽﾄﾝﾘﾝｸﾞｾｯﾄ	1	1	1	
2-12		3V1-00011-0	* PISTON RING *ﾋﾟｽﾄﾝﾘﾝｸﾞ	1	1	1	1st
2-13		3V1-00012-0	* PISTON RING *ﾋﾟｽﾄﾝﾘﾝｸﾞ	1	1	1	2nd
2-14		3V1-00013-0	* PISTON RING-OIL *ﾋﾟｽﾄﾝﾘﾝｸﾞ ｵｲﾙ	1	1	1	Oil

Fig. 3 OIL PAN
オイルパン




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
3-1	3ABB07400-0	OILPAN ASSY ｵｲﾙﾊﾟﾝｱｯｼ	1	1	1	
3-2	3AB-07421-0	* OIL SIGHT GAUGE *ｵｲﾙｻｲﾄｹﾞｰｼﾞ	1	1	1	
3-3	345-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	2	
3-4	3H6-07705-1	DRAIN BOLT 10-14 P1.25 ﾄﾞﾚﾝﾎﾞﾙﾄ 10-14 P1.25	1	1	1	
3-5	3H6-07406-0	WASHER 10.2-19-1 ﾜｯｼｬ 10.2-19-1	1	1	1	
3-6	3AB-07402-0	OILPAN GASKET ｵｲﾙﾊﾟﾝｶﾞｽｹｯﾄ	1	1	1	
3-7	9101F4-5635	BOLT ﾎﾞﾙﾄ	8	8	8	
3-8	3GT-05101-0	BRACKET ﾌﾞﾗｹｯﾄ ｽﾄｯﾊﾟ	1	1	1	
3-9	3A0-76079-0	COLLAR 6.2-9-7.4 ｶﾗｰ 6.2-9-7.4	2	2	2	
3-10	9101E3-5620	BOLT ﾎﾞﾙﾄ	2	2	2	
3-11	98AB-50-080	HOSE ﾎｰｽ	1	1	1	98AB-501000
3-12	338-02215-0	CLIP φ10 ｸﾘｯﾌﾟ ﾌｭｴﾙﾊﾟｲﾌﾟ φ10	2	2	2	
3-13	3AB-61012-0	DRIVE SHAFT HOUSING GASKET ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾞｽｹｯﾄ	1	1	1	
3-14	3AB-01210-0	CRANKCASE HEAD ｸﾗﾝｸｹｰｽﾍｯﾄﾞ	1	1	1	
3-15	3AB-01215-0	OIL SEAL 10.1-20-7 ｵｲﾙｼｰﾙ 10.1-20-7	2	2	2	
3-16	3V1-02012-0	O-RING 2.4-35.2 Oﾘﾝｸﾞ 2.4-35.2	1	1	1	
3-17	9101E3-5620	BOLT ﾎﾞﾙﾄ	2	2	2	

Fig. 4 **INTAKE MANIFOLD・CARBURETOR**
インテークマニホールド・キャブレタ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS2B	MFS2.5B	MFS3.5B	
4-1		3BRB02091-1	INTAKE MANIFOLD ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞ	1	1	1	STD
4-2		3GTB02010-0	INTAKE MANIFOLD ASSY ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｱｯｼ		1	1	Nipple for USA Model
4-3		98AB-70-185	HOSE ﾎｰｽ		1	1	for USA Model 98AB-701000
4-4		3V1-76148-0	SPIRAL TUBE PROTECTOR φ10-100 ｽﾊﾟｲﾗﾙﾁｭｰﾌﾞﾌﾟﾛﾃｸﾀ φ10-100		1	1	for USA Model
4-5		3C7-02215-0	CLIP φ12 ｸﾘｯﾌﾟ φ12		2	2	for USA Model
4-6		3AB-02104-0	INTAKE MANIFOLD GASKET ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｶﾞｽｹｯﾄ	1	1	1	
4-7		9101F4-5630	BOLT ﾎﾞﾙﾄ	2	2	2	
4-8	1	3GT-03200-0	CARBURETOR ASSY ｷｬﾌﾞﾚﾀｱｯｼ	1			2ps Mark 3GTA
4-8	2	3GU-03200-0	CARBURETOR ASSY ｷｬﾌﾞﾚﾀｱｯｼ		1		2.5ps Mark 3GUA
4-8	3	3GV-03200-0	CARBURETOR ASSY ｷｬﾌﾞﾚﾀｱｯｼ			1	3.5ps Mark 3GVA
4-9	1	3GT-03252-0	* MAIN NOZZLE *ﾒｲﾝﾉｽﾞﾙ	1			2ps
4-9	2	3GU-03252-0	* MAIN NOZZLE *ﾒｲﾝﾉｽﾞﾙ		1		2.5ps
4-9	3	3R4-03252-0	* MAIN NOZZLE *ﾒｲﾝﾉｽﾞﾙ			1	3.5ps
4-10	1	3DJ-04458-0	* MAIN JET (#58) *ﾒｲﾝｼﾞｪｯﾄ (#58)	1			2ps
4-10	2	3R1-03251-0	* MAIN JET (#65) *ﾒｲﾝｼﾞｪｯﾄ (#65)		1		2.5ps
4-10	3	3AU-04468-0	* MAIN JET (#68) *ﾒｲﾝｼﾞｪｯﾄ (#68)			1	3.5ps
4-11	1	3GT-04915-0	* SLOW AIR JET (#115) *ｽﾛｰｴｱｼﾞｪｯﾄ (#115)	1		1	2/3.5ps
4-11	2	3GT-04925-0	* SLOW AIR JET (#125) *ｽﾛｰｴｱｼﾞｪｯﾄ (#125)		1		2.5ps
4-12		3GT-03231-0	* FLOAT *ﾌﾛｰﾄ	1	1	1	
4-13		3H6-03240-0	* FLOAT VALVE *ﾌﾛｰﾄﾊﾞﾙﾌﾞ	1	1	1	
4-14		3H6-03244-0	* CLIP *ｸﾘｯﾌﾟ	1	1	1	
4-15		3H6-03232-0	* FLOAT ARM PIN *ﾌﾛｰﾄｱｰﾑﾋﾟﾝ	1	1	1	
4-16		3GT-03221-0	* FLOAT CHAMBER *ﾌﾛｰﾄﾁｬﾝﾊﾞ	1	1	1	
4-17		3H6-03222-0	* FLOAT CHAMBER O-RING *ﾌﾛｰﾄﾁｬﾝﾊﾞOﾘﾝｸﾞ	1	1	1	
4-18		922503-6412	* SCREW *ｽｸﾘｭ	2	2	2	
4-19		3H6-03292-0	* DRAIN SCREW *ﾄﾞﾚﾝｽｸﾘｭ	1	1	1	
4-20		3H6-03293-0	* O-RING *Oﾘﾝｸﾞ ﾄﾞﾚﾝｽｸﾘｭ	1	1	1	
4-21		3AB-03265-0	* STOP SCREW *ｽﾄｯﾌﾟｽｸﾘｭ	1	1	1	
4-22		3H6-03267-0	* SPRING *ｽﾌﾟﾘﾝｸﾞ ｽﾄｯﾌﾟｽｸﾘｭ	1	1	1	

Fig. 4 **INTAKE MANIFOLD・CARBURETOR**
インテークマニホールド・キャブレタ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS2B	MFS2.5B	MFS3.5B	
4-23		3GT-03256-0	* RUBBER CAP *ﾗﾊﾞｰｷｬｯﾌﾟ	1	1	1	
4-24	1	3AB-03266-0	* PILOT SCREW *ﾊﾟｲﾛｯﾄｽｸﾘｭ	1		1	2/3.5ps
4-24	2	3AS-03266-0	* PILOT SCREW *ﾊﾟｲﾛｯﾄｽｸﾘｭ		1		2.5ps
4-25		3H6-02011-0	CARBURETOR GASKET ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ	2	2	2	
4-26		3H6-03952-1	INSULATOR ｲﾝｼｭﾚｰﾀ	1	1	1	
4-27		3H6-02411-0	INTAKE SILENCER ｲﾝﾃｰｸｻｲﾚﾝｻ	1	1	1	
4-28		3H6-02603-0	FLAME ARRESTER ﾌﾚｰﾑｱﾚｽﾀ	1	1	1	
4-29		3A0-76079-0	COLLAR 6.2-9-7.4 ｶﾗｰ 6.2-9-7.4	2	2	2	
4-30		3H6-76079-1	COLLAR 6.2-9-7 ｶﾗｰ 6.2-9-7	1	1	1	
4-31		9161F1-0685	BOLT ﾎﾞﾙﾄ	2	2	2	
4-32		940103-0600	WASHER ﾜｯｼｬ	2	2	2	
4-33		3H6-63505-0	CABLE HOLDER ｹｰﾌﾞﾙﾎﾙﾀﾞ	1	1	1	
4-34		910103-0616	BOLT ﾎﾞﾙﾄ	1	1	1	
4-35		930103-0600	NUT ﾅｯﾄ	1	1	1	
4-36		98AB-30-230	HOSE ﾎｰｽ	2	2	2	98AB-301000
4-37		3AB-07435-0	BREATHER HOSE ﾌﾞﾘｰｻﾞﾎｰｽ	1	1	1	
4-38		3GT-04000-0	FUEL PUMP ASSY ﾌｭｴﾙﾎﾟﾝﾌﾟｱｯｼ		1	1	for USA Model
4-39		9101E3-5620	BOLT ﾎﾞﾙﾄ		2	2	for USA Model
4-40		338-02215-0	CLIP φ10 ｸﾘｯﾌﾟ ﾌｭｴﾙﾊﾟｲﾌﾟ φ10		2	2	for USA Model

Fig. 5 **THROTTLE**
スロットル




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
5-1	3ABB63508-0	THROTTLE WIRE BRACKET ｽﾛｯﾄﾙﾜｲﾔﾌﾞﾗｹｯﾄ	1	1	1	
5-2	398-06972-0	CLAMP 6.5-67P ｸﾗﾝﾌﾟ 6.5-67P	1	1	1	
5-3	9101E3-5625	BOLT ﾎﾞﾙﾄ	2	2	2	
5-4	3H6-63611-0	THROTTLE DRUM ｽﾛｯﾄﾙﾄﾞﾗﾑ	1	1	1	
5-5	3H6-63612-0	THROTTLE OPENER ｽﾛｯﾄﾙｵｰﾌﾟﾅ	1	1	1	
5-6	3H6-63618-0	COLLAR ｶﾗｰ ﾄﾞﾗﾑ	1	1	1	
5-7	9161E3-0635	BOLT ﾎﾞﾙﾄ	1	1	1	
5-8	3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	1	1	1	
5-9	3AB-63617-0	THROTTLE ROD ｽﾛｯﾄﾙﾛｯﾄﾞ	1	1	1	

Fig. 6 **RECOIL STARTER**
リコイルスタータ




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
6-1	3AB-05090-0	RECOIL STARTER ASSY ﾘｺｲﾙｽﾀｰﾀｱｯｼ	1	1	1	
6-2	3AA-67503-0	* STARTER SEAL * ｽﾀｰﾀｼｰﾙ	1	1	1	
6-3	3AB-05004-0	* STARTER SPRING * ｽﾀｰﾀｽﾌﾟﾘﾝｸﾞ	1	1	1	
6-4	3AB-05104-0	* REEL * ﾘｰﾙ	1	1	1	
6-5	3AB-05013-0	* STARTER ROPE φ3.5-1200 * ｽﾀｰﾀﾛｰﾌﾟ φ3.5-1200	1	1	1	
6-6	3AB-05003-0	* RATCHET * ﾗﾁｪｯﾄ	2	2	2	
6-7	3AB-05012-0	* RETURN SPRING * ﾘﾀｰﾝｽﾌﾟﾘﾝｸﾞ	2	2	2	
6-8	3AB-05006-0	* FRICTION PLATE * ﾌﾘｸｼｮﾝﾌﾟﾚｰﾄ	1	1	1	
6-9	3AB-05138-0	* BOLT * ﾎﾞﾙﾄ	1	1	1	
6-10	3AB-05007-0	* FRICTION SPRING * ﾌﾘｸｼｮﾝｽﾌﾟﾘﾝｸﾞ	1	1	1	
6-11	3AB-05019-0	* STARTER HANDLE * ｽﾀｰﾀﾊﾝﾄﾞﾙ	1	1	1	
6-12	3AB-05131-0	* ROPE ANCHOR * ﾛｰﾌﾟｱﾝｶ	1	1	1	
6-13	3AB-05134-0	* ROPE ANCHOR PLATE * ﾛｰﾌﾟｱﾝｶﾌﾟﾚｰﾄ	1	1	1	
6-14	3GT-60108-0	PRE-COATED BOLT 6-60 ﾌﾟﾚｺｰﾄﾎﾞﾙﾄ 6-60	3	3	3	
6-15	3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	3	3	3	
6-16	398-06972-0	CLAMP 6.5-67P ｸﾗﾝﾌﾟ 6.5-67P	1	1	1	

Fig. 7 MAGNETO
マグネト




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
7-1	3GT-06001-0	FLYWHEEL ﾌﾗｲﾎｲｰﾙ	1	1	1	Mark MF5494
7-2	940121-1000	WASHER ﾜｯｼｬ	1	1	1	
7-3	309-00132-0	NUT 10-P1.25 ﾅｯﾄ 10-P1.25	1	1	1	Magneto
7-4	3GT-06041-0	IGNITER W/R-CAP ｲｸﾞﾅｲﾀ W/R-ｷｬｯﾌﾟ	1	1	1	Mark IU3123
7-5	3H6-06999-0	* PLUG CAP W/RESISTANCE *ﾌﾟﾗｸﾞｷｬｯﾌﾟ W/ﾚｼﾞｽﾀﾝｽ	1	1	1	
7-6	910103-5625	BOLT ﾎﾞﾙﾄ	2	2	2	
7-7	3AB-06300-1	RING GEAR COVER ASSY ﾘﾝｸﾞｷﾞﾔｶﾊﾞｰｱｯｼ	1	1	1	
7-8	3AB-06303-1	COLLAR 6.2-9-35 ｶﾗｰ 6.2-9-35	3	3	3	

Fig. 8 **DRIVE SHAFT HOUSING**
ドライブシャフトハウジング




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
8-1	3ABQ61020-2	DRIVE SHAFT HOUSING ASSY (S) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ (S)	1	1	1	
8-2	3ABQ62001-1	STEERING BRACKET ｽﾃｱﾘﾝｸﾞﾌﾞﾗｹｯﾄ	1	1	1	
8-3	9101E3-5835	BOLT ﾎﾞﾙﾄ	2	2	2	
8-4	345-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	2	
8-5	3AB-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	1	1	1	
8-6	9101E3-5630	BOLT ﾎﾞﾙﾄ	7	7	7	
8-7	9106E3-0808	BOLT ﾎﾞﾙﾄ	1	1	1	
8-8	332-60006-0	GASKET 8.1-15-1 ｶﾞｽｹｯﾄ 8.1-15-1	1	1	1	
8-9	369-61016-0	GROMMET 29-3 ｸﾞﾛﾒｯﾄ 29-3	1	1	1	
8-10	98AB-30-050	HOSE ﾎｰｽ	1	1	1	98AB-301000
8-11	3ABQ61100-0	EXTENSION HOUSING ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞ	1	1	1	for Transom “L”
8-12	3AB-60003-0	DRIVE SHAFT BUSHING ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾌﾞｯｼﾝｸﾞ	1	1	1	for Transom “L”
8-13	3AB-64332-0	STOPPER ｽﾄｯﾊﾟ ﾌﾞｯｼﾝｸﾞ	1	1	1	for Transom “L”
8-14	172-36008-0	GROMMET 13-2 ｸﾞﾛﾒｯﾄ 13-2	1	1	1	for Transom “L”
8-15	9101E3-5612	BOLT ﾎﾞﾙﾄ	2	2	2	for Transom “L”
8-16	3AB-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	1	1	1	for Transom “L”
8-17	3AB-60001-1	BOLT ﾎﾞﾙﾄ	1	1	1	for Transom “L”
8-18	3F0-61101-1	STUD 6-171 ｽﾀｯﾄﾞ 6-171	1	1	1	for Transom “L”
8-19	9301E3-0600	NUT ﾅｯﾄ	1	1	1	for Transom “L”

Fig. 9 SHIFT
シフト




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
9-1	3AB-66214-0	SHIFT ROD (S) ｼﾌﾄﾛｯﾄﾞ (S)	1	1	1	
9-2	940103-0600	WASHER ﾜｯｼｬ	1	1	1	
9-3	951503-0212	SPLIT PIN 2-12 ｽﾌﾟﾘｯﾄﾋﾟﾝ 2-12	1	1	1	
9-4	369-66241-0	SHIFT ROD JOINT ASSY ｼﾌﾄﾛｯﾄﾞｼﾞｮｲﾝﾄｱｯｼ	1	1	1	
9-5	910103-5616	BOLT ﾎﾞﾙﾄ	1	1	1	
9-6	3AB-66130-0	SHIFT LEVER SHAFT ASSY ｼﾌﾄﾚﾊﾞｰｼｬﾌﾄｱｯｼ	1	1	1	
9-7	345-66021-0	O-RING 1.9-6.8 Oﾘﾝｸﾞ 1.9-6.8	2	2	2	
9-8	369-66116-0	CERAMIC BALL 7.7 ｾﾗﾐｯｸﾎﾞｰﾙ 7.7	1	1	1	
9-9	369-66112-1	SPRING ｽﾌﾟﾘﾝｸﾞ ｼﾌﾄﾚﾊﾞｰｽﾄｯﾊﾟ	1	1	1	
9-10	332-61315-0	WASHER 10.5-18-1.5 ﾜｯｼｬ 10.5-18-1.5	1	1	1	
9-11	3AB-66225-0	SHIFT ROD LEVER ｼﾌﾄﾛｯﾄﾞﾚﾊﾞｰ	1	1	1	
9-12	910903-6512	BOLT ﾎﾞﾙﾄ	1	1	1	

Fig. 10 **GEAR CASE**
ギヤケース




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS2B	MFS2.5B	MFS3.5B	
10-1		3BMQ60000-1	GEAR CASE ASSY ｷﾞﾔｹｰｽｱｯｼ	1	1	1	
10-2		3AB-60213-0	* BALL BEARING 6000 *ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6000	1	1	1	
10-3		338-60218-2	* ANODE *ｱﾉｰﾄﾞ	1	1	1	
10-4		910103-0616	* BOLT *ﾎﾞﾙﾄ	1	1	1	
10-5		332-60005-2	PLUG ﾌﾟﾗｸﾞ	2	2	2	
10-6		332-60006-0	GASKET 8.1-15-1 ｶﾞｽｹｯﾄ 8.1-15-1	2	2	2	
10-7		9601-0-6004	BALL BEARING 6004 ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6004	1	1	1	
10-8	1	369-64014-0	SHIM 21-28-0.1 ｼﾑ 21-28-0.1	A	A	A	
10-8	2	369-64015-0	SHIM 21-28-0.15 ｼﾑ 21-28-0.15	A	A	A	
10-9		369-64010-2	BEVEL GEAR ASSY (A) ﾍﾞﾍﾞﾙｷﾞﾔｱｯｼ (A)	1	1	1	
10-10	1	3AB-64306-0	DRIVE SHAFT ASSY (S) ﾄﾞﾗｲﾌﾞｼｬﾌﾄｱｯｼ (S)	1	1	1	for Transom “S”
10-10	2	3AB-64307-0	DRIVE SHAFT ASSY (L) ﾄﾞﾗｲﾌﾞｼｬﾌﾄｱｯｼ (L)	1	1	1	for Transom “L”
10-11		3AB-60213-0	* BALL BEARING 6000 *ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6000	1	1	1	
10-12		3F0-64321-0	SPACER 10.1-15-72 ｽﾍﾟｰｻ 10.1-15-72	1	1	1	
10-13		369-64020-2	BEVEL GEAR B ﾍﾞﾍﾞﾙｷﾞﾔ B	1	1	1	
10-14		3F0-66011-0	CLUTCH CAM ｸﾗｯﾁｶﾑ	1	1	1	
10-15	1	3F0-66012-0	CAM ROD (S) ｶﾑﾛｯﾄﾞ (S)	1	1	1	for Transom “S”
10-15	2	3F0-66013-0	CAM ROD (L) ｶﾑﾛｯﾄﾞ (L)	1	1	1	for Transom “L”
10-16		951407-0308	SPRING PIN 3-8 ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-8	2	2	2	
10-17		3F0-65020-0	PUMP CASE GASKET (LOWER) ﾎﾟﾝﾌﾟｹｰｽｶﾞｽｹｯﾄ (ﾛﾜ)	1	1	1	
10-18		3H2-65040-1	PUMP CASE ASSY (LOWER) ﾎﾟﾝﾌﾟｹｰｽｱｯｼ (ﾛﾜ)	1	1	1	
10-19		3F0-60223-0	* OIL SEAL 10-22-8 *ｵｲﾙｼｰﾙ 10-22-8	1	1	1	
10-20		3B2-65022-0	KEY ｷｰ	2	2	2	
10-21		3F0-65029-0	GUIDE PLATE GASKET ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	1	
10-22		3AB-65025-0	WATER PUMP GUIDE PLATE ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	1	
10-23		3F0-65018-0	PUMP CASE GASKET ﾎﾟﾝﾌﾟｹｰｽｶﾞｽｹｯﾄ	1	1	1	
10-24		369-66021-1	O-RING 2.5-4.9 Oﾘﾝｸﾞ A 2.5-4.9	2	2	2	
10-25		301-66023-0	O-RING 2.4-9.5 Oﾘﾝｸﾞ 2.4-9.5	1	1	1	
10-26		3F0-66031-0	CAM ROD BUSHING ｶﾑﾛｯﾄﾞﾌﾞｯｼﾝｸﾞ	1	1	1	

Fig. 10 GEAR CASE
ギヤケース




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数 MFS2B	 MFS2.5B	 MFS3.5B	Remarks 備 考
10-27		369-65021-1	WATER PUMP IMPELLER ｳｫｰﾀﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ	1	1	1	
10-28		369-65022-0	KEY ｷｰ ﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ	1	1	1	
10-29		3F0-65016-0	PUMP CASE (UPPER) ﾎﾟﾝﾌﾟｹｰｽ (ｱｯﾊﾟ)	1	1	1	
10-30		3F0-65011-0	PUMP CASE LINER ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ	1	1	1	
10-31		3F0-65032-0	GROMMET ｸﾞﾛﾒｯﾄ ｳｫｰﾀﾊﾟｲﾌﾟ (ﾛﾜ)	1	1	1	
10-32		9161E3-0645	BOLT ﾎﾞﾙﾄ	4	4	4	
10-33		940103-0600	WASHER ﾜｯｼｬ	4	4	4	
10-34		941303-0600	SPRING WASHER ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ	4	4	4	
10-35		3F0-64215-0	CLUTCH ｸﾗｯﾁ	1	1	1	
10-36		3F0-64221-0	SPRING ｽﾌﾟﾘﾝｸﾞ ｸﾗｯﾁ	1	1	1	
10-37		3F0-64223-0	PUSH ROD ﾌﾟｯｼｭﾛｯﾄﾞ ｸﾗｯﾁ	1	1	1	
10-38		3F0-64211-0	PROPELLER SHAFT ﾌﾟﾛﾍﾟﾗｼｬﾌﾄ	1	1	1	
10-39		3F0Q87323-1	PROPELLER SHAFT HOUSING ASSY ﾌﾟﾛﾍﾟﾗｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ	1	1	1	
10-40		3F0Q60101-1	* PROPELLER SHAFT HOUSING *ﾌﾟﾛﾍﾟﾗｼｬﾌﾄﾊｳｼﾞﾝｸﾞ	1	1	1	
10-41		9601-0-6001	* BALL BEARING 6001 *ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6001	1	1	1	
10-42		309-60111-0	* OIL SEAL 12-24-8 *ｵｲﾙｼｰﾙ 12-24-8	1	1	1	
10-43		345-65015-0	* O-RING 3.2-47 *Oﾘﾝｸﾞ 3.2-47	1	1	1	
10-44		9101E3-5620	BOLT ﾎﾞﾙﾄ	2	2	2	
10-45		3AB-60001-1	BOLT ﾎﾞﾙﾄ	2	2	2	
10-46	1	3F0-64101-0	PROPELLER ASSY (7″) ﾌﾟﾛﾍﾟﾗｱｯｼ (7″) (ﾌﾟﾗｽﾁｯｸ)	1	1	1	Plastic STD 3×188×178
10-46	2	3F0B64512-0	PROPELLER ASSY (6″) ﾌﾟﾛﾍﾟﾗｱｯｼ (6″) (ｱﾙﾐ)	1	1	1	Aluminum with Rubber Hub OPT 3×188×145
10-46	3	309-64106-0	PROPELLER ASSY (6″) ﾌﾟﾛﾍﾟﾗｱｯｼ (6″) (ﾌﾟﾗｽﾁｯｸ)	1	1	1	Plastic OPT 3×188×145
10-46	4	314-64103-0	PROPELLER ASSY (4.5″) ﾌﾟﾛﾍﾟﾗｱｯｼ (4.5″) (ﾌﾟﾗｽﾁｯｸ)	1	1	1	Plastic OPT 3×188×110
10-47		309-64126-1	SHEAR PIN 4-24 ｼｬｰﾋﾟﾝ 4-24	1	1	1	
10-48		951503-0435	SPLIT PIN 4-35 ｽﾌﾟﾘｯﾄﾋﾟﾝ 4-35	1	1	1	
10-49	1	3AB-65191-0	WATER PIPE ASSY (S) ｳｫｰﾀﾊﾟｲﾌﾟｱｯｼ (S)	1	1	1	for Transom “S”
10-49	2	3AB-65192-0	WATER PIPE ASSY (L) ｳｫｰﾀﾊﾟｲﾌﾟｱｯｼ (L)	1	1	1	for Transom “L”
10-50		3AB-65031-0	* GROMMET *ｸﾞﾛﾒｯﾄ ｳｫｰﾀﾊﾟｲﾌﾟ (ｱｯﾊﾟ)	1	1	1	

Fig. 11 **CLAMP BRACKET・SWIVEL BRACKET**
クランプブラケット・スイベルブラケット




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS2B	MFS2.5B	MFS3.5B	
11-1	3ABQ62111-2	CLAMP BRACKET ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ	1	1	1	
11-2	301-66023-0	O-RING 2.4-9.5 Oﾘﾝｸﾞ 2.4-9.5	1	1	1	
11-3	309-62463-0	KNOB ﾉﾌﾞ ﾁﾙﾄｽﾄｯﾊﾟ	1	1	1	
11-4	3AB-62464-3	TILT STOPPER ﾁﾙﾄｽﾄｯﾊﾟ	1	1	1	
11-5	3ABQ62391-1	SWIVEL BRACKET ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄ A	1	1	1	
11-6	3AB-66334-1	STOPPER ｽﾄｯﾊﾟ	1	1	1	
11-7	3AB-63068-0	LEVER ﾚﾊﾞｰ	1	1	1	
11-8	951403-0212	SPRING PIN 2-12 ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 2-12	1	1	1	
11-9	3AB-66336-0	SPRING ｽﾌﾟﾘﾝｸﾞ	1	1	1	
11-10	9161E3-0650	BOLT ﾎﾞﾙﾄ	1	1	1	
11-11	9401E3-0600	WASHER ﾜｯｼｬ	1	1	1	
11-12	309-62115-2	BOLT 8-122 ﾎﾞﾙﾄ 8-122	1	1	1	
11-13	930403-0800	NYLON NUT 8-P1.25 ﾅｲﾛﾝﾅｯﾄ 8-P1.25	1	1	1	
11-14	307-62116-1	WASHER 8.5-28-1 ﾜｯｼｬ 8.5-28-1	2	2	2	
11-15	309-62118-0	DISTANCE PIECE ﾃﾞｨｽﾀﾝｽﾋﾟｰｽ	1	1	1	
11-16	9301E3-0600	NUT ﾅｯﾄ	2	2	2	
11-17	9401E3-0600	WASHER ﾜｯｼｬ	2	2	2	
11-18	3AB-62212-0	THRUST SUPPORTER ｽﾗｽﾄｻﾎﾟｰﾀ	1	1	1	
11-19	3AB-61336-1	DAMPER (LOWER) ﾀﾞﾝﾊﾟ (ﾛﾜ)	1	1	1	
11-20	3F0-62160-0	THRUST ROD ASSY ｽﾗｽﾄﾛｯﾄﾞｱｯｼ	1	1	1	
11-21	3ABQ62392-1	SWIVEL BRACKET ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄ B	1	1	1	
11-22	309-62441-2	FRICTION PIECE ﾌﾘｸｼｮﾝﾋﾟｰｽ	1	1	1	
11-23	309-62446-1	SPRING ｽﾌﾟﾘﾝｸﾞ ﾌﾘｸｼｮﾝﾌﾟﾚｰﾄ	1	1	1	
11-24	9401E3-0600	WASHER ﾜｯｼｬ	1	1	1	
11-25	309Q62442-2	FRICTION KNOB ﾌﾘｸｼｮﾝﾉﾌﾞ	1	1	1	
11-26	3AB-62321-1	BUSHING ﾌﾞｯｼﾝｸﾞ ﾋﾟﾎﾞｯﾄ	1	1	1	
11-27	393-62416-1	BUSHING ﾌﾞｯｼﾝｸﾞ ｱｯﾊﾟ ｽﾃｱﾘﾝｸﾞ	1	1	1	
11-28	3H6-62325-0	THRUST BUSHING ｽﾗｽﾄﾌﾞｯｼﾝｸﾞ	1	1	1	
11-29	3V1-60001-1	BOLT ﾎﾞﾙﾄ	4	4	4	

Fig. 11 **CLAMP BRACKET・SWIVEL BRACKET**
クランプブラケット・スイベルブラケット




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数 MFS2B	 MFS2.5B	 MFS3.5B	Remarks 備 考
11-30		3GTQ62105-0	CLAMP SCREW KIT ｸﾗﾝﾌﾟｽｸﾘｭｷｯﾄ	2	2	2	
11-31		3GTQ62108-0	* CLAMP SCREW ASSY * ｸﾗﾝﾌﾟｽｸﾘｭｱｯｼ	1	1	1	
11-32		369-62106-0	** CLAMP SCREW ** ｸﾗﾝﾌﾟｽｸﾘｭ	1	1	1	
11-33		3ABQ62102-0	** CLAMP SCREW HANDLE ** ｸﾗﾝﾌﾟｽｸﾘｭﾊﾝﾄﾞﾙ	1	1	1	
11-34		3C8-62104-2	** RIVET 3-22 ** ﾘﾍﾞｯﾄ 3-22	1	1	1	
11-35		332-62101-1	* CLAMP SCREW PAD * ｸﾗﾝﾌﾟｽｸﾘｭﾊﾟｯﾄﾞ	1	1	1	
11-36		3C8-62107-0	* SHOULDER BOLT * ｼｮﾙﾀﾞﾎﾞﾙﾄ	1	1	1	

Fig. 12 TILLER HANDLE
ティラハンドル




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数 MFS2B	 MFS2.5B	 MFS3.5B	Remarks 備 考
12-1		3V1Q63003-4	TILLER HANDLE ASSY ﾃｨﾗﾊﾝﾄﾞﾙｱｯｼ	1	1	1	
12-2		3V1Q63011-3	* TILLER HANDLE * ﾃｨﾗﾊﾝﾄﾞﾙ	1	1	1	
12-3		3H6-63510-0	* BUSHING 14-15.8-7 * ﾌﾞｯｼﾝｸﾞ 14-15.8-7	1	1	1	
12-4		3H6-63048-0	* THROTTLE SHAFT DAMPER * ｽﾛｯﾄﾙｼｬﾌﾄﾀﾞﾝﾊﾟ	1	1	1	
12-5		3V1-63041-0	* THROTTLE SHAFT * ｽﾛｯﾄﾙｼｬﾌﾄ	1	1	1	
12-6		3R3-63012-0	* GRIP * ｸﾞﾘｯﾌﾟ	1	1	1	
12-7		3V9-72019-0	* THROTTLE DECAL * ｽﾛｯﾄﾙﾃﾞｶｰﾙ	1	1	1	
12-8		9208E3-0518	* SCREW * ｽｸﾘｭ	1	1	1	
12-9		3V1-63035-1	* FRICTION PIECE * ﾌﾘｸｼｮﾝﾋﾟｰｽ	1	1	1	
12-10		3V1-63077-0	* ADJUSTING NUT * ｱｼﾞｬｽﾄﾅｯﾄ	1	1	1	
12-11		3V1-63036-0	* SPRING * ｽﾌﾟﾘﾝｸﾞ	1	1	1	
12-12		910103-0625	* BOLT * ﾎﾞﾙﾄ	1	1	1	
12-13		3B2-63063-0	* THROTTLE SHAFT SUPPORT * ｽﾛｯﾄﾙｼｬﾌﾄｻﾎﾟｰﾄ	1	1	1	
12-14		921503-0612	* SCREW * ｽｸﾘｭ	1	1	1	
12-15		3V1-63600-0	THROTTLE WIRE ｽﾛｯﾄﾙﾜｲﾔ	2	2	2	
12-16		3H9-70313-0	FUEL HOSE PROTECTOR ﾌｭｴﾙﾎｰｽﾌﾟﾛﾃｸﾀ	1	1	1	
12-17		3AB-63102-0	BUSHING ﾌﾞｯｼﾝｸﾞ ﾊﾝﾄﾞﾙ	2	2	2	
12-18		3BR-63102-1	BUSHING 32-34-11.8 ﾌﾞｯｼﾝｸﾞ ﾊﾝﾄﾞﾙ 32-34-11.8	2	2	2	
12-19		3AB-63107-0	COVER ｶﾊﾞｰ	1	1	1	
12-20		9101E3-0616	BOLT ﾎﾞﾙﾄ	2	2	2	

Fig. 13 BOTTOM COWL
ボトムカウル




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数 MFS2B	 MFS2.5B	 MFS3.5B	Remarks 備 考
13-1		3ABQ67100-0	BOTTOM COWL ﾎﾞﾄﾑｶｳﾙ	1	1	1	
13-2		3AA-67120-0	COWL LATCH ASSY ｶｳﾙﾗｯﾁｱｯｼ	1	1	1	
13-3		3A0-76079-0	COLLAR 6.2-9-7.4 ｶﾗｰ 6.2-9-7.4	1	1	1	
13-4		9101E3-5616	BOLT ﾎﾞﾙﾄ	1	1	1	
13-5		3AB-67104-0	CHOKE ROD BUSHING ﾁｮｰｸﾛｯﾄﾞﾌﾞｯｼﾝｸﾞ	1	1	1	
13-6		3H6-67151-0	CHOKE ROD ﾁｮｰｸﾛｯﾄﾞ	1	1	1	
13-7		3AB-67197-0	CHOKE WIRE ﾁｮｰｸﾜｲﾔ	1	1	1	
13-8		346-67115-0	WASHER 6.5-21-1 ﾜｯｼｬ 6.5-21-1	1	1	1	
13-9		910103-0612	BOLT ﾎﾞﾙﾄ	1	1	1	
13-10		3GR-06870-0	STOP SWITCH ASSY ｽﾄｯﾌﾟｽｲｯﾁｱｯｼ	1	1	1	
13-11		353-06821-0	* STOP SWITCH LANYARD ASSY * ｽﾄｯﾌﾟｽｲｯﾁﾗﾝﾔｰﾄﾞｱｯｼ	1	1	1	
13-12		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	Ground
13-13		353-06283-0	COLLAR 6.4-10-4.7 ｶﾗｰ 6.4-10-4.7	4	4	4	
13-14		9101E3-0616	BOLT ﾎﾞﾙﾄ	4	4	4	
13-15		3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	4	4	4	
13-16		3H6-72026-0	SPARK PLUG DECAL ｽﾊﾟｰｸﾌﾟﾗｸﾞﾃﾞｶｰﾙ	1	1	1	DCPR6E
13-17		3BN-67578-0	SHIFT DECAL (F-N) ｼﾌﾄﾃﾞｶｰﾙ (F-N)	1	1	1	N ⇔ F
13-18		3AB-72024-2	FUEL LEVER DECAL ﾌｭｴﾙﾚﾊﾞｰﾃﾞｶｰﾙ	1	1	1	OFF - ON
13-19		3GT-72046-0	OIL LEVEL DECAL ｵｲﾙﾚﾍﾞﾙﾃﾞｶｰﾙ	1	1	1	Lower
13-20		3AB-67572-0	STORAGE DECAL ｽﾄﾚｰｼﾞﾃﾞｶｰﾙ	1	1	1	↑ Up

Fig. 14 TOP COWL
トップカウル




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS2B	MFS2.5B	MFS3.5B	
14-1		3ABQ67645-2	TOP COWL ASSY ﾄｯﾌﾟｶｳﾙｱｯｼ	1	1	1	
14-2		3ABQ67521-2	* TILT HANDLE * ﾁﾙﾄﾊﾝﾄﾞﾙ	1	1	1	
14-3		940103-0600	* WASHER * ﾜｯｼｬ	4	4	4	
14-4		941303-0600	* SPRING WASHER * ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ	4	4	4	
14-5		930103-0600	* NUT * ﾅｯﾄ	4	4	4	
14-6		3GT-67501-0	* TOP COWL SEAL L=1100 * ﾄｯﾌﾟｶｳﾙｼｰﾙ L=1100	1	1	1	
14-7	1	3BV-87801-2	* DECAL SET MFS2B * ﾃﾞｶｰﾙｾｯﾄ (MFS2B)	1			2ps
14-7	2	3AB-87801-2	* DECAL SET MFS2.5B * ﾃﾞｶｰﾙｾｯﾄ (MFS2.5B)		1		2.5ps
14-7	3	3BR-87801-2	* DECAL SET MFS3.5B * ﾃﾞｶｰﾙｾｯﾄ (MFS3.5B)			1	3.5ps
14-8		3R0-72180-0	CAUTION DECAL (A) ｺｰｼｮﾝﾃﾞｶｰﾙ (A)	1	1	1	

Fig. 15 FUEL TANK
フュエルタンク




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS2B	MFS2.5B	MFS3.5B	
15-1	1	3GT-70310-0	FUEL TANK ASSY ﾌｭｴﾙﾀﾝｸｱｯｼ		1	1	Low Permeation Parts EPA-YZK-YK3 USA
15-1	2	3AB-70310-2	FUEL TANK ASSY ﾌｭｴﾙﾀﾝｸｱｯｼ	1	1	1	STD
15-2		3AB-06846-1	COVER ｶﾊﾞｰ ﾌｪﾙﾀﾝｸ	1	1	1	
15-3		3T5-76079-0	COLLAR 6.2-9-10.7 ｶﾗｰ 6.2-9-10.7	3	3	3	
15-4		3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	3	3	3	
15-5		9101E3-0625	BOLT ﾎﾞﾙﾄ	3	3	3	
15-6		369-70311-0	FUEL COCK ASSY ﾌｭｴﾙｺｯｸｱｯｼ	1	1	1	
15-7		3GT-70326-0	FUEL HOSE 155-20-20 ﾌｭｴﾙﾎｰｽ 155-20-20	1	1	1	Fuel Tank Valve - Carburetor STD
15-8		3GT-02161-0	FUEL HOSE W/PROTECTOR L=390 ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ L=390		1	1	Fuel Pump - Carburetor EPA-KRI-15G USA
15-9		3GT-02165-0	FUEL HOSE W/PROTECTOR L=340 ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ L=340		1	1	Fuel Tank Valve - Fuel Pump EPA-KRI-15G USA
15-10		3AB-35143-0	CLIP φ9.4 ｸﾘｯﾌﾟ φ9.4	2	2	2	
15-11		3GT-70325-0	FUEL HOSE L=215 ﾌｭｴﾙﾎｰｽ L=215	1	1	1	Fuel Tank - Fuel Tank Valve STD
15-12		3GT-02175-0	FUEL HOSE W/PROTECTOR L=215 ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ L=215		1	1	Fuel Tank - Fuel Tank Valve EPA-KRI-15G USA
15-13		3AB-02215-1	CLIP φ15 ｸﾘｯﾌﾟ φ15	2	2	2	
15-14		3GT-70062-0	FUEL COCK KNOB ﾌｭｴﾙｺｯｸﾉﾌﾞ	1	1	1	
15-15		3G9-66136-0	O-RING 2-10 Oﾘﾝｸﾞ 2-10	1	1	1	
15-16		369-70063-0	SEAL RING ｼｰﾙﾘﾝｸﾞ ﾌｭｴﾙｺｯｸﾛｯﾄﾞﾉﾌﾞ	1	1	1	
15-17		3AB-72183-0	CAUTION TAG (B) ｺｰｼｮﾝﾀｸﾞ (B)	1	1	1	
15-18		3AB-70036-1	FUEL TANK SEAL ﾌｭｴﾙﾀﾝｸｼｰﾙ	1	1	1	
15-19		3GT-70321-0	FUEL TANK CAP ASSY ﾌｭｴﾙﾀﾝｸｷｬｯﾌﾟｱｯｼ		1	1	Low Permeation Parts EPA-ITX-DRN USA
15-20		3R6-70320-1	FUEL TANK CAP ASSY ﾌｭｴﾙﾀﾝｸｷｬｯﾌﾟｱｯｼ	1	1	1	STD
15-21		309-70021-3	* TANK FILLER CAP GASKET * ﾀﾝｸﾌｨﾗｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	1	STD
15-22		3C8-71017-0	* CAP HOOK * ｷｬｯﾌﾟﾌｯｸ ﾀﾝｸ	1	1	1	STD

Fig. 16 OPTIONAL PARTS (ACCESSORIES)
オプショナルパーツ（アクセサリ）




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS2B	MFS2.5B	MFS3.5B	
16-1		3BJ-72100-0	TOOL KIT ツールキット	1	1	1	
16-2		312-72201-0	SAFETY ROPE φ4-1000 セーフティロープ φ4-1000	1	1	1	
16-3		336-60007-0	FLUSHING PLUG フラッシングプラグ	1	1	1	
16-4	1	3GU-10230-0	ALTITUDE ADJUSTMENT KIT 高地補正キット		1		2.5ps
16-4	2	3GV-10230-0	ALTITUDE ADJUSTMENT KIT 高地補正キット			1	3.5ps

Fig. 17 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数 MFS2B	MFS2.5B	MFS3.5B	Remarks 備 考
17-1	1	3BMQ87301-1	LOWER UNIT ASSY (S) ﾛﾜﾕﾆｯﾄｱｯｼ (S)	1	1	1	for Transom "S"
17-1	2	3BMQ87302-1	LOWER UNIT ASSY (L) ﾛﾜﾕﾆｯﾄｱｯｼ (L)	1	1	1	for Transom "L"
17-2		3GTB87090-3	ENGINE SHORT BLOCK KIT ｴﾝｼﾞﾝｼｮｰﾄﾌﾞﾛｯｸｷｯﾄ	1	1	1	
17-3	1	3GT-87122-0	CARBURETOR REPAIR KIT ｷｬﾌﾞﾚﾀﾘﾍﾟｱｷｯﾄ	1	1	1	
17-3	2	3GT-03231-0	* FLOAT * ﾌﾛｰﾄ	1	1	1	
17-3	3	3H6-03240-0	* FLOAT VALVE * ﾌﾛｰﾄﾊﾞﾙﾌﾞ	1	1	1	
17-3	4	3H6-03244-0	* CLIP * ｸﾘｯﾌﾟ	1	1	1	
17-3	5	3H6-03232-0	* FLOAT ARM PIN * ﾌﾛｰﾄｱｰﾑﾋﾟﾝ	1	1	1	
17-3	6	3H6-03222-0	* FLOAT CHAMBER O-RING * ﾌﾛｰﾄﾁｬﾝﾊﾞｰOﾘﾝｸﾞ	1	1	1	
17-3	7	922503-6412	* SCREW * ｽｸﾘｭ	2	2	2	
17-3	8	3H6-03293-0	* O-RING * Oﾘﾝｸﾞ ﾄﾞﾚﾝｽｸﾘｭ	1	1	1	
17-4	1	3AB-87121-0	POWER HEAD GASKET SET ﾊﾟﾜｰﾍｯﾄﾞｶﾞｽｹｯﾄｾｯﾄ	1	1	1	
17-4	2	3AB-01024-1	* CYLINDER HEAD COVER GASKET * ｼﾘﾝﾀﾞｰﾍｯﾄﾞｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	1	
17-4	3	3AB-01032-0	* THERMOSTAT CAP GASKET * ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	1	
17-4	4	3AB-07432-0	* GASKET * ｶﾞｽｹｯﾄ ﾌﾞﾘｰｻﾞﾁｬﾝﾊﾞｰｶﾊﾞｰ	1	1	1	
17-4	5	3AB-00121-0	* OIL SEAL 20-35-7 * ｵｲﾙｼｰﾙ 20-35-7	2	2	2	
17-4	6	3H6-03293-0	* O-RING * Oﾘﾝｸﾞ ﾄﾞﾚﾝｽｸﾘｭ	1	1	1	
17-4	7	3H6-02011-0	* CARBURETOR GASKET * ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ	1	1	1	
17-4	8	3AB-02104-0	* INTAKE MANIFOLD GASKET * ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｶﾞｽｹｯﾄ	1	1	1	
17-4	9	3AB-07402-0	* OILPAN GASKET * ｵｲﾙﾊﾟﾝｶﾞｽｹｯﾄ	1	1	1	
17-4	10	3R0-07422-0	* O-RING 3.1-24.4 * Oﾘﾝｸﾞ 3.1-24.4	1	1	1	
17-4	11	3AB-01215-0	* OIL SEAL 10.1-20-7 * ｵｲﾙｼｰﾙ 10.1-20-7	2	2	2	
17-4	12	3V1-02012-0	* O-RING 2.4-35.2 * Oﾘﾝｸﾞ 2.4-35.2	1	1	1	
17-4	13	3AB-61012-0	* DRIVE SHAFT HOUSING GASKET * ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾞｽｹｯﾄ	1	1	1	
17-5	1	3AB-87322-0	WATER PUMP REPAIR KIT ｳｫｰﾀﾎﾟﾝﾌﾟﾘﾍﾟｱｷｯﾄ	1	1	1	
17-5	2	369-65021-1	* WATER PUMP IMPELLER * ｳｫｰﾀﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ	1	1	1	
17-5	3	369-65022-0	* KEY * ｷｰ ﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ	1	1	1	
17-5	4	3F0-65011-0	* PUMP CASE LINER * ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ	1	1	1	
17-5	5	3F0-65018-0	* PUMP CASE GASKET * ﾎﾟﾝﾌﾟｹｰｽｶﾞｽｹｯﾄ	1	1	1	

Fig. 17 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ



Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS2B	MFS2.5B	MFS3.5B	
17-5	6	3AB-65025-0	* WATER PUMP GUIDE PLATE * ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	1	
17-5	7	3F0-65029-0	* GUIDE PLATE GASKET * ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	1	
17-6	1	3F0-87321-0	LOWER UNIT GASKET SET ﾛﾜﾕﾆｯﾄｶﾞｽｹｯﾄｾｯﾄ	1	1	1	
17-6	2	332-60006-0	* GASKET 8.1-15-1 * ｶﾞｽｹｯﾄ 8.1-15-1	2	2	2	
17-6	3	369-65021-1	* WATER PUMP IMPELLER * ｳｫｰﾀﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ	1	1	1	
17-6	4	369-65022-0	* KEY * ｷｰ ﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ	1	1	1	
17-6	5	3F0-65018-0	* PUMP CASE GASKET * ﾎﾟﾝﾌﾟｹｰｽｶﾞｽｹｯﾄ	1	1	1	
17-6	6	3F0-65029-0	* GUIDE PLATE GASKET * ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	1	
17-6	7	3F0-60223-0	* OIL SEAL 10-22-8 * ｵｲﾙｼｰﾙ 10-22-8	1	1	1	
17-6	8	3F0-65020-0	* PUMP CASE GASKET (LOWER) * ﾎﾟﾝﾌﾟｹｰｽｶﾞｽｹｯﾄ (ﾛﾜ)	1	1	1	
17-6	9	309-60111-0	* OIL SEAL 12-24-8 * ｵｲﾙｼｰﾙ 12-24-8	1	1	1	
17-6	10	345-65015-0	* O-RING 3.2-47 * Oﾘﾝｸﾞ 3.2-47	1	1	1	
17-6	11	369-66021-1	* O-RING 2.5-4.9 * Oﾘﾝｸﾞ A 2.5-4.9	1	1	1	
17-6	12	301-66023-0	* O-RING 2.4-9.5 * Oﾘﾝｸﾞ 2.4-9.5	1	1	1	
17-7	1	3ABQ87312-0	EXTENSION HOUSING KIT (L) ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞｷｯﾄ (L)	1	1	1	for Transom “S”⇒“L”
17-7	2	3ABQ61100-0	* EXTENSION HOUSING * ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞ	1	1	1	
17-7	3	3AB-60003-0	* DRIVE SHAFT BUSHING * ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾌﾞｯｼﾝｸﾞ	1	1	1	
17-7	4	3AB-64332-0	* STOPPER * ｽﾄｯﾊﾟ ﾌﾞｯｼﾝｸﾞ	1	1	1	
17-7	5	172-36008-0	* GROMMET 13-2 * ｸﾞﾛﾒｯﾄ 13-2	1	1	1	
17-7	6	9101E3-5612	* BOLT * ﾎﾞﾙﾄ	2	2	2	
17-7	7	3F0-61101-1	* STUD 6-171 * ｽﾀｯﾄﾞ 6-171	1	1	1	
17-7	8	3AB-60001-1	* BOLT * ﾎﾞﾙﾄ	1	1	1	
17-7	9	9301E3-0600	* NUT * ﾅｯﾄ	1	1	1	
17-7	10	3AB-64307-0	* DRIVE SHAFT ASSY (L) * ﾄﾞﾗｲﾌﾞｼｬﾌﾄｱｯｼ (L)	1	1	1	
17-7	11	3F0-66013-0	* CAM ROD (L) * ｶﾑﾛｯﾄﾞ (L)	1	1	1	
17-7	12	951407-0308	* SPRING PIN 3-8 * ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-8	2	2	2	
17-7	13	3AB-65192-0	* WATER PIPE ASSY (L) * ｳｫｰﾀﾊﾟｲﾌﾟｱｯｼ (L)	1	1	1	
17-7	14	3AB-01111-0	* DOWEL PIN 6-12 * ﾀﾞｳｪﾙﾋﾟﾝ 6-12	1	1	1	
17-8	1	3GT-87130-0	PISTON REPAIR KIT ﾋﾟｽﾄﾝﾘﾍﾟｱｷｯﾄ	1	1	1	

Fig. 17 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ



Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS2B	MFS2.5B	MFS3.5B	
17-8	2	3AB-00001-1	＊PISTON ＊ﾋﾟｽﾄﾝ	1	1	1	
17-8	3	332-00021-1	＊PISTON PIN ＊ﾋﾟｽﾄﾝﾋﾟﾝ	1	1	1	
17-8	4	350-00024-1	＊PISTON PIN CLIP ＊ﾋﾟｽﾄﾝﾋﾟﾝｸﾘｯﾌﾟ	2	2	2	

索引

<O>

Oリング 1.9-6.8 9-7
Oリング 2.4-35.2 3-16
Oリング 2.4-35.2 17-4-12
Oリング 2.4-9.5 10-25
Oリング 2.4-9.5 11-2
Oリング 2.4-9.5 17-6-12
Oリング 2-10 15-15
Oリング 3.1-24.4 1-9
Oリング 3.1-24.4 17-4-10
Oリング 3.2-47 10-43
Oリング 3.2-47 17-6-10
Oリング A 2.5-4.9 10-24
Oリング A 2.5-4.9 17-6-11
Oリング ドレンスクリュ 4-20
Oリング ドレンスクリュ 17-3-8
Oリング ドレンスクリュ 17-4-6

<ア>

アジャストナット 1-23
アジャストナット 12-10
アノード 10-3

<イ>

イグナイタ W/R-キャップ 7-4
インシュレータ 4-26
インテークサイレンサ 4-27
インテークバルブ 1-11
インテークバルブステムシール 1-2
インテークマニホールド 4-1
インテークマニホールドアッシ 4-2
インテークマニホールドガスケット 4-6
インテークマニホールドガスケット 17-4-8

<ウ>

ウォータパイプアッシ (L) 10-49-2
ウォータパイプアッシ (L) 17-7-13
ウォータパイプアッシ (S) 10-49-1
ウォータポンプインペラ 10-27
ウォータポンプインペラ 17-5-2
ウォータポンプインペラ 17-6-3
ウォータポンプガイドプレート 10-22
ウォータポンプガイドプレート 17-5-6
ウォータポンプリペアキット 17-5-1

<エ>

エキゾーストバルブ 1-12
エキゾーストバルブステムシール 1-3
エクステンションハウジング 8-11
エクステンションハウジング 17-7-2
エクステンションハウジングキット (L) 17-7-1
エンジンショートブロックキット 17-2

<オ>

オイルサイトゲージ 3-2
オイルシール 10.1-20-7 3-15
オイルシール 10.1-20-7 17-4-11
オイルシール 10-22-8 10-19
オイルシール 10-22-8 17-6-7
オイルシール 12-24-8 10-42
オイルシール 12-24-8 17-6-9
オイルシール 20-35-7 2-4
オイルシール 20-35-7 17-4-5
オイルパンアッシ 3-1
オイルパンガスケット 3-6
オイルパンガスケット 17-4-9
オイルフィラキャップ 1-8
オイルレベルデカール 13-19

<カ>

ガイドプレートガスケット 10-21
ガイドプレートガスケット 17-5-7
ガイドプレートガスケット 17-6-6
カウルラッチアッシ 13-2
ガスケット 8.1-15-1 8-8
ガスケット 8.1-15-1 10-6
ガスケット 8.1-15-1 17-6-2
ガスケット ブリーザチャンバーカバー 17-4-4
ガスケット ブリーザチャンバカバー 1-35
カバー 12-19
カバー フェルタンク 15-2
カムシャフトアッシ 1-10
カムロッド (L) 10-15-2
カムロッド (L) 17-7-11
カムロッド (S) 10-15-1
カムロッドブッシング 10-26
カラー 6.2-9-10.7 15-3
カラー 6.2-9-35 7-8
カラー 6.2-9-7 4-30
カラー 6.2-9-7.4 3-9
カラー 6.2-9-7.4 4-29
カラー 6.2-9-7.4 13-3
カラー 6.4-10-4.7 13-13
カラー ドラム 5-6

<キ>

キー 10-20
キー ポンプインペラ 10-28
キー ポンプインペラ 17-5-3
キー ポンプインペラ 17-6-4
キー マグネト 2-10
ギヤケースアッシ 10-1
キャップフック タンク 15-22
キャブレタアッシ 4-8-1
キャブレタアッシ 4-8-2
キャブレタアッシ 4-8-3
キャブレタガスケット 4-25
キャブレタガスケット 17-4-7
キャブレタリペアキット 17-3-1

<ク>

クラッチ 10-35
クラッチカム 10-14
クランクケースヘッド 3-14
クランクシャフトアッシ W/ギヤ 2-1
クランプ 6.5-67P 1-32
クランプ 6.5-67P 5-2
クランプ 6.5-67P 6-16
クランプスクリュ 11-32
クランプスクリュアッシ 11-31
クランプスクリュキット 11-30
クランプスクリュパッド 11-35
クランプスクリュハンドル 11-33
クランプブラケット 11-1
クリップ 4-14
クリップ 17-3-4
グリップ 12-6
クリップ φ12 4-5
クリップ φ15 15-13
クリップ φ9.4 15-10
クリップ フュエルパイプ φ10 3-12
クリップ フュエルパイプ φ10 4-40
グロメット 13-2 8-14
グロメット 13-2 17-7-5
グロメット 29-3 8-9
グロメット ウォータパイプ (アッパ) 10-50
グロメット ウォータパイプ (ロワ) 10-31

<ケ>

ケーブルホルダ 4-33

<コ>

高地補正キット 16-4-1
高地補正キット 16-4-2
コーションタグ (B) 15-17
コーションデカール (A) 14-8
コッタ 1-15
コンロッドアッシ 2-5
コンロッドボルト 2-6

<サ>

サーモスタット 1-28
サーモスタットキャップ 1-29
サーモスタットキャップ 1-30
サーモスタットキャップガスケット 1-31
サーモスタットキャップガスケット 17-4-3

<シ>

シールリング フュエルコックロッドノブ 15-16
シフトデカール (F-N) 13-17
シフトレバーシャフトアッシ 9-6
シフトロッド (S) 9-1
シフトロッドジョイントアッシ 9-4
シフトロッドレバー 9-11
シム 21-28-0.1 10-8-1
シム 21-28-0.15 10-8-2
シャーピン 4-24 10-47
ショルダボルト 11-36
シリンダブロック&クランクケースアッシ 1-1
シリンダヘッドカバー 1-24

シリンダヘッドカバーガスケット 1-25
シリンダヘッドカバーガスケット 17-4-2
<ス>
スイベルブラケット A..... 11-5
スイベルブラケット B..... 11-21
スクリュ..... 4-18
スクリュ..... 12-8
スクリュ..... 12-14
スクリュ..... 17-3-7
スタータシール..... 6-2
スタータスプリング..... 6-3
スタータハンドル..... 6-11
スタータロープ φ3.5-1200..... 6-5
スタッド 6-171..... 8-18
スタッド 6-171..... 17-7-7
ステアリングブラケット 8-2
ストッパ..... 11-6
ストッパ ブッシング 8-13
ストッパ ブッシング 17-7-4
ストップスイッチアッシ 13-10
ストップスイッチランヤードアッシ 13-11
ストップスクリュ..... 4-21
ストレージデカール..... 13-20
スパークプラグ (DCPR6E) 1-38
スパークプラグデカール 13-16
スパイラルチューブプロテクタ φ10-100..... 4-4
スプリットピン 2-12..... 9-3
スプリットピン 4-35 10-48
スプリング 11-9
スプリング 12-11
スプリング クラッチ 10-36
スプリング シフトレバーストッパ..... 9-9
スプリング ストップスクリュ 4-22
スプリング フリクションプレート..... 11-23
スプリングピン 2-12..... 11-8
スプリングピン 3-8 10-16
スプリングピン 3-8 17-7-12
スプリングワッシャ..... 10-34
スプリングワッシャ..... 14-4
スペーサ 10.1-15-72..... 10-12
スラストサポータ..... 11-18
スラストブッシング..... 11-28
スラストプレート 20.2-32-1..... 2-3
スラストロッドアッシ 11-20
スリンガ..... 1-37
スローエアジェット (#115)..... 4-11-1
スローエアジェット (#125)..... 4-11-2
スロットルオープナ..... 5-5
スロットルシャフト..... 12-5
スロットルシャフトサポート..... 12-13
スロットルシャフトダンパ..... 12-4
スロットルデカール..... 12-7
スロットルドラム..... 5-4
スロットルロッド..... 5-9
スロットルワイヤ..... 12-15
スロットルワイヤブラケット..... 5-1
<セ>
セーフティロープ φ4-1000 16-2
セラミックボール 7.7 9-8
<タ>
ダウェルピン 6-12 1-4
ダウェルピン 6-12 3-3
ダウェルピン 6-12 8-4
ダウェルピン 6-12 8-5
ダウェルピン 6-12 8-16
ダウェルピン 6-12 17-7-14
タンクフィラキャップガスケット 15-21
ダンパ (ロワ)..... 11-19
<チ>
チョークロッド..... 13-6
チョークロッドブッシング..... 13-5
チョークワイヤ..... 13-7
チルトストッパ..... 11-4
チルトハンドル..... 14-2
<ツ>
ツールキット 16-1
<テ>
ディスタンスピース..... 11-15
ティラハンドル..... 12-2
ティラハンドルアッシ 12-1
デカールセット (MFS2.5B)..... 14-7-2
デカールセット (MFS2B) 14-7-1
デカールセット (MFS3.5B)..... 14-7-3
<ト>
トップカウルアッシ..... 14-1
トップカウルシール L=1100..... 14-6
ドライブシャフトアッシ (L)..... 10-10-2
ドライブシャフトアッシ (L)..... 17-7-10
ドライブシャフトアッシ (S)..... 10-10-1
ドライブシャフトハウジングアッシ (S)..... 8-1
ドライブシャフトハウジングガスケット..... 3-13
ドライブシャフトハウジングガスケット..... 17-4-13
ドライブシャフトブッシング..... 8-12
ドライブシャフトブッシング..... 17-7-3
ドレンスクリュ 4-19
ドレンボルト 10-14 P1.25 3-4
<ナ>
ナイロンナット 8-P1.25 11-13
ナット..... 4-35
ナット..... 8-19
ナット..... 11-16
ナット..... 14-5
ナット..... 17-7-9
ナット 10-P1.25..... 7-3
<ノ>
ノブ チルトストッパ..... 11-3
<ハ>
パイロットスクリュ..... 4-24-1
パイロットスクリュ..... 4-24-2
バルブスプリング L=35 1-13
バルブスプリングシート 1-16
パワーヘッドガスケットセット 17-4-1
<ヒ>
ピストン..... 2-7
ピストン..... 17-8-2
ピストンピン 2-8
ピストンピン 17-8-3
ピストンピンクリップ 2-9
ピストンピンクリップ 17-8-4
ピストンリペアキット 17-8-1
ピストンリング..... 2-12
ピストンリング..... 2-13
ピストンリング オイル..... 2-14
ピストンリングセット 2-11
ピボット ロッカアーム..... 1-22
ピボットボルト 1-20
<フ>
プッシュロッド..... 1-18
プッシュロッド クラッチ..... 10-37
ブッシング 14-15.8-7..... 12-3
ブッシング アッパ ステアリング 11-27
ブッシング ハンドル..... 12-17
ブッシング ハンドル 32-34-11.8..... 12-18
ブッシング ピボット 11-26
フュエルコックアッシ 15-6
フュエルコックノブ..... 15-14
フュエルタンクアッシ 15-1-1
フュエルタンクアッシ 15-1-2
フュエルタンクキャップアッシ 15-19
フュエルタンクキャップアッシ 15-20
フュエルタンクシール 15-18
フュエルホース 155-20-20 15-7
フュエルホース L=215 15-11
フュエルホース W/プロテクタ L=215..... 15-12
フュエルホース W/プロテクタ L=340..... 15-9
フュエルホース W/プロテクタ L=390..... 15-8
フュエルホースプロテクタ..... 12-16
フュエルポンプアッシ 4-38
フュエルレバーデカール..... 13-18
フライホイール..... 7-1
プラグ..... 10-5
プラグキャップ W/レジスタンス 7-5
ブラケット ストッパ..... 3-8
フラッシングプラグ..... 16-3
ブリーザチャンバカバー 1-34
ブリーザホース..... 4-37
フリクションスプリング 6-10
フリクションノブ..... 11-25
フリクションピース..... 11-22
フリクションピース..... 12-9
フリクションプレート 6-8
プレート プッシュロッド..... 1-19
フレームアレスタ..... 4-28
プレコートボルト 6-60..... 6-14
フロート..... 4-12
フロート..... 17-3-2

フロートアームピン..... 4-15
フロートアームピン..... 17-3-5
フロートチャンバ..... 4-16
フロートチャンバOリング..... 4-17
フロートチャンバOリング..... 17-3-6
フロートバルブ..... 4-13
フロートバルブ..... 17-3-3
プロペラアッシ (4.5") (プラスチック) 10-46-4
プロペラアッシ (6") (アルミ)..... 10-46-2
プロペラアッシ (6") (プラスチック) 10-46-3
プロペラアッシ (7") (プラスチック) 10-46-1
プロペラシャフト..... 10-38
プロペラシャフトハウジング..... 10-40
プロペラシャフトハウジングアッシ 10-39
<ヘ>
ベベルギヤ B..... 10-13
ベベルギヤアッシ (A) 10-9
<ホ>
ホース..... 3-11
ホース..... 4-3
ホース..... 4-36
ホース..... 8-10
ボールベアリング 6000 10-2
ボールベアリング 6000 10-11
ボールベアリング 6001 10-41
ボールベアリング 6004 10-7
ボールベアリング 6204 2-2
ボトムカウル 13-1
ボルト..... 1-5
ボルト..... 1-6
ボルト..... 1-26
ボルト..... 1-33
ボルト..... 1-36
ボルト..... 3-7
ボルト..... 3-10
ボルト..... 3-17
ボルト..... 4-7
ボルト..... 4-31
ボルト..... 4-34
ボルト..... 4-39
ボルト..... 5-3
ボルト..... 5-7
ボルト..... 6-9
ボルト..... 7-6
ボルト..... 8-3
ボルト..... 8-6
ボルト..... 8-7
ボルト..... 8-15
ボルト..... 8-17
ボルト..... 9-5
ボルト..... 9-12
ボルト..... 10-4
ボルト..... 10-32
ボルト..... 10-44
ボルト..... 10-45
ボルト..... 11-10
ボルト..... 11-29
ボルト..... 12-12
ボルト..... 12-20
ボルト..... 13-4
ボルト..... 13-9
ボルト..... 13-12
ボルト..... 13-14
ボルト..... 15-5
ボルト..... 17-7-6
ボルト..... 17-7-8
ボルト 8-122..... 11-12
ポンプケース (アッパ)..... 10-29
ポンプケースアッシ (ロワ) 10-18
ポンプケースガスケット 10-23
ポンプケースガスケット 17-5-5
ポンプケースガスケット 17-6-5
ポンプケースガスケット (ロワ)..... 10-17
ポンプケースガスケット (ロワ)..... 17-6-8
ポンプケースライナ..... 10-30
ポンプケースライナ..... 17-5-4
<メ>
メインジェット (#58) 4-10-1
メインジェット (#65) 4-10-2
メインジェット (#68) 4-10-3
メインノズル 4-9-1
メインノズル 4-9-2
メインノズル 4-9-3
<ラ>
ラチェット 6-6
ラバーキャップ..... 4-23
<リ>
リール..... 6-4
リコイルスタータアッシ 6-1
リターンスプリング..... 6-7
リテーナ..... 1-14
リフタ 1-17
リベット 3-22..... 11-34
リングギヤカバーアッシ 7-7
<レ>
レバー..... 11-7
<ロ>
ロープアンカ 6-12
ロープアンカプレート 6-13
ロッカアーム 1-21
ロワユニットアッシ (L)..... 17-1-2
ロワユニットアッシ (S)..... 17-1-1
ロワユニットガスケットセット 17-6-1
<ワ>
ワッシャ..... 1-7
ワッシャ..... 4-32
ワッシャ..... 7-2
ワッシャ..... 9-2
ワッシャ..... 10-33
ワッシャ..... 11-11
ワッシャ..... 11-17
ワッシャ..... 11-24
ワッシャ..... 14-3
ワッシャ 10.2-19-1..... 3-5
ワッシャ 10.5-18-1.5 9-10
ワッシャ 6.5-21-1 13-8
ワッシャ 6-16-1.5 1-27
ワッシャ 6-16-1.5 5-8
ワッシャ 6-16-1.5 6-15
ワッシャ 6-16-1.5 13-15
ワッシャ 6-16-1.5 15-4
ワッシャ 8.5-28-1 11-14

INDEX

<A>
ADJUSTING NUT 1-23
ADJUSTING NUT 12-10
ALTITUDE ADJUSTMENT KIT 16-4-1
ALTITUDE ADJUSTMENT KIT 16-4-2
ANODE 10-3
<B>
BALL BEARING 6000.....10-2
BALL BEARING 6000.....10-11
BALL BEARING 6001.....10-41
BALL BEARING 6004.....10-7
BALL BEARING 6204.....2-2
BEVEL GEAR ASSY (A).....10-9
BEVEL GEAR B.....10-13
BOLT 1-5
BOLT 1-6
BOLT 1-26
BOLT 1-33
BOLT 1-36
BOLT 3-7
BOLT 3-10
BOLT 3-17
BOLT 4-7
BOLT 4-31
BOLT 4-34
BOLT 4-39
BOLT 5-3
BOLT 5-7
BOLT 6-9
BOLT 7-6
BOLT 8-3
BOLT 8-6
BOLT 8-7
BOLT 8-15
BOLT 8-17
BOLT 9-5
BOLT 9-12
BOLT 10-4
BOLT 10-32
BOLT 10-44
BOLT 10-45
BOLT 11-10
BOLT 11-29
BOLT 12-12
BOLT 12-20
BOLT 13-4
BOLT 13-9
BOLT 13-12
BOLT 13-14
BOLT 15-5
BOLT 17-7-6
BOLT 17-7-8
BOLT 8-122 11-12
BOTTOM COWL 13-1
BRACKET.....3-8
BREATHER CHAMBER COVER 1-34
BREATHER HOSE 4-37
BUSHING 11-26
BUSHING 11-27
BUSHING 12-17
BUSHING 14-15.8-7 12-3
BUSHING 32-34-11.8 12-18
<C>
CABLE HOLDER 4-33
CAM ROD (L).....10-15-2
CAM ROD (L).....17-7-11
CAM ROD (S).....10-15-1
CAM ROD BUSHING.....10-26
CAMSHAFT ASSY.....1-10
CAP HOOK.....15-22
CARBURETOR ASSY 4-8-1
CARBURETOR ASSY 4-8-2
CARBURETOR ASSY 4-8-3
CARBURETOR GASKET.....4-25
CARBURETOR GASKET.....17-4-7
CARBURETOR REPAIR KIT 17-3-1
CAUTION DECAL (A).....14-8
CAUTION TAG (B) 15-17
CERAMIC BALL 7.7 9-8
CHOKE ROD.....13-6
CHOKE ROD BUSHING.....13-5
CHOKE WIRE.....13-7
CLAMP 6.5-67P 1-32
CLAMP 6.5-67P 5-2
CLAMP 6.5-67P 6-16
CLAMP BRACKET.....11-1
CLAMP SCREW.....11-32
CLAMP SCREW ASSY 11-31
CLAMP SCREW HANDLE.....11-33
CLAMP SCREW KIT 11-30
CLAMP SCREW PAD 11-35
CLIP 4-14
CLIP 17-3-4
CLIP φ10 3-12
CLIP φ10 4-40
CLIP φ12 4-5
CLIP φ15 15-13
CLIP φ9.4.....15-10
CLUTCH 10-35
CLUTCH CAM 10-14
COLLAR.....5-6
COLLAR 6.2-9-10.7 15-3
COLLAR 6.2-9-35 7-8
COLLAR 6.2-9-7 4-30
COLLAR 6.2-9-7.4 3-9
COLLAR 6.2-9-7.4 4-29
COLLAR 6.2-9-7.4 13-3
COLLAR 6.4-10-4.7 13-13
CONNECTING ROD ASSY 2-5
CONNECTING ROD BOLT 2-6
COTTER.....1-15
COVER.....12-19
COVER.....15-2
COWL LATCH ASSY.....13-2
CRANKCASE HEAD 3-14
CRANKSHAFT ASSY W/GEAR.....2-1
CYL BLOCK & CRANKCASE ASSY 1-1
CYLINDER HEAD COVER 1-24
CYLINDER HEAD COVER GASKET.....1-25
CYLINDER HEAD COVER GASKET.....17-4-2
<D>
DAMPER (LOWER).....11-19
DECAL SET MFS2.5B.....14-7-2
DECAL SET MFS2B.....14-7-1
DECAL SET MFS3.5B.....14-7-3
DISTANCE PIECE 11-15
DOWEL PIN 6-12 1-4
DOWEL PIN 6-12 3-3
DOWEL PIN 6-12 8-4
DOWEL PIN 6-12 8-5
DOWEL PIN 6-12 8-16
DOWEL PIN 6-12 17-7-14
DRAIN BOLT 10-14 P1.25 3-4
DRAIN SCREW.....4-19
DRIVE SHAFT ASSY (L) 10-10-2
DRIVE SHAFT ASSY (L) 17-7-10
DRIVE SHAFT ASSY (S) 10-10-1
DRIVE SHAFT BUSHING.....8-12
DRIVE SHAFT BUSHING.....17-7-3
DRIVE SHAFT HOUSING ASSY (S).....8-1
DRIVE SHAFT HOUSING GASKET 3-13
DRIVE SHAFT HOUSING GASKET 17-4-13
<E>
ENGINE SHORT BLOCK KIT.....17-2
EXHAUST VALVE 1-12
EXHAUST VALVE STEM SEAL.....1-3
EXTENSION HOUSING 8-11
EXTENSION HOUSING 17-7-2
EXTENSION HOUSING KIT (L).....17-7-1
<F>
FLAME ARRESTER 4-28
FLOAT 4-12
FLOAT 17-3-2
FLOAT ARM PIN 4-15
FLOAT ARM PIN 17-3-5
FLOAT CHAMBER.....4-16
FLOAT CHAMBER O-RING.....4-17
FLOAT CHAMBER O-RING.....17-3-6
FLOAT VALVE 4-13
FLOAT VALVE 17-3-3
FLUSHING PLUG 16-3
FLYWHEEL.....7-1
FRICTION KNOB.....11-25
FRICTION PIECE 11-22
FRICTION PIECE 12-9
FRICTION PLATE.....6-8
FRICTION SPRING 6-10
FUEL COCK ASSY.....15-6
FUEL COCK KNOB 15-14
FUEL HOSE 155-20-20.....15-7
FUEL HOSE L=215.....15-11
FUEL HOSE PROTECTOR 12-16
FUEL HOSE W/PROTECTOR L=215 15-12
FUEL HOSE W/PROTECTOR L=340 15-9
FUEL HOSE W/PROTECTOR L=390 15-8
FUEL LEVER DECAL.....13-18
FUEL PUMP ASSY 4-38
FUEL TANK ASSY 15-1-1
FUEL TANK ASSY 15-1-2
FUEL TANK CAP ASSY 15-19
FUEL TANK CAP ASSY 15-20
FUEL TANK SEAL 15-18
<G>
GASKET.....1-35
GASKET.....17-4-4
GASKET 8.1-15-1 8-8
GASKET 8.1-15-1 10-6
GASKET 8.1-15-1 17-6-2
GEAR CASE ASSY.....10-1
GRIP.....12-6
GROMMET.....10-31
GROMMET.....10-50
GROMMET 13-2 8-14
GROMMET 13-2 17-7-5
GROMMET 29-3 8-9
GUIDE PLATE GASKET 10-21
GUIDE PLATE GASKET 17-5-7
GUIDE PLATE GASKET 17-6-6
<H>
HOSE 3-11
HOSE 4-3
HOSE 4-36
HOSE 8-10
<I>
IGNITER W/R-CAP 7-4
INSULATOR 4-26
INTAKE MANIFOLD.....4-1
INTAKE MANIFOLD ASSY 4-2
INTAKE MANIFOLD GASKET.....4-6
INTAKE MANIFOLD GASKET.....17-4-8
INTAKE SILENCER 4-27
INTAKE VALVE.....1-11
INTAKE VALVE STEM SEAL 1-2
<K>
KEY.....2-10
KEY.....10-20
KEY.....10-28
KEY.....17-5-3
KEY.....17-6-4
KNOB.....11-3
<L>
LEVER 11-7
LIFTER 1-17
LOWER UNIT ASSY (L) 17-1-2
LOWER UNIT ASSY (S) 17-1-1
LOWER UNIT GASKET SET.....17-6-1
<M>
MAIN JET (#58).....4-10-1
MAIN JET (#65).....4-10-2
MAIN JET (#68).....4-10-3
MAIN NOZZLE 4-9-1
MAIN NOZZLE 4-9-2
MAIN NOZZLE 4-9-3
<N>
NUT 4-35
NUT 8-19
NUT 11-16

NUT 14-5
NUT 17-7-9
NUT 10-P1.25 7-3
NYLON NUT 8-P1.25....11-13
<O>
OIL FILLER CAP....1-8
OIL LEVEL DECAL....13-19
OIL SEAL 10.1-20-7....3-15
OIL SEAL 10.1-20-7....17-4-11
OIL SEAL 10-22-8....10-19
OIL SEAL 10-22-8....17-6-7
OIL SEAL 12-24-8....10-42
OIL SEAL 12-24-8....17-6-9
OIL SEAL 20-35-7....2-4
OIL SEAL 20-35-7....17-4-5
OIL SIGHT GAUGE....3-2
OILPAN ASSY 3-1
OILPAN GASKET....3-6
OILPAN GASKET....17-4-9
O-RING 4-20
O-RING 17-3-8
O-RING 17-4-6
O-RING 1.9-6.8 9-7
O-RING 2.4-35.2....3-16
O-RING 2.4-35.2....17-4-12
O-RING 2.4-9.5 10-25
O-RING 2.4-9.5 11-2
O-RING 2.4-9.5 17-6-12
O-RING 2.5-4.9 10-24
O-RING 2.5-4.9 17-6-11
O-RING 2-10 15-15
O-RING 3.1-24.4....1-9
O-RING 3.1-24.4....17-4-10
O-RING 3.2-47....10-43
O-RING 3.2-47....17-6-10
<P>
PILOT SCREW 4-24-1
PILOT SCREW 4-24-2
PISTON 2-7
PISTON 17-8-2
PISTON PIN 2-8
PISTON PIN 17-8-3
PISTON PIN CLIP 2-9
PISTON PIN CLIP 17-8-4
PISTON REPAIR KIT 17-8-1
PISTON RING....2-12
PISTON RING....2-13
PISTON RING SET....2-11
PISTON RING-OIL....2-14
PIVOT....1-22
PIVOT BOLT....1-20
PLATE 1-19
PLUG 10-5
PLUG CAP W/RESISTANCE 7-5
POWER HEAD GASKET SET....17-4-1
PRE-COATED BOLT 6-60 6-14
PROPELLER ASSY (4.5") 10-46-4
PROPELLER ASSY (6")....10-46-2
PROPELLER ASSY (6")....10-46-3
PROPELLER ASSY (7")....10-46-1
PROPELLER SHAFT 10-38
PROPELLER SHAFT HOUSING 10-40
PROPELLER SHAFT HOUSING ASSY....10-39
PUMP CASE (UPPER) 10-29
PUMP CASE ASSY (LOWER) 10-18
PUMP CASE GASKET....10-23
PUMP CASE GASKET....17-5-5
PUMP CASE GASKET....17-6-5
PUMP CASE GASKET (LOWER) 10-17
PUMP CASE GASKET (LOWER) 17-6-8
PUMP CASE LINER....10-30
PUMP CASE LINER....17-5-4
PUSH ROD 1-18
PUSH ROD 10-37
<R>
RATCHET 6-6
RECOIL STARTER ASSY....6-1
REEL....6-4
RETAINER 1-14
RETURN SPRING....6-7
RING GEAR COVER ASSY....7-7
RIVET 3-22 11-34
ROCKER ARM 1-21
ROPE ANCHOR....6-12
ROPE ANCHOR PLATE 6-13
RUBBER CAP 4-23
<S>
SAFETY ROPE φ4-1000....16-2
SCREW....4-18
SCREW....12-8
SCREW....12-14
SCREW....17-3-7
SEAL RING 15-16
SHEAR PIN 4-24 10-47
SHIFT DECAL (F-N) 13-17
SHIFT LEVER SHAFT ASSY....9-6
SHIFT ROD (S)....9-1
SHIFT ROD JOINT ASSY 9-4
SHIFT ROD LEVER 9-11
SHIM 21-28-0.1 10-8-1
SHIM 21-28-0.15 10-8-2
SHOULDER BOLT....11-36
SLINGER 1-37
SLOW AIR JET (#115) 4-11-1
SLOW AIR JET (#125) 4-11-2
SPACER 10.1-15-72....10-12
SPARK PLUG (DCPR6E) 1-38
SPARK PLUG DECAL....13-16
SPIRAL TUBE PROTECTOR φ10-100....4-4
SPLIT PIN 2-12 9-3
SPLIT PIN 4-35 10-48
SPRING 4-22
SPRING 9-9
SPRING 10-36
SPRING 11-9
SPRING 11-23
SPRING 12-11
SPRING PIN 2-12 11-8
SPRING PIN 3-8....10-16
SPRING PIN 3-8....17-7-12
SPRING WASHER....10-34
SPRING WASHER....14-4
STARTER HANDLE....6-11
STARTER ROPE φ3.5-1200....6-5
STARTER SEAL 6-2
STARTER SPRING....6-3
STEERING BRACKET 8-2
STOP SCREW....4-21
STOP SWITCH ASSY 13-10
STOP SWITCH LANYARD ASSY 13-11
STOPPER....8-13
STOPPER....11-6
STOPPER....17-7-4
STORAGE DECAL....13-20
STUD 6-171....8-18
STUD 6-171....17-7-7
SWIVEL BRACKET....11-5
SWIVEL BRACKET....11-21
<T>
TANK FILLER CAP GASKET 15-21
THERMOSTAT....1-28
THERMOSTAT CAP 1-29
THERMOSTAT CAP 1-30
THERMOSTAT CAP GASKET....1-31
THERMOSTAT CAP GASKET....17-4-3
THROTTLE DECAL....12-7
THROTTLE DRUM 5-4
THROTTLE OPENER....5-5
THROTTLE ROD 5-9
THROTTLE SHAFT 12-5
THROTTLE SHAFT DAMPER....12-4
THROTTLE SHAFT SUPPORT 12-13
THROTTLE WIRE....12-15
THROTTLE WIRE BRACKET 5-1
THRUST BUSHING....11-28
THRUST PLATE 20.2-32-1 2-3
THRUST ROD ASSY....11-20
THRUST SUPPORTER 11-18
TILLER HANDLE 12-2
TILLER HANDLE ASSY....12-1
TILT HANDLE....14-2
TILT STOPPER 11-4
TOOL KIT 16-1
TOP COWL ASSY 14-1
TOP COWL SEAL L=1100 14-6
<V>
VALVE SPRING L=35....1-13
VALVE SPRING SEAT....1-16
<W>
WASHER....1-7
WASHER....4-32
WASHER....7-2
WASHER....9-2
WASHER....10-33
WASHER....11-11
WASHER....11-17
WASHER....11-24
WASHER....14-3
WASHER 10.2-19-1 3-5
WASHER 10.5-18-1.5 9-10
WASHER 6.5-21-1 13-8
WASHER 6-16-1.5 1-27
WASHER 6-16-1.5 5-8
WASHER 6-16-1.5 6-15
WASHER 6-16-1.5 13-15
WASHER 6-16-1.5 15-4
WASHER 8.5-28-1 11-14
WATER PIPE ASSY (L) 10-49-2
WATER PIPE ASSY (L) 17-7-13
WATER PIPE ASSY (S) 10-49-1
WATER PUMP GUIDE PLATE 10-22
WATER PUMP GUIDE PLATE 17-5-6
WATER PUMP IMPELLER....10-27
WATER PUMP IMPELLER....17-5-2
WATER PUMP IMPELLER....17-6-3
WATER PUMP REPAIR KIT....17-5-1

INDEX (Parts Number)

172-36008-0 8-14
172-36008-0 17-7-5
301-66023-0 10-25
301-66023-0 11-2
301-66023-0 17-6-12
307-62116-1 11-14
309-00131-0 2-10
309-00132-0 7-3
309-60111-0 10-42
309-60111-0 17-6-9
309-62115-2 11-12
309-62118-0 11-15
309-62441-2 11-22
309-62446-1 11-23
309-62463-0 11-3
309-64106-0 10-46-3
309-64126-1 10-47
309-70021-3 15-21
309Q62442-2 11-25
312-72201-0 16-2
314-64103-0 10-46-4
332-00021-1 2-8
332-00021-1 17-8-3
332-60005-2 10-5
332-60006-0 8-8
332-60006-0 10-6
332-60006-0 17-6-2
332-61315-0 9-10
332-62101-1 11-35
336-60007-0 16-3
338-02215-0 4-40
338-02215-0 3-12
338-60218-2 10-3
345-01111-0 1-4
345-01111-0 3-3
345-01111-0 8-4
345-65015-0 10-43
345-65015-0 17-6-10
345-66021-0 9-7
346-67115-0 13-8
350-00024-1 2-9
350-00024-1 17-8-4
353-06283-0 13-13
353-06821-0 13-11
369-61016-0 8-9
369-62106-0 11-32
369-64010-2 10-9
369-64014-0 10-8-1
369-64015-0 10-8-2
369-64020-2 10-13
369-65021-1 10-27
369-65021-1 17-5-2
369-65021-1 17-6-3
369-65022-0 10-28
369-65022-0 17-5-3
369-65022-0 17-6-4
369-66021-1 10-24
369-66021-1 17-6-11
369-66112-1 9-9
369-66116-0 9-8
369-66241-0 9-4
369-70063-0 15-16
369-70311-0 15-6
393-62416-1 11-27
398-06972-0 1-32
398-06972-0 5-2
398-06972-0 6-16
3A0-76079-0 3-9
3A0-76079-0 4-29
3A0-76079-0 13-3
3AA-67120-0 13-2
3AA-67503-0 6-2
3AB-00001-1 2-7
3AB-00001-1 17-8-2
3AB-00040-0 2-5
3AB-00059-0 2-6
3AB-00070-0 2-1
3AB-00115-0 2-3
3AB-00121-0 2-4
3AB-00121-0 17-4-5
3AB-01024-1 1-25
3AB-01024-1 17-4-2
3AB-01032-0 1-31
3AB-01032-0 17-4-3
3AB-01111-0 8-5
3AB-01111-0 8-16
3AB-01111-0 17-7-14
3AB-01210-0 3-14
3AB-01215-0 3-15
3AB-01215-0 17-4-11
3AB-02104-0 4-6
3AB-02104-0 17-4-8
3AB-02215-1 15-13
3AB-03265-0 4-21
3AB-03266-0 4-24-1
3AB-05003-0 6-6
3AB-05004-0 6-3
3AB-05006-0 6-8
3AB-05007-0 6-10
3AB-05012-0 6-7
3AB-05013-0 6-5
3AB-05019-0 6-11
3AB-05090-0 6-1
3AB-05104-0 6-4
3AB-05131-0 6-12
3AB-05134-0 6-13
3AB-05138-0 6-9
3AB-06300-1 7-7
3AB-06303-1 7-8
3AB-06846-1 15-2
3AB-07201-0 1-11
3AB-07231-0 1-17
3AB-07233-0 1-19
3AB-07235-0 1-21
3AB-07402-0 3-6
3AB-07402-0 17-4-9
3AB-07421-0 3-2
3AB-07431-0 1-34
3AB-07432-0 1-35
3AB-07432-0 17-4-4
3AB-07435-0 4-37
3AB-07640-0 1-37
3AB-35143-0 15-10
3AB-60001-1 10-45
3AB-60001-1 8-17
3AB-60001-1 17-7-8
3AB-60003-0 8-12
3AB-60003-0 17-7-3
3AB-60213-0 10-2
3AB-60213-0 10-11
3AB-61012-0 3-13
3AB-61012-0 17-4-13
3AB-61336-1 11-19
3AB-62212-0 11-18
3AB-62321-1 11-26
3AB-62464-3 11-4
3AB-63068-0 11-7
3AB-63102-0 12-17
3AB-63107-0 12-19
3AB-63617-0 5-9
3AB-64306-0 10-10-1
3AB-64307-0 10-10-2
3AB-64307-0 17-7-10
3AB-64332-0 8-13
3AB-64332-0 17-7-4
3AB-65025-0 10-22
3AB-65025-0 17-5-6
3AB-65031-0 10-50
3AB-65191-0 10-49-1
3AB-65192-0 10-49-2
3AB-65192-0 17-7-13
3AB-66130-0 9-6
3AB-66214-0 9-1
3AB-66225-0 9-11
3AB-66334-1 11-6
3AB-66336-0 11-9
3AB-67104-0 13-5
3AB-67197-0 13-7
3AB-67572-0 13-20
3AB-70036-1 15-18
3AB-70310-2 15-1-2
3AB-72024-2 13-18
3AB-72183-0 15-17
3AB-87121-0 17-4-1
3AB-87322-0 17-5-1
3AB-87801-2 14-7-2
3ABB01021-0 1-24
3ABB01031-0 1-29
3ABB07400-0 3-1
3ABB63508-0 5-1
3ABQ61020-2 8-1
3ABQ61100-0 8-11
3ABQ61100-0 17-7-2
3ABQ62001-1 8-2
3ABQ62102-0 11-33
3ABQ62111-2 11-1
3ABQ62391-1 11-5
3ABQ62392-1 11-21
3ABQ67100-0 13-1
3ABQ67521-2 14-2
3ABQ67645-2 14-1
3ABQ87312-0 17-7-1
3AE-07203-0 1-13
3AS-03266-0 4-24-2
3AU-04468-0 4-10-3
3B2-63063-0 12-13
3B2-65022-0 10-20
3BJ-72100-0 16-1
3BMQ60000-1 10-1
3BMQ87301-1 17-1-1
3BMQ87302-1 17-1-2
3BN-67578-0 13-17
3BR-63102-1 12-18
3BR-87801-2 14-7-3
3BRB02091-1 4-1
3BV-87801-2 14-7-1
3C7-02215-0 4-5
3C8-62104-2 11-34
3C8-62107-0 11-36
3C8-66308-0 1-27
3C8-66308-0 5-8
3C8-66308-0 6-15
3C8-66308-0 13-15
3C8-66308-0 15-4
3C8-71017-0 15-22
3DJ-04458-0 4-10-1
3F0-60223-0 10-19
3F0-60223-0 17-6-7
3F0-61101-1 8-18
3F0-61101-1 17-7-7
3F0-62160-0 11-20
3F0-64101-0 10-46-1
3F0-64211-0 10-38
3F0-64215-0 10-35
3F0-64221-0 10-36
3F0-64223-0 10-37
3F0-64321-0 10-12
3F0-65011-0 10-30
3F0-65011-0 17-5-4
3F0-65016-0 10-29
3F0-65018-0 10-23
3F0-65018-0 17-5-5
3F0-65018-0 17-6-5
3F0-65020-0 10-17
3F0-65020-0 17-6-8
3F0-65029-0 10-21
3F0-65029-0 17-5-7
3F0-65029-0 17-6-6
3F0-65032-0 10-31
3F0-66011-0 10-14
3F0-66012-0 10-15-1
3F0-66013-0 10-15-2
3F0-66013-0 17-7-11
3F0-66031-0 10-26
3F0-87321-0 17-6-1
3F0B64512-0 10-46-2
3F0Q60101-1 10-40
3F0Q87323-1 10-39
3FK-87123-0 2-11
3G9-66136-0 15-15
3GR-06870-0 13-10
3GT-02161-0 15-8
3GT-02165-0 15-9
3GT-02175-0 15-12
3GT-03200-0 4-8-1
3GT-03221-0 4-16
3GT-03231-0 4-12
3GT-03231-0 17-3-2
3GT-03252-0 4-9-1
3GT-03256-0 4-23
3GT-04000-0 4-38
3GT-04915-0 4-11-1
3GT-04925-0 4-11-2
3GT-05101-0 3-8
3GT-06001-0 7-1
3GT-06041-0 7-4
3GT-07810-0 1-10
3GT-60108-0 6-14
3GT-67501-0 14-6
3GT-70062-0 15-14
3GT-70310-0 15-1-1
3GT-70321-0 15-19
3GT-70325-0 15-11
3GT-70326-0 15-7
3GT-72046-0 13-19
3GT-87122-0 17-3-1
3GT-87130-0 17-8-1
3GTB01031-0 1-30
3GTB01100-2 1-1
3GTB02010-0 4-2
3GTB87090-3 17-2
3GTQ62105-0 11-30
3GTQ62108-0 11-31
3GU-03200-0 4-8-2
3GU-03252-0 4-9-2
3GU-10230-0 16-4-1
3GV-03200-0 4-8-3
3GV-10230-0 16-4-2
3H2-65040-1 10-18
3H6-01030-0 1-28
3H6-02011-0 4-25
3H6-02011-0 17-4-7
3H6-02411-0 4-27
3H6-02603-0 4-28
3H6-03222-0 4-17
3H6-03222-0 17-3-6
3H6-03232-0 4-15
3H6-03232-0 17-3-5
3H6-03240-0 4-13
3H6-03240-0 17-3-3
3H6-03244-0 4-14
3H6-03244-0 17-3-4
3H6-03267-0 4-22
3H6-03292-0 4-19
3H6-03293-0 4-20
3H6-03293-0 17-3-8
3H6-03293-0 17-4-6
3H6-03952-1 4-26
3H6-06999-0 7-5
3H6-07205-0 1-16
3H6-07223-0 1-15
3H6-07232-0 1-18
3H6-07234-0 1-20
3H6-07236-0 1-22
3H6-07406-0 3-5
3H6-07705-1 3-4
3H6-07937-0 1-23
3H6-62325-0 11-28
3H6-63048-0 12-4
3H6-63505-0 4-33
3H6-63510-0 12-3
3H6-63611-0 5-4
3H6-63612-0 5-5
3H6-63618-0 5-6
3H6-67151-0 13-6
3H6-72026-0 13-16

3H6-76079-1 4-30
3H9-70313-0 12-16
3R0-07422-0 1-9
3R0-07422-0 17-4-10
3R0-71015-1 1-8
3R0-72180-0 14-8
3R1-03251-0 4-10-2
3R3-07204-0 1-2
3R3-07206-0 1-3
3R3-63012-0 12-6
3R4-03252-0 4-9-3
3R6-70320-1 15-20
3T5-76079-0 15-3
3V1-00011-0 2-12
3V1-00012-0 2-13
3V1-00013-0 2-14
3V1-02012-0 3-16
3V1-02012-0 17-4-12
3V1-07202-0 1-12
3V1-07221-0 1-14
3V1-60001-1 11-29
3V1-63035-1 12-9
3V1-63036-0 12-11
3V1-63041-0 12-5
3V1-63077-0 12-10
3V1-63600-0 12-15
3V1-76148-0 4-4
3V1Q63003-4 12-1
3V1Q63011-3 12-2
3V9-72019-0 12-7
910103-0612. 13-9
910103-0616. 4-34
910103-0616. 10-4
910103-0625. 12-12
910103-5612. 13-12
910103-5616. 9-5
910103-5625. 7-6
910121-0616. 1-26
9101E3-0616. 12-20
9101E3-0616. 13-14
9101E3-0625. 15-5
9101E3-5612. 8-15
9101E3-5612. 17-7-6
9101E3-5616. 1-36
9101E3-5616. 13-4
9101E3-5620. 4-39
9101E3-5620. 10-44
9101E3-5620. 3-10
9101E3-5620. 3-17
9101E3-5625. 5-3
9101E3-5630. 1-33
9101E3-5630. 8-6
9101E3-5835. 8-3
9101F4-5630. 4-7
9101F4-5635. 1-5
9101F4-5635. 3-7
9106E3-0808. 8-7
910903-6512. 9-12
9161E3-0635. 5-7
9161E3-0645. 10-32
9161E3-0650. 11-10
9161F1-0685. 4-31
9161F9-0675. 1-6
9208E3-0518. 12-8
921503-0612. 12-14
922503-6412. 4-18
922503-6412. 17-3-7
930103-0600. 4-35
930103-0600. 14-5
9301E3-0600. 8-19
9301E3-0600. 11-16
9301E3-0600. 17-7-9
930403-0800. 11-13
940103-0600. 4-32
940103-0600. 10-33
940103-0600. 9-2
940103-0600. 14-3
940121-1000. 7-2
9401E3-0600. 1-7
9401E3-0600. 11-11
9401E3-0600. 11-17
9401E3-0600. 11-24
941303-0600. 10-34
941303-0600. 14-4
951403-0212. 11-8
951407-0308. 10-16
951407-0308. 17-7-12
951503-0212. 9-3
951503-0435. 10-48
9601-0-6001 10-41
9601-0-6004 10-7
9603-3-6204 2-2
9701-1-1103 1-38
98AB-30-050. 8-10
98AB-30-230. 4-36
98AB-50-080. 3-11
98AB-70-185. 4-3

Copyright © 2012 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means without the express written permission of Tohatsu Corporation.

TOHATSU

TOHATSU CORPORATION
Address : 5-4,3-chome,Azusawa,Itabashi-ku,
TOKYO,174-0051 JAPAN
Phone : TOKYO (03)3966-3117
FAX : TOKYO (03)3966-0090
Website : www.tohatsu.co.jp

トーハツ船外機
パーツ カタログ

PARTS CATALOG

MFS 2B
2.5B
3.5B

2012
Serial Number 000001AB~

本　　社 〒174-0051 東京都板橋区小豆沢3-5-4 03(3966)3116
マリン九州 〒812-0892 福岡市博多区東那珂2-10-55 092(411)8770
マリン関西 〒530-0043 大阪市北区天満1-8-27 06(6358)2971
マリン関東 〒174-0051 東京都板橋区小豆沢3-5-4 03(3966)2222

002-21052-5
1203