
2018 PARTS CATALOG

トーハツ船外機 パーツカタログ

TOHATSU
Feel the Wind™

MFS 9.9E
MFS 15E
MFS 20E
Models

Serial Number 000001AH～
OB NO.002-21057-0AH 3RS 1801



BACKS YOU UP™

TOHATSU CORPORATION


パーツカタログのご使用について

1. このパーツカタログは、2018 年 1 月現在で編集しております。

2. 新設、廃止または、変更が生じた場合は、サービスブルテン等にてお知らせ致しますので、その都度、ご訂正ください。

3. イラストレーション (部品図）は部品検査の目安として記載していますので現品と形状が異なる場合があります。

4. イラストが一つに対して複数の品番がありますので枝番、適用モデル、備考を確認してからご注文願います。



5. アッセンブリまたは、キットでの販売部品は、その構成する部品の頭に (＊）印をつけて表しています。

6. 本文中に記載されている記号は、次の様になっています。

STD	: スタンダード	OPT	: オプション
O/S	: オーバーサイズ	ASSY	: アッセンブリ
DO	: 日本国内向け	EX	: 海外輸出向け
A	: 必要に応じて選択	EU	: 欧州連合

7. オーダー上の注意
塗装部品の注文に当っては、以下に従ってください。
パーツナンバーの 4 桁目が B”・Q” 記号のものは塗装されています。
現在の塗装色はパワーヘッドがブラック (B)、ロワユニットがアクアマリンブルー (Q)、プロペラがブラック (B) です。
[例示]

エンジンショートブロックキット	ロワユニットアッシ (L)
3BJB87090-3	3BHQ87302-0
B: ブラック	Q: アクアマリンブルー


8. ボルト・ナット・ワッシャのサイズ記号に付いて

ボルト 9161F9 - 0630
- 首下長さ
- 径
- 座付き (0) : 座なし

ナット・ワッシャ 9401E3 - 0600
- 径

9. 標準部品のホースは、長巻 (備考を参照) に代替されます。

ホース　　98AB - 50 - 110



HOSE/PIPE

Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Bulk part No. ﾊﾞﾙｸ部品番号	Bulk part ﾊﾞﾙｸ部品	
					Inner Diameter(mm) 内径(ﾐﾘ)	Length(m) 長さ(ﾒｰﾄﾙ)
1-3		99AA-4-0330	PIPE ﾋﾞﾆﾙﾊﾟｲﾌﾟ	99AA-4-1000	4	1
16-7	2	98AB-70-700	HOSE ﾎｰｽ	98AB-701000	7	1
16-8	2	98AB-701600	HOSE ﾎｰｽ	98AB-701000×2	7	1


HOW TO USE THIS PARTS CATALOG

1. This Parts Catalog provides information available as of the end of January, 2018.

2. Please keep the Parts Catalog updated each time when receiving the Service Bulletin describing the addition, abolition and/or change of parts.

3. Actual shapes of parts may be different from the illustrations shown in this Parts Catalog because they are described only as a guide for searching parts.

4. One illustration is given more than one article number. Please confirm the sub-number, applicable model and remarks before ordering parts.



5. Given mark in (∗) to part number shows assembly or kit part.

6. Marks in this Parts Catalog show.

STD	: Standard	OPT	: Optional Parts
O/S	: Over size	ASSY	: Assembly
DO	: Domestic Model	EX	: Export Model
A	: As required	EU	: European Union

7. Attention to order
   Please order painted parts in accordance with following.
   The parts that fourth figure of the parts number is (B), (Q) have painted.
   Present coloring of power head is black (B) , lower unit is aqua marine blue (Q) and propeller is black (B).
   [Example]

ENGINE SHORT BLOCK KIT	LOWER UNIT ASSY (L)
3BJB87090-3	3BHQ87302-0
B: Black	Q: Aquamarine Blue

8. About dimensional identification of bolts, nuts and washers.

BOLT 9161F9-0630
- Length below neck
- Diameter
- Washer based (0) : No washer

NUTS & WASHERS 9401E3-0600
- Diameter

9. Hose, that is a standard part, is replaced with long hose.

HOSE 98AB - 50 -110

Length
Diameter

HOSE/PIPE

Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Bulk part No. ﾊﾞﾙｸ部品番号	Bulk part ﾊﾞﾙｸ部品	
					Inner Diameter(mm) 内径(ミリ)	Length(m) 長さ(メートル)
1-3		99AA-4-0330	PIPE ﾋﾞﾆﾙﾊﾟｲﾌﾟ	99AA-4-1000	4	1
16-7	2	98AB-70-700	HOSE ﾎｰｽ	98AB-701000	7	1
16-8	2	98AB-701600	HOSE ﾎｰｽ	98AB-701000×2	7	1

CONTENTS
目　　次

Fig. 1 CYLINDER・CRANK CASE ····· 1
シリンダ・クランクケース

Fig. 2 PISTON・CRANK SHAFT ····· 5
ピストン・クランクシャフト

Fig. 3 CYLINDER HEAD・OIL PUMP ····· 7
シリンダヘッド・オイルポンプ

Fig. 4 PULLEY・TIMING BELT ····· 11
プーリ・タイミングベルト

Fig. 5 FUEL PUMP ····· 13
フュエルポンプ

Fig. 6 RECOIL STARTER ····· 21
リコイルスタータ

Fig. 7 MAGNETO・ELECTRIC PARTS ····· 23
マグネト・エレクトリックパーツ

Fig. 8 DRIVE SHAFT HOUSING ····· 31
ドライブシャフトハウジング

Fig. 9 GEAR CASE ····· 35
ギヤケース

Fig. 10 BRACKET (MANUAL) ····· 41
ブラケット (マニュアル)

Fig. 11 BRACKET (PTT) ····· 47
ブラケット(PTT)

Fig. 12 TILLER HANDLE・SHIFT ····· 53
ティラハンドル・シフト

Fig. 13 FRONT PANEL・DRIVE SHAFT HOUSING COVER ····· 59
フロントパネル・ドライブシャフトハウジングカバー

Fig. 14 REMOTE CONTROL PARTS ····· 63
リモートコントロールパーツ

Fig. 15 TOP COWL ····· 65
トップカウル

Fig. 16 FUEL TANK ····· 67
フュエルタンク

Fig. 17 COMPONENT PARTS OF REMOTE CONTROL ····· 69
リモコンボックス構成部品

Fig. 18 COMPONENT PARTS OF REMOTE CONTROL (ELECTRIC PARTS) ····· 73
リモコンボックス構成部品(電装品関係)

Fig. 19 OPTIONAL PARTS・ACCESORIES ····· 75
オプショナルパーツ・アクセサリ

Fig. 20 ASSEMBLY・KIT PARTS ····· 77
アッセンブリ・キットパーツ

索引 ····· 85

INDEX ····· 91

INDEX (Parts Number) ····· 95

Fig. 1 CYLINDER・CRANK CASE
シリンダ・クランクケース




Fig. 2 PISTON・CRANK SHAFT
ピストン・クランクシャフト




Fig. 3 CYLINDER HEAD・OIL PUMP
シリンダヘッド・オイルポンプ




Fig. 4 PULLEY・TIMING BELT
プーリ・タイミングベルト




Fig. 5 FUEL PUMP
フュエルポンプ




Fig. 6 RECOIL STARTER
リコイルスタータ




Fig. 7 MAGNETO・ELECTRIC PARTS
マグネト・エレクトリックパーツ




Fig. 8 DRIVE SHAFT HOUSING
ドライブシャフトハウジング




Fig. 9 GEAR CASE
ギヤケース




Fig. 10 BRACKET (MANUAL)
ブラケット (マニュアル)




Fig. 11 BRACKET (PTT)
ブラケット(PTT)




Fig. 12 TILLER HANDLE・SHIFT
ティラハンドル・シフト




Fig. 13 FRONT PANEL・DRIVE SHAFT HOUSING COVER
フロントパネル・ドライブシャフトハウジングカバー




Fig. 14 REMOTE CONTROL PARTS
リモートコントロールパーツ




Fig. 15 TOP COWL
トップカウル




Fig. 16 FUEL TANK
フュエルタンク




Fig. 17 COMPONENT PARTS OF REMOTE CONTROL
リモコンボックス構成部品




Fig. 18 COMPONENT PARTS OF REMOTE CONTROL (ELECTRIC PARTS)
リモコンボックス構成部品(電装品関係)




Fig. 19 OPTIONAL PARTS・ACCESORIES
オプショナルパーツ・アクセサリ






Fig. 20 ASSEMBLY・KIT PARTS
アッセンブリ・キットパーツ





POWER HEAD GASKET SET
パワーヘッドガスケットセット — 3

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 4

WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 5

WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット（クロムメッキ） — 6


ELECTRIC STARTER KIT (F TYPE)
エレクトリックスタータキット（Fタイプ） — 7

MAINTENANCE KIT
メンテナンスキット — 9

INTAKE VALVE KIT
インテークバルブキット — 10


EXHAUST VALVE KIT
エキゾーストバルブキット — 11

Fig. 1 CYLINDER・CRANK CASE
シリンダ・クランクケース




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
1-1	3RSB01100-0	CYL BLOCK & CRANKCASE ASSY ｼﾘﾝﾀﾞﾌﾞﾛｯｸ＆ｸﾗﾝｸｹｰｽｱｯｼ	1	1	1	
1-2	3RS-07636-0	* OIL FILTER BOLT * ｵｲﾙﾌｨﾙﾀﾎﾞﾙﾄ	1	1	1	
1-3	99AA-4-0330	* PIPE * ﾋﾞﾆﾙﾊﾟｲﾌﾟ	1	1	1	99AA-4-1000
1-4	345-01111-0	* DOWEL PIN 6-12 * ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	2	
1-5	3H8-01012-1	* CYLINDER HEAD BOLT 8-50 * ｼﾘﾝﾀﾞﾍｯﾄﾞﾎﾞﾙﾄ 8-50	4	4	4	Crankcase
1-6	9161F9-0630	* BOLT * ﾎﾞﾙﾄ	6	6	6	
1-7	9402E3-0600	* WASHER * ﾜｯｼｬ	6	6	6	
1-8	3BJ-07615-0	OIL FILTER ｵｲﾙﾌｨﾙﾀｱｯｼ	1	1	1	
1-9	3RS-01513-0	HANGER ﾊﾝｶﾞ	1	1	1	
1-10	910103-5820	BOLT ﾎﾞﾙﾄ	1	1	1	
1-11	3RS-01030-0	THERMOSTAT ｻｰﾓｽﾀｯﾄ	1	1	1	
1-12	3H6B01031-0	THERMOSTAT CAP ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟ	1	1	1	
1-13	346-01032-0	THERMOSTAT CAP GASKET ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	1	
1-14	3RT-06869-0	BRACKET ﾌﾞﾗｹｯﾄ	1	1	1	
1-15	3RS-02095-0	BOLT 40mm ﾎﾞﾙﾄ	2	2	2	
1-16	9402E3-0600	WASHER ﾜｯｼｬ	2	2	2	
1-17	3RSB02301-0	EXHAUST COVER (OUTER) ｴｷｿﾞｰｽﾄｶﾊﾞｰ (ｱｳﾀ)	1	1	1	
1-18	3RS-02305-0	EXHAUST COVER GASKET ｴｷｿﾞｰｽﾄｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	1	
1-19	3NT-02319-0	BOLT 25mm ﾎﾞﾙﾄ 25mm	5	5	5	
1-20	9402E3-0600	WASHER ﾜｯｼｬ	5	5	5	
1-21	3KY-84398-0	BAND ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ	2	2	2	
1-22	369-84398-0	BAND 158 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 158	1	1	1	
1-23	3RS-01303-0	ENGINE BASEMENT GASKET ｴﾝｼﾞﾝﾍﾞｰｽｶﾞｽｹｯﾄ	1	1	1	
1-24	3BJ-61017-1	BOLT 8-P1.25 ﾎﾞﾙﾄ 8-P1.25	6	6	6	
1-25	3RS-07710-0	OIL STRAINER ASSY ｵｲﾙｽﾄﾚｰﾅｱｯｼ	1	1	1	
1-26	369-84398-0	BAND 158 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 158	2	2	2	
1-27	98AH-95-150	HOSE ﾎｰｽ	1	1	1	98AH-951000
1-28	3RS-67143-0	COWL SUPPORT ｶｳﾙｻﾎﾟｰﾄ	2	2	2	
1-29	3RT-67143-0	COWL SUPPORT ｶｳﾙｻﾎﾟｰﾄ	1	1	1	

Fig. 1 **CYLINDER・CRANK CASE**
シリンダ・クランクケース




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
1-30		3RS-67144-0	COWL SUPPORT RUBBER ｶｳﾙｻﾎﾟｰﾄﾗﾊﾞｰ	3	3	3	

Fig. 2 PISTON・CRANK SHAFT
ピストン・クランクシャフト




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
2-1		3RS-00040-0	CONNECTING ROD ASSY ｺﾝﾛｯﾄﾞｱｯｼ	2	2	2	
2-2		3RS-00059-0	* CONNECTING ROD BOLT *ｺﾝﾛｯﾄﾞﾎﾞﾙﾄ	2	2	2	
2-3		3RS-00030-0	CRANKSHAFT ASSY ｸﾗﾝｸｼｬﾌﾄｱｯｼ	1	1	1	
2-4	1	3RS-07708-0	PLAIN SHAFT BEARING ﾌﾟﾚｰﾝｼｬﾌﾄﾍﾞｱﾘﾝｸﾞ	A	A	A	Blue see Service Manual
2-4	2	3RS-07707-0	PLAIN SHAFT BEARING ﾌﾟﾚｰﾝｼｬﾌﾄﾍﾞｱﾘﾝｸﾞ	A	A	A	Red see Service Manual
2-5		3R3-00121-0	OIL SEAL 32-44-9 ｵｲﾙｼｰﾙ 32-44-9	1	1	1	Upper
2-6		3BJ-00121-0	OIL SEAL 36-50-7 ｵｲﾙｼｰﾙ 36-50-7	1	1	1	Lower
2-7		3RS-87123-1	PISTON REPAIR KIT ﾋﾟｽﾄﾝﾘﾍﾟｱｷｯﾄ	2	2	2	
2-8		3RS-00011-0	* PISTON *ﾋﾟｽﾄﾝ	1	1	1	
2-9		3RS-00012-0	* PISTON PIN *ﾋﾟｽﾄﾝﾋﾟﾝ	1	1	1	
2-10		3RS-00013-0	* PISTON PIN CLIP *ﾋﾟｽﾄﾝﾋﾟﾝｸﾘｯﾌﾟ	2	2	2	
2-11		3RS-87123-1	PISTON RING SET ﾋﾟｽﾄﾝﾘﾝｸﾞｾｯﾄ	2	2	2	
2-12		3RS-00011-0	* PISTON RING *ﾋﾟｽﾄﾝﾘﾝｸﾞ	1	1	1	1st
2-13		3RS-00012-0	* PISTON RING *ﾋﾟｽﾄﾝﾘﾝｸﾞ	1	1	1	2nd
2-14		3RS-00013-0	* PISTON RING-OIL *ﾋﾟｽﾄﾝﾘﾝｸﾞ ｵｲﾙ	1	1	1	Oil

Fig. 3 **CYLINDER HEAD・OIL PUMP**
シリンダヘッド・オイルポンプ




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
3-1	9701-1-1103	SPARK PLUG(DCPR6E) ｽﾊﾟｰｸﾌﾟﾗｸﾞ(DCPR6E)	2	2	2	
3-2	3RSB01000-0	CYLINDER HEAD COMPLETE ｼﾘﾝﾀﾞｰﾍｯﾄﾞｺﾝﾌﾟﾘｰﾄ	1	1	1	
3-3	3RSB01001-0	* CYLINDER HEAD ASSY * ｼﾘﾝﾀﾞｰﾍｯﾄﾞｱｯｼ	1	1	1	
3-4	345-01111-0	** DOWEL PIN 6-12 ** ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	2	
3-5	3H8-07025-0	** OIL SEAL 18-35-8 ** ｵｲﾙｼｰﾙ 18-35-8	1	1	1	
3-6	3RS-07810-0	* CAMSHAFT ASSY * ｶﾑｼｬﾌﾄｱｯｼ	1	1	1	
3-7	3Y2-07935-0	* ROCKER ARM * ﾛｯｶｰｱｰﾑ	3	3	3	
3-8	3RS-07935-0	* ROCKER ARM * ﾛｯｶｰｱｰﾑ	1	1	1	
3-9	3R0-07238-0	* ADJUSTING SCREW * ｱｼﾞｬｽﾄｽｸﾘｭ	4	4	4	
3-10	3H8-07237-0	* ADJUSTING NUT * ｱｼﾞｬｽﾄﾅｯﾄ	4	4	4	
3-11	3RS-07920-0	* ROCKER ARM SHAFT * ﾛｯｶｱｰﾑｼｬﾌﾄ	1	1	1	
3-12	3AA-07225-0	* ROCKER SHAFT SPRING L=25 * ﾛｯｶｼｬﾌﾄｽﾌﾟﾘﾝｸﾞ L=25	2	2	2	
3-13	3R3-07227-0	* WASHER 13.2-21.8-2 * ﾜｯｼｬ 13.2-21.8-2	2	2	2	
3-14	3RS-07939-0	* COLLAR * ｶﾗｰ	2	2	2	
3-15	3RS-07901-0	* INTAKE VALVE * ｲﾝﾃｰｸﾊﾞﾙﾌﾞ	2	2	2	
3-16	3RS-07902-0	* EXHAUST VALVE * ｴｷｿﾞｰｽﾄﾊﾞﾙﾌﾞ	2	2	2	
3-17	3RS-07903-0	* VALVE SPRING * ﾊﾞﾙﾌﾞｽﾌﾟﾘﾝｸﾞ	4	4	4	
3-18	3V1-07221-0	* RETAINER * ﾘﾃｰﾅ	4	4	4	
3-19	3H6-07223-0	* COTTER * ｺｯﾀ	8	8	8	
3-20	3RS-07905-0	* VALVE SPRING SEAT * ﾊﾞﾙﾌﾞｽﾌﾟﾘﾝｸﾞｼｰﾄ	4	4	4	
3-21	3R3-07204-0	* INTAKE VALVE STEM SEAL * ｲﾝﾃｰｸﾊﾞﾙﾌﾞｽﾃﾑｼｰﾙ	2	2	2	
3-22	3R3-07206-0	* EXHAUST VALVE STEM SEAL * ｴｷｿﾞｰｽﾄﾊﾞﾙﾌﾞｽﾃﾑｼｰﾙ	2	2	2	
3-22a	3KM-01142-0	* ANODE PLUG ASSY * ｱﾉｰﾄﾞﾌﾟﾗｸﾞｱｯｼ	1	1	1	
3-23	3P0-01143-0	** ANODE PLUG ** ｱﾉｰﾄﾞﾌﾟﾗｸﾞ	1	1	1	
3-24	3T5-10046-0	** O-RING 1.9-13 ** Oﾘﾝｸﾞ 1.9-13	1	1	1	
3-25	3P0-60218-0	** ANODE ** ｱﾉｰﾄﾞ	1	1	1	
3-26	921503-0530	** SCREW ** ｽｸﾘｭ	1	1	1	
3-27	3RS-07600-0	* OIL PUMP ASSY * ｵｲﾙﾎﾟﾝﾌﾟｱｯｼ	1	1	1	
3-28	3RS-07653-0	* OIL PUMP GASKET * ｵｲﾙﾎﾟﾝﾌﾟｶﾞｽｹｯﾄ	1	1	1	

Fig. 3 CYLINDER HEAD・OIL PUMP
シリンダヘッド・オイルポンプ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
3-29		9101E3-5635	* BOLT * ﾎﾞﾙﾄ	3	3	3	
3-30		3RS-01005-0	CYLINDER HEAD GASKET ｼﾘﾝﾀﾞｰﾍｯﾄﾞｶﾞｽｹｯﾄ	1	1	1	
3-31		3H8-01013-0	CYLINDER HEAD BOLT 8-60 ｼﾘﾝﾀﾞｰﾍｯﾄﾞﾎﾞﾙﾄ 8-60	6	6	6	
3-32		9161F9-0640	BOLT ﾎﾞﾙﾄ	1	1	1	
3-33		9402E3-0600	WASHER ﾜｯｼｬ	3	3	3	
3-34		3RSB01020-0	CYLINDER HEAD COVER ASSY ｼﾘﾝﾀﾞｰﾍｯﾄﾞｶﾊﾞｰｱｯｼ	1	1	1	
3-35		3H8-02093-0	* NIPPLE 10-32 * ﾆｯﾌﾟﾙ 10-32	1	1	1	
3-36		3RS-07731-0	* BREATHER CHAMBER COVER * ﾌﾞﾘｰｻﾞｰﾁｬﾝﾊﾞｰｶﾊﾞｰ	1	1	1	
3-37		921503-0406	* SCREW * ｽｸﾘｭ	4	4	4	
3-38		3RS-01024-0	CYLINDER HEAD COVER GASKET ｼﾘﾝﾀﾞｰﾍｯﾄﾞｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	1	
3-39		9101E3-5625	BOLT ﾎﾞﾙﾄ	4	4	4	
3-40		3R0-71015-1	OIL FILLER CAP ｵｲﾙﾌｨﾗｷｬｯﾌﾟ	1	1	1	
3-41		3R0-07422-0	O-RING 3.1-24.4 Oﾘﾝｸﾞ 3.1-24.4	1	1	1	
3-42		3NT-02319-0	BOLT 25mm ﾎﾞﾙﾄ 25mm	2	2	2	

Fig. 4 PULLEY・TIMING BELT
プーリ・タイミングベルト




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
4-1		3RS-07721-0	OIL LEVEL GAUGE ｵｲﾙﾚﾍﾞﾙｹﾞｰｼﾞ	1	1	1	
4-2		3RS-07720-0	OIL LEVEL GAUGE GUIDE ｵｲﾙﾚﾍﾞﾙｹﾞｰｼﾞｶﾞｲﾄﾞ	1	1	1	
4-3		3T5-10162-0	O-RING 1.9-9.8 Oﾘﾝｸﾞ 1.9-9.8	1	1	1	
4-4		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
4-5		3BJ-10060-0	DRIVE PULLEY ﾄﾞﾗｲﾌﾟﾌﾟｰﾘ(ﾀｲﾐﾝｸﾞﾌﾟﾌﾟｰﾘ)	1	1	1	Crankshaft
4-6		309-00131-0	KEY 10-3.7-3 ｷｰ 10-3.7-3	1	1	1	
4-7		309-00131-0	KEY 10-3.7-3 ｷｰ 10-3.7-3	1	1	1	
4-8		3BJ-10063-0	BELT GUIDE ﾍﾞﾙﾄｶﾞｲﾄﾞ	1	1	1	
4-9		3BJ-10069-0	LOCK WASHER ﾛｯｸﾜｯｼｬ	1	1	1	
4-10		3T5-10068-2	NUT ﾅｯﾄ ﾌﾟｰﾘ	1	1	1	
4-11		3H8-10062-2	DRIVEN PULLEY ﾄﾞﾘﾌﾞﾝﾌﾟｰﾘ	1	1	1	
4-12		3AA-60108-0	PRE-COATED BOLT 6-20 ﾌﾟﾚｺｰﾄﾎﾞﾙﾄ 6-20	1	1	1	
4-13		3H8-10066-0	WASHER 6.5-19-3.2 ﾜｯｼｬ 6.5-19-3.2	1	1	1	
4-14		3RS-10045-0	TIMING BELT ﾀｲﾐﾝｸﾞﾍﾞﾙﾄ	1	1	1	

Fig. 5 FUEL PUMP
フュエルポンプ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
5-1		3RS-10200-0	FUEL RAIL ASSY ﾌｭｴﾙﾚｰﾙｱｯｼ	1	1	1	
5-2		3RS-10201-0	* FUEL RAIL * ﾌｭｴﾙﾚｰﾙ	1	1	1	
5-3		3RS-10300-0	* FUEL INJECTOR ASSY * ﾌｭｴﾙｲﾝｼﾞｪｸﾀｱｯｼ	2	2	2	
5-4		3RS-10323-0	* SEAL RING * ｼｰﾙﾘﾝｸﾞ	2	2	2	
5-5		3T5-10098-0	* VALVE ASSY (PRESSURE CHECK) * ﾊﾞﾙﾌﾞｱｯｼ (ﾌﾟﾚｯｼｬﾁｪｯｸ)	1	1	1	
5-6		3T5-10099-0	* CAP * ｷｬｯﾌﾟ ﾊﾞﾙﾌﾞ	1	1	1	
5-7		3T5-10161-0	* NIPPLE * ﾆｯﾌﾟﾙ	1	1	1	
5-8		3T5-10162-0	* O-RING 1.9-9.8 * Oﾘﾝｸﾞ 1.9-9.8	2	2	2	
5-9		3T5-10169-0	* HOLDING PLATE * ﾎｰﾙﾃﾞｨﾝｸﾞﾌﾟﾚｰﾄ	1	1	1	
5-10		910103-5612	* BOLT * ﾎﾞﾙﾄ	1	1	1	
5-11		910103-5625	BOLT ﾎﾞﾙﾄ	2	2	2	
5-12		3RS-03952-0	INSULATOR ｲﾝｼｭﾚｰﾀ	1	1	1	
5-13		3RS-10100-0	THROTTLE BODY ASSY ｽﾛｯﾄﾙﾎﾞﾃﾞｨｱｯｼ	1	1	1	
5-14		3RS-10211-0	* ISC VALVE * ISCﾊﾞﾙﾌﾞ	1	1	1	
5-15		3RS-10214-0	* MAP SENSOR * ﾏｯﾌﾟｾﾝｻ	1	1	1	
5-16		921503-5510	* SCREW * ｽｸﾘｭ	2	2	2	
5-17		921503-5516	* SCREW * ｽｸﾘｭ	2	2	2	
5-18		930103-0600	NUT ﾅｯﾄ	2	2	2	
5-19		940103-0600	WASHER ﾜｯｼｬ	2	2	2	
5-20		3BJ-02011-0	CARBURETOR GASKET ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ	1	1	1	
5-21		3RS-10212-0	HOSE ﾎｰｽ	1	1	1	SC Valve-Intake Silencer
5-22		3RS-02409-0	INTAKE SILENCER ASSY ｲﾝﾃｰｸｻｲﾚﾝｻｱｯｼ	1	1	1	
5-23		910103-0620	BOLT ﾎﾞﾙﾄ	2	2	2	
5-24		910103-5630	BOLT ﾎﾞﾙﾄ	2	2	2	
5-25		3KY-06920-0	RUBBER MOUNT ﾗﾊﾞｰﾏｳﾝﾄ	2	2	2	
5-26		3RS-76079-0	COLLAR ｶﾗｰ	2	2	2	
5-27		3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	2	2	2	
5-28	1	3RT-02418-0	GASKET ｶﾞｽｹｯﾄ		1		
5-28	2	3RS-02418-0	GASKET ｶﾞｽｹｯﾄ			1	

Fig. 5 FUEL PUMP
フュエルポンプ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
5-28	3	3RU-02418-0	GASKET ｶﾞｽｹｯﾄ	1			
5-29	1	3RT-03536-0	RESTRICTOR ﾘｽﾄﾘｸﾀ		1		
5-29	2	3RU-03536-0	RESTRICTOR ﾘｽﾄﾘｸﾀ	1			
5-30		3RS-10150-0	VAPOR SEPARATOR ASSY ﾍﾞｰﾊﾟｾﾊﾟﾚｰﾀｱｯｼ	1	1	1	
5-31		3RS-10179-0	* COVER *ｶﾊﾞｰ	1	1	1	
5-32		3RS-10180-0	* SEAL *ｼｰﾙ	1	1	1	
5-33		921503-0408	* SCREW *ｽｸﾘｭ	4	4	4	
5-34		3RS-03292-0	* DRAIN SCREW *ﾄﾞﾚﾝｽｸﾘｭ	1	1	1	
5-35		3RS-04116-0	* GASKET *ｶﾞｽｹｯﾄ	1	1	1	
5-36		3RS-03239-0	* FLOAT VALVE ASSY *ﾌﾛｰﾄﾊﾞﾙﾌﾞｱｯｼ	1	1	1	
5-37		3RS-03232-0	* FLOAT ARM PIN *ﾌﾛｰﾄｱｰﾑﾋﾟﾝ	1	1	1	
5-38		3RS-03230-0	* FLOAT *ﾌﾛｰﾄ	1	1	1	
5-39		3RS-04314-0	* GROMMET *ｸﾞﾛﾒｯﾄ	1	1	1	
5-40		3RS-04322-0	* FILTER (INLET) *ﾌｨﾙﾀ(ｲﾝﾚｯﾄ)	1	1	1	
5-42		3RS-10157-0	* HOLDER *ﾎﾙﾀﾞ	1	1	1	Regulator
5-43		3RS-04302-0	* FUEL FEED PUMP *ﾌｭｴﾙﾌｨｰﾄﾞﾎﾟﾝﾌﾟ	1	1	1	
5-44		3RS-03116-0	* O-RING *Oﾘﾝｸﾞ	1	1	1	FFP Out Side
5-45		3RT-03116-0	* O-RING *Oﾘﾝｸﾞ	1	1	1	Connector
5-46		3RS-10095-0	* O-RING *Oﾘﾝｸﾞ	1	1	1	Regulator
5-47		3RS-10154-0	* FUEL REGULATOR *ﾌｭｴﾙﾚｷﾞｭﾚｰﾀ	1	1	1	
5-48		921503-0408	* SCREW *ｽｸﾘｭ	1	1	1	
5-49		3RS-10172-0	* VST CONNECTOR *VSTｺﾈｸﾀ	1	1	1	
5-50		3RS-03244-0	* CLIP *ｸﾘｯﾌﾟ	1	1	1	
5-51		921503-0516	* SCREW *ｽｸﾘｭ	1	1	1	
5-52		3KY-06920-0	RUBBER MOUNT ﾗﾊﾞｰﾏｳﾝﾄ	2	2	2	
5-53		3RS-76079-0	COLLAR ｶﾗｰ	2	2	2	
5-54		3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	2	2	2	
5-55		910103-0625	BOLT ﾎﾞﾙﾄ	2	2	2	
5-56		3RS-02168-0	FUEL HOSE W/PROTECTOR ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	VST-Fuel Rail

Fig. 5 FUEL PUMP
フュエルポンプ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
5-57		3AC-10087-0	CLAMP φ16.8 ｸﾗﾝﾌﾟ φ16.8	2	2	2	
5-58		3RS-10185-0	VENT HOSE W/PROTECTOR ﾍﾞﾝﾄﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	VST-Catch Tank
5-59		3RT-10185-0	VENT HOSE W/PROTECTOR ﾍﾞﾝﾄﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	Catch Tank-Vent
5-60		3RU-10185-0	VENT HOSE W/PROTECTOR ﾍﾞﾝﾄﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	Catch Tank-Exposure
5-61		3H8-04000-1	FUEL PUMP ASSY ﾌｭｴﾙﾎﾟﾝﾌﾟｱｯｼ	1	1	1	
5-62		3H8-62415-0	O-RING 3.5-25.7 Oﾘﾝｸﾞ 3.5-25.7	1	1	1	
5-63		910103-5625	BOLT ﾎﾞﾙﾄ	2	2	2	
5-64	1	3RS-04080-0	FUEL HOSE W/PROTECTOR ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	Fuel Pump-VST
5-64	2	3RS-04077-0	FUEL HOSE W/PROTECTOR ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	Fuel Pump-VST US Model
5-65	1	3RT-04080-0	FUEL HOSE W/PROTECTOR ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	Fuel Filter-Fuel Pump
5-65	2	3RS-02166-0	FUEL HOSE W/PROTECTOR ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	Fuel Filter-Fuel Pump US Model
5-66		3GT-35143-0	CLIP φ9.4 ｸﾘｯﾌﾟ φ9.4	2	2	2	Fuel Pump-VST
5-67		3GT-35143-0	CLIP φ9.4 ｸﾘｯﾌﾟ φ9.4	2	2	2	Fuel Filter-Fuel Pum
5-69		3RS-02232-0	FUEL FILTER HOLDER ﾌｭｴﾙﾌｨﾙﾀﾎﾙﾀﾞ	1	1	1	
5-70		3RS-02239-0	PLATE ﾌﾟﾚｰﾄ	1	1	1	
5-71		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
5-72		3RS-76117-0	CLAMP ｸﾗﾝﾌﾟ	1	1	1	
5-73		3T1-06915-0	CLAMP φ10 ｸﾗﾝﾌﾟ φ10	3	3	3	
5-75		3RT-65212-0	WATER HOSE ｳｫｰﾀﾎｰｽ	1	1	1	Drive Shaft Housing-Fuel Cooler
5-76		3RS-65210-0	COOLING HOSE ｸｰﾘﾝｸﾞﾎｰｽ	1	1	1	Idle Port Cover-Nipple
5-77		3RT-65210-0	COOLING HOSE ｸｰﾘﾝｸﾞﾎｰｽ	1	1	1	Idle Port Cover-Fuel Cooler
5-78		3RS-07734-0	BREATHER HOSE W/PROTECTOR ﾌﾞﾘｰｻﾞﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	Head Cover-Intake Silencer
5-79		3C7-02215-0	CLIP φ12 ｸﾘｯﾌﾟ φ12	1	1	1	Head Side
5-80		3RS-01138-0	NIPPLE ﾆｯﾌﾟﾙ	2	2	2	Drive Shaft Housing
5-81		9101E3-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
5-82	1	3RU-04080-0	FUEL HOSE W/PROTECTOR ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ	1	1	1	Fuel Connector - Fuel Filter
5-82	2	3JK-02160-0	FUEL HOSE W/PROTECTOR 455-25 ﾌｭｴﾙﾎｰｽ W/ﾌﾟﾛﾃｸﾀ 455-25	1	1	1	Fuel Connector - Fuel Filter for US Model
5-83		3GT-35143-0	CLIP φ9.4 ｸﾘｯﾌﾟ φ9.4	2	2	2	
5-84		369-84398-0	BAND 158 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 158	1	1	1	

Fig. 5 FUEL PUMP
フュエルポンプ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
5-85		3RS-02230-0	FUEL FILTER ASSY ﾌｭｴﾙﾌｨﾙﾀｰｱｯｼ	1	1	1	
5-86		3RS-02237-0	* CUP *ｶｯﾌﾟ	1	1	1	
5-87		3B7-02234-0	* FILTER *ﾌｨﾙﾀｰ	1	1	1	
5-88		3B7-02235-0	* O-RING *Oﾘﾝｸﾞ	1	1	1	
5-89		3RS-02235-0	* O-RING *Oﾘﾝｸﾞ	1	1	1	
5-90		3RS-02253-0	* DRAIN VALVE *ﾄﾞﾚﾝﾊﾞﾙﾌﾞ	1	1	1	
5-91		3RS-02258-0	* SEAL *ｼｰﾙ	1	1	1	
5-92		3RS-02229-0	* FLOAT *ﾌﾛｰﾄ	1	1	1	

Fig. 6 RECOIL STARTER
リコイルスタータ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
6-1		3RS-05090-0	RECOIL STARTER ASSY ﾘｺｲﾙｽﾀｰﾀｱｯｼ	1	1	1	
6-2		3RS-05105-0	* STARTER CASE * ｽﾀｰﾀｹｰｽ	1	1	1	
6-3		3AC-05258-0	* STARTER LOCK CAM SPRING * ｽﾀｰﾀﾛｯｸｶﾑｽﾌﾟﾘﾝｸﾞ	1	1	1	
6-4		3H8-05004-0	* STARTER SPRING * ｽﾀｰﾀｽﾌﾟﾘﾝｸﾞ	1	1	1	
6-5		3BJ-05104-0	* REEL * ﾘｰﾙ	1	1	1	
6-6		3BJ-05135-0	* BUSHING * ﾌﾞｯｼﾝｸﾞ	1	1	1	
6-7		3BJ-05003-0	* RATCHET * ﾗﾁｪｯﾄ	1	1	1	
6-8		3BJ-05913-0	* TAPPING SCREW * ﾀｯﾋﾟﾝｸﾞｽｸﾘｭ	1	1	1	
6-9		3RS-05913-0	* TAPPING SCREW * ﾀｯﾋﾟﾝｸﾞｽｸﾘｭ	1	1	1	
6-10		3RS-05012-0	* RETURN SPRING * ﾘﾀｰﾝｽﾌﾟﾘﾝｸﾞ	1	1	1	
6-11		3H8-05123-1	* RETURN SPRING * ﾘﾀｰﾝｽﾌﾟﾘﾝｸﾞ	1	1	1	
6-12		3RS-05007-0	* FRICTION SPRING * ﾌﾘｸｼｮﾝｽﾌﾟﾘﾝｸﾞ	1	1	1	
6-13		3R3-05006-0	* FRICTION PLATE * ﾌﾘｸｼｮﾝﾌﾟﾚｰﾄ	1	1	1	
6-14		3R3-05013-0	* STARTER ROPE φ5-1800 * ｽﾀｰﾀﾛｰﾌﾟ φ5-1800	1	1	1	
6-15		3RS-05019-0	* STARTER HANDLE * ｽﾀｰﾀﾊﾝﾄﾞﾙ	1	1	1	
6-16		3AB-05131-0	* ROPE ANCHOR * ﾛｰﾌﾟｱﾝｶ	1	1	1	
6-17		3R3-05252-0	* STARTER LOCK * ｽﾀｰﾀﾛｯｸ	1	1	1	
6-18		3R3-05216-0	* STARTER LOCK SPRING * ｽﾀｰﾀﾛｯｸｽﾌﾟﾘﾝｸﾞ	1	1	1	
6-19		3RS-05207-0	* STARTER LOCK WIRE * ｽﾀｰﾀﾛｯｸﾜｲﾔ	1	1	1	
6-20		3RS-67503-0	STARTER SEAL ｽﾀｰﾀｼｰﾙ	1	1	1	
6-21		3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	3	3	3	
6-22		3AL-60108-0	PRE-COATED BOLT 6-20 ﾌﾟﾚｺｰﾄﾎﾞﾙﾄ 6-20	3	3	3	
6-23		3RS-06308-1	BELT COVER ﾍﾞﾙﾄｶﾊﾞｰ	1	1	1	
6-24		172-36008-0	GROMMET 13-2 ｸﾞﾛﾒｯﾄ 13-2	2	2	2	
6-25	1	3PA-72181-1	CAUTION DECAL (B) ｺｰｼｮﾝﾃﾞｶｰﾙ(B)		1	1	EU Model
6-25	2	3NV-72181-0	CAUTION DECAL (B) ｺｰｼｮﾝﾃﾞｶｰﾙ (B)	1	1	1	
6-26		3RS-10320-0	AIR VENT ASSY ｴｱﾍﾞﾝﾄｱｯｼ	1	1	1	
6-27		3AC-05913-0	TAPPING SCREW 5-16 ﾀｯﾋﾟﾝｸﾞｽｸﾘｭ 5-16	3	3	3	

Fig. 7 MAGNETO・ELECTRIC PARTS
マグネト・エレクトリックパーツ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
7-1	1	3RS-06001-0	FLYWHEEL ﾌﾗｲﾎｲｰﾙ	1	1	1	for M Type
7-1	2	3RT-06191-0	FLYWHEEL W/RING GEAR ﾌﾗｲﾎｲｰﾙ W/ﾘﾝｸﾞｷﾞﾔ	1	1	1	for EF/EP Type
7-2	1	3RS-06023-0	ALTERNATOR ASSY ｵﾙﾀﾈｰﾀｱｯｼ	1	1	1	for M Type
7-2	2	3RT-06023-0	ALTERNATOR ASSY ｵﾙﾀﾈｰﾀｱｯｼ	1	1	1	for EF/EP Type
7-3		3RS-06071-0	PULSAR COIL ﾊﾟﾙｻｺｲﾙ	1	1	1	
7-4		910103-5512	BOLT ﾎﾞﾙﾄ	2	2	2	Pulsar
7-5		3T5-10131-0	KEY ｷｰ 13.4-5-4	1	1	1	
7-6		931121-1600	NUT ﾅｯﾄ	1	1	1	
7-7		3H8-00133-0	WASHER 16-27-3.2 ﾜｯｼｬ 16-27-3.2	1	1	1	
7-8		910103-5625	BOLT ﾎﾞﾙﾄ	3	3	3	Alternator
7-9		3RS-06008-0	COIL BRACKET ｺｲﾙﾌﾞﾗｹｯﾄ	1	1	1	
7-10		910103-5625	BOLT ﾎﾞﾙﾄ	4	4	4	Coil Bracket
7-11		3PR-06972-0	CLAMP 6.5-47.5P ｸﾗﾝﾌﾟ 6.5-47.5P	1	1	1	
7-12		345-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	2	
7-13		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
7-14	1	3RU-06401-0	ECU ASSY ECU ｱｯｼ	1			
7-14	2	3RT-06401-0	ECU ASSY ECU ｱｯｼ		1		
7-14	3	3RS-06401-0	ECU ASSY ECU ｱｯｼ			1	
7-15		3RS-06410-0	ECU HOLDER ECUﾎﾙﾀﾞ	1	1	1	
7-16		3RS-06322-0	PLATE ﾌﾟﾚｰﾄ	1	1	1	
7-17		3RT-06322-0	PLATE ﾌﾟﾚｰﾄ	1	1	1	
7-18		910103-5616	BOLT ﾎﾞﾙﾄ	2	2	2	
7-19		3BJ-84398-0	BAND 135 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 135	2	2	2	
7-20		369-84398-0	BAND 158 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 158	1	1	1	
7-21		369-84398-0	BAND 158 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 158	1	1	1	
7-22		369-84398-0	BAND 158 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 158	1	1	1	for PT Type
7-23	1	3RS-76110-0	CORD ASSY ｺｰﾄﾞｱｯｼ	1	1	1	for MF Type
7-23	2	3RT-76110-0	CORD ASSY ｺｰﾄﾞｱｯｼ	1	1	1	for EF/EFT Type
7-23	3	3RU-76110-0	CORD ASSY ｺｰﾄﾞｱｯｼ	1	1	1	for EP/EPT Type

Fig. 7 MAGNETO・ELECTRIC PARTS
マグネト・エレクトリックパーツ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
7-24		3T5-76247-0	* FUSE 20A * ﾋｭｰｽﾞ 20A	1	1	1	
7-25		910103-5612	BOLT ﾎﾞﾙﾄ	2	2	2	
7-26		3RS-06040-0	IGNITION COIL W/R-CAP ｲｸﾞﾆｯｼｮﾝｺｲﾙ W/R-ｷｬｯﾌﾟ	1	1	1	
7-27		3AC-06999-0	* PLUG CAP W/RESISTANCE * ﾌﾟﾗｸﾞｷｬｯﾌﾟ W/ﾚｼﾞｽﾀﾝｽ	2	2	2	
7-28		910103-5625	BOLT ﾎﾞﾙﾄ	2	2	2	
7-29		3H6-07611-0	OIL PRESSURE SWITCH ｵｲﾙﾌﾟﾚｯｼｬｽｲｯﾁ	1	1	1	
7-30		3KY-72510-0	ENGINE TEMP SENSOR ｴﾝｼﾞﾝﾃﾝﾌﾟｾﾝｻ	1	1	1	
7-31		3A3-76037-0	CABLE TERMINAL PLUG ｹｰﾌﾞﾙﾀｰﾐﾅﾙ ﾌﾟﾗｸﾞ	2	2	2	
7-32		3V1-06133-0	PROTECTOR φ24-70 ﾌﾟﾛﾃｸﾀ φ24-70	1	1	1	
7-33		3BJ-06133-0	PROTECTOR φ10.7-320 ﾌﾟﾛﾃｸﾀ φ10.7-320	1	1	1	
7-34		3BA-06133-0	PROTECTOR φ10.7-180 ﾌﾟﾛﾃｸﾀ φ10.7-180	1	1	1	
7-35	1	3RS-06899-0	ELECTRIC BRACKET ASSY ｴﾚｸﾄﾘｯｸﾌﾞﾗｹｯﾄｱｯｼ	1	1	1	for EF/EP Type
7-35	2	3RT-06899-0	ELECTRIC BRACKET ASSY ｴﾚｸﾄﾘｯｸﾌﾞﾗｹｯﾄｱｯｼ	1	1	1	for EFT/EPT Type
7-36		3RS-06901-0	* BRACKET * ﾌﾞﾗｹｯﾄ	1	1	1	
7-37		3H8-76040-0	* STARTER SOLENOID * ｽﾀｰﾀｿﾚﾉｲﾄﾞ	1	1	1	
7-38		910103-5610	* BOLT * ﾎﾞﾙﾄ	2	2	2	
7-39		3C8-72580-0	* PTT SOLENOID SWITCH (A) * PTTｿﾚﾉｲﾄﾞｽｲｯﾁ (A)	1	1	1	
7-40		930103-0600	* NUT * ﾅｯﾄ	3	3	3	
7-41		941303-0600	* SPRING WASHER * ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ	3	3	3	
7-42		3C8-72581-0	* PTT SOLENOID SWITCH (B) * PTTｿﾚﾉｲﾄﾞｽｲｯﾁ (B)	1	1	1	
7-43		930103-0600	* NUT * ﾅｯﾄ	3	3	3	
7-44		941303-0600	* SPRING WASHER * ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ	3	3	3	
7-45		3RS-72582-0	* SOLENOID SWITCH CORD (A) * ｿﾚﾉｲﾄﾞｽｲｯﾁｺｰﾄﾞ (A)	1	1	1	Red
7-46		3RS-72583-0	* SOLENOID SWITCH CORD (B) * ｿﾚﾉｲﾄﾞｽｲｯﾁｺｰﾄﾞ (B)	1	1	1	
7-47		3Y1-76145-0	* TERMINAL CAP 8-13-28 * ﾀｰﾐﾅﾙｷｬｯﾌﾟ	4	4	4	Red
7-48		3A3-76145-0	* TERMINAL CAP 8-13-28 * ﾀｰﾐﾅﾙｷｬｯﾌﾟ ｽﾀｰﾀ	2	2	2	Black
7-49		910103-5612	* BOLT * ﾎﾞﾙﾄ	2	2	2	
7-50		3B7-76142-1	* GROUND CABLE L=120 * ｸﾞﾗﾝﾄﾞｹｰﾌﾞﾙ (AV2) L=120	1	1	1	
7-51		3T5-84398-0	* BAND 104 * ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 104	2	2	2	

Fig. 7 **MAGNETO・ELECTRIC PARTS**
マグネト・エレクトリックパーツ




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
7-52	3KY-06920-0	RUBBER MOUNT ラバーマウント	3	3	3	
7-53	3RS-76079-0	COLLAR カラー	3	3	3	
7-54	3C8-66308-0	WASHER 6-16-1.5 ワッシャ 6-16-1.5	3	3	3	
7-55	910103-0625	BOLT ボルト	3	3	3	
7-56	3RS-76010-0	STARTER MOTOR ASSY スタータモータアッシ	1	1	1	
7-57	930203-0600	* NUT * ナット	2	2	2	
7-58	3GF-75019-0	* BOLT * ボルト	2	2	2	
7-59	941303-0600	* SPRING WASHER * スプリングワッシャ	2	2	2	
7-60	941321-0500	* SPRING WASHER * スプリングワッシャ	2	2	2	
7-61	940221-0500	* WASHER * ワッシャ	2	2	2	
7-62	3RS-76015-0	* PINION ASSY * ピニオンアッシ	1	1	1	
7-63	3GF-75015-0	* WASHER * ワッシャ	1	1	1	
7-64	3GF-75014-0	* BRUSH HOLDER ASSY * ブラシホルダアッシ	1	1	1	
7-65	921521-6408	* SCREW * スクリュ	2	2	2	
7-66	3GF-75017-0	* BUSHING 2 * ブッシング 2	1	1	1	
7-67	3GF-75018-0	* O-RING * Oリング	1	1	1	
7-68	940103-0600	* WASHER * ワッシャ	2	2	2	
7-69	3GF-75016-0	* BUSHING 1 * ブッシング 1	1	1	1	
7-70	3RS-76009-0	STARTER MOTOR BAND スタータモータバンド	1	1	1	
7-71	3C8-76007-0	DAMPER ダンパ スタータモータ	1	1	1	
7-72	910103-5825	BOLT ボルト	2	2	2	
7-73	910103-5612	BOLT ボルト	2	2	2	
7-74	3RS-76060-0	RECTIFIER COMPLETE レクチファイヤコンプリート	1	1	1	
7-75	910103-5620	BOLT ボルト	2	2	2	
7-76	3RS-76163-0	RECTIFIER BRACKET レクチファイヤブラケット	1	1	1	
7-77	910103-5612	BOLT ボルト	2	2	2	
7-78	3BH-76120-0	BATTERY CABLE バッテリケーブル	1	1	1	
7-79	910103-5612	BOLT ボルト	1	1	1	
7-80	3BJ-76145-0	TERMINAL CAP 15.5-20-28 ターミナルキャップ	1	1	1	

Fig. 7 MAGNETO・ELECTRIC PARTS
マグネト・エレクトリックパーツ




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
7-81		3Y0-76145-0	TERMINAL CAP 8-18-28 ﾀｰﾐﾅﾙｷｬｯﾌﾟ	1	1	1	Red
7-82		3AA-76145-0	TERMINAL CAP 13-13-28 ﾀｰﾐﾅﾙｷｬｯﾌﾟ	1	1	1	
7-83		345-06915-0	CLAMP 6.5-14L ｸﾗﾝﾌﾟ 6.5-14L	1	1	1	
7-84		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
7-85		3RS-76141-0	STARTER CABLE ｽﾀｰﾀｹｰﾌﾞﾙ	1	1	1	Starter Solenoid-Stater Motor
7-86		3B7-76142-1	GROUND CABLE L=120 ｸﾞﾗﾝﾄﾞｹｰﾌﾞﾙ (AV2) L=120	1	1	1	

Fig. 8 DRIVE SHAFT HOUSING
ドライブシャフトハウジング




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
8-1	1	3RSQ61020-0	DRIVE SHAFT HOUSING ASSY (S) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ (S)	1	1	1	
8-1	2	3RSQ61030-0	DRIVE SHAFT HOUSING ASSY (L) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ (L)	1	1	1	
8-1	3	3RTQ61020-0	DRIVE SHAFT HOUSING ASSY (S) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ (S)	1	1	1	PT Type
8-2		350-01215-1	OIL SEAL 12.8-25-7 ｵｲﾙｼｰﾙ 12.8-25-7	1	1	1	
8-3		3R3-07705-1	DRAIN BOLT 14-14 ﾄﾞﾚﾝﾎﾞﾙﾄ	1	1	1	
8-4		3R3-07406-0	WASHER 14.5-24-1 ﾜｯｼｬ 14.5-24-1	1	1	1	
8-5		345-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	2	
8-6		3AB-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	2	
8-7		3AB-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2		2	Extension Housing
8-8	1	3RS-65100-0	WATER PIPE (S) ｳｫｰﾀﾊﾟｲﾌﾟ (S)	1	1	1	
8-8	2	3RS-65110-0	WATER PIPE (L) ｳｫｰﾀﾊﾟｲﾌﾟ (L)	1	1	1	
8-8	3	3RS-65120-0	WATER PIPE (UL) ｳｫｰﾀﾊﾟｲﾌﾟ (UL)	1		1	
8-9		3V1-65206-0	WATER PIPE SEAL (UPPER) ｳｫｰﾀﾊﾟｲﾌﾟｼｰﾙ (ｱｯﾊﾟｰ)	1	1	1	
8-10		3RS-65203-0	LOCK PLATE ﾛｯｸﾌﾟﾚｰﾄ	1	1	1	
8-11		3V1-65204-0	WATER PIPE AUXILIARY MOUNT 13-2.5 ｳｫｰﾀﾊﾟｲﾌﾟｵｳｷｼﾘｱﾘﾏｳﾝﾄ 13-2.5	1	1	1	
8-12		9101E3-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
8-13		3C8-62396-1	GROUND L=210 ｸﾞﾗﾝﾄﾞ (ｱｰｽﾜｲﾔ) L=210	1	1	1	Drive Shaft Housing-Mount Bracket
8-14		910103-0612	BOLT ﾎﾞﾙﾄ	1	1	1	
8-15		3RS-72404-0	FLUSHING CONNECTOR CAP ﾌﾗｯｼﾝｸﾞｺﾈｸﾀｷｬｯﾌﾟ	1	1	1	
8-16		3RS-67147-0	SEAL RING ｼｰﾙﾘﾝｸﾞ	1	1	1	
8-17		3RSQ61209-0	IDLE EXHAUST PORT COVER ASSY ｱｲﾄﾞﾙｴｷｿﾞｰｽﾄﾎﾟｰﾄｶﾊﾞｰｱｯｼ	1	1	1	
8-18		3RS-62114-0	PLATE ﾌﾟﾚｰﾄ	1	1	1	
8-19		9101E3-0512	BOLT ﾎﾞﾙﾄ	3	3	3	
8-20		3RS-61220-0	IDLE EXHAUST PORT GASKET ｱｲﾄﾞﾙｴｷｿﾞｰｽﾄﾎﾟｰﾄｶﾞｽｹｯﾄ	1	1	1	
8-21		9101E3-5616	BOLT ﾎﾞﾙﾄ	6	6	6	
8-22		3RS-67116-0	ENGINE BASEMENT SEAL ｴﾝｼﾞﾝﾍﾞｰｽｼｰﾙ	1	1	1	
8-23		3RSQ61110-0	EXTENSION HOUSING UL ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞ UL	1		1	
8-24		3BJ-60001-0	BOLT 8-31 ﾎﾞﾙﾄ	4		4	
8-25		3BJ-60003-0	DRIVE SHAFT BUSHING ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾌﾞｯｼﾝｸﾞ	1		1	

Fig. 8 DRIVE SHAFT HOUSING
ドライブシャフトハウジング




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
8-26		3V1-64332-0	STOPPER ｽﾄｯﾊﾟﾌﾞｯｼﾝｸﾞ	1		1	
8-27		9101E3-5612	BOLT ﾎﾞﾙﾄ	2		2	

Fig. 9 GEAR CASE
ギヤケース




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
9-1	3RSQ60000-0	GEAR CASE ASSY ｷﾞｬｹｰｽｱｯｼ	1	1	1	
9-2	3BJ-60211-0	* ROLLER BEARING * ﾛｰﾗﾍﾞｱﾘﾝｸﾞ	1	1	1	
9-3	3BJ-60215-0	BALL BEARING 6205HS ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6205HS	1	1	1	
9-4	332-60005-2	PLUG 8-8 ﾌﾟﾗｸﾞ 8-8	2	2	2	
9-5	332-60006-0	GASKET 8.1-15-1 ｶﾞｽｹｯﾄ 8.1-15-1	2	2	2	
9-6	362-60206-1	WATER STRAINER ｳｫｰﾀｽﾄﾚｰﾅ	2	2	2	
9-7	921503-0430	SCREW ｽｸﾘｭ	1	1	1	
9-8	930403-0400	NYLON NUT 4-P0.7 ﾅｲﾛﾝﾅｯﾄ 4-P0.7	1	1	1	
9-9	3KY-60218-0	ANODE ｱﾉｰﾄﾞ	1	1	1	
9-10	910103-5620	BOLT ﾎﾞﾙﾄ	1	1	1	
9-11	930403-0600	NYLON NUT 6-P1.0 ﾅｲﾛﾝﾅｯﾄ 6-P1.0	1	1	1	
9-12	3BJ-60001-0	BOLT 8-31 ﾎﾞﾙﾄ	4	4	4	
9-13	3RS-60041-0	WATER SEAL RUBBER ｳｫｰﾀｼｰﾙﾗﾊﾞｰ	1	1	1	
9-14	3RS-60042-0	WATER SEAL PLATE ｳｫｰﾀｼｰﾙﾌﾟﾚｰﾄ	1	1	1	
9-15	3RSQ60100-1	PROPELLER SHAFT HOUSING ASSY ﾌﾟﾛﾍﾟﾗｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ	1	1	1	
9-17	3RS-60213-0	* BALL BEARING * ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ	1	1	1	
9-18	121-32071-0	* O-RING 2.4-59.6 * Oﾘﾝｸﾞ 2.4-59.6	1	1	1	
9-19	346-65013-0	* OIL SEAL 17-30-9 * ｵｲﾙｼｰﾙ 17-30-9	1	1	1	
9-20	3BJ-60108-0	BOLT ﾌﾟﾚｺｰﾄﾎﾞﾙﾄ	2	2	2	
9-21	3RS-64010-0	BEVEL GEAR ASSY (A) ﾍﾞﾍﾞﾙｷﾞｬｱｯｼ (A)	1	1	1	
9-22	3RS-64020-0	BEVEL GEAR B ﾍﾞﾍﾞﾙｷﾞｱ B	1	1	1	
9-23	346-64027-1	NUT ﾅｯﾄ ﾍﾞﾍﾞﾙｷﾞﾔ B	1	1	1	
9-24	3RS-64030-0	BEVEL GEAR C ﾍﾞﾍﾞﾙｷﾞｱ C	1	1	1	
9-25	350-64032-0	WASHER 17.1-22-1.5 ﾜｯｼｬ 17.1-22-1.5	1	1	1	
9-26	3RS-64211-0	PROPELLER SHAFT ﾌﾟﾛﾍﾟﾗｼｬﾌﾄ	1	1	1	
9-27	3BJ-64215-0	CLUTCH ｸﾗｯﾁ	1	1	1	
9-28	350-64218-0	PIN φ5-30 ﾋﾟﾝ ｸﾗｯﾁ φ5-30	1	1	1	
9-29	350-64219-0	SNAP ｽﾅｯﾌﾟ ｸﾗｯﾁﾋﾟﾝ	1	1	1	
9-30	332-64221-0	SPRING ｽﾌﾟﾘﾝｸﾞ ｸﾗｯﾁ	1	1	1	

Fig. 9 GEAR CASE
ギヤケース




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
9-31		3RS-64223-0	PUSH ROD ﾌﾟｯｼｭﾛｯﾄﾞ	1	1	1	
9-32		3LD-65021-0	WATER PUMP IMPELLER ｲﾝﾍﾟﾗｳｫｰﾀﾎﾟﾝﾌﾟ	1	1	1	
9-33		3RS-65022-0	KEY ｷｰ	1	1	1	
9-34		3RS-65016-0	PUMP CASE (UPPER) ﾎﾟﾝﾌﾟｹｰｽ (ｱｯﾊﾟ)	1	1	1	
9-35		350-65011-1	PUMP CASE LINER ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ	1	1	1	
9-36		350-65014-0	WATER PIPE SEAL (LOWER) ｳｫｰﾀﾊﾟｲﾌﾟｼｰﾙ (ﾛﾜ)	1	1	1	
9-37		3RS-65002-0	PUMP CASE ASSY (LOWER) ﾎﾟﾝﾌﾟｹｰｽｱｯｼ (ﾛﾜ)	1	1	1	
9-38		332-60223-0	* OIL SEAL 13.8-26-9.5 * ｵｲﾙｼｰﾙ 13.8-26-9.5	1	1	1	
9-39		3RS-65020-0	PUMP CASE GASKET (LOWER) ﾎﾟﾝﾌﾟｹｰｽｶﾞｽｹｯﾄ (ﾛﾜ)	1	1	1	
9-40		3RS-65025-0	WATER PUMP GUIDE PLATE ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	1	
9-41		3RS-65029-0	GUIDE PLATE GASKET ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	1	
9-42		334-65012-0	DOWEL PIN 4-10 ﾀﾞｳｪﾙﾋﾟﾝ 4-10	2	2	2	
9-43		3RT-66033-0	STOPPER ｽﾄｯﾊﾟ ｶﾑﾛｯﾄﾞﾌﾞｯｼﾝｸﾞ	1	1	1	
9-44		3RS-66033-0	STOPPER ｽﾄｯﾊﾟ	1	1	1	
9-45		3RS-66021-0	O-RING Oﾘﾝｸﾞ	1	1	1	
9-46		9101E3-5625	BOLT ﾎﾞﾙﾄ	1	1	1	
9-47		9101E3-5652	BOLT ﾎﾞﾙﾄ	4	4	4	
9-48		910103-5512	BOLT ﾎﾞﾙﾄ	1	1	1	
9-49	1	346-64081-0	SHIM 35-41.9-0.1 ｼﾑ 35-41.9-0.1	A	A	A	
9-49	2	346-64082-0	SHIM 35-41.9-0.15 ｼﾑ 35-41.9-0.15	A	A	A	
9-49	3	346-64083-0	SHIM 35-41.9-0.3 ｼﾑ 35-41.9-0.3	A	A	A	
9-49	4	346-64084-0	SHIM 35-41.9-0.5 ｼﾑ 35-41.9-0.5	A	A	A	
9-50	1	3RS-64301-0	DRIVE SHAFT (S) ﾄﾞﾗｲﾌﾞｼｬﾌﾄ (S)	1	1	1	
9-50	2	3RS-64302-0	DRIVE SHAFT (L) ﾄﾞﾗｲﾌﾞｼｬﾌﾄ (L)	1	1	1	
9-50	3	3RS-64303-0	DRIVE SHAFT (UL) ﾄﾞﾗｲﾌﾞｼｬﾌﾄ (UL)	1		1	
9-51		3RT-60213-0	BALL BEARING ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ	1	1	1	
9-52	1	3RS-66012-0	CAM ROD ｶﾑﾛｯﾄﾞ	1	1	1	
9-52	2	3RS-66014-0	CAM ROD (UL) ｶﾑﾛｯﾄﾞ (UL)	1		1	
9-53		369-66011-0	CLUTCH CAM ｸﾗｯﾁｶﾑ	1	1	1	

Fig. 9 GEAR CASE
ギヤケース




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
9-54		951407-0310	SPRING PIN 3-10 ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-10	1	1	1	
9-55		951407-2512	SPRING PIN ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ	1	1	1	
9-56	1	362B64107-1	PROPELLER ASSY (6″) ﾌﾟﾛﾍﾟﾗｱｯｼ (6″)	1	1	1	OPT 3 x 234 x 155
9-56	2	362B64105-1	PROPELLER ASSY (7″) ﾌﾟﾛﾍﾟﾗｱｯｼ (7″)	1	1	1	OPT 3 x 174 x 234
9-56	3	3BAB64516-1	PROPELLER ASSY (8″) ﾌﾟﾛﾍﾟﾗｱｯｼ (8″)	1	1	1	MFS9.9 : L STD 3 x 235 x 203
9-56	4	3BAB64518-1	PROPELLER ASSY (9″) ﾌﾟﾛﾍﾟﾗｱｯｼ (9″)	1	1	1	MFS9.9 : S MFS15/20 : L/UL STD 3 x 235 x 299
9-56	5	3BAB64521-1	PROPELLER ASSY (10″) ﾌﾟﾛﾍﾟﾗｱｯｼ (10″)	1	1	1	MFS15/20 : S STD 3 x 235 x 254
9-56	6	3BAB64524-1	PROPELLER ASSY (11.5″) ﾌﾟﾛﾍﾟﾗｱｯｼ (11.5″)	1	1	1	OPT 3 x 235 x 299
9-56	7	3Z0S64514-3	PROPELLER ASSY (7″) ﾌﾟﾛﾍﾟﾗｱｯｼ (7″)	1	1	1	OPT 4 x 178 x 234
9-57		3RS-87326-0	PROPELLER HARDWARE KIT ﾌﾟﾛﾍﾟﾗﾊｰﾄﾞｳｪｱｷｯﾄ	1	1	1	
9-58		3RS-64231-0	* THRUST HOLDER * ｽﾗｽﾄﾎﾙﾀﾞ	1	1	1	
9-59		346-64124-5	* WASHER 12.5-32-2.5 * ﾜｯｼｬ 12.5-32-2.5	1	1	1	
9-60		346-64121-5	* PROPELLER NUT * ﾌﾟﾛﾍﾟﾗﾅｯﾄ	1	1	1	
9-61		951503-0322	* SPLIT PIN 3-22 * ｽﾌﾟﾘｯﾄﾋﾟﾝ 3-22	1	1	1	

Fig. 10 BRACKET (MANUAL)
ブラケット (マニュアル)




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
10-1		3RSQ62112-0	CLAMP BRACKET (R) ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (R)	1	1	1	Starboard Side
10-2		3RSQ62113-0	CLAMP BRACKET (L) ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (L)	1	1	1	Port Side
10-3		3H8-72049-0	CO-PILOT DECAL ｺﾊﾟｲﾛｯﾄﾃﾞｶﾙ	1	1	1	
10-4		338-60218-2	ANODE ｱﾉｰﾄﾞ	2	2	2	Clamp Bracket
10-5		338-60218-2	ANODE ｱﾉｰﾄﾞ	1	1	1	Mount Bracket
10-6		910103-5620	BOLT ﾎﾞﾙﾄ	3	3	3	
10-7		3RS-62117-0	DISTANCE PIECE ﾃﾞｨｽﾀﾝｽﾋﾟｰｽ	1	1	1	
10-8		9401E3-0600	WASHER ﾜｯｼｬ	2	2	2	Distance Piece Side
10-9		9401E3-0600	WASHER ﾜｯｼｬ	2	2	2	Nut Side
10-10		9301E3-0600	NUT ﾅｯﾄ	2	2	2	
10-11		3AC-62191-0	SWIVEL BRACKET SHAFT ASSY ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄｼｬﾌﾄｱｯｼ	1	1	1	
10-12		346-62124-1	NYLON NUT 7/8-14 ﾅｲﾛﾝﾅｯﾄ 7/8-14	1	1	1	
10-13		349-62126-0	BUSHING ﾌﾞｯｼﾝｸﾞ	2	2	2	
10-14		346-62127-0	CAP NUT ｷｬｯﾌﾟﾅｯﾄ ﾌﾞﾗｹｯﾄﾎﾞﾙﾄ	2	2	2	
10-15		3RS-62123-0	THRUST ROD ASSY ｽﾗｽﾄﾛｯﾄﾞｱｯｼ	1	1	1	
10-16		369-62122-2	* THRUST ROD SPRING * ｽﾗｽﾄﾛｯﾄﾞｽﾌﾟﾘﾝｸﾞ	1	1	1	
10-17	1	3RTQ62309-0	SWIVEL BRACKET ASSY ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄｱｯｼ	1	1	1	Transom "S"
10-17	2	3RSQ62309-0	SWIVEL BRACKET ASSY ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄｱｯｼ	1	1	1	Transom "L"&"UL"
10-19		344-67177-1	GREASE FITTING ｸﾞﾘｽﾌｨｯﾃｨﾝｸﾞ	3	3	3	
10-20		3A3-62396-1	GROUND L=110 ｸﾞﾗﾝﾄﾞ (ｱｰｽﾜｲﾔ) L=110	1	1	1	Swivel Bracket-Mount Bracket
10-21		3AA-61199-0	CARRYING HANDLE ｷｬﾘﾝｸﾞﾊﾝﾄﾞﾙ	1	1	1	
10-22		3RS-62441-0	FRICTION LEVER ﾌﾘｸｼｮﾝﾚﾊﾞｰ	1	1	1	
10-23		3R3-62443-0	WASHER 8.1-20-0.8 ﾜｯｼｬ 8.1-20-0.8	1	1	1	
10-24		3B7-63730-0	WASHER 8.5-24-1.5 ﾜｯｼｬ 8.5-24-1.5	1	1	1	
10-25		3RS-62445-0	BOLT ﾎﾞﾙﾄ	1	1	1	
10-26		3V5-62442-0	NYLON NUT 8-P1.25 ﾅｲﾛﾝﾅｯﾄ 8-P1.25	1	1	1	
10-27		345-66021-0	O-RING 1.9-6.8 Oﾘﾝｸﾞ 1.9-6.8	1	1	1	
10-28		3RS-62447-0	PLATE ﾌﾟﾚｰﾄ	1	1	1	
10-29		9101E3-5612	BOLT ﾎﾞﾙﾄ	2	2	2	

Fig. 10 BRACKET (MANUAL)
ブラケット (マニュアル)




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
10-30		3RS-62448-1	WASHER ﾜｯｼｬ	1	1	1	
10-31		3RS-62449-0	DISC 8.5-38-2 ﾃﾞｨｽｸｺﾊﾟｲﾛｯﾄ 8.5-38-2	2	2	2	
10-32		3RSQ62993-0	TILT STOPPER ﾁﾙﾄｽﾄｯﾊﾟ	1	1	1	
10-33		951403-0540	SPRING PIN ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ	1	1	1	
10-34		350-62437-0	BUSHING 8.2-10-26.5 ﾌﾞｯｼﾝｸﾞ 8.2-10-26.5	1	1	1	
10-35		350-62439-1	SETTING PLATE ｾｯﾃｨﾝｸﾞﾌﾟﾚｰﾄ	1	1	1	
10-36		9101E3-5818	BOLT ﾎﾞﾙﾄ	2	2	2	
10-37		3C8-62421-1	FRICTION SPRING ﾌﾘｸｼｮﾝｽﾌﾟﾘﾝｸﾞ	1	1	1	
10-38		346-62438-0	SETTING PIECE ｾｯﾃｨﾝｸﾞﾋﾟｰｽ ﾁﾙﾄｽﾄｯﾊﾟ	1	1	1	
10-39		3RS-66311-0	REVERSE LOCK LEVER ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰ	1	1	1	
10-40		3AL-66333-0	REVERSE LOCK LEVER GRIP ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰｸﾞﾘｯﾌﾟ	1	1	1	
10-41		346-66334-0	STOPPER ｽﾄｯﾊﾟ ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰｸﾞﾘｯﾌﾟ	1	1	1	
10-42		3AL-05254-0	SHOULDER BOLT 6-8 ｼｮﾙﾀﾞﾎﾞﾙﾄ 6-8	1	1	1	
10-43		9401E3-0800	WASHER ﾜｯｼｬ	1	1	1	
10-44		3AL-05212-0	BUSHING 8.1-20 ﾌﾞｯｼﾝｸﾞ 8.1-20	1	1	1	
10-45		3AA-83719-0	WASHER 8.5-18-1.6 ﾜｯｼｬ 8.5-18-1.6	1	1	1	
10-46		3R0-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	1	1	1	
10-47		3RS-66351-0	REVERSE LOCK (R) ﾘﾊﾞｰｽﾛｯｸ (R)	1	1	1	
10-48		3RS-66313-0	REVERSE LOCK ARM ﾘﾊﾞｰｽﾛｯｸｱｰﾑ	1	1	1	
10-49		3RS-66324-0	REVERSE LOCK SHAFT ﾘﾊﾞｰｽﾛｯｸｼｬﾌﾄ	1	1	1	
10-50		945303-0600	E-RING d=6 Eﾘﾝｸﾞ d=6	2	2	2	
10-51		3G2-66321-0	REVERSE LOCK ROD ﾘﾊﾞｰｽﾛｯｸﾛｯﾄﾞ A	1	1	1	
10-52		951503-0212	SPLIT PIN 2-12 ｽﾌﾟﾘｯﾄﾋﾟﾝ 2-12	2	2	2	
10-53		3RS-66312-0	REVERSE LOCK LINK ﾘﾊﾞｰｽﾛｯｸﾘﾝｸ	1	1	1	
10-54		3RS-66331-0	REVERSE LOCK SPRING (S) ﾘﾊﾞｰｽﾛｯｸｽﾌﾟﾘﾝｸﾞ (S)	2	2	2	
10-55		350-66315-0	REVERSE LOCK SPRING ﾘﾊﾞｰｽﾛｯｸｽﾌﾟﾘﾝｸﾞ	1	1	1	
10-56	1	3RTQ62010-0	STEERING SHAFT ASSY ｽﾃｱﾘﾝｸﾞｼｬﾌﾄｱｯｼ	1	1	1	
10-56	2	3RSQ62010-0	STEERING SHAFT ASSY ｽﾃｱﾘﾝｸﾞｼｬﾌﾄｱｯｼ	1	1	1	
10-57		3R3-62417-0	BUSHING 28-31-35 ﾌﾞｯｼﾝｸﾞ 28-31-35	2	2	2	

Fig. 10 BRACKET (MANUAL)
ブラケット (マニュアル)




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
10-58		3H8-62423-1	THRUST PLATE (UPPER) ｽﾗｽﾄﾌﾟﾚｰﾄ (ｱｯﾊﾟ)	2	2	2	
10-59		3H8-62415-0	O-RING 3.5-25.7 Oﾘﾝｸﾞ 3.5-25.7	1	1	1	
10-60		3RS-61301-0	RUBBER MOUNT (UPPER) ﾗﾊﾞｰﾏｳﾝﾄ (ｱｯﾊﾟ)	2	2	2	
10-61		9101E3-5830	BOLT ﾎﾞﾙﾄ	4	4	4	
10-62		3RS-61307-0	BOLT ﾎﾞﾙﾄ	2	2	2	
10-63		3RS-61333-0	DAMPER (UPPER) ﾀﾞﾝﾊﾟ (ｱｯﾊﾟ)	2	2	2	
10-64		3C8-62098-0	NYLON NUT 10-P1.25 ﾅｲﾛﾝﾅｯﾄ 10-P1.25	2	2	2	
10-65		9402E3-1000	WASHER ﾜｯｼｬ	2	2	2	
10-66		3RS-61337-0	DAMPER (UPPER) ﾀﾞﾝﾊﾟ (ｱｯﾊﾟ)	1	1	1	
10-67		3RS-61336-0	DAMPER (LOWER) ﾀﾞﾝﾊﾟ (ﾛﾜ)	1	1	1	
10-68		3RS-61302-0	RUBBER MOUNT (LOWER) ﾗﾊﾞｰﾏｳﾝﾄ (ﾛﾜ)	2	2	2	
10-69		3RSQ61401-0	MOUNT BRACKET (R) ﾏｳﾝﾄﾌﾞﾗｹｯﾄ (R)	1	1	1	Starboard Side
10-70		3RSQ61402-0	MOUNT BRACKET (L) ﾏｳﾝﾄﾌﾞﾗｹｯﾄ (L)	1	1	1	Port Side
10-71		9101E3-0885	BOLT ﾎﾞﾙﾄ	2	2	2	
10-72		3P0-66233-0	WASHER 8.1-16-1.5 ﾜｯｼｬ 8.1-16-1.5	2	2	2	
10-73		3RSQ62105-0	CLAMP SCREW KIT ｸﾗﾝﾌﾟｽｸﾘｭｷｯﾄ	2	2	2	
10-74		3RSQ62108-0	* CLAMP SCREW ASSY * ｸﾗﾝﾌﾟｽｸﾘｭｱｯｼ	1	1	1	
10-75		3RS-62106-0	** CLAMP SCREW ** ｸﾗﾝﾌﾟｽｸﾘｭ	1	1	1	
10-76		3RSQ62102-0	** CLAMP SCREW HANDLE ** ｸﾗﾝﾌﾟｽｸﾘｭﾊﾝﾄﾞﾙ	1	1	1	
10-77		951403-0622	** SPRING PIN ** ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ	1	1	1	
10-78		332-62101-1	* CLAMP SCREW PAD * ｸﾗﾝﾌﾟｽｸﾘｭﾊﾟｯﾄﾞ	1	1	1	
10-79		945303-0600	* E-RING d=6 * Eﾘﾝｸﾞ d=6	1	1	1	
10-80		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	

Fig. 11 BRACKET (PTT)
ブラケット (PTT)




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
11-1		3H6-60218-0	ANODE ｱﾉｰﾄﾞ	2	2	2	
11-2		398-62396-1	GROUND L=130 ｸﾞﾗﾝﾄﾞ(ｱｰｽﾜｲﾔ) L=130	1	1	1	Clamp Bracket (L)-PT
11-3		398-62396-1	GROUND L=130 ｸﾞﾗﾝﾄﾞ(ｱｰｽﾜｲﾔ) L=130	1	1	1	Clamp Bracket (R)-Swivel Brackey
11-4		3V5-62442-0	NYLON NUT 8-P1.25 ﾅｲﾛﾝﾅｯﾄ 8-P1.25	2	2	2	
11-5		3P0-66233-0	WASHER 8.1-16-1.5 ﾜｯｼｬ 8.1-16-1.5	2	2	2	
11-6		3Z0Q77211-2	CLAMP BRACKET (PTT-R) ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (PTT-R)	1	1	1	
11-7		3Z0Q77212-0	CLAMP BRACKET (PTT-L) ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (PTT-L)	1	1	1	
11-8		3Z0-77115-0	TRIM LOCK PIN ﾄﾘﾑﾛｯｸﾋﾟﾝ	2	2	2	
11-9		910103-5616	BOLT ﾎﾞﾙﾄ	2	2	2	
11-10		3AA-62116-0	WASHER 22-36-1 ﾜｯｼｬ 22-36-1	2	2	2	Nylon
11-11		307-62116-1	WASHER 8.5-28-1 ﾜｯｼｬ 8.5-28-1	2	2	2	
11-12	1	3RSQ77208-0	SWIVEL BRACKET ASSY ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄｱｯｼ (PTT)	1	1	1	Transom "L"&"UL"
11-12	2	3RTQ77208-0	SWIVEL BRACKET ASSY ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄｱｯｼ(PTT)	1	1	1	Transom "S"
11-13		3Z0-62476-2	TILT STOPPER ﾁﾙﾄｽﾄｯﾊﾟ (PTT)	1	1	1	
11-14		369-62433-1	TILT STOPPER GRIP ﾁﾙﾄｽﾄｯﾊﾟｸﾞﾘｯﾌﾟ	1	1	1	
11-15		9401E3-1000	WASHER ﾜｯｼｬ	1	1	1	
11-16		951403-3516	SPRING PIN 3.5-16 ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3.5-16	1	1	1	
11-17		3R0-62473-0	TILT STOPPER SPRING ﾁﾙﾄｽﾄｯﾊﾟｽﾌﾟﾘﾝｸﾞ	1	1	1	
11-18		353-63207-0	COLLAR 10.2-12-12 ｶﾗｰ 10.2-12-12	2	2	2	
11-19		3Z0-84398-0	BAND 203 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 203	2	2	2	
11-20		3KY-77071-0	CYLINDER PIN (UPPER) ｼﾘﾝﾀﾞﾋﾟﾝ (ｱｯﾊﾟ)	1	1	1	
11-21		3Z0-77076-0	BUSHING 13-16-31 ﾌﾞｯｼﾝｸﾞ 13-16-31	1	1	1	
11-22		3R0-77076-0	BUSHING 13-17-19.5 13-17-19.5 ﾌﾞｯｼﾝｸﾞ 13-17-19.5	2	2	2	
11-23		3Z0-77076-0	BUSHING 13-16-31 ﾌﾞｯｼﾝｸﾞ 13-16-31	4	4	4	
11-24		345-05122-1	WASHER 6.5-23-1.5 ﾜｯｼｬ 6.5-23-1.5	1	1	1	
11-25		9101E3-0612	BOLT ﾎﾞﾙﾄ	1	1	1	
11-26		3Z0-77101-1	CYLINDER PIN (LOWER) ｼﾘﾝﾀﾞﾋﾟﾝ (ﾛﾜ)	1	1	1	
11-27		9101E3-0820	BOLT ﾎﾞﾙﾄ	2	2	2	
11-28		3BJ-72120-0	RIGGING BOLT SET ﾘｷﾞﾝｸﾞﾎﾞﾙﾄｾｯﾄ	1	1	1	

Fig. 11 BRACKET (PTT)
ブラケット (PTT)




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
11-29	9101E3-0885	* BOLT * ﾎﾞﾙﾄ	4	4	4	
11-30	9301E3-0800	* NUT * ﾅｯﾄ	4	4	4	
11-31	9401E3-0800	* WASHER * ﾜｯｼｬ	8	8	8	
11-32	3RS-77217-0	CLAMP SCREW KIT ｸﾗﾝﾌﾟｽｸﾘｭｷｯﾄ	2	2	2	
11-33	3RS-77216-0	* CLAMP SCREW (PTT) * ｸﾗﾝﾌﾟｽｸﾘｭ (PTT)	1	1	1	
11-34	332-62101-1	* CLAMP SCREW PAD * ｸﾗﾝﾌﾟｽｸﾘｭﾊﾟｯﾄﾞ	1	1	1	
11-35	945303-0600	* E-RING d=6 * Eﾘﾝｸﾞ d=6	1	1	1	
11-36	9101E3-5616	BOLT ﾎﾞﾙﾄ	1	1	1	
11-36a	345-06915-0	CLAMP 6.5-14L ｸﾗﾝﾌﾟ 6.5-14L	1	1	1	
11-37	910103-5612	BOLT ﾎﾞﾙﾄ	4	4	4	
11-38	3RSQ77151-0	PT ASSY PT ｱｯｼ	1	1	1	
11-39	3Z0-77221-0	* CAP ASSY * ｷｬｯﾌﾟｱｯｼ	1	1	1	
11-40	3B7-77169-0	** O-RING ** Oﾘﾝｸﾞ	1	1	1	
11-41	3BA-77175-0	* MANUAL VALVE ASSY * ﾏﾆｭｱﾙﾊﾞﾙﾌﾞｱｯｼ	1	1	1	
11-42	3R0-77177-0	** O-RING 2.4-9.8 ** Oﾘﾝｸﾞ 2.4-9.8	1	1	1	
11-43	3Z0-77179-0	** O-RING ** Oﾘﾝｸﾞ	1	1	1	
11-44	3R0-77171-0	* C-RING * Cﾘﾝｸﾞ	1	1	1	
11-45	3AC-77173-0	* SEAL WASHER * ｼｰﾙﾜｯｼｬ	1	1	1	
11-46	3BA-77450-0	* RELIEF VALVE ASSY * ﾘﾘｰﾌﾊﾞﾙﾌﾞｱｯｼ	1	1	1	
11-47	3Z0-77179-0	** O-RING ** Oﾘﾝｸﾞ	1	1	1	
11-48	3Z0-77460-0	* VALVE ASSY * ﾊﾞﾙﾌﾞｱｯｼ	1	1	1	
11-49	3R0-77451-0	** O-RING 1.5-3.5 ** Oﾘﾝｸﾞ 1.5-3.5	1	1	1	
11-50	3B7-77169-0	* O-RING * Oﾘﾝｸﾞ	2	2	2	
11-51	3B7-77430-0	* PUMP * ﾎﾟﾝﾌﾟ	1	1	1	
11-52	3B7-77432-1	* BOLT * ﾎﾞﾙﾄ	2	2	2	
11-53	3B7-77431-1	* BOLT * ﾎﾞﾙﾄ	1	1	1	
11-54	3Z0-77431-0	* BOLT * ﾎﾞﾙﾄ	2	2	2	
11-55	3B7-77434-1	* FILTER * ﾌｨﾙﾀ B	1	1	1	
11-56	3E0-77163-0	* COUPLING * ｶｯﾌﾟﾘﾝｸﾞ ﾎﾟﾝﾌﾟ	1	1	1	

Fig. 11 BRACKET (PTT)
ブラケット (PTT)




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
11-57		3R0-77167-0	* O-RING 2-62.5 * Oﾘﾝｸﾞ 2-62.5	1	1	1	
11-58		3Z1-84398-1	* BAND * ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ	1	1	1	
11-59		3V1-64333-0	* PRE-COATED SCREW 5-12 * ﾌﾟﾚｺｰﾄｽｸﾘｭ 5-12	1	1	1	
11-60		3RS-77180-0	* MOTOR ASSY * ﾓｰﾀｱｯｼ	1	1	1	
11-61		3RS-77192-0	** MOTOR BRACKET ASSY ** ﾓｰﾀﾌﾞﾗｹｯﾄｱｯｼ	1	1	1	
11-62		3Z0-77191-0	*** BREAKER *** ﾌﾞﾚｰｶ	1	1	1	
11-63		3Z0-77187-0	*** BREAKER HOLDER *** ﾌﾞﾚｰｶﾎﾙﾀﾞ	1	1	1	
11-64		3Z0-77167-0	*** O-RING *** Oﾘﾝｸﾞ	1	1	1	
11-65		3E0-77183-0	*** BRUSH *** ﾌﾞﾗｼ	1	1	1	
11-66		3E0-77184-0	*** BRUSH SPRING *** ﾌﾞﾗｼｽﾌﾟﾘﾝｸﾞ	2	2	2	
11-67		921521-5512	*** SCREW *** ｽｸﾘｭ	3	3	3	
11-68		3Z0-77186-0	*** BRUSH HOLDER *** ﾌﾞﾗｼﾎﾙﾀﾞ	1	1	1	
11-69		3E0-77193-0	*** OIL SEAL *** ｵｲﾙｼｰﾙ	1	1	1	
11-70		3Z0-77190-0	** ARMATURE ASSY ** ｱｰﾏﾁｭｱｱｯｼ	1	1	1	
11-71		9215E3-5512	** SCREW ** ｽｸﾘｭ	2	2	2	
11-72		3Z0-77195-0	** YOKE ASSY ** ﾖｰｸｱｯｼ	1	1	1	

Fig. 12 TILLER HANDLE・SHIFT
ティラハンドル・シフト




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
12-1		3RS-63622-0	THROTTLE DRUM ASSY ｽﾛｯﾄﾙﾄﾞﾗﾑｱｯｼ	1	1	1	
12-3		3RS-66124-0	COLLAR ｶﾗｰ	1	1	1	
12-4		3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	2	2	2	
12-5		910103-0640	BOLT ﾎﾞﾙﾄ	1	1	1	
12-6		3RS-63508-0	THROTTLE WIRE BRACKET ｽﾛｯﾄﾙﾜｲﾔﾌﾞﾗｹｯﾄ	1	1	1	
12-7		910103-5616	BOLT ﾎﾞﾙﾄ	2	2	2	
12-8		3RS-63610-0	LINK ROD ASSY (THROTTLE) ﾘﾝｸﾛｯﾄﾞｱｯｼ (ｽﾛｯﾄﾙ)	1	1	1	
12-9		3RS-63617-0	* THROTTLE ROD * ｽﾛｯﾄﾙﾛｯﾄﾞ	1	1	1	
12-10		3B7-05243-0	* BALL JOINT CONNECTOR * ﾎﾞｰﾙｼﾞｮｲﾝﾄｺﾈｸﾀ	2	2	2	
12-11		930103-0500	* NUT * ﾅｯﾄ	2	2	2	
12-12		3RS-66043-0	GROMMET ｸﾞﾛﾒｯﾄ	1	1	1	
12-13		3GF-66113-1	SHIFT DETENT SPRING ｼﾌﾄﾃﾞｨﾃﾝﾄｽﾌﾟﾘﾝｸﾞ	2	2	2	
12-14		3Y1-66117-0	SHIFT DETENT SUPPORTER ｼﾌﾄﾃﾞｨﾃﾝﾄｻﾎﾟｰﾀｰ	1	1	1	
12-15		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
12-16		3RS-66130-0	SHIFT LEVER SHAFT ASSY ｼﾌﾄﾚﾊﾞｰｼｬﾌﾄｱｯｼ	1	1	1	
12-17		3RS-66145-0	HOLDER ﾎﾙﾀﾞ	1	1	1	C/case Right Side
12-18		3RT-66145-0	HOLDER ﾎﾙﾀﾞ	1	1	1	C/case Left Side
12-19		910103-5620	BOLT ﾎﾞﾙﾄ	4	4	4	
12-20	1	3RS-66214-0	SHIFT ROD (S) ｼﾌﾄﾛｯﾄﾞ (S)	1	1	1	
12-20	2	3RS-66215-0	SHIFT ROD (L) ｼﾌﾄﾛｯﾄﾞ (L)	1	1	1	
12-21		3AA-66241-0	SHIFT ROD JOINT ｼﾌﾄﾛｯﾄﾞｼﾞｮｲﾝﾄ	1	1	1	
12-22		930103-0500	NUT ﾅｯﾄ	1	1	1	
12-23		3NV-76080-0	NEUTRAL SWITCH ﾆｭｰﾄﾗﾙｽｲｯﾁ	1	1	1	
12-24		398-76083-0	NEUTRAL SWITCH ACTUATOR ﾆｭｰﾄﾗﾙｽｲｯﾁｱｸﾁｴｰﾀ	1	1	1	
12-25		3RS-76081-0	NEUTRAL SWITCH BRACKET ﾆｭｰﾄﾗﾙｽｲｯﾁﾌﾞﾗｹｯﾄ	1	1	1	
12-26		910103-5616	BOLT ﾎﾞﾙﾄ	1	1	1	
12-27		3RSQ63003-0	TILLER HANDLE ASSY ﾃｨﾗﾊﾝﾄﾞﾙｱｯｼ	1	1	1	PT Type
12-28		3RTQ63003-0	* TILLER HANDLE ASSY * ﾃｨﾗﾊﾝﾄﾞﾙｱｯｼ	1	1	1	
12-29		350-67154-0	** PLASTIC RIVET 6.5 ** ﾌﾟﾗｽﾁｯｸﾘﾍﾞｯﾄ 6.5	1	1	1	

Fig. 12 TILLER HANDLE・SHIFT
ティラハンドル・シフト




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
12-30	3B2-63104-1	** STUD ** ｽﾀｯﾄﾞ	1	1	1	
12-31	3R3-63012-0	** GRIP ** ｸﾞﾘｯﾌﾟ	1	1	1	
12-32	3V1-63041-0	** THROTTLE SHAFT ** ｽﾛｯﾄﾙｼｬﾌﾄ	1	1	1	
12-33	3H6-63048-0	** THROTTLE SHAFT DAMPER ** ｽﾛｯﾄﾙｼｬﾌﾄﾀﾞﾝﾊﾟ	1	1	1	
12-34	3H6-63510-0	** BUSHING 14-15.8-7 ** ﾌﾞｯｼﾝｸﾞ 14-15.8-7	1	1	1	
12-35	921803-0520	** SCREW ** ｽｸﾘｭ	1	1	1	
12-36	3B2-63063-0	** THROTTLE SHAFT SUPPORT ** ｽﾛｯﾄﾙｼｬﾌﾄｻﾎﾟｰﾄ	1	1	1	
12-37	9215E3-0612	** SCREW ** ｽｸﾘｭ	1	1	1	
12-38	3V1-63035-1	** FRICTION PIECE ** ﾌﾘｸｼｮﾝﾋﾟｰｽ	1	1	1	
12-39	3V1-63077-0	** ADJUSTING NUT ** ｱｼﾞｬｽﾄﾅｯﾄ	1	1	1	
12-40	3V1-63036-0	** SPRING ** ｽﾌﾟﾘﾝｸﾞ	1	1	1	
12-41	9101E3-0625	** BOLT ** ﾎﾞﾙﾄ	1	1	1	
12-42	3RS-06869-0	** BRACKET ** ﾌﾞﾗｹｯﾄ	1	1	1	
12-43	9215E3-0612	** SCREW ** ｽｸﾘｭ	1	1	1	
12-44	3RS-06830-0	** STOP SWITCH ASSY ** ｽﾄｯﾌﾟｽｲｯﾁｱｯｼ	1	1	1	
12-45	3AC-72200-0	** STOP SWITCH DECAL ** ｽﾄｯﾌﾟｽｲｯﾁﾃﾞｶｰﾙ	1	1	1	
12-46	3AC-72019-0	** THROTTLE DECAL ** ｽﾛｯﾄﾙﾃﾞｶｰﾙ	1	1	1	
12-47	3RS-72615-0	* PTT SWITCH ASSY * PTTｽｲｯﾁｱｯｼ	1	1	1	PT Type
12-48	3V1-76032-0	* SWITCH BOX * ｽｲｯﾁﾎﾞｯｸｽ	1	1	1	PT Type
12-49	9215E3-0516	* SCREW * ｽｸﾘｭ	2	2	2	PT Type
12-50	336-06973-0	* CLAMP 6-9.5L * ｸﾗﾝﾌﾟ 6-9.5L	2	2	2	PT Type
12-51	9215E3-0512	* SCREW * ｽｸﾘｭ	2	2	2	PT Type
12-52	3V1-63102-0	BUSHING ﾌﾞｯｼﾝｸﾞ ﾊﾝﾄﾞﾙ	1	1	1	
12-53	3RS-63102-0	BUSHING ﾌﾞｯｼﾝｸﾞ	1	1	1	
12-54	3RS-63108-0	WASHER ﾜｯｼｬ	1	1	1	
12-55	3RS-63107-0	COVER ｶﾊﾞｰ	1	1	1	
12-56	9301E3-0600	NUT ﾅｯﾄ	1	1	1	
12-57	9402E3-0600	WASHER ﾜｯｼｬ	1	1	1	
12-58	3RS-63600-0	THROTTLE WIRE ｽﾛｯﾄﾙﾜｲﾔ	2	2	2	

Fig. 12 TILLER HANDLE・SHIFT
ティラハンドル・シフト




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
12-59		3RSQ62001-0	STEERING BRACKET ｽﾃｱﾘﾝｸﾞﾌﾞﾗｹｯﾄ	1	1	1	
12-60		344-67177-1	GREASE FITTING ｸﾞﾘｽﾌｨｯﾃｨﾝｸﾞ	1	1	1	
12-61		3RS-63201-0	BOLT ﾎﾞﾙﾄ	1	1	1	
12-62		3RT-63201-0	BOLT ﾎﾞﾙﾄ	1	1	1	
12-63		3V9-67578-4	SHIFT DECAL ｼﾌﾄﾃﾞｶｰﾙ	1	1	1	
12-64		3RS-66110-0	SHIFT LEVER ｼﾌﾄﾚﾊﾞｰ	1	1	1	
12-65		3H6-63619-1	COLLAR 6.5-10.5-10 ｶﾗｰ ﾌﾞﾗｹｯﾄ 6.5-10.5-10	1	1	1	
12-66		346-67115-0	WASHER 6.5-21-1 ﾜｯｼｬ 6.5-21-1	1	1	1	
12-67		9101E3-0620	BOLT ﾎﾞﾙﾄ	1	1	1	
12-68		3RT-66134-0	SHIFT LEVER ROD ｼﾌﾄﾚﾊﾞｰﾛｯﾄﾞ	1	1	1	
12-69		951603-0500	SNAP PIN d=5 ｽﾅｯﾌﾟﾋﾟﾝ d=5	1	1	1	
12-70		3RS-05259-0	WAVE WASHER ｳｪｰﾌﾞﾜｯｼｬ	1	1	1	
12-71		3RS-61315-0	WASHER ﾜｯｼｬ	1	1	1	

Fig. 13 FRONT PANEL・DRIVE SHAFT HOUSING COVER
フロントパネル・ドライブシャフトハウジングカバー




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
13-1	3RSQ67010-0	FRONT PANEL ﾌﾛﾝﾄﾊﾟﾈﾙ	1	1	1	
13-2	3R3-71040-0	PILOT LAMP ASSY ﾊﾟｲﾛｯﾄﾗﾝﾌﾟｱｯｼ	1	1	1	
13-3	394-70260-0	FUEL CONNECTOR (MALE) ﾌｭｴﾙｺﾈｸﾀ (ｴﾝｼﾞﾝﾒｰﾙ)	1	1	1	
13-4	910103-5616	BOLT ﾎﾞﾙﾄ	1	1	1	
13-5	345-67117-0	GROMMET 17-2.7 ｸﾞﾛﾒｯﾄ 17-2.7	1	1	1	Main Switch Hole for M Type
13-6	3RS-66260-0	GROMMET ｸﾞﾛﾒｯﾄ	1	1	1	Shift Rod Hole for F Type
13-7	3R3-66226-0	GROMMET 40-18-3 ｸﾞﾛﾒｯﾄ ｼﾌﾄﾛｯﾄﾞ	1	1	1	
13-8	3RS-67512-0	COVER STAY (FRONT) ｶﾊﾞｰｽﾃｰ (ﾌﾛﾝﾄ)	1	1	1	
13-9	3AL-67592-0	RIVET 4-12.9-2.4 ﾘﾍﾞｯﾄ	2	2	2	
13-10	3AA-76026-0	MAIN SWITCH ASSY ﾒｲﾝｽｲｯﾁｱｯｼ	1	1	1	for EF Type
13-11	345-67161-0	GROMMET 22-3 ｸﾞﾛﾒｯﾄ 22-3	1	1	1	Shift Rod Hole for EP Type
13-12	346-67113-0	MOUNT 8.5-14-2.5 ﾏｳﾝﾄ 8.5-14-2.5	2	2	2	
13-13	3B7-06920-0	RUBBER MOUNT 8.5-14-2.5 ﾗﾊﾞｰﾏｳﾝﾄ 8.5-14-2.5	2	2	2	
13-14	3RS-63619-0	COLLAR ｶﾗｰ	2	2	2	
13-15	3BJ-67115-0	WASHER 6.5-20.5-1 ﾜｯｼｬ ﾗﾊﾞｰﾏｳﾝﾄ	2	2	2	
13-16	346-67115-0	WASHER 6.5-21-1 ﾜｯｼｬ 6.5-21-1	2	2	2	
13-17	9101E3-0630	BOLT ﾎﾞﾙﾄ	2	2	2	
13-18	3RSQ67003-0	DRIVE SHAFT HOUSING COVER (R) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾊﾞｰ (R)	1	1	1	
13-19	3RSQ67004-0	DRIVE SHAFT HOUSING COVER (L) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾊﾞｰ (L)	1	1	1	
13-20	3RTQ67004-0	DRIVE SHAFT HOUSING COVER (L) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾊﾞｰ(L)	1	1	1	for EPT Type
13-21	3RS-67485-0	BOLT ﾎﾞﾙﾄ	10	10	10	
13-22	3RS-63621-0	GROMMET ｸﾞﾛﾒｯﾄ	1	1	1	for F Type
13-23	3AA-67120-1	COWL LATCH ASSY ｶｳﾙﾗｯﾁｱｯｼ	1	1	1	
13-24	910103-0612	BOLT ﾎﾞﾙﾄ	1	1	1	
13-25	345-05122-1	WASHER 6.5-23-1.5 ﾜｯｼｬ 6.5-23-1.5	1	1	1	
13-26	3H6-67572-0	STORAGE DECAL ｽﾄﾚｰｼﾞﾃﾞｶｰﾙ	1	1	1	
13-27	3SY-72615-0	PTT SWITCH ASSY PTTｽｲｯﾁｱｯｼ	1	1	1	
13-28	3F3-72616-1	GASKET ｶﾞｽｹｯﾄ PTTｽｲｯﾁ	1	1	1	
13-29	3SY-76032-0	SWITCH BOX ｽｲｯﾁﾎﾞｯｸｽ	1	1	1	

Fig. 13 FRONT PANEL・DRIVE SHAFT HOUSING COVER
フロントパネル・ドライブシャフトハウジングカバー




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
13-30		3SY-76035-0	SWITCH BOX GROMMET ｽｲｯﾁﾎﾞｯｸｽ ｸﾞﾛﾒｯﾄ	1	1	1	
13-31		9215E3-5512	SCREW ｽｸﾘｭ	2	2	2	
13-32		3RS-67501-0	TOP COWL SEAL ﾄｯﾌﾟｶｳﾙｼｰﾙ	1	1	1	
13-33		3RS-83732-0	GROMMET ｸﾞﾛﾒｯﾄ	1	1	1	
13-34		3H6-70262-0	FUEL CONNECTOR PROTECTOR ﾌｭｴﾙｺﾈｸﾀﾌﾟﾛﾃｸﾀ	1	1	1	

Fig. 14 REMOTE CONTROL PARTS
リモートコントロールパーツ




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
14-1	3BA-84905-0	DRAG LINK ASSY ﾄﾞﾗｯｸﾞﾘﾝｸｱｯｼ	1	1	1	
14-2	3E0-84914-0	* SPACER 9.6-19-13 * ｽﾍﾟｰｻ ﾄﾞﾗｯｸﾞﾘﾝｸ H	1	1	1	
14-3	3C8-84964-0	* BOLT 3/8-35 * ﾎﾞﾙﾄ 3/8-35	1	1	1	
14-4	353-84918-0	* NYLON NUT 3/8-24UNF * ﾅｲﾛﾝﾅｯﾄ 3/8-24UNF	2	2	2	
14-5	353-84916-0	* WASHER 9.6-18-2 * ﾜｯｼｬ 9.6-18-2	3	3	3	
14-6	3F3-84908-0	* SEAL RING * ｼｰﾙﾘﾝｸﾞ ﾄﾞﾗｯｸﾞﾘﾝｸ	1	1	1	
14-7	3RS-83880-0	REMOTE CONTROL FITTING ASSY ﾘﾓｰﾄｺﾝﾄﾛｰﾙﾌｨｯﾃｨﾝｸﾞｱｯｼ	1	1	1	
14-8	3RS-83732-0	* GROMMET * ｸﾞﾛﾒｯﾄ	1	1	1	
14-9	3RS-83820-0	* CABLE CLIP ASSY * ｹｰﾌﾞﾙｸﾘｯﾌﾟｱｯｼ	1	1	1	
14-10	910103-5616	* BOLT * ﾎﾞﾙﾄ	3	3	3	
14-11	3B7-83715-2	* CABLE JOINT * ｹｰﾌﾞﾙｼﾞｮｲﾝﾄ	2	2	2	
14-12	3AA-83719-0	* WASHER 8.5-18-1.6 * ﾜｯｼｬ 8.5-18-1.6	2	2	2	
14-13	3AA-83719-0	* WASHER 8.5-18-1.6 * ﾜｯｼｬ 8.5-18-1.6	2	2	2	
14-14	951603-0800	* SNAP PIN d=8 * ｽﾅｯﾌﾟﾋﾟﾝ d=8	2	2	2	
14-15	3RS-66122-0	* SHIFT ARM * ｼﾌﾄｱｰﾑ	1	1	1	
14-16	3KY-76079-0	* COLLAR 6.5-10.5-9.3 * ｶﾗｰ 6.5-10.5-9.3	1	1	1	
14-17	3C8-66308-0	* WASHER 6-16-1.5 * ﾜｯｼｬ 6-16-1.5	2	2	2	
14-18	3C8-66308-0	* WASHER 6-16-1.5 * ﾜｯｼｬ 6-16-1.5	2	2	2	
14-19	910103-0625	* BOLT * ﾎﾞﾙﾄ	1	1	1	
14-20	3RS-66134-0	* SHIFT LEVER ROD * ｼﾌﾄﾚﾊﾞｰﾛｯﾄﾞ	1	1	1	
14-21	951603-0800	* SNAP PIN d=8 * ｽﾅｯﾌﾟﾋﾟﾝ d=8	2	2	2	
14-22	3RS-63751-0	* THROTTLE ARM * ｽﾛｯﾄﾙｱｰﾑ	1	1	1	
14-23	3RS-63612-0	* THROTTLE OPENER * ｽﾛｯﾄﾙｵｰﾌﾟﾅ	1	1	1	
14-24	3RS-66124-0	* COLLAR * ｶﾗｰ	1	1	1	
14-25	910103-0640	* BOLT * ﾎﾞﾙﾄ	1	1	1	
14-26	3RS-83830-0	* STEERING HOOK PLATE * ｽﾃｱﾘﾝｸﾞﾌｯｸﾌﾟﾚｰﾄ	1	1	1	
14-27	9111E3-1030	* BOLT * ﾎﾞﾙﾄ	2	2	2	
14-28	9401E3-1000	* WASHER * ﾜｯｼｬ	2	2	2	
14-29	3RV-83914-0	THROTTLE LEVER STOPPER ｽﾛｯﾄﾙﾚﾊﾞｰｽﾄｯﾊﾟ	1			

Fig. 15 TOP COWL
トップカウル




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
15-1		3RSQ67645-1	TOP COWL ASSY ﾄｯﾌﾟｶｳﾙｱｯｼ	1	1	1	
15-2		3RSQ67640-0	* TOP COWL SUB-ASSY *ﾄｯﾌﾟｶｳﾙｻﾌﾞｱｯｼ	1	1	1	
15-3		3UA-67523-0	** AIR GUIDE 2S **ｴｱｶﾞｲﾄﾞ	1	1	1	
15-4		3T5-06437-0	** TAPPING SCREW 6-16 **ﾀｯﾋﾟﾝｸﾞｽｸﾘｭ 6-16	4	4	4	
15-5		3UA-67524-0	** SEAL RUBBER 3D **ｼｰﾙﾗﾊﾞｰ	1	1	1	
15-6	1	3RU-87801-1	* DECAL SET (MFS9.9E) *ﾃﾞｶｰﾙｾｯﾄ (MFS9.9E)	1			9.9ps
15-6	2	3RT-87801-1	* DECAL SET (MFS15E) *ﾃﾞｶｰﾙｾｯﾄ (MFS15E)		1		15ps
15-6	3	3RS-87801-1	* DECAL SET (MFS20E) *ﾃﾞｶｰﾙｾｯﾄ (MFS20E)			1	20ps
15-7		3AC-76190-0	WARNING DECAL ｵｲﾙﾌﾟﾚｯｼｬﾃﾞｶｰﾙ	1	1	1	
15-8		3R0-72180-0	CAUTION DECAL (A) ｺｰｼｮﾝﾃﾞｶｰﾙ (A)	1	1	1	
15-9		3AC-72185-0	CAUTION DECAL ｺｰｼｮﾝﾃﾞｶｰﾙ		1	1	for EU Model
15-10		3RS-67573-1	SPORT DECAL SPORTﾃﾞｶｰﾙ	1	1	1	

Fig. 16 FUEL TANK
フュエルタンク




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
16-1	1	3AD-70200-2	PRIMER BULB ASSY ﾌﾟﾗｲﾏﾊﾞﾙﾌﾞｱｯｼ	1	1	1	Low Permeation Parts for USA Model
16-1	2	3H6-70200-2	PRIMER BULB ASSY ﾌﾟﾗｲﾏﾊﾞﾙﾌﾞｱｯｼ	1	1	1	STD
16-2		3C7-70220-1	JOINT ASSY (INLET) ｼﾞｮｲﾝﾄｱｯｼ (ｲﾝﾚｯﾄ)	1	1	1	
16-3		332-70201-0	CLAMP ｸﾗﾝﾌﾟ	4	4	4	
16-4		3C7-70224-1	JOINT ASSY (OUTLET) ｼﾞｮｲﾝﾄｱｯｼ (ｱｳﾄﾚｯﾄ)	1	1	1	
16-5	1	3GF-70211-1	PRIMER BULB ﾌﾟﾗｲﾏﾊﾞﾙﾌﾞ	1	1	1	Low Permeation Parts for USA Model
16-5	2	3C7-70211-1	PRIMER BULB ﾌﾟﾗｲﾏﾊﾞﾙﾌﾞ	1	1	1	STD
16-6		3C7-70217-0	CLAMP ｸﾗﾝﾌﾟ	2	2	2	
16-7	1	3GF-70241-1	LOW PERMEATION HOSE L=700 ﾛｰﾊﾟｰﾐｪｰｼｮﾝﾎｰｽ L=700	1	1	1	Low Permeation Parts USA EPA KRI-15G
16-7	2	98AB-70-700	HOSE ﾎｰｽ	1	1	1	STD 98AB-701000
16-8	1	3GF-70240-1	LOW PERMEATION HOSE L=1600 ﾛｰﾊﾟｰﾐｪｰｼｮﾝﾎｰｽ L=1600	1	1	1	Low Permeation Parts USA EPA KRI-15G
16-8	2	98AB-701600	HOSE ﾎｰｽ	1	1	1	STD 98AB-701000 x2
16-9		3GR-70280-0	FUEL CONNECTOR MARK ﾌｭｴﾙｺﾈｸﾀﾏｰｸ	1	1	1	
16-10		3GF-70281-0	FUEL CONNECTOR ﾌｭｴﾙｺﾈｸﾀ (ﾀﾝｸﾌｨﾒｰﾙ)	1	1	1	
16-11		3GR-70250-0	FUEL CONNECTOR ﾌｭｴﾙｺﾈｸﾀ (ｴﾝｼﾞﾝﾌｨﾒｰﾙ)	1	1	1	
16-12	1	3UA-70167-0	FUEL TANK ASSY 12L ﾌｭｴﾙﾀﾝｸｱｯｼ 12L (ﾄｰﾊﾂ)	1	1	1	for USA Model
16-12	2	3RS-70167-0	FUEL TANK ASSY 12L ﾌｭｴﾙﾀﾝｸｱｯｼ 12L (ﾄｰﾊﾂ)	1	1	1	
16-13		3AC-70052-1	FUEL TANK CAP ASSY ﾌｭｴﾙﾀﾝｸｷｬｯﾌﾟｱｯｼ	1	1	1	for USA Model
16-14		3AC-70055-0	RETAINING RING ﾘﾃｰﾆﾝｸﾞﾘﾝｸﾞ	1	1	1	for USA Model
16-15		3E0-70270-0	QUICK-CONNECTOR (MALE) ｸｲｯｸｺﾈｸﾀ (ﾀﾝｸﾒｰﾙ)	1	1	1	
16-20		3C7-70199-0	O-RING Oﾘﾝｸﾞ	1	1	1	
16-21		3C7-70113-0	FILTER ﾌｨﾙﾀ	1	1	1	
16-22		3RS-70020-0	* FUEL TANK CAP ASSY * ﾌｭｴﾙﾀﾝｸｷｬｯﾌﾟｱｯｼ	1	1	1	
16-22a		3RS-70021-0	** TANK FILLER CAP GASKET ** ﾀﾝｸﾌｨﾗｰｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	1	
16-23		3B2-70155-0	PICK-UP ELBOW ASSY ﾋﾟｯｸｱｯﾌﾟｴﾙﾎﾞｱｯｼ	1	1	1	

Fig. 17 COMPONENT PARTS OF REMOTE CONTROL
リモコンボックス構成部品




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
17-1	1	3U2B84330-0	REMOTE CONTROL HEAD ASSY(RC12A) ﾘﾓｰﾄｺﾝﾄﾛｰﾙﾍｯﾄﾞｱｯｼ(RC12A)	1	1	1	EPT Type
17-1	2	3U2B84340-0	REMOTE CONTROL HEAD ASSY(RC12B) ﾘﾓｰﾄｺﾝﾄﾛｰﾙﾍｯﾄﾞｱｯｼ(RC12B)	1	1	1	EP Type
17-2		3A3-84365-1	* THROTTLE ARM * ｽﾛｯﾄﾙｱｰﾑ	1	1	1	
17-3		3A3-84428-0	* THROTTLE FRICTION ARM * ｽﾛｯﾄﾙﾌﾘｸｼｮﾝｱｰﾑ	1	1	1	
17-4		945303-0600	* E-RING d=6 * Eﾘﾝｸﾞ d=6	3	3	3	
17-5		353-84394-0	* WASHER * ﾜｯｼｬ	1	1	1	
17-6		3U2-84427-0	* ADJUSTING SCREW * ｱｼﾞｬｽﾄｽｸﾘｭ	1	1	1	
17-7		3A3-84381-0	* SHIFT GEAR ASSY * ｼﾌﾄｷﾞﾔｱｯｼ	1	1	1	
17-8		3A3-83314-2	* CABLE TERMINAL * ｹｰﾌﾞﾙﾀｰﾐﾅﾙ	2	2	2	
17-9		3A3-84364-2	* DRIVE GEAR * ﾄﾞﾗｲﾌﾞｷﾞﾔ	1	1	1	
17-10		930103-0500	* NUT * ﾅｯﾄ	1	1	1	
17-11		910103-0525	* BOLT * ﾎﾞﾙﾄ	1	1	1	
17-12		3A3-84376-0	* GROMMET * ｸﾞﾛﾒｯﾄ	1	1	1	
17-13		3U2B84441-0	* REAR HOUSING * ﾘﾔﾊｳｼﾞﾝｸﾞ	1	1	1	
17-14		3U2B84366-0	* REAR PANEL * ﾘﾔﾊﾟﾈﾙ	1	1	1	
17-15		3U2-84401-0	* NEUTRAL LOCK ARM * ﾆｭｰﾄﾗﾙﾛｯｸｱｰﾑ	1	1	1	
17-16		3A3-84403-0	* NEUTRAL LOCK SPRING * ﾆｭｰﾄﾗﾙﾛｯｸｽﾌﾟﾘﾝｸﾞ	1	1	1	
17-17		3U2-84404-0	* GRIP * ｸﾞﾘｯﾌﾟ	1	1	1	
17-18		3U2-84343-0	* CONTROL LEVER * ｺﾝﾄﾛｰﾙﾚﾊﾞｰ	1	1	1	
17-19		3A3-84368-0	* WAVE WASHER * ｳｪｰﾌﾞﾜｯｼｬ	1	1	1	
17-20		3A3-84391-0	* FREE THROTTLE DRUM * ﾌﾘｰｽﾛｯﾄﾙﾄﾞﾗﾑ	1	1	1	
17-21		3A3-84435-0	* BUSHING * ﾌﾞｯｼﾝｸﾞ D	1	1	1	
17-22		3A3-84422-0	* THRUST PLATE * ｽﾗｽﾄﾌﾟﾚｰﾄ	1	1	1	
17-23		921603-0512	* SCREW * ｽｸﾘｭ	2	2	2	
17-24		3U2-84339-0	* INSTRUCTION DECAL * ｲﾝｽﾄﾗｸｼｮﾝﾃﾞｶｰﾙ	1	1	1	
17-25		3A3-84432-0	* BUSHING * ﾌﾞｯｼﾝｸﾞ B	1	1	1	
17-26		3U2-84375-0	* SCREW * ｽｸﾘｭ	3	3	3	
17-27		3VK-84375-0	* SCREW * ｽｸﾘｭ	7	7	7	
17-28		3VL-84375-0	* SCREW * ｽｸﾘｭ	1	1	1	

Fig. 17 COMPONENT PARTS OF REMOTE CONTROL
リモコンボックス構成部品




Ref.No. 見出番号	Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
			MFS9.9E	MFS15E	MFS20E	
17-29	3A3-84374-0	* SPACER * ｽﾍﾟｰｻ	3	3	3	
17-30	353-84371-0	* WASHER * ﾜｯｼｬ ﾘﾓｺﾝﾎﾞｯｸｽ	3	3	3	
17-31	3U2-84371-0	* WASHER * ﾜｯｼｬ	2	2	2	
17-32	930103-0600	* NUT * ﾅｯﾄ	3	3	3	
17-33	3A3-84383-0	* WASHER * ﾜｯｼｬ	1	1	1	
17-34	3A3-84421-0	* ROLLER * ﾛｰﾗ	1	1	1	
17-35	3U2-84431-0	* BUSHING * ﾌﾞｯｼﾝｸﾞ	2	2	2	
17-36	940103-0800	* WASHER * ﾜｯｼｬ	1	1	1	
17-37	3U2-84442-0	* BOLT * ﾎﾞﾙﾄ	1	1	1	
17-38	353-84388-0	* DETENT ROLLER * ﾃﾞﾃﾝﾄﾛｰﾗ	1	1	1	
17-39	3U2B84312-0	* FREE THROTTLE LEVER * ﾌﾘｰｽﾛｯﾄﾙﾚﾊﾞｰ	1	1	1	
17-40	921503-0406	* SCREW * ｽｸﾘｭ	3	3	3	
17-41	3A3-84423-0	* DETENT RETAINER * ﾃﾞﾃﾝﾄﾘﾃｰﾅ	1	1	1	
17-42	3A3-84307-0	* DETENT SPRING * ﾃﾞﾃﾝﾄｽﾌﾟﾘﾝｸﾞ	5	5	5	
17-43	3A3-84424-0	* FREE THROTTLE ROLLER * ﾌﾘｰｽﾛｯﾄﾙﾛｰﾗ	1	1	1	
17-44	3A3-84426-0	* ROLLER RETAINER * ﾛｰﾗﾘﾃｰﾅ	1	1	1	
17-45	3A3-84425-0	* FREE THROTTLE SPRING * ﾌﾘｰｽﾛｯﾄﾙｽﾌﾟﾘﾝｸﾞ	1	1	1	
17-46	3VK-63107-0	* COVER * ｶﾊﾞｰ	1	1	1	
17-47	3U2-63506-0	* HOLDER * ﾎﾙﾀﾞ	1	1	1	
17-48	3U2-84917-0	* BOLT * ﾎﾞﾙﾄ	1	1	1	
17-49	3U2-77367-0	* JOINT * ｼﾞｮｲﾝﾄ	1	1	1	
17-50	3U2-06973-0	* CLAMP * ｸﾗﾝﾌﾟ	1	1	1	
17-51	3U2-72187-0	* CAUTION DECAL(SIGP) * ｺｰｼｮﾝﾃﾞｶｰﾙ (SIGP)	1	1	1	
17-52	3U2B84440-0	* FRONT HOUSING * ﾌﾛﾝﾄﾊｳｼﾞﾝｸﾞ	1	1	1	
17-53	3U2-84452-0	* TILT SWITCH PLUG * ﾁﾙﾄｽｲｯﾁﾌﾟﾗｸﾞ	1	1	1	RC12B
17-54	353-76037-0	* CABLE TERMINAL PLUG * ｹｰﾌﾞﾙﾀｰﾐﾅﾙ ﾌﾟﾗｸﾞ	2	2	2	RC12B
17-55	3A3-81301-0	TWIN REMOTE CONTROL KIT ﾂｲﾝﾘﾓｰﾄｺﾝﾄﾛｰﾙｷｯﾄ	1	1	1	

Fig. 18 COMPONENT PARTS OF REMOTE CONTROL (ELECTRIC PARTS)
リモコンボックス構成部品 (電装品関係)




Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
18-1		3GF-76020-0	MAIN SWITCH ASSY ﾒｲﾝｽｲｯﾁｱｯｼ	1	1	1	
18-2	1	3GF-76217-0	* MAIN SWITCH KEY * ﾒｲﾝｽｲｯﾁｷｰ No.943	A	A	A	
18-2	2	3GF-76218-0	* MAIN SWITCH KEY * ﾒｲﾝｽｲｯﾁｷｰ No.944	A	A	A	
18-2	3	3GF-76219-0	* MAIN SWITCH KEY * ﾒｲﾝｽｲｯﾁｷｰ No.945	A	A	A	
18-3		3GF-76205-0	* MAIN SWITCH KEY COVERING CAP * ﾒｲﾝｽｲｯﾁｷｰｶﾊﾞｰﾘﾝｸﾞｷｬｯﾌﾟ	1	1	1	
18-4		3A3-76115-1	CORD ASSY L=6200 ｺｰﾄﾞｱｯｼ L=6200	1	1	1	
18-5		353-72546-0	ASSIST CORD (RED) L=200 ｱｼｽﾄｺｰﾄﾞ (ﾚｯﾄﾞ) L=200	1	1	1	
18-6		3U2-84331-0	DECAL (LEVER) ﾃﾞｶｰﾙ (ﾚﾊﾞｰ)	1	1	1	
18-7		3U2-84336-0	SHIFT POSITION DECAL ｼﾌﾄﾎﾟｼﾞｼｮﾝﾃﾞｶｰﾙ	1	1	1	
18-8		3A3-84398-0	BAND ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ	1	1	1	
18-9		3U2-84398-0	BAND ﾊﾞﾝﾄﾞ	3	3	3	
18-10		3A3-76086-1	NEUTRAL SWITCH (REMOTE CONT) ﾆｭｰﾄﾗﾙｽｲｯﾁ (ﾘﾓｰﾄｺﾝﾄﾛｰﾙ)	1	1	1	
18-11		921503-5316	SCREW ｽｸﾘｭ	2	2	2	
18-12		3U2-72615-0	PTT SWITCH ASSY PTTｽｲｯﾁｱｯｼ	1	1	1	RC12A
18-13		3C8-76171-0	OVERHEAT BUZZER ｵｰﾊﾞｰﾋｰﾄﾌﾞｻﾞｰ	1	1	1	
18-14		3A3-06830-0	STOP SWITCH ASSY ｽﾄｯﾌﾟｽｲｯﾁｱｯｼ	1	1	1	
18-15		353-06821-0	* STOP SWITCH LANYARD ASSY * ｽﾄｯﾌﾟｽｲｯﾁﾗﾝﾔｰﾄﾞｱｯｼ	1	1	1	
18-16		3U2-72200-0	STOP SWITCH DECAL ｽﾄｯﾌﾟｽｲｯﾁﾃﾞｶｰﾙ	2	2	2	
18-17		3U2-84334-0	REMOTE CONTROL LOGO DECAL ﾘﾓｰﾄｺﾝﾄﾛｰﾙﾛｺﾞﾃﾞｶｰﾙ	1	1	1	


Fig. 19 **OPTIONAL PARTS・ACCESORIES**
オプショナルパーツ・アクセサリ



Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
19-1		3BJ-72100-0	TOOL KIT ツールキット	1	1	1	
19-2		3B7-72201-0	SAFETY ROPE φ5-1600 セーフティロープ φ5-1600	1	1	1	
19-16		361-72539-0	TACHOMETER LEAD WIRE L=6000 タコメータリードワイヤ L=6000	1	1	1	
19-17		3RS-06128-0	ALTERNATOR KIT オルタネータキット	1	1	1	
19-18		3RT-06023-0	* ALTERNATOR ASSY * オルタネータアッシ	1	1	1	
19-19		3RS-76160-0	* RECTIFIER KIT * レクチファイヤキット	1	1	1	
19-20		3RS-76060-0	** RECTIFIER COMPLETE ** レクチファイヤコンプリート	1	1	1	
19-21		910103-5620	** BOLT ** ボルト	2	2	2	
19-22		3RS-76163-0	** RECTIFIER BRACKET ** レクチファイヤブラケット	1	1	1	
19-23		910103-5612	** BOLT ** ボルト	2	2	2	
19-24		910103-5612	** BOLT ** ボルト	1	1	1	
19-25		3BJ-76161-0	** EXTENSION CORD L=3000 ** エクステンションコード L=3000	1	1	1	
19-26		3T5-76247-0	*** FUSE 20A *** ヒューズ 20A	2	2	2	
19-27		1E0-34093-0	*** CAP *** キャップ ヒューズボックス (Y)	1	1	1	Yellow
19-28		3T1-72405-0	HOSE JOINT (WATER-WORKS) ホースジョイント (ウォータワーク)	1	1	1	

Fig. 20 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ






POWER HEAD GASKET SET
パワーヘッドガスケットセット — 3

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 4

WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 5

WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット（クロムメッキ） — 6

ELECTRIC STARTER KIT (F TYPE)
エレクトリックスタータキット（Fタイプ） — 7




MAINTENANCE KIT
メンテナンスキット — 9


INTAKE VALVE KIT
インテークバルブキット — 10

EXHAUST VALVE KIT
エキゾーストバルブキット — 11

Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
20-1	1	3RSQ87301-0	LOWER UNIT ASSY (S) ﾛﾜﾕﾆｯﾄｱｯｼ (S)	1	1	1	for Transom "S"
20-1	2	3RSQ87302-0	LOWER UNIT ASSY (L) ﾛﾜﾕﾆｯﾄｱｯｼ (L)	1	1	1	for Transom "L"
20-1	3	3RSQ87304-0	LOWER UNIT ASSY (UL) ﾛﾜﾕﾆｯﾄｱｯｼ (UL)	1		1	for Transom "UL"
20-2		3RSB87090-0	ENGINE SHORT BLOCK KIT ｴﾝｼﾞﾝｼｮｰﾄﾌﾞﾛｯｸｷｯﾄ	1	1	1	
20-3	1	3RS-87121-0	POWER HEAD GASKET SET ﾊﾟﾜｰﾍｯﾄﾞｶﾞｽｹｯﾄｾｯﾄ	1	1	1	
20-3	2	3RS-01005-0	* CYLINDER HEAD GASKET * ｼﾘﾝﾀﾞｰﾍｯﾄﾞｶﾞｽｹｯﾄ	1	1	1	
20-3	3	3RS-01024-0	* CYLINDER HEAD COVER GASKET * ｼﾘﾝﾀﾞｰﾍｯﾄﾞｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	1	
20-3	4	3R0-07422-0	* O-RING 3.1-24.4 * Oﾘﾝｸﾞ 3.1-24.4	1	1	1	
20-3	5	3RS-02305-0	* EXHAUST COVER GASKET * ｴｷｿﾞｰｽﾄｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	1	
20-3	6	346-01032-0	* THERMOSTAT CAP GASKET * ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	1	
20-3	7	3RS-01303-0	* ENGINE BASEMENT GASKET * ｴﾝｼﾞﾝﾍﾞｰｽｶﾞｽｹｯﾄ	1	1	1	
20-3	8	3R3-00121-0	OIL SEAL 32-44-9 ｵｲﾙｼｰﾙ 32-44-9	1	1	1	
20-3	9	3BJ-00121-0	OIL SEAL 36-50-7 ｵｲﾙｼｰﾙ 36-50-7	1	1	1	
20-3	10	3BJ-02011-0	* CARBURETOR GASKET * ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ	1	1	1	
20-3	11	3H8-62415-0	* O-RING 3.5-25.7 * Oﾘﾝｸﾞ 3.5-25.7	1	1	1	
20-3	12	3RS-07653-0	* OIL PUMP GASKET * ｵｲﾙﾎﾟﾝﾌﾟｶﾞｽｹｯﾄ	1	1	1	
20-3	13	3H8-07025-0	* OIL SEAL 18-35-8 * ｵｲﾙｼｰﾙ 18-35-8	1	1	1	
20-4	1	3RS-87321-0	LOWER UNIT GASKET SET ﾛﾜﾕﾆｯﾄｶﾞｽｹｯﾄｾｯﾄ	1	1	1	
20-4	2	3RS-65029-0	* GUIDE PLATE GASKET * ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	1	
20-4	3	332-60006-0	* GASKET 8.1-15-1 * ｶﾞｽｹｯﾄ 8.1-15-1	2	2	2	
20-4	4	121-32071-0	* O-RING 2.4-59.6 * Oﾘﾝｸﾞ 2.4-59.6	1	1	1	
20-4	5	346-65013-0	* OIL SEAL 17-30-9 * ｵｲﾙｼｰﾙ 17-30-9	1	1	1	
20-4	6	332-60223-0	* OIL SEAL 13.8-26-9.5 * ｵｲﾙｼｰﾙ 13.8-26-9.5	1	1	1	
20-4	7	3RS-65020-0	* PUMP CASE GASKET (LOWER) * ﾎﾟﾝﾌﾟｹｰｽｶﾞｽｹｯﾄ (ﾛﾜ)	1	1	1	
20-4	8	3RS-66021-0	* O-RING * Oﾘﾝｸﾞ	1	1	1	

Fig. 20 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ






POWER HEAD GASKET SET
パワーヘッドガスケットセット — 3

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 4

WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 5

WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット（クロムメッキ） — 6

ELECTRIC STARTER KIT (F TYPE)
エレクトリックスタータキット（Fタイプ） — 7




MAINTENANCE KIT
メンテナンスキット — 9


INTAKE VALVE KIT
インテークバルブキット — 10

EXHAUST VALVE KIT
エキゾーストバルブキット — 11

Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
20-5	1	3RS-87322-0	WATER PUMP REPAIR KIT ｳｫｰﾀﾎﾟﾝﾌﾟﾘﾍﾟｱｷｯﾄ	1	1	1	
20-5	2	3RS-65029-0	* GUIDE PLATE GASKET *ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	1	
20-5	3	3LD-65021-0	* WATER PUMP IMPELLER *ｲﾝﾍﾟﾗｳｫｰﾀﾎﾟﾝﾌﾟ	1	1	1	
20-5	4	3RS-65022-0	* KEY *ｷｰ	1	1	1	
20-5	5	350-65011-1	* PUMP CASE LINER *ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ	1	1	1	
20-5	6	3RS-65025-0	* WATER PUMP GUIDE PLATE *ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	1	
20-5	7	9101E3-5652	* BOLT *ﾎﾞﾙﾄ	4	4	4	
20-6	1	3RS-65231-0	WATER PUMP KIT (CHROME PLATED) ｳｫｰﾀﾎﾟﾝﾌﾟｷｯﾄ (ｸﾛﾑﾒｯｷ)	1	1	1	
20-6	2	3RS-65029-0	* GUIDE PLATE GASKET *ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	1	
20-6	3	3LD-65021-0	* WATER PUMP IMPELLER *ｲﾝﾍﾟﾗｳｫｰﾀﾎﾟﾝﾌﾟ	1	1	1	
20-6	4	362-65238-0	* PUMP CASE LINER *ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ ｸﾛﾑﾒｯｷ	1	1	1	
20-6	5	3RS-65025-0	* WATER PUMP GUIDE PLATE *ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	1	
20-7	1	3RS-76300-1	ELECTRIC STARTER KIT (F) ｴﾚｸﾄﾘｯｸｽﾀｰﾀｷｯﾄ (F)	1	1	1	
20-7	2	3RT-06023-0	* ALTERNATOR ASSY *ｵﾙﾀﾈｰﾀｱｯｼ	1	1	1	
20-7	3	3RT-06191-0	* FLYWHEEL W/RING GEAR *ﾌﾗｲﾎｲｰﾙ W/ﾘﾝｸﾞｷﾞﾔ	1	1	1	
20-7	4	3RT-76110-0	* CORD ASSY *ｺｰﾄﾞｱｯｼ	1	1	1	
20-7	5	3BJ-06133-0	PROTECTOR φ10.7-320 ﾌﾟﾛﾃｸﾀ φ10.7-320	1	1	1	
20-7	6	3BA-06133-0	PROTECTOR φ10.7-180 ﾌﾟﾛﾃｸﾀ φ10.7-180	1	1	1	
20-7	7	3RS-01047-0	* PLUG *ﾌﾟﾗｸﾞ	1	1	1	
20-7	8	3RS-06901-0	* BRACKET *ﾌﾞﾗｹｯﾄ	1	1	1	
20-7	9	3H8-76040-0	* STARTER SOLENOID *ｽﾀｰﾀｿﾚﾉｲﾄﾞ	1	1	1	
20-7	10	910103-5610	* BOLT *ﾎﾞﾙﾄ	2	2	2	
20-7	11	3KY-06920-0	* RUBBER MOUNT *ﾗﾊﾞｰﾏｳﾝﾄ	3	3	3	
20-7	12	3RS-76079-0	* COLLAR *ｶﾗｰ	3	3	3	
20-7	13	3C8-66308-0	* WASHER 6-16-1.5 *ﾜｯｼｬ 6-16-1.5	3	3	3	
20-7	14	910103-0625	* BOLT *ﾎﾞﾙﾄ	3	3	3	
20-7	15	3RS-76010-0	* STARTER MOTOR ASSY *ｽﾀｰﾀﾓｰﾀｱｯｼ	1	1	1	

Fig. 20 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ






POWER HEAD GASKET SET
パワーヘッドガスケットセット — 3

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 4

WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 5

WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット（クロムメッキ） — 6

ELECTRIC STARTER KIT (F TYPE)
エレクトリックスタータキット（Fタイプ） — 7




MAINTENANCE KIT
メンテナンスキット — 9


INTAKE VALVE KIT
インテークバルブキット — 10

EXHAUST VALVE KIT
エキゾーストバルブキット — 11

Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数 MFS9.9E	MFS15E	MFS20E	Remarks 備 考
20-7	16	3RS-76009-0	* STARTER MOTOR BAND * ｽﾀｰﾀﾓｰﾀﾊﾞﾝﾄﾞ	1	1	1	
20-7	17	3C8-76007-0	* DAMPER * ﾀﾞﾝﾊﾟ ｽﾀｰﾀﾓｰﾀ	1	1	1	
20-7	18	910103-5825	* BOLT * ﾎﾞﾙﾄ	2	2	2	
20-7	19	910103-5612	BOLT ﾎﾞﾙﾄ	2	2	2	
20-7	20	3RS-76060-0	* RECTIFIER COMPLETE * ﾚｸﾁﾌｧｲﾔｺﾝﾌﾟﾘｰﾄ	1	1	1	
20-7	21	910103-5620	* BOLT * ﾎﾞﾙﾄ	2	2	2	
20-7	22	3RS-76163-0	* RECTIFIER BRACKET * ﾚｸﾁﾌｧｲﾔﾌﾞﾗｹｯﾄ	1	1	1	
20-7	23	910103-5612	BOLT ﾎﾞﾙﾄ	2	2	2	
20-7	24	910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
20-7	25	3BH-76120-0	* BATTERY CABLE * ﾊﾞｯﾃﾘｹｰﾌﾞﾙ	1	1	1	
20-7	26	910103-5612	BOLT ﾎﾞﾙﾄ	1	1	1	
20-7	27	3BJ-76145-0	TERMINAL CAP 15.5-20-28 ﾀｰﾐﾅﾙｷｬｯﾌﾟ	1	1	1	
20-7	28	3Y0-76145-0	TERMINAL CAP 8-18-28 ﾀｰﾐﾅﾙｷｬｯﾌﾟ	1	1	1	
20-7	29	3AA-76145-0	TERMINAL CAP 13-13-28 ﾀｰﾐﾅﾙｷｬｯﾌﾟ	1	1	1	
20-7	30	3RS-76141-0	* STARTER CABLE * ｽﾀｰﾀｹｰﾌﾞﾙ	1	1	1	
20-7	31	3NV-76080-0	* NEUTRAL SWITCH * ﾆｭｰﾄﾗﾙｽｲｯﾁ	1	1	1	
20-7	32	398-76083-0	* NEUTRAL SWITCH ACTUATOR * ﾆｭｰﾄﾗﾙｽｲｯﾁｱｸﾁｴｰﾀ	1	1	1	
20-7	33	3RS-76081-0	* NEUTRAL SWITCH BRACKET * ﾆｭｰﾄﾗﾙｽｲｯﾁﾌﾞﾗｹｯﾄ	1	1	1	
20-7	34	910103-5616	* BOLT * ﾎﾞﾙﾄ	1	1	1	
20-7	35	3AA-76026-0	* MAIN SWITCH ASSY * ﾒｲﾝｽｲｯﾁｱｯｼ	1	1	1	
20-7	36	369-84398-0	BAND 158 ﾊﾞﾝﾄﾞ ﾘｰﾄﾞﾜｲﾔ 158	3	3	3	
20-8	1	3RSQ87314-0	EXTENSION HOUSING KIT (UL) ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞｷｯﾄ (UL)	1	1	1	
20-8	2	3RSQ61110-0	* EXTENSION HOUSING UL * ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞ UL	1	1	1	
20-8	3	3AB-01111-0	* DOWEL PIN 6-12 * ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	2	
20-8	4	3BJ-60001-0	* BOLT 8-31 * ﾎﾞﾙﾄ	4	4	4	
20-8	5	3BJ-60003-0	* DRIVE SHAFT BUSHING * ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾌﾞｯｼﾝｸﾞ	1	1	1	
20-8	6	3V1-64332-0	* STOPPER * ｽﾄｯﾊﾟ ﾌﾞｯｼﾝｸﾞ	1	1	1	
20-8	7	9101E3-5612	* BOLT * ﾎﾞﾙﾄ	2	2	2	

Fig. 20 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ






POWER HEAD GASKET SET
パワーヘッドガスケットセット — 3

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 4

WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 5

WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット（クロムメッキ） — 6

ELECTRIC STARTER KIT (F TYPE)
エレクトリックスタータキット（Fタイプ） — 7



MAINTENANCE KIT
メンテナンスキット — 9

INTAKE VALVE KIT
インテークバルブキット — 10

EXHAUST VALVE KIT
エキゾーストバルブキット — 11

Ref.No. 見出番号		Parat No. 部品番号	Description 部 品 名	Q'ty/個数			Remarks 備 考
				MFS9.9E	MFS15E	MFS20E	
20-8	8	3RS-65120-0	* WATER PIPE (UL) * ｳｫｰﾀﾊﾟｲﾌﾟ (UL)	1	1	1	
20-8	9	3RS-64303-0	* DRIVE SHAFT (UL) * ﾄﾞﾗｲﾌﾞｼｬﾌﾄ (UL)	1	1	1	
20-8	10	3RS-66014-0	* CAM ROD (UL) * ｶﾑﾛｯﾄﾞ (UL)	1	1	1	
20-9	1	3RS-87500-0	MAINTENANCE KIT ﾒﾝﾃﾅﾝｽｷｯﾄ	1	1	1	
20-9	2	3P0-60218-0	* ANODE * ｱﾉｰﾄﾞ	1	1	1	
20-9	3	3BJ-07615-0	* OIL FILTER * ｵｲﾙﾌｨﾙﾀｱｯｼ	1	1	1	
20-9	4	3LD-65021-0	* WATER PUMP IMPELLER * ｲﾝﾍﾟﾗｳｫｰﾀﾎﾟﾝﾌﾟ	1	1	1	
20-9	5	350-65011-1	* PUMP CASE LINER * ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ	1	1	1	
20-9	6	3RS-65022-0	* KEY * ｷｰ	1	1	1	
20-9	7	3RS-65025-0	* WATER PUMP GUIDE PLATE * ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	1	
20-9	8	3RS-65029-0	* GUIDE PLATE GASKET * ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	1	
20-9	9	332-60006-0	* GASKET 8.1-15-1 * ｶﾞｽｹｯﾄ 8.1-15-1	2	2	2	
20-9	10	3R3-07406-0	* WASHER 14.5-24-1 * ﾜｯｼｬ 14.5-24-1	1	1	1	
20-9	11	3KY-60218-0	* ANODE * ｱﾉｰﾄﾞ	1	1	1	
20-9	12	951503-0322	* SPLIT PIN 3-22 * ｽﾌﾟﾘｯﾄﾋﾟﾝ 3-22	1	1	1	
20-9	13	9701-1-1103	* SPARK PLUG(DCPR6E) * ｽﾊﾟｰｸﾌﾟﾗｸﾞ (DCPR6E)	2	2	2	
20-10	1	3RS-07895-0	INTAKE VALVE KIT ｲﾝﾃｰｸﾊﾞﾙﾌﾞｷｯﾄ	1	1	1	
20-10	2	3RS-07901-0	* INTAKE VALVE * ｲﾝﾃｰｸﾊﾞﾙﾌﾞ	1	1	1	
20-10	3	3V1-07221-0	* RETAINER * ﾘﾃｰﾅ	1	1	1	
20-10	4	3H6-07223-0	* COTTER * ｺｯﾀ	2	2	2	
20-11	1	3RS-07896-0	EXHAUST VALVE KIT ｴｷｿﾞｰｽﾄﾊﾞﾙﾌﾞｷｯﾄ	1	1	1	
20-11	2	3RS-07902-0	* EXHAUST VALVE * ｴｷｿﾞｰｽﾄﾊﾞﾙﾌﾞ	1	1	1	
20-11	3	3V1-07221-0	* RETAINER * ﾘﾃｰﾅ	1	1	1	
20-11	4	3H6-07223-0	* COTTER * ｺｯﾀ	2	2	2	

索引

<C>

Cリング 11-44

<E>

ECU アッシ 7-14-1
ECU アッシ 7-14-2
ECU アッシ 7-14-3
ECUホルダ 7-15
Eリング d=6 10-50
Eリング d=6 10-79
Eリング d=6 11-35
Eリング d=6 17-4

<I>

ISCバルブ 5-14

<O>

Oリング 5-44
Oリング 5-45
Oリング 5-46
Oリング 5-88
Oリング 5-89
Oリング 7-67
Oリング 9-45
Oリング 11-40
Oリング 11-43
Oリング 11-47
Oリング 11-50
Oリング 11-64
Oリング 16-20
Oリング 20-4-8
Oリング 1.5-3.5 11-49
Oリング 1.9-13. 3-24
Oリング 1.9-6.8 10-27
Oリング 1.9-9.8 4-3
Oリング 1.9-9.8 5-8
Oリング 2.4-59.6. 9-18
Oリング 2.4-59.6. 20-4-4
Oリング 2.4-9.8 11-42
Oリング 2-62.5. 11-57
Oリング 3.1-24.4. 3-41
Oリング 3.1-24.4. 20-3-4
Oリング 3.5-25.7. 5-62
Oリング 3.5-25.7. 10-59
Oリング 3.5-25.7. 20-3-11

<P>

PT アッシ 11-38
PTTスイッチアッシ 12-47
PTTスイッチアッシ 13-27
PTTスイッチアッシ 18-12
PTTソレノイドスイッチ (A). 7-39
PTTソレノイドスイッチ (B). 7-42

<S>

SPORTデカール 15-10

<V>

VSTコネクタ 5-49

<ア>

アーマチュアアッシ 11-70
アイドルエキゾーストポートガスケット 8-20
アイドルエキゾーストポートカバーアッシ. 8-17
アシストコード (レッド) L=200 18-5
アジャストスクリュ 3-9
アジャストスクリュ 17-6
アジャストナット. 3-10
アジャストナット. 12-39
アノード. 3-25
アノード. 9-9
アノード. 10-4
アノード. 10-5
アノード. 11-1
アノード. 20-9-2
アノード. 20-9-11
アノードプラグ 3-23
アノードプラグアッシ. 3-22a

<イ>

イグニッションコイル W/R-キャップ 7-26
インシュレータ 5-12
インストラクションデカール. 17-24
インテークサイレンサアッシ. 5-22
インテークバルブ. 3-15
インテークバルブ. 20-10-2
インテークバルブキット 20-10-1
インテークバルブステムシール 3-21
インペラウォータポンプ 9-32
インペラウォータポンプ 20-5-3
インペラウォータポンプ 20-6-3
インペラウォータポンプ 20-9-4

<ウ>

ウェーブワッシャ 12-70
ウェーブワッシャ 17-19
ウォータシールプレート 9-14
ウォータシールラバー 9-13
ウォータストレーナ 9-6
ウォータパイプ (L) 8-8-2
ウォータパイプ (S) 8-8-1
ウォータパイプ (UL) 8-8-3
ウォータパイプ (UL) 20-8-8
ウォータパイプオウキシリアリマウント 13-2.5. 8-11
ウォータパイプシール (アッパ) 8-9
ウォータパイプシール (ロワ). 9-36
ウォータポンプガイドプレート 9-40
ウォータポンプガイドプレート 20-5-6
ウォータポンプガイドプレート 20-6-5
ウォータポンプガイドプレート 20-9-7
ウォータポンプキット (クロムメッキ). 20-6-1
ウォータポンプリペアキット. 20-5-1
ウォ-タホ-ス 5-75

<エ>

エアガイド 15-3
エアベントアッシ. 6-26
エキゾーストカバー (アウタ). 1-17
エキゾーストカバーガスケット 1-18
エキゾーストカバーガスケット 20-3-5
エキゾーストバルブ 3-16
エキゾーストバルブ 20-11-2
エキゾーストバルブキット 20-11-1
エキゾーストバルブステムシール. 3-22
エクステンションコード L=3000 19-25
エクステンションハウジング UL 8-23
エクステンションハウジング UL 20-8-2
エクステンションハウジングキット (UL) 20-8-1
エレクトリックスタータキット (F) 20-7-1
エレクトリックブラケットアッシ. 7-35-1
エレクトリックブラケットアッシ. 7-35-2
エンジンショートブロックキット. 20-2
エンジンテンプセンサ 7-30
エンジンベースガスケット 1-23
エンジンベースガスケット 20-3-7
エンジンベースシール 8-22

<オ>

オイルシール. 11-69
オイルシール 12.8-25-7 8-2
オイルシール 13.8-26-9.5 9-38
オイルシール 13.8-26-9.5 20-4-6
オイルシール 17-30-9 9-19
オイルシール 17-30-9 20-4-5
オイルシール 18-35-8 3-5
オイルシール 18-35-8 20-3-13
オイルシール 32-44-9 2-5
オイルシール 32-44-9 20-3-8
オイルシール 36-50-7 2-6
オイルシール 36-50-7 20-3-9
オイルストレーナアッシ 1-25
オイルフィラキャップ. 3-40
オイルフィルタアッシ. 1-8
オイルフィルタアッシ. 20-9-3
オイルフィルタボルト. 1-2
オイルプレッシャスイッチ. 7-29
オイルプレッシャデカール. 15-7
オイルポンプアッシ 3-27
オイルポンプガスケット 3-28
オイルポンプガスケット 20-3-12
オイルレベルゲージ 4-1
オイルレベルゲージガイド 4-2
オーバーヒートブザー. 18-13
オルタネータアッシ 7-2-1
オルタネータアッシ 7-2-2
オルタネータアッシ 19-18
オルタネータアッシ 20-7-2
オルタネータキット 19-17

<カ>

ガイドプレートガスケット 9-41
ガイドプレートガスケット 20-4-2
ガイドプレートガスケット 20-5-2
ガイドプレートガスケット 20-6-2
ガイドプレートガスケット 20-9-8
カウルサポート 1-28
カウルサポート 1-29
カウルサポートラバー. 1-30

カウルラッチアッシ 13-23
ガスケット 5-28-1
ガスケット 5-28-2
ガスケット 5-28-3
ガスケット 5-35
ガスケット 8.1-15-1. 9-5
ガスケット 8.1-15-1. 20-4-3
ガスケット 8.1-15-1. 20-9-9
ガスケット PTTスイッチ. 13-28
カップ 5-86
カップリング ポンプ 11-56
カバ- 5-31
カバ- 17-46
カバー 12-55
カバーステー (フロント). 13-8
カムシャフトアッシ 3-6
カムロッド 9-52-1
カムロッド (UL) 9-52-2
カムロッド (UL) 20-8-10
カラ- 3-14
カラー 5-26
カラー 5-53
カラー 7-53
カラー 12-3
カラー 13-14
カラー 14-24
カラー 20-7-12
カラー 10.2-12-12. 11-18
カラー 6.5-10.5-9.3 14-16
カラー ブラケット 6.5-10.5-10 12-65
<キ>
キー. 9-33
キー. 20-5-4
キー. 20-9-6
キー 10-3.7-3 4-6
キー 10-3.7-3 4-7
キー 13.4-5-4 7-5
ギャケースアッシ 9-1
キャップ バルブ 5-6
キャップ ヒューズボックス (Y) 19-27
キャップアッシ 11-39
キャップナット ブラケットボルト 10-14
キャブレタガスケット 5-20
キャブレタガスケット 20-3-10
キャリングハンドル 10-21
<ク>
クイックコネクタ (タンクメール). 16-15
クラッチ. 9-27
クラッチカム. 9-53
クランクシャフトアッシ 2-3
グランド (アースワイヤ) L=110 10-20
グランド (アースワイヤ) L=130 11-2
グランド (アースワイヤ) L=130 11-3
グランド (アースワイヤ) L=210 8-13
グランドケーブル (AV2) L=120. 7-50
グランドケーブル (AV2) L=120. 7-86
クランプ. 5-72
クランプ. 16-3
クランプ. 16-6
クランプ. 17-50
クランプ 6.5-14L. 7-83
クランプ 6.5-14L. 11-36a
クランプ 6.5-47.5P 7-11
クランプ 6-9.5L 12-50
クランプ φ10 5-73
クランプ φ16.8 5-57
クランプスクリュ 10-75
クランプスクリュ (PTT) 11-33
クランプスクリュアッシ 10-74
クランプスクリュキット 10-73
クランプスクリュキット 11-32
クランプスクリュパッド 10-78
クランプスクリュパッド 11-34
クランプスクリュハンドル 10-76
クランプブラケット (L) 10-2
クランプブラケット (PTT-L). 11-7
クランプブラケット (PTT-R) 11-6
クランプブラケット (R) 10-1
グリスフィッティング 10-19
グリスフィッティング 12-60
クリップ. 5-50
グリップ. 12-31
グリップ. 17-17
クリップ φ12 5-79
クリップ φ9.4 5-66
クリップ φ9.4 5-67
クリップ φ9.4 5-83
ク-リングホ-ス. 5-76
ク-リングホ-ス. 5-77
グロメット 5-39
グロメット 12-12
グロメット 13-6
グロメット 13-22
グロメット 13-33
グロメット 14-8
グロメット 17-12
グロメット 13-2 6-24
グロメット 17-2.7 13-5
グロメット 22-3 13-11
グロメット シフトロッド 13-7
<ケ>
ケーブルクリップアッシ 14-9
ケーブルジョイント 14-11
ケーブルターミナル 17-8
ケーブルターミナル プラグ. 7-31
ケーブルターミナル プラグ. 17-54
<コ>
コイルブラケット 7-9
コーションデカール 15-9
コーションデカール (A) 15-8
コーションデカール (B) 6-25-2
コーションデカール (SIGP) 17-51
コーションデカール（B). 6-25-1
コードアッシ. 7-23-1
コードアッシ. 7-23-2
コードアッシ. 7-23-3
コードアッシ. 20-7-4
コードアッシ L=6200 18-4
コッタ 3-19
コッタ 20-10-4
コッタ 20-11-4
コパイロットデカル 10-3
コントロールレバー 17-18
コンロッドアッシ. 2-1
コンロッドボルト. 2-2
<サ>
サーモスタット 1-11
サーモスタットキャップ 1-12
サーモスタットキャップガスケット 1-13
サーモスタットキャップガスケット 20-3-6
<シ>
シール 5-91
シールラバー. 15-5
シールリング. 5-4
シールリング. 8-16
シールリング ドラッグリンク 14-6
シールワッシャ 11-45
シフトアーム. 14-15
シフトギヤアッシ. 17-7
シフトディテントサポーター. 12-14
シフトディテントスプリング. 12-13
シフトデカール 12-63
シフトポジションデカール 18-7
シフトレバー. 12-64
シフトレバーシャフトアッシ. 12-16
シフトレバーロッド 14-20
シフトレバーロッド 12-68
シフトロッド (L). 12-20-2
シフトロッド (S). 12-20-1
シフトロッドジョイント 12-21
シム 35-41.9-0.1 9-49-1
シム 35-41.9-0.15 9-49-2
シム 35-41.9-0.3 9-49-3
シム 35-41.9-0.5 9-49-4
ジョイント 17-49
ジョイントアッシ (アウトレット). 16-4
ジョイントアッシ (インレット) 16-2
ショルダボルト 6-8. 10-42
シリンダピン (アッパ) 11-20
シリンダピン (ロワ). 11-26
シリンダブロック＆クランクケ-スアッシ. 1-1
シリンダヘッドアッシ. 3-3
シリンダヘッドガスケット 3-30
シリンダヘッドガスケット 20-3-2
シリンダヘッドカバーアッシ. 3-34
シリンダヘッドカバーガスケット. 3-38
シリンダヘッドカバーガスケット. 20-3-3
シリンダヘッドコンプリート. 3-2
シリンダヘッドボルト 8-50. 1-5
シリンダヘッドボルト 8-60. 3-31
シ-ル 5-32
<ス>
スイッチボックス. 12-48
スイッチボックス. 13-29

スイッチボックス グロメット 13-30
スイベルブラケットアッシ 10-17-1
スイベルブラケットアッシ 10-17-2
スイベルブラケットアッシ (PTT) 11-12-1
スイベルブラケットアッシ(PTT). 11-12-2
スイベルブラケットシャフトアッシ 10-11
スクリュ. 3-26
スクリュ. 3-37
スクリュ. 5-16
スクリュ. 5-17
スクリュ. 5-33
スクリュ. 5-48
スクリュ. 5-51
スクリュ. 7-65
スクリュ. 9-7
スクリュ. 11-67
スクリュ. 11-71
スクリュ. 12-35
スクリュ. 12-37
スクリュ. 12-43
スクリュ. 12-49
スクリュ. 12-51
スクリュ. 13-31
スクリュ. 17-23
スクリュ. 17-26
スクリュ. 17-27
スクリュ. 17-28
スクリュ. 17-40
スクリュ. 18-11
スタータケース 6-2
スタータケーブル. 7-85
スタータケーブル. 20-7-30
スタータシール 6-20
スタータスプリング 6-4
スタータソレノイド 7-37
スタータソレノイド 20-7-9
スタータハンドル. 6-15
スタータモータアッシ. 7-56
スタータモータアッシ. 20-7-15
スタータモータバンド. 7-70
スタータモータバンド. 20-7-16
スタータロープ φ5-1800 6-14
スタータロック 6-17
スタータロックカムスプリング 6-3
スタータロックスプリング 6-18
スタータロックワイヤ. 6-19
スタッド. 12-30
ステアリングシャフトアッシ. 10-56-1
ステアリングシャフトアッシ. 10-56-2
ステアリングフックプレート. 14-26
ステアリングブラケット 12-59
ストッパ. 9-44
ストッパ カムロッドブッシング. 9-43
ストッパ ブッシング 8-26
ストッパ ブッシング 20-8-6
ストッパ リバースロックレバーグリップ 10-41
ストップスイッチアッシ 12-44
ストップスイッチアッシ 18-14
ストップスイッチデカール 18-16
ストップスイッチデカ-ル 12-45
ストップスイッチランヤードアッシ 18-15
ストレージデカール 13-26
スナップ クラッチピン. 9-29
スナップピン d=5. 12-69
スナップピン d=8. 14-14
スナップピン d=8. 14-21
スパークプラグ (DCPR6E) 3-1
スパークプラグ (DCPR6E) 20-9-13
スプリットピン 2-12 10-52
スプリットピン 3-22 9-61
スプリットピン 3-22 20-9-12
スプリング 12-40
スプリング クラッチ 9-30
スプリングピン 9-55
スプリングピン 10-33
スプリングピン 10-77
スプリングピン 3.5-16 11-16
スプリングピン 3-10 9-54
スプリングワッシャ 7-41
スプリングワッシャ 7-44
スプリングワッシャ 7-59
スプリングワッシャ 7-60
スペーサ. 17-29
スペーサ ドラッグリンク H. 14-2
スラストプレート. 17-22
スラストプレート (アッパ) 10-58
スラストホルダ 9-58
スラストロッドアッシ 10-15
スラストロッドスプリング 10-16
スロットルアーム. 14-22
スロットルアーム. 17-2
スロットルオープナ 14-23
スロットルシャフト 12-32
スロットルシャフトサポート. 12-36
スロットルシャフトダンパ 12-33
スロットルデカール 12-46
スロットルドラムアッシ 12-1
スロットルフリクションアーム 17-3
スロットルボディアッシ 5-13
スロットルレバーストッパ. 14-29
スロットルロッド. 12-9
スロットルワイヤ. 12-58
スロットルワイヤブラケット. 12-6
<セ>
セーフティロープ φ5-1600 19-2
セッティングピース チルトストッパ. 10-38
セッティングプレート 10-35
<ソ>
ソレノイドスイッチコード (A). 7-45
ソレノイドスイッチコード (B) 7-46
<タ>
ターミナルキャップ 7-47
ターミナルキャップ 7-80
ターミナルキャップ 7-81
ターミナルキャップ 7-82
ターミナルキャップ 20-7-27
ターミナルキャップ 20-7-28
ターミナルキャップ 20-7-29
ターミナルキャップ スタータ 7-48
タイミングベルト. 4-14
ダウェルピン 4-10 9-42
ダウェルピン 6-12 1-4
ダウェルピン 6-12 3-4
ダウェルピン 6-12 7-12
ダウェルピン 6-12 8-5
ダウェルピン 6-12 8-6
ダウェルピン 6-12 8-7
ダウェルピン 6-12 20-8-3
タコメータリードワイヤ L=6000 19-16
タッピングスクリュ 6-8
タッピングスクリュ 6-9
タッピングスクリュ 5-16 6-27
タッピングスクリュ 6-16 15-4
タンクフィラーキャップガスケット 16-22a
ダンパ (アッパ). 10-63
ダンパ (アッパ). 10-66
ダンパ (ロワ) 10-67
ダンパ スタータモータ. 7-71
ダンパ スタータモータ. 20-7-17
<チ>
チルトスイッチプラグ 17-53
チルトストッパ 10-32
チルトストッパ (PTT). 11-13
チルトストッパグリップ 11-14
チルトストッパスプリング 11-17
<ツ>
ツインリモートコントロールキット 17-55
ツールキット. 19-1
<テ>
ディスクコパイロット 8.5-38-2 10-31
ディスタンスピース 10-7
ティラハンドルアッシ. 12-27
ティラハンドルアッシ. 12-28
デカール (レバー) 18-6
デカールセット (MFS15E) 15-6-2
デカールセット (MFS20E) 15-6-3
デカールセット (MFS9.9E). 15-6-1
デテントスプリング 17-42
デテントリテーナ. 17-41
デテントローラ 17-38
<ト>
トップカウルアッシ 15-1
トップカウルサブアッシ 15-2
トップカウルシール 13-32
ドライブギヤ. 17-9
ドライブシャフト (L). 9-50-2
ドライブシャフト (S). 9-50-1
ドライブシャフト (UL). 9-50-3
ドライブシャフト (UL). 20-8-9
ドライブシャフトハウジングアッシ (L) 8-1-2
ドライブシャフトハウジングアッシ (S) 8-1-1
ドライブシャフトハウジングアッシ (S) 8-1-3
ドライブシャフトハウジングカバー (L) 13-19
ドライブシャフトハウジングカバー (R) 13-18

ドライブシャフトハウジングカバー(L) 13-20
ドライブシャフトブッシング. 8-25
ドライブシャフトブッシング. 20-8-5
ドライブプーリ (タイミングプーリ) 4-5
ドラッグリンクアッシ 14-1
ドリブンプーリ 4-11
トリムロックピン 11-8
ドレンスクリュ 5-34
ドレンバルブ. 5-90
ドレンボルト. 8-3
<ナ>
ナイロンナット 10-P1.25 10-64
ナイロンナット 3/8-24UNF 14-4
ナイロンナット 4-P0.7 9-8
ナイロンナット 6-P1.0 9-11
ナイロンナット 7/8-14. 10-12
ナイロンナット 8-P1.25 10-26
ナイロンナット 8-P1.25 11-4
ナット 5-18
ナット 7-6
ナット 7-40
ナット 7-43
ナット 7-57
ナット 10-10
ナット 11-30
ナット 12-11
ナット 12-22
ナット 12-56
ナット 17-10
ナット 17-32
ナット プーリ 4-10
ナット ベベルギヤ B 9-23
<ニ>
ニップル. 5-7
ニップル. 5-80
ニップル 10-32. 3-35
ニュートラルスイッチ (リモートコントロール) 18-10
ニュートラルスイッチアクチエータ 12-24
ニュートラルスイッチアクチエータ 20-7-32
ニュートラルスイッチブラケット. 12-25
ニュートラルスイッチブラケット. 20-7-33
ニュートラルロックアーム 17-15
ニュートラルロックスプリング 17-16
ニュ-トラルスイッチ 12-23
ニュ-トラルスイッチ 20-7-31
<ハ>
パイロットランプアッシ 13-2
バッテリケーブル. 7-78
バッテリケーブル. 20-7-25
パルサコイル. 7-3
バルブアッシ. 11-48
バルブアッシ (プレッシャチェック) 5-5
バルブスプリング. 3-17
バルブスプリングシ-ト 3-20
パワーヘッドガスケットセット 20-3-1
ハンガ 1-9
バンド 18-9
バンド リードワイヤ 1-21
バンド リードワイヤ 11-58
バンド リードワイヤ 18-8
バンド リードワイヤ 104 7-51
バンド リードワイヤ 135 7-19
バンド リードワイヤ 158 1-22
バンド リードワイヤ 158 1-26
バンド リードワイヤ 158 5-84
バンド リードワイヤ 158 7-20
バンド リードワイヤ 158 7-21
バンド リードワイヤ 158 7-22
バンド リードワイヤ 158 20-7-36
バンド リードワイヤ 203 11-19
<ヒ>
ピストン. 2-8
ピストンピン? 2-9
ピストンピンクリップ 2-10
ピストンリペアキット 2-7
ピストンリング 2-12
ピストンリング 2-13
ピストンリング オイル. 2-14
ピストンリングセット 2-11
ピックアップエルボアッシ 16-23
ピニオンアッシ 7-62
ビニルパイプ. 1-3
ヒューズ 20A. 7-24
ヒューズ 20A. 19-26
ピン クラッチ φ5-30. 9-28
<フ>
フィルタ. 16-21
フィルタ B 11-55
フィルタ（インレット） 5-40
フィルター 5-87
ブッシュロッド 9-31
ブッシング 6-6
ブッシング 10-13
ブッシング 12-53
ブッシング 17-35
ブッシング 1 7-69
ブッシング 13-16-31 11-21
ブッシング 13-16-31 11-23
ブッシング 13-17-19.5 11-22
ブッシング 14-15.8-7. 12-34
ブッシング 2 7-66
ブッシング 28-31-35 10-57
ブッシング 8.1-20 10-44
ブッシング 8.2-10-26.5. 10-34
ブッシング B 17-25
ブッシング D. 17-21
ブッシング ハンドル 12-52
フュエルインジェクタアッシ. 5-3
フュエルコネクタ (エンジンフィメール) 16-11
フュエルコネクタ (エンジンメール) 13-3
フュエルコネクタ (タンクフィメール). 16-10
フュエルコネクタプロテクタ. 13-34
フュエルコネクタマーク 16-9
フュエルタンクアッシ 12L (トーハツ) 16-12-1
フュエルタンクアッシ 12L (トーハツ) 16-12-2
フュエルタンクキャップアッシ 16-13
フュエルタンクキャップアッシ 16-22
フュエルフィードポンプ 5-43
フュエルフィルターアッシ 5-85
フュエルフィルタホルダ 5-69
フュエルホース W/プロテクタ. 5-56
フュエルホース W/プロテクタ. 5-64-1
フュエルホース W/プロテクタ. 5-64-2
フュエルホース W/プロテクタ. 5-65-1
フュエルホース W/プロテクタ. 5-65-2
フュエルホース W/プロテクタ. 5-82-1
フュエルホース W/プロテクタ 455-25. 5-82-2
フュエルポンプアッシ. 5-61
フュエルレール 5-2
フュエルレールアッシ 5-1
フュエルレギュレータ. 5-47
フライホイール 7-1-1
フライホイール W/リングギヤ. 7-1-2
フライホイール W/リングギヤ. 20-7-3
プライマバルブ 16-5-1
プライマバルブ 16-5-2
プライマバルブアッシ. 16-1-1
プライマバルブアッシ. 16-1-2
プラグ 20-7-7
プラグ 8-8. 9-4
プラグキャップ W/レジスタンス 7-27
ブラケット 1-14
ブラケット 7-36
ブラケット 12-42
ブラケット 20-7-8
ブラシ 11-65
ブラシスプリング. 11-66
ブラシホルダ. 11-68
ブラシホルダアッシ 7-64
プラスチックリベット 6.5. 12-29
フラッシングコネクタキャップ 8-15
ブリーザホース W/プロテクタ. 5-78
フリースロットルスプリング. 17-45
フリースロットルドラム 17-20
フリースロットルレバー 17-39
フリースロットルローラ 17-43
フリクションスプリング 6-12
フリクションスプリング 10-37
フリクションピース 12-38
フリクションプレート 6-13
フリクションレバー 10-22
ブリ-ザチャンバーカバー 3-36
ブレーカ. 11-62
ブレーカホルダ 11-63
プレート. 5-70
プレート. 7-16
プレート. 7-17
プレート. 8-18
プレート. 10-28
プレコートスクリュ 5-12 11-59
プレコートボルト. 9-20
プレコートボルト 6-20. 4-12
プレコートボルト 6-20. 6-22
プレ-ンシャフトベアリング 2-4-1

プレ-ンシャフトベアリング 2-4-2
フロート 5-38
フロート 5-92
フロートアームピン 5-37
フロートバルブアッシ 5-36
プロテクタ φ10.7-180 7-34
プロテクタ φ10.7-180 20-7-6
プロテクタ φ10.7-320 7-33
プロテクタ φ10.7-320 20-7-5
プロテクタ φ24-70 7-32
プロペラアッシ (10") 9-56-5
プロペラアッシ (11.5") 9-56-6
プロペラアッシ (6") 9-56-1
プロペラアッシ (7") 9-56-2
プロペラアッシ (7") 9-56-7
プロペラアッシ (8") 9-56-3
プロペラアッシ (9") 9-56-4
プロペラシャフト 9-26
プロペラシャフトハウジングアッシ 9-15
プロペラナット 9-60
プロペラハードウェアキット 9-57
フロントハウジング 17-52
フロントパネル 13-1
<ヘ>
ベーパセパレータアッシ 5-30
ベベルギア B 9-22
ベベルギア C 9-24
ベベルギャアッシ (A) 9-21
ベルトガイド 4-8
ベルトカバー 6-23
ベントホース W/プロテクタ 5-58
ベントホース W/プロテクタ 5-59
ベントホース W/プロテクタ 5-60
<ホ>
ホース 1-27
ホース 5-21
ホース 16-7-2
ホース 16-8-2
ホースジョイント (ウォータワーク) 19-28
ボールジョイントコネクタ 12-10
ホールディングプレート 5-9
ボールベアリング 9-17
ボールベアリング 9-51
ボールベアリング 6205HS 9-3
ホルダ 5-42
ホルダ 12-17
ホルダ 12-18
ホルダ 17-47
ボルト 1-6
ボルト 1-10
ボルト 1-15
ボルト 3-29
ボルト 3-32
ボルト 3-39
ボルト 4-4
ボルト 5-10
ボルト 5-11
ボルト 5-23
ボルト 5-24
ボルト 5-55
ボルト 5-63
ボルト 5-71
ボルト 5-81
ボルト 7-4
ボルト 7-8
ボルト 7-10
ボルト 7-13
ボルト 7-18
ボルト 7-25
ボルト 7-28
ボルト 7-38
ボルト 7-49
ボルト 7-55
ボルト 7-58
ボルト 7-72
ボルト 7-73
ボルト 7-75
ボルト 7-77
ボルト 7-79
ボルト 7-84
ボルト 8-12
ボルト 8-14
ボルト 8-19
ボルト 8-21
ボルト 8-24
ボルト 8-27
ボルト 9-10
ボルト 9-12
ボルト 9-46
ボルト 9-47
ボルト 9-48
ボルト 10-6
ボルト 10-25
ボルト 10-29
ボルト 10-36
ボルト 10-61
ボルト 10-62
ボルト 10-71
ボルト 10-80
ボルト 11-9
ボルト 11-25
ボルト 11-27
ボルト 11-29
ボルト 11-36
ボルト 11-37
ボルト 11-52
ボルト 11-53
ボルト 11-54
ボルト 12-5
ボルト 12-7
ボルト 12-15
ボルト 12-19
ボルト 12-26
ボルト 12-41
ボルト 12-61
ボルト 12-62
ボルト 12-67
ボルト 13-4
ボルト 13-17
ボルト 13-21
ボルト 13-24
ボルト 14-10
ボルト 14-19
ボルト 14-25
ボルト 14-27
ボルト 17-11
ボルト 17-37
ボルト 17-48
ボルト 19-21
ボルト 19-23
ボルト 19-24
ボルト 20-5-7
ボルト 20-7-10
ボルト 20-7-14
ボルト 20-7-18
ボルト 20-7-19
ボルト 20-7-21
ボルト 20-7-23
ボルト 20-7-24
ボルト 20-7-26
ボルト 20-7-34
ボルト 20-8-4
ボルト 20-8-7
ボルト 25mm. 1-19
ボルト 25mm. 3-42
ボルト 3/8-35. 14-3
ボルト 8-P1.25 1-24
ポンプ 11-51
ポンプケース (アッパ) 9-34
ポンプケースアッシ (ロワ) 9-37
ポンプケースガスケット (ロワ) 9-39
ポンプケースガスケット (ロワ) 20-4-7
ポンプケースライナ 9-35
ポンプケースライナ 20-5-5
ポンプケースライナ 20-9-5
ポンプケースライナ クロムメッキ 20-6-4
<マ>
マウント 8.5-14-2.5 13-12
マウントブラケット (L) 10-70
マウントブラケット (R) 10-69
マップセンサ 5-15
マニュアルバルブアッシ 11-41
<メ>
メインスイッチアッシ 13-10
メインスイッチアッシ 18-1
メインスイッチアッシ 20-7-35
メインスイッチキー No.943 18-2-1
メインスイッチキー No.944 18-2-2
メインスイッチキー No.945 18-2-3
メインスイッチキーカバリングキャップ 18-3
メンテナンスキット 20-9-1
<モ>
モータアッシ 11-60
モータブラケットアッシ 11-61

<ヨ>
ヨークアッシ 11-72
<ラ>
ラチェット 6-7
ラバーマウント 5-25
ラバーマウント 5-52
ラバーマウント 7-52
ラバーマウント 20-7-11
ラバーマウント (アッパ) 10-60
ラバーマウント (ロワ) 10-68
ラバーマウント 8.5-14-2.5 13-13
<リ>
リール 6-5
リギングボルトセット 11-28
リコイルスタータアッシ 6-1
リストリクタ 5-29-1
リストリクタ 5-29-2
リターンスプリング 6-10
リターンスプリング 6-11
リテーナ 3-18
リテーナ 20-10-3
リテーナ 20-11-3
リテーニングリング 16-14
リバースロック (R) 10-47
リバースロックアーム 10-48
リバースロックシャフト 10-49
リバースロックスプリング 10-55
リバースロックスプリング (S) 10-54
リバースロックリンク 10-53
リバースロックレバー 10-39
リバースロックレバーグリップ 10-40
リバースロックロッド A 10-51
リベット 13-9
リモートコントロールフィッティングアッシ 14-7
リモートコントロールヘッドアッシ(RC12A) 17-1-1
リモートコントロールヘッドアッシ(RC12B) 17-1-2
リモートコントロールロゴデカール 18-17
リヤハウジング 17-13
リヤパネル 17-14
リリーフバルブアッシ 11-46
リンクロッドアッシ (スロットル) 12-8
<レ>
レクチファイヤキット 19-19
レクチファイヤコンプリート 7-74
レクチファイヤコンプリート 19-20
レクチファイヤコンプリート 20-7-20
レクチファイヤブラケット 7-76
レクチファイヤブラケット 19-22
レクチファイヤブラケット 20-7-22
<ロ>
ローパーミェーションホース L=1600 16-8-1
ローパーミェーションホース L=700 16-7-1
ロープアンカ 6-16
ローラ 17-34
ローラベアリング 9-2
ローラリテーナ 17-44
ロッカーアーム 3-8
ロッカ-アーム 3-7
ロッカアームシャフト 3-11
ロッカシャフトスプリング L=25 3-12
ロックプレート 8-10
ロックワッシャ 4-9
ロワユニットアッシ (L) 20-1-2
ロワユニットアッシ (S) 20-1-1
ロワユニットアッシ (UL) 20-1-3
ロワユニットガスケットセット 20-4-1
<ワ>
ワッシャ 1-7
ワッシャ 1-16
ワッシャ 1-20
ワッシャ 3-33
ワッシャ 5-19
ワッシャ 7-61
ワッシャ 7-63
ワッシャ 7-68
ワッシャ 10-8
ワッシャ 10-9
ワッシャ 10-30
ワッシャ 10-43
ワッシャ 10-65
ワッシャ 11-15
ワッシャ 11-31
ワッシャ 12-54
ワッシャ 12-57
ワッシャ 12-71
ワッシャ 14-28
ワッシャ 17-5
ワッシャ 17-31
ワッシャ 17-33
ワッシャ 17-36
ワッシャ 12.5-32-2.5 9-59
ワッシャ 13.2-21.8-2 3-13
ワッシャ 14.5-24-1 8-4
ワッシャ 14.5-24-1 20-9-10
ワッシャ 16-27-3.2 7-7
ワッシャ 17.1-22-1.5 9-25
ワッシャ 22-36-1 11-10
ワッシャ 6.5-19-3.2 4-13
ワッシャ 6.5-21-1 12-66
ワッシャ 6.5-21-1 13-16
ワッシャ 6.5-23-1.5 11-24
ワッシャ 6.5-23-1.5 13-25
ワッシャ 6-16-1.5 5-27
ワッシャ 6-16-1.5 5-54
ワッシャ 6-16-1.5 6-21
ワッシャ 6-16-1.5 7-54
ワッシャ 6-16-1.5 10-46
ワッシャ 6-16-1.5 12-4
ワッシャ 6-16-1.5 14-17
ワッシャ 6-16-1.5 14-18
ワッシャ 6-16-1.5 20-7-13
ワッシャ 8.1-16-1.5 10-72
ワッシャ 8.1-16-1.5 11-5
ワッシャ 8.1-20-0.8 10-23
ワッシャ 8.5-18-1.6 10-45
ワッシャ 8.5-18-1.6 14-12
ワッシャ 8.5-18-1.6 14-13
ワッシャ 8.5-24-1.5 10-24
ワッシャ 8.5-28-1 11-11
ワッシャ 9.6-18-2 14-5
ワッシャ ラバーマウント 13-15
ワッシャ リモコンボックス 17-30

INDEX

<A>
ADJUSTING NUT 3-10
ADJUSTING NUT 12-39
ADJUSTING SCREW 3-9
ADJUSTING SCREW 17-6
AIR GUIDE 2S 15-3
AIR VENT ASSY 6-26
ALTERNATOR ASSY 7-2-1
ALTERNATOR ASSY 7-2-2
ALTERNATOR ASSY 19-18
ALTERNATOR ASSY 20-7-2
ALTERNATOR KIT 19-17
ANODE 3-25
ANODE 9-9
ANODE 10-4
ANODE 10-5
ANODE 11-1
ANODE 20-9-2
ANODE 20-9-11
ANODE PLUG 3-23
ANODE PLUG ASSY 3-22a
ARMATURE ASSY 11-70
ASSIST CORD (RED) L=200 18-5
<B>
BALL BEARING 9-17
BALL BEARING 9-51
BALL BEARING 6205HS 9-3
BALL JOINT CONNECTOR 12-10
BAND 1-21
BAND 11-58
BAND 18-8
BAND 18-9
BAND 104 7-51
BAND 135 7-19
BAND 158 1-22
BAND 158 1-26
BAND 158 5-84
BAND 158 7-20
BAND 158 7-21
BAND 158 7-22
BAND 158 20-7-36
BAND 203 11-19
BATTERY CABLE 7-78
BATTERY CABLE 20-7-25
BELT COVER 6-23
BELT GUIDE 4-8
BEVEL GEAR ASSY (A) 9-21
BEVEL GEAR B 9-22
BEVEL GEAR C 9-24
BOLT 1-6
BOLT 1-10
BOLT 3-29
BOLT 3-32
BOLT 3-39
BOLT 4-4
BOLT 5-10
BOLT 5-11
BOLT 5-23
BOLT 5-24
BOLT 5-55
BOLT 5-63
BOLT 5-71
BOLT 5-81
BOLT 7-4
BOLT 7-8
BOLT 7-10
BOLT 7-13
BOLT 7-18
BOLT 7-25
BOLT 7-28
BOLT 7-38
BOLT 7-49
BOLT 7-55
BOLT 7-58
BOLT 7-72
BOLT 7-73
BOLT 7-75
BOLT 7-77
BOLT 7-79
BOLT 7-84
BOLT 8-12
BOLT 8-14
BOLT 8-19
BOLT 8-21
BOLT 8-27
BOLT 9-10
BOLT 9-20
BOLT 9-46
BOLT 9-47
BOLT 9-48
BOLT 10-6
BOLT 10-25
BOLT 10-29
BOLT 10-36
BOLT 10-61
BOLT 10-62
BOLT 10-71
BOLT 10-80
BOLT 11-9
BOLT 11-25
BOLT 11-27
BOLT 11-29
BOLT 11-36
BOLT 11-37
BOLT 11-52
BOLT 11-53
BOLT 11-54
BOLT 12-5
BOLT 12-7
BOLT 12-15
BOLT 12-19
BOLT 12-26
BOLT 12-41
BOLT 12-61
BOLT 12-62
BOLT 12-67
BOLT 13-4
BOLT 13-17
BOLT 13-21
BOLT 13-24
BOLT 14-10
BOLT 14-19
BOLT 14-25
BOLT 14-27
BOLT 17-11
BOLT 17-37
BOLT 17-48
BOLT 19-21
BOLT 19-23
BOLT 19-24
BOLT 20-5-7
BOLT 20-7-10
BOLT 20-7-14
BOLT 20-7-18
BOLT 20-7-19
BOLT 20-7-21
BOLT 20-7-23
BOLT 20-7-24
BOLT 20-7-26
BOLT 20-7-34
BOLT 20-8-7
BOLT 25mm 1-19
BOLT 25mm 3-42
BOLT 3/8-35 14-3
BOLT 40mm 1-15
BOLT 8-31 8-24
BOLT 8-31 9-12
BOLT 8-31 20-8-4
BOLT 8-P1.25 1-24
BRACKET 1-14
BRACKET 7-36
BRACKET 12-42
BRACKET 20-7-8
BREAKER 11-62
BREAKER HOLDER 11-63
BREATHER CHAMBER COVER 3-36
BREATHER HOSE W/PROTECTOR 5-78
BRUSH 11-65
BRUSH HOLDER 11-68
BRUSH HOLDER ASSY 7-64
BRUSH SPRING 11-66
BUSHING 6-6
BUSHING 10-13
BUSHING 12-52
BUSHING 12-53
BUSHING 17-21
BUSHING 17-25
BUSHING 17-35
BUSHING 1 7-69
BUSHING 13-16-31 11-21
BUSHING 13-16-31 11-23
BUSHING 13-17-19.5 13-17-19.5 11-22
BUSHING 14-15.8-7 12-34
BUSHING 2 7-66
BUSHING 28-31-35 10-57
BUSHING 8.1-20 10-44
BUSHING 8.2-10-26.5 10-34
<C>
CABLE CLIP ASSY 14-9
CABLE JOINT 14-11
CABLE TERMINAL 17-8
CABLE TERMINAL PLUG 7-31
CABLE TERMINAL PLUG 17-54
CAM ROD 9-52-1
CAM ROD (UL) 9-52-2
CAM ROD (UL) 20-8-10
CAMSHAFT ASSY 3-6
CAP 5-6
CAP 19-27
CAP ASSY 11-39
CAP NUT 10-14
CARBURETOR GASKET 5-20
CARBURETOR GASKET 20-3-10
CARRYING HANDLE 10-21
CAUTION DECAL 15-9
CAUTION DECAL (A) 15-8
CAUTION DECAL (B) 6-25-1
CAUTION DECAL (B) 6-25-2
CAUTION DECAL(SIGP) 17-51
CLAMP 5-72
CLAMP 16-3
CLAMP 16-6
CLAMP 17-50
CLAMP 6.5-14L 7-83
CLAMP 6.5-14L 11-36a
CLAMP 6.5-47.5P 7-11
CLAMP 6-9.5L 12-50
CLAMP BRACKET (L) 10-2
CLAMP BRACKET (PTT-L) 11-7
CLAMP BRACKET (PTT-R) 11-6
CLAMP BRACKET (R) 10-1
CLAMP SCREW 10-75
CLAMP SCREW (PTT) 11-33
CLAMP SCREW ASSY 10-74
CLAMP SCREW HANDLE 10-76
CLAMP SCREW KIT 10-73
CLAMP SCREW KIT 11-32
CLAMP SCREW PAD 10-78
CLAMP SCREW PAD 11-34
CLAMP φ10 5-73
CLAMP φ16.8 5-57
CLIP 5-50
CLIP φ12 5-79
CLIP φ9.4 5-66
CLIP φ9.4 5-67
CLIP φ9.4 5-83
CLUTCH 9-27
CLUTCH CAM 9-53
COIL BRACKET 7-9
COLLAR 3-14
COLLAR 5-26
COLLAR 5-53
COLLAR 7-53
COLLAR 12-3
COLLAR 13-14
COLLAR 14-24
COLLAR 20-7-12

COLLAR 10.2-12-12 11-18
COLLAR 6.5-10.5-10 12-65
COLLAR 6.5-10.5-9.3 14-16
CONNECTING ROD ASSY 2-1
CONNECTING ROD BOLT 2-2
CONTROL LEVER 17-18
COOLING HOSE 5-76
COOLING HOSE 5-77
CO-PILOT DECAL 10-3
CORD ASSY 7-23-1
CORD ASSY 7-23-2
CORD ASSY 7-23-3
CORD ASSY 20-7-4
CORD ASSY L=6200 18-4
COTTER 3-19
COTTER 20-10-4
COTTER 20-11-4
COUPLING 11-56
COVER 5-31
COVER 12-55
COVER 17-46
COVER STAY (FRONT) 13-8
COWL LATCH ASSY 13-23
COWL SUPPORT 1-28
COWL SUPPORT 1-29
COWL SUPPORT RUBBER 1-30
CRANKSHAFT ASSY 2-3
C-RING 11-44
CUP 5-86
CYL BLOCK & CRANKCASE ASSY 1-1
CYLINDER HEAD ASSY 3-3
CYLINDER HEAD BOLT 8-50 1-5
CYLINDER HEAD BOLT 8-60 3-31
CYLINDER HEAD COMPLETE 3-2
CYLINDER HEAD COVER ASSY 3-34
CYLINDER HEAD COVER GASKET 3-38
CYLINDER HEAD COVER GASKET 20-3-3
CYLINDER HEAD GASKET 3-30
CYLINDER HEAD GASKET 20-3-2
CYLINDER PIN (LOWER) 11-26
CYLINDER PIN (UPPER) 11-20
<D>
DAMPER 7-71
DAMPER 20-7-17
DAMPER (LOWER) 10-67
DAMPER (UPPER) 10-63
DAMPER (UPPER) 10-66
DECAL (LEVER) 18-6
DECAL SET (MFS15E) 15-6-2
DECAL SET (MFS20E) 15-6-3
DECAL SET (MFS9.9E) 15-6-1
DETENT RETAINER 17-41
DETENT ROLLER 17-38
DETENT SPRING 17-42
DISC 8.5-38-2 10-31
DISTANCE PIECE 10-7
DOWEL PIN 4-10 9-42
DOWEL PIN 6-12 1-4
DOWEL PIN 6-12 3-4
DOWEL PIN 6-12 7-12
DOWEL PIN 6-12 8-5
DOWEL PIN 6-12 8-6
DOWEL PIN 6-12 8-7
DOWEL PIN 6-12 20-8-3
DRAG LINK ASSY 14-1
DRAIN BOLT 14-14 8-3
DRAIN SCREW 5-34
DRAIN VALVE 5-90
DRIVE GEAR 17-9
DRIVE PULLEY 4-5
DRIVE SHAFT (L) 9-50-2
DRIVE SHAFT (S) 9-50-1
DRIVE SHAFT (UL) 9-50-3
DRIVE SHAFT (UL) 20-8-9
DRIVE SHAFT BUSHING 8-25
DRIVE SHAFT BUSHING 20-8-5
DRIVE SHAFT HOUSING ASSY (L) 8-1-2
DRIVE SHAFT HOUSING ASSY (S) 8-1-1
DRIVE SHAFT HOUSING ASSY (S) 8-1-3
DRIVE SHAFT HOUSING COVER (L) 13-19
DRIVE SHAFT HOUSING COVER (L) 13-20
DRIVE SHAFT HOUSING COVER (R) 13-18
DRIVEN PULLEY 4-11
<E>
ECU ASSY 7-14-1
ECU ASSY 7-14-2
ECU ASSY 7-14-3
ECU HOLDER 7-15
ELECTRIC BRACKET ASSY 7-35-1
ELECTRIC BRACKET ASSY 7-35-2
ELECTRIC STARTER KIT (F) 20-7-1
ENGINE BASEMENT GASKET 1-23
ENGINE BASEMENT GASKET 20-3-7
ENGINE BASEMENT SEAL 8-22
ENGINE SHORT BLOCK KIT 20-2
ENGINE TEMP SENSOR 7-30
E-RING d=6 10-50
E-RING d=6 10-79
E-RING d=6 11-35
E-RING d=6 17-4
EXHAUST COVER (OUTER) 1-17
EXHAUST COVER GASKET 1-18
EXHAUST COVER GASKET 20-3-5
EXHAUST VALVE 3-16
EXHAUST VALVE 20-11-2
EXHAUST VALVE KIT 20-11-1
EXHAUST VALVE STEM SEAL 3-22
EXTENSION CORD L=3000 19-25
EXTENSION HOUSING KIT (UL) 20-8-1
EXTENSION HOUSING UL 8-23
EXTENSION HOUSING UL 20-8-2
<F>
FILTER 5-87
FILTER 11-55
FILTER 16-21
FILTER (INLET) 5-40
FLOAT 5-38
FLOAT 5-92
FLOAT ARM PIN 5-37
FLOAT VALVE ASSY 5-36
FLUSHING CONNECTOR CAP 8-15
FLYWHEEL 7-1-1
FLYWHEEL W/RING GEAR 7-1-2
FLYWHEEL W/RING GEAR 20-7-3
FREE THROTTLE DRUM 17-20
FREE THROTTLE LEVER 17-39
FREE THROTTLE ROLLER 17-43
FREE THROTTLE SPRING 17-45
FRICTION LEVER 10-22
FRICTION PIECE 12-38
FRICTION PLATE 6-13
FRICTION SPRING 6-12
FRICTION SPRING 10-37
FRONT HOUSING 17-52
FRONT PANEL 13-1
FUEL CONNECTOR 16-10
FUEL CONNECTOR 16-11
FUEL CONNECTOR (MALE) 13-3
FUEL CONNECTOR MARK 16-9
FUEL CONNECTOR PROTECTOR 13-34
FUEL FEED PUMP 5-43
FUEL FILTER ASSY 5-85
FUEL FILTER HOLDER 5-69
FUEL HOSE W/PROTECTOR 5-56
FUEL HOSE W/PROTECTOR 5-64-1
FUEL HOSE W/PROTECTOR 5-64-2
FUEL HOSE W/PROTECTOR 5-65-1
FUEL HOSE W/PROTECTOR 5-65-2
FUEL HOSE W/PROTECTOR 5-82-1
FUEL HOSE W/PROTECTOR 455-25 5-82-2
FUEL INJECTOR ASSY 5-3
FUEL PUMP ASSY 5-61
FUEL RAIL 5-2
FUEL RAIL ASSY 5-1
FUEL REGULATOR 5-47
FUEL TANK ASSY 12L 16-12-1
FUEL TANK ASSY 12L 16-12-2
FUEL TANK CAP ASSY 16-13
FUEL TANK CAP ASSY 16-22
FUSE 20A 7-24
FUSE 20A 19-26
<G>
GASKET 5-28-1
GASKET 5-28-2
GASKET 5-28-3
GASKET 5-35
GASKET 13-28
GASKET 8.1-15-1 9-5
GASKET 8.1-15-1 20-4-3
GASKET 8.1-15-1 20-9-9
GEAR CASE ASSY 9-1
GREASE FITTING 10-19
GREASE FITTING 12-60
GRIP 12-31
GRIP 17-17
GROMMET 5-39
GROMMET 12-12
GROMMET 13-6
GROMMET 13-22
GROMMET 13-33
GROMMET 14-8
GROMMET 17-12
GROMMET 13-2 6-24
GROMMET 17-2.7 13-5
GROMMET 22-3 13-11
GROMMET 40-18-3 13-7
GROUND CABLE L=120 7-50
GROUND CABLE L=120 7-86
GROUND L=110 10-20
GROUND L=130 11-2
GROUND L=130 11-3
GROUND L=210 8-13
GUIDE PLATE GASKET 9-41
GUIDE PLATE GASKET 20-4-2
GUIDE PLATE GASKET 20-5-2
GUIDE PLATE GASKET 20-6-2
GUIDE PLATE GASKET 20-9-8
<H>
HANGER 1-9
HOLDER 5-42
HOLDER 12-17
HOLDER 12-18
HOLDER 17-47
HOLDING PLATE 5-9
HOSE 1-27
HOSE 5-21
HOSE 16-7-2
HOSE 16-8-2
HOSE JOINT (WATER-WORKS) 19-28
<I>
IDLE EXHAUST PORT COVER ASSY 8-17
IDLE EXHAUST PORT GASKET 8-20
IGNITION COIL W/R-CAP 7-26
INSTRUCTION DECAL 17-24
INSULATOR 5-12
INTAKE SILENCER ASSY 5-22
INTAKE VALVE 3-15
INTAKE VALVE 20-10-2
INTAKE VALVE KIT 20-10-1
INTAKE VALVE STEM SEAL 3-21
ISC VALVE 5-14
<J>
JOINT 17-49
JOINT ASSY (INLET) 16-2
JOINT ASSY (OUTLET) 16-4
<K>
KEY 7-5
KEY 9-33
KEY 20-5-4
KEY 20-9-6
KEY 10-3.7-3 4-6
KEY 10-3.7-3 4-7
<L>
LINK ROD ASSY (THROTTLE) 12-8
LOCK PLATE 8-10
LOCK WASHER 4-9
LOW PERMEATION HOSE L=1600 16-8-1
LOW PERMEATION HOSE L=700 16-7-1
LOWER UNIT ASSY (L) 20-1-2
LOWER UNIT ASSY (S) 20-1-1
LOWER UNIT ASSY (UL) 20-1-3
LOWER UNIT GASKET SET 20-4-1
<M>
MAIN SWITCH ASSY 13-10
MAIN SWITCH ASSY 18-1
MAIN SWITCH ASSY 20-7-35
MAIN SWITCH KEY 18-2-1
MAIN SWITCH KEY 18-2-2
MAIN SWITCH KEY 18-2-3

MAIN SWITCH KEY COVERING CAP 18-3
MAINTENANCE KIT. 20-9-1
MANUAL VALVE ASSY. 11-41
MAP SENSOR 5-15
MOTOR ASSY 11-60
MOTOR BRACKET ASSY 11-61
MOUNT 8.5-14-2.5 13-12
MOUNT BRACKET (L) 10-70
MOUNT BRACKET (R) 10-69
<N>
NEUTRAL LOCK ARM 17-15
NEUTRAL LOCK SPRING 17-16
NEUTRAL SWITCH 12-23
NEUTRAL SWITCH 20-7-31
NEUTRAL SWITCH (REMOTE CONT) 18-10
NEUTRAL SWITCH ACTUATOR 12-24
NEUTRAL SWITCH ACTUATOR 20-7-32
NEUTRAL SWITCH BRACKET 12-25
NEUTRAL SWITCH BRACKET 20-7-33
NIPPLE 5-7
NIPPLE 5-80
NIPPLE 10-32 3-35
NUT 4-10
NUT 5-18
NUT 7-6
NUT 7-40
NUT 7-43
NUT 7-57
NUT 9-23
NUT 10-10
NUT 11-30
NUT 12-11
NUT 12-22
NUT 12-56
NUT 17-10
NUT 17-32
NYLON NUT 10-P1.25 10-64
NYLON NUT 3/8-24UNF 14-4
NYLON NUT 4-P0.7 9-8
NYLON NUT 6-P1.0 9-11
NYLON NUT 7/8-14 10-12
NYLON NUT 8-P1.25 10-26
NYLON NUT 8-P1.25 11-4
<O>
OIL FILLER CAP 3-40
OIL FILTER 1-8
OIL FILTER 20-9-3
OIL FILTER BOLT 1-2
OIL LEVEL GAUGE 4-1
OIL LEVEL GAUGE GUIDE 4-2
OIL PRESSURE SWITCH 7-29
OIL PUMP ASSY. 3-27
OIL PUMP GASKET 3-28
OIL PUMP GASKET 20-3-12
OIL SEAL 11-69
OIL SEAL 12.8-25-7 8-2
OIL SEAL 13.8-26-9.5 9-38
OIL SEAL 13.8-26-9.5 20-4-6
OIL SEAL 17-30-9 9-19
OIL SEAL 17-30-9 20-4-5
OIL SEAL 18-35-8 3-5
OIL SEAL 18-35-8 20-3-13
OIL SEAL 32-44-9 2-5
OIL SEAL 32-44-9 20-3-8
OIL SEAL 36-50-7 2-6
OIL SEAL 36-50-7 20-3-9
OIL STRAINER ASSY 1-25
O-RING 5-44
O-RING 5-45
O-RING 5-46
O-RING 5-88
O-RING 5-89
O-RING 7-67
O-RING 9-45
O-RING 11-40
O-RING 11-43
O-RING 11-47
O-RING 11-50
O-RING 11-64
O-RING 16-20
O-RING 20-4-8
O-RING 1.5-3.5 11-49
O-RING 1.9-13 3-24
O-RING 1.9-6.8 10-27
O-RING 1.9-9.8 4-3
O-RING 1.9-9.8 5-8
O-RING 2.4-59.6 9-18
O-RING 2.4-59.6 20-4-4
O-RING 2.4-9.8 11-42
O-RING 2-62.5 11-57
O-RING 3.1-24.4 3-41
O-RING 3.1-24.4 20-3-4
O-RING 3.5-25.7 5-62
O-RING 3.5-25.7 10-59
O-RING 3.5-25.7 20-3-11
OVERHEAT BUZZER 18-13
<P>
PICK-UP ELBOW ASSY. 16-23
PILOT LAMP ASSY 13-2
PIN φ5-30 9-28
PINION ASSY 7-62
PIPE 1-3
PISTON 2-8
PISTON PIN 2-9
PISTON PIN CLIP 2-10
PISTON REPAIR KIT 2-7
PISTON RING 2-12
PISTON RING 2-13
PISTON RING SET 2-11
PISTON RING-OIL 2-14
PLAIN SHAFT BEARING 2-4-1
PLAIN SHAFT BEARING 2-4-2
PLASTIC RIVET 6.5 12-29
PLATE 5-70
PLATE 7-16
PLATE 7-17
PLATE 8-18
PLATE 10-28
PLUG 20-7-7
PLUG 8-8 9-4
PLUG CAP W/RESISTANCE 7-27
POWER HEAD GASKET SET 20-3-1
PRE-COATED BOLT 6-20 4-12
PRE-COATED BOLT 6-20 6-22
PRE-COATED SCREW 5-12 11-59
PRIMER BULB 16-5-1
PRIMER BULB 16-5-2
PRIMER BULB ASSY 16-1-1
PRIMER BULB ASSY 16-1-2
PROPELLER ASSY (10″) 9-56-5
PROPELLER ASSY (11.5″) 9-56-6
PROPELLER ASSY (6″) 9-56-1
PROPELLER ASSY (7″) 9-56-2
PROPELLER ASSY (7″) 9-56-7
PROPELLER ASSY (8″) 9-56-3
PROPELLER ASSY (9″) 9-56-4
PROPELLER HARDWARE KIT 9-57
PROPELLER NUT 9-60
PROPELLER SHAFT 9-26
PROPELLER SHAFT HOUSING ASSY 9-15
PROTECTOR φ10.7-180 7-34
PROTECTOR φ10.7-180 20-7-6
PROTECTOR φ10.7-320 7-33
PROTECTOR φ10.7-320 20-7-5
PROTECTOR φ24-70 7-32
PT ASSY 11-38
PTT SOLENOID SWITCH (A) 7-39
PTT SOLENOID SWITCH (B) 7-42
PTT SWITCH ASSY 12-47
PTT SWITCH ASSY 13-27
PTT SWITCH ASSY 18-12
PULSAR COIL 7-3
PUMP 11-51
PUMP CASE (UPPER) 9-34
PUMP CASE ASSY (LOWER) 9-37
PUMP CASE GASKET (LOWER) 9-39
PUMP CASE GASKET (LOWER) 20-4-7
PUMP CASE LINER 9-35
PUMP CASE LINER 20-5-5
PUMP CASE LINER 20-6-4
PUMP CASE LINER 20-9-5
PUSH ROD 9-31
<Q>
QUICK-CONNECTOR (MALE) 16-15
<R>
RATCHET 6-7
REAR HOUSING 17-13
REAR PANEL 17-14
RECOIL STARTER ASSY 6-1
RECTIFIER BRACKET 7-76
RECTIFIER BRACKET 19-22
RECTIFIER BRACKET 20-7-22
RECTIFIER COMPLETE 7-74
RECTIFIER COMPLETE 19-20
RECTIFIER COMPLETE 20-7-20
RECTIFIER KIT 19-19
REEL 6-5
RELIEF VALVE ASSY 11-46
REMOTE CONTROL FITTING ASSY. 14-7
REMOTE CONTROL HEAD ASSY(RC12A) 17-1-1
REMOTE CONTROL HEAD ASSY(RC12B) 17-1-2
REMOTE CONTROL LOGO DECAL 18-17
RESTRICTOR 5-29-1
RESTRICTOR 5-29-2
RETAINER 3-18
RETAINER 20-10-3
RETAINER 20-11-3
RETAINING RING 16-14
RETURN SPRING 6-10
RETURN SPRING 6-11
REVERSE LOCK (R) 10-47
REVERSE LOCK ARM 10-48
REVERSE LOCK LEVER 10-39
REVERSE LOCK LEVER GRIP 10-40
REVERSE LOCK LINK 10-53
REVERSE LOCK ROD 10-51
REVERSE LOCK SHAFT 10-49
REVERSE LOCK SPRING 10-55
REVERSE LOCK SPRING (S) 10-54
RIGGING BOLT SET 11-28
RIVET 4-12.9-2.4 13-9
ROCKER ARM 3-7
ROCKER ARM 3-8
ROCKER ARM SHAFT 3-11
ROCKER SHAFT SPRING L=25 3-12
ROLLER 17-34
ROLLER BEARING 9-2
ROLLER RETAINER 17-44
ROPE ANCHOR 6-16
RUBBER MOUNT 5-25
RUBBER MOUNT 5-52
RUBBER MOUNT 7-52
RUBBER MOUNT 20-7-11
RUBBER MOUNT (LOWER) 10-68
RUBBER MOUNT (UPPER) 10-60
RUBBER MOUNT 8.5-14-2.5 13-13
<S>
SAFETY ROPE φ5-1600 19-2
SCREW 3-26
SCREW 3-37
SCREW 5-16
SCREW 5-17
SCREW 5-33
SCREW 5-48
SCREW 5-51
SCREW 7-65
SCREW 9-7
SCREW 11-67
SCREW 11-71
SCREW 12-35
SCREW 12-37
SCREW 12-43
SCREW 12-49
SCREW 12-51
SCREW 13-31
SCREW 17-23
SCREW 17-26
SCREW 17-27
SCREW 17-28
SCREW 17-40
SCREW 18-11
SEAL 5-32
SEAL 5-91
SEAL RING 5-4
SEAL RING 8-16
SEAL RING 14-6
SEAL RUBBER 3D 15-5
SEAL WASHER 11-45
SETTING PIECE 10-38

SETTING PLATE 10-35
SHIFT ARM 14-15
SHIFT DECAL 12-63
SHIFT DETENT SPRING 12-13
SHIFT DETENT SUPPORTER 12-14
SHIFT GEAR ASSY 17-7
SHIFT LEVER 12-64
SHIFT LEVER ROD 12-68
SHIFT LEVER ROD 14-20
SHIFT LEVER SHAFT ASSY 12-16
SHIFT POSITION DECAL 18-7
SHIFT ROD (L) 12-20-2
SHIFT ROD (S) 12-20-1
SHIFT ROD JOINT 12-21
SHIM 35-41.9-0.1 9-49-1
SHIM 35-41.9-0.15 9-49-2
SHIM 35-41.9-0.3 9-49-3
SHIM 35-41.9-0.5 9-49-4
SHOULDER BOLT 6-8 10-42
SNAP 9-29
SNAP PIN d=5 12-69
SNAP PIN d=8 14-14
SNAP PIN d=8 14-21
SOLENOID SWITCH CORD (A) 7-45
SOLENOID SWITCH CORD (B) 7-46
SPACER 17-29
SPACER 9.6-19-13 14-2
SPARK PLUG(DCPR6E) 3-1
SPARK PLUG(DCPR6E) 20-9-13
SPLIT PIN 2-12 10-52
SPLIT PIN 3-22 9-61
SPLIT PIN 3-22 20-9-12
SPORT DECAL 15-10
SPRING 9-30
SPRING 12-40
SPRING PIN 9-55
SPRING PIN 10-33
SPRING PIN 10-77
SPRING PIN 3.5-16 11-16
SPRING PIN 3-10 9-54
SPRING WASHER 7-41
SPRING WASHER 7-44
SPRING WASHER 7-59
SPRING WASHER 7-60
STARTER CABLE 7-85
STARTER CABLE 20-7-30
STARTER CASE 6-2
STARTER HANDLE 6-15
STARTER LOCK 6-17
STARTER LOCK CAM SPRING 6-3
STARTER LOCK SPRING 6-18
STARTER LOCK WIRE 6-19
STARTER MOTOR ASSY 7-56
STARTER MOTOR ASSY 20-7-15
STARTER MOTOR BAND 7-70
STARTER MOTOR BAND 20-7-16
STARTER ROPE φ5-1800 6-14
STARTER SEAL 6-20
STARTER SOLENOID 7-37
STARTER SOLENOID 20-7-9
STARTER SPRING 6-4
STEERING BRACKET 12-59
STEERING HOOK PLATE 14-26
STEERING SHAFT ASSY 10-56-1
STEERING SHAFT ASSY 10-56-2
STOP SWITCH ASSY 12-44
STOP SWITCH ASSY 18-14
STOP SWITCH DECAL 12-45
STOP SWITCH DECAL 18-16
STOP SWITCH LANYARD ASSY 18-15
STOPPER 8-26
STOPPER 9-43
STOPPER 9-44
STOPPER 10-41
STOPPER 20-8-6
STORAGE DECAL 13-26
STUD 12-30
SWITCH BOX 12-48
SWITCH BOX 13-29
SWITCH BOX GROMMET 13-30
SWIVEL BRACKET ASSY 10-17-1
SWIVEL BRACKET ASSY 10-17-2
SWIVEL BRACKET ASSY 11-12-1
SWIVEL BRACKET ASSY 11-12-2
SWIVEL BRACKET SHAFT ASSY 10-11
<T>
TACHOMETER LEAD WIRE L=6000 19-16
TANK FILLER CAP GASKET 16-22a
TAPPING SCREW 6-8
TAPPING SCREW 6-9
TAPPING SCREW 5-16 6-27
TAPPING SCREW 6-16 15-4
TERMINAL CAP 13-13-28 7-82
TERMINAL CAP 13-13-28 20-7-29
TERMINAL CAP 15.5-20-28 7-80
TERMINAL CAP 15.5-20-28 20-7-27
TERMINAL CAP 8-13-28 7-47
TERMINAL CAP 8-13-28 7-48
TERMINAL CAP 8-18-28 7-81
TERMINAL CAP 8-18-28 20-7-28
THERMOSTAT 1-11
THERMOSTAT CAP 1-12
THERMOSTAT CAP GASKET 1-13
THERMOSTAT CAP GASKET 20-3-6
THROTTLE ARM 14-22
THROTTLE ARM 17-2
THROTTLE BODY ASSY 5-13
THROTTLE DECAL 12-46
THROTTLE DRUM ASSY 12-1
THROTTLE FRICTION ARM 17-3
THROTTLE LEVER STOPPER 14-29
THROTTLE OPENER 14-23
THROTTLE ROD 12-9
THROTTLE SHAFT 12-32
THROTTLE SHAFT DAMPER 12-33
THROTTLE SHAFT SUPPORT 12-36
THROTTLE WIRE 12-58
THROTTLE WIRE BRACKET 12-6
THRUST HOLDER 9-58
THRUST PLATE 17-22
THRUST PLATE (UPPER) 10-58
THRUST ROD ASSY 10-15
THRUST ROD SPRING 10-16
TILLER HANDLE ASSY 12-27
TILLER HANDLE ASSY 12-28
TILT STOPPER 10-32
TILT STOPPER 11-13
TILT STOPPER GRIP 11-14
TILT STOPPER SPRING 11-17
TILT SWITCH PLUG 17-53
TIMING BELT 4-14
TOOL KIT 19-1
TOP COWL ASSY 15-1
TOP COWL SEAL 13-32
TOP COWL SUB-ASSY 15-2
TRIM LOCK PIN 11-8
TWIN REMOTE CONTROL KIT 17-55
<V>
VALVE ASSY 11-48
VALVE ASSY (PRESSURE CHECK) 5-5
VALVE SPRING 3-17
VALVE SPRING SEAT 3-20
VAPOR SEPARATOR ASSY 5-30
VENT HOSE W/PROTECTOR 5-58
VENT HOSE W/PROTECTOR 5-59
VENT HOSE W/PROTECTOR 5-60
VST CONNECTOR 5-49
<W>
WARNING DECAL 15-7
WASHER 1-7
WASHER 1-16
WASHER 1-20
WASHER 3-33
WASHER 5-19
WASHER 7-61
WASHER 7-63
WASHER 7-68
WASHER 10-8
WASHER 10-9
WASHER 10-30
WASHER 10-43
WASHER 10-65
WASHER 11-15
WASHER 11-31
WASHER 12-54
WASHER 12-57
WASHER 12-71
WASHER 14-28
WASHER 17-5
WASHER 17-30
WASHER 17-31
WASHER 17-33
WASHER 17-36
WASHER 12.5-32-2.5 9-59
WASHER 13.2-21.8-2 3-13
WASHER 14.5-24-1 8-4
WASHER 14.5-24-1 20-9-10
WASHER 16-27-3.2 7-7
WASHER 17.1-22-1.5 9-25
WASHER 22-36-1 11-10
WASHER 6.5-19-3.2 4-13
WASHER 6.5-20.5-1 13-15
WASHER 6.5-21-1 12-66
WASHER 6.5-21-1 13-16
WASHER 6.5-23-1.5 11-24
WASHER 6.5-23-1.5 13-25
WASHER 6-16-1.5 5-27
WASHER 6-16-1.5 5-54
WASHER 6-16-1.5 6-21
WASHER 6-16-1.5 7-54
WASHER 6-16-1.5 10-46
WASHER 6-16-1.5 12-4
WASHER 6-16-1.5 14-17
WASHER 6-16-1.5 14-18
WASHER 6-16-1.5 20-7-13
WASHER 8.1-16-1.5 10-72
WASHER 8.1-16-1.5 11-5
WASHER 8.1-20-0.8 10-23
WASHER 8.5-18-1.6 10-45
WASHER 8.5-18-1.6 14-12
WASHER 8.5-18-1.6 14-13
WASHER 8.5-24-1.5 10-24
WASHER 8.5-28-1 11-11
WASHER 9.6-18-2 14-5
WATER HOSE 5-75
WATER PIPE (L) 8-8-2
WATER PIPE (S) 8-8-1
WATER PIPE (UL) 8-8-3
WATER PIPE (UL) 20-8-8
WATER PIPE AUXILIARY MOUNT 13-2.5 8-11
WATER PIPE SEAL (LOWER) 9-36
WATER PIPE SEAL (UPPER) 8-9
WATER PUMP GUIDE PLATE 9-40
WATER PUMP GUIDE PLATE 20-5-6
WATER PUMP GUIDE PLATE 20-6-5
WATER PUMP GUIDE PLATE 20-9-7
WATER PUMP IMPELLER 9-32
WATER PUMP IMPELLER 20-5-3
WATER PUMP IMPELLER 20-6-3
WATER PUMP IMPELLER 20-9-4
WATER PUMP KIT (CHROME PLATED) .. 20-6-1
WATER PUMP REPAIR KIT 20-5-1
WATER SEAL PLATE 9-14
WATER SEAL RUBBER 9-13
WATER STRAINER 9-6
WAVE WASHER 12-70
WAVE WASHER 17-19
<Y>
YOKE ASSY 11-72

INDEX (Parts Number)

121-32071-0 9-18
121-32071-0 20-4-4
172-36008-0 6-24
1E0-34093-0 19-27
307-62116-1 11-11
309-00131-0 4-6
309-00131-0 4-7
332-60005-2 9-4
332-60006-0 9-5
332-60006-0 20-4-3
332-60006-0 20-9-9
332-60223-0 9-38
332-60223-0 20-4-6
332-62101-1 10-78
332-62101-1 11-34
332-64221-0 9-30
332-70201-0 16-3
334-65012-0 9-42
336-06973-0 12-50
338-60218-2 10-4
338-60218-2 10-5
344-67177-1 10-19
344-67177-1 12-60
345-01111-0 1-4
345-01111-0 3-4
345-01111-0 7-12
345-01111-0 8-5
345-05122-1 11-24
345-05122-1 13-25
345-06915-0 7-83
345-06915-0 . . . . . .11-36a
345-66021-0 10-27
345-67117-0 13-5
345-67161-0 13-11
346-01032-0 1-13
346-01032-0 20-3-6
346-62124-1 10-12
346-62127-0 10-14
346-62438-0 10-38
346-64027-1 9-23
346-64081-0 9-49-1
346-64082-0 9-49-2
346-64083-0 9-49-3
346-64084-0 9-49-4
346-64121-5 9-60
346-64124-5 9-59
346-65013-0 9-19
346-65013-0 20-4-5
346-66334-0 10-41
346-67113-0 13-12
346-67115-0 12-66
346-67115-0 13-16
349-62126-0 10-13
350-01215-1 8-2
350-62437-0 10-34
350-62439-1 10-35
350-64032-0 9-25
350-64218-0 9-28
350-64219-0 9-29
350-65011-1 9-35
350-65011-1 20-5-5
350-65011-1 20-9-5
350-65014-0 9-36
350-66315-0 10-55
350-67154-0 12-29
353-06821-0 18-15
353-63207-0 11-18
353-72546-0 18-5
353-76037-0 17-54
353-84371-0 17-30
353-84388-0 17-38
353-84394-0 17-5
353-84916-0 14-5
353-84918-0 14-4
361-72539-0 19-16
362-60206-1 9-6
362-65238-0 20-6-4
362B64105-1 9-56-2
362B64107-1 9-56-1
369-62122-2 10-16
369-62433-1 11-14
369-66011-0 9-53
369-84398-0 1-22
369-84398-0 1-26
369-84398-0 5-84
369-84398-0 7-20
369-84398-0 7-21
369-84398-0 7-22
369-84398-0 20-7-36
394-70260-0 13-3
398-62396-1 11-2
398-62396-1 11-3
398-76083-0 12-24
398-76083-0 20-7-32
3A3-06830-0 18-14
3A3-62396-1 10-20
3A3-76037-0 7-31
3A3-76086-1 18-10
3A3-76115-1 18-4
3A3-76145-0 7-48
3A3-81301-0 17-55
3A3-83314-2 17-8
3A3-84307-0 17-42
3A3-84364-2 17-9
3A3-84365-1 17-2
3A3-84368-0 17-19
3A3-84374-0 17-29
3A3-84376-0 17-12
3A3-84381-0 17-7
3A3-84383-0 17-33
3A3-84391-0 17-20
3A3-84398-0 18-8
3A3-84403-0 17-16
3A3-84421-0 17-34
3A3-84422-0 17-22
3A3-84423-0 17-41
3A3-84424-0 17-43
3A3-84425-0 17-45
3A3-84426-0 17-44
3A3-84428-0 17-3
3A3-84432-0 17-25
3A3-84435-0 17-21
3AA-07225-0 3-12
3AA-60108-0 4-12
3AA-61199-0 10-21
3AA-62116-0 11-10
3AA-66241-0 12-21
3AA-67120-1 13-23
3AA-76026-0 13-10
3AA-76026-0 20-7-35
3AA-76145-0 7-82
3AA-76145-0 20-7-29
3AA-83719-0 10-45
3AA-83719-0 14-12
3AA-83719-0 14-13
3AB-01111-0 8-6
3AB-01111-0 8-7
3AB-01111-0 20-8-3
3AB-05131-0 6-16
3AC-05258-0 6-3
3AC-05913-0 6-27
3AC-06999-0 7-27
3AC-10087-0 5-57
3AC-62191-0 10-11
3AC-70052-1 16-13
3AC-70055-0 16-14
3AC-72019-0 12-46
3AC-72185-0 15-9
3AC-72200-0 12-45
3AC-76190-0 15-7
3AC-77173-0 11-45
3AD-70200-2 16-1-1
3AL-05212-0 10-44
3AL-05254-0 10-42
3AL-60108-0 6-22
3AL-66333-0 10-40
3AL-67592-0 13-9
3B2-63063-0 12-36
3B2-63104-1 12-30
3B2-70155-0 16-23
3B7-02234-0 5-87
3B7-02235-0 5-88
3B7-05243-0 12-10
3B7-06920-0 13-13
3B7-63730-0 10-24
3B7-72201-0 19-2
3B7-76142-1 7-50
3B7-76142-1 7-86
3B7-77169-0 11-40
3B7-77169-0 11-50
3B7-77430-0 11-51
3B7-77431-1 11-53
3B7-77432-1 11-52
3B7-77434-1 11-55
3B7-83715-2 14-11
3BA-06133-0 7-34
3BA-06133-0 20-7-6
3BA-77175-0 11-41
3BA-77450-0 11-46
3BA-84905-0 14-1
3BAB64516-1 9-56-3
3BAB64518-1 9-56-4
3BAB64521-1 9-56-5
3BAB64524-1 9-56-6
3BH-76120-0 7-78
3BH-76120-0 20-7-25
3BJ-00121-0 2-6
3BJ-00121-0 20-3-9
3BJ-02011-0 5-20
3BJ-02011-0 20-3-10
3BJ-05003-0 6-7
3BJ-05104-0 6-5
3BJ-05135-0 6-6
3BJ-05913-0 6-8
3BJ-06133-0 7-33
3BJ-06133-0 20-7-5
3BJ-07615-0 1-8
3BJ-07615-0 20-9-3
3BJ-10060-0 4-5
3BJ-10063-0 4-8
3BJ-10069-0 4-9
3BJ-60001-0 8-24
3BJ-60001-0 9-12
3BJ-60001-0 20-8-4
3BJ-60003-0 8-25
3BJ-60003-0 20-8-5
3BJ-60108-0 9-20
3BJ-60211-0 9-2
3BJ-60215-0 9-3
3BJ-61017-1 1-24
3BJ-64215-0 9-27
3BJ-67115-0 13-15
3BJ-72100-0 19-1
3BJ-72120-0 11-28
3BJ-76145-0 7-80
3BJ-76145-0 20-7-27
3BJ-76161-0 19-25
3BJ-84398-0 7-19
3C7-02215-0 5-79
3C7-70113-0 16-21
3C7-70199-0 16-20
3C7-70211-1 16-5-2
3C7-70217-0 16-6
3C7-70220-1 16-2
3C7-70224-1 16-4
3C8-62098-0 10-64
3C8-62396-1 8-13
3C8-62421-1 10-37
3C8-66308-0 5-27
3C8-66308-0 5-54
3C8-66308-0 6-21
3C8-66308-0 7-54
3C8-66308-0 12-4
3C8-66308-0 14-17
3C8-66308-0 14-18
3C8-66308-0 20-7-13
3C8-72580-0 7-39
3C8-72581-0 7-42
3C8-76007-0 7-71
3C8-76007-0 20-7-17
3C8-76171-0 18-13
3C8-84964-0 14-3
3E0-70270-0 16-15
3E0-77163-0 11-56
3E0-77183-0 11-65
3E0-77184-0 11-66
3E0-77193-0 11-69
3E0-84914-0 14-2
3F3-72616-1 13-28
3F3-84908-0 14-6
3G2-66321-0 10-51
3GF-66113-1 12-13
3GF-70211-1 16-5-1
3GF-70240-1 16-8-1
3GF-70241-1 16-7-1
3GF-70281-0 16-10
3GF-75014-0 7-64
3GF-75015-0 7-63
3GF-75016-0 7-69
3GF-75017-0 7-66
3GF-75018-0 7-67
3GF-75019-0 7-58
3GF-76020-0 18-1
3GF-76205-0 18-3
3GF-76217-0 18-2-1
3GF-76218-0 18-2-2
3GF-76219-0 18-2-3
3GR-70250-0 16-11
3GR-70280-0 16-9
3GT-35143-0 5-66
3GT-35143-0 5-67
3GT-35143-0 5-83
3H6-07223-0 3-19
3H6-07223-0 20-10-4
3H6-07223-0 20-11-4
3H6-07611-0 7-29
3H6-60218-0 11-1
3H6-63048-0 12-33
3H6-63510-0 12-34
3H6-63619-1 12-65
3H6-67572-0 13-26
3H6-70200-2 16-1-2
3H6-70262-0 13-34
3H6B01031-0. 1-12
3H8-00133-0 7-7
3H8-01012-1 1-5
3H8-01013-0 3-31
3H8-02093-0 3-35
3H8-04000-1 5-61
3H8-05004-0 6-4
3H8-05123-1 6-11
3H8-07025-0 3-5
3H8-07025-0 20-3-13
3H8-07237-0 3-10
3H8-10062-2 4-11
3H8-10066-0 4-13
3H8-62415-0 5-62
3H8-62415-0 10-59
3H8-62415-0 20-3-11
3H8-62423-1 10-58
3H8-72049-0 10-3
3H8-76040-0 7-37
3H8-76040-0 20-7-9
3JK-02160-0 5-82-2
3KM-01142-0. . . . . .3-22a
3KY-06920-0 5-25
3KY-06920-0 5-52
3KY-06920-0 7-52
3KY-06920-0 20-7-11
3KY-60218-0 9-9
3KY-60218-0 20-9-11
3KY-72510-0 7-30
3KY-76079-0 14-16
3KY-77071-0 11-20
3KY-84398-0 1-21

3LD-65021-0 9-32
3LD-65021-0 20-5-3
3LD-65021-0 20-6-3
3LD-65021-0 20-9-4
3NT-02319-0 1-19
3NT-02319-0 3-42
3NV-72181-0 6-25-2
3NV-76080-0 12-23
3NV-76080-0 20-7-31
3P0-01143-0 3-23
3P0-60218-0 3-25
3P0-60218-0 20-9-2
3P0-66233-0 10-72
3P0-66233-0 11-5
3PA-72181-1 6-25-1
3PR-06972-0 7-11
3R0-07238-0 3-9
3R0-07422-0 3-41
3R0-07422-0 20-3-4
3R0-62473-0 11-17
3R0-66308-0 10-46
3R0-71015-1 3-40
3R0-72180-0 15-8
3R0-77076-0 11-22
3R0-77167-0 11-57
3R0-77171-0 11-44
3R0-77177-0 11-42
3R0-77451-0 11-49
3R3-00121-0 2-5
3R3-00121-0 20-3-8
3R3-05006-0 6-13
3R3-05013-0 6-14
3R3-05216-0 6-18
3R3-05252-0 6-17
3R3-07204-0 3-21
3R3-07206-0 3-22
3R3-07227-0 3-13
3R3-07406-0 8-4
3R3-07406-0 20-9-10
3R3-07705-1 8-3
3R3-62417-0 10-57
3R3-62443-0 10-23
3R3-63012-0 12-31
3R3-66226-0 13-7
3R3-71040-0 13-2
3RS-00011-0 2-8
3RS-00011-0 2-12
3RS-00012-0 2-9
3RS-00012-0 2-13
3RS-00013-0 2-10
3RS-00013-0 2-14
3RS-00030-0 2-3
3RS-00040-0 2-1
3RS-00059-0 2-2
3RS-01005-0 3-30
3RS-01005-0 20-3-2
3RS-01024-0 3-38
3RS-01024-0 20-3-3
3RS-01030-0 1-11
3RS-01047-0 20-7-7
3RS-01138-0 5-80
3RS-01303-0 1-23
3RS-01303-0 20-3-7
3RS-01513-0 1-9
3RS-02095-0 1-15
3RS-02166-0 5-65-2
3RS-02168-0 5-56
3RS-02229-0 5-92
3RS-02230-0 5-85
3RS-02232-0 5-69
3RS-02235-0 5-89
3RS-02237-0 5-86
3RS-02239-0 5-70
3RS-02253-0 5-90
3RS-02258-0 5-91
3RS-02305-0 1-18
3RS-02305-0 20-3-5
3RS-02409-0 5-22
3RS-02418-0 5-28-2
3RS-03116-0 5-44
3RS-03230-0 5-38
3RS-03232-0 5-37
3RS-03239-0 5-36
3RS-03244-0 5-50
3RS-03292-0 5-34
3RS-03952-0 5-12
3RS-04077-0 5-64-2
3RS-04080-0 5-64-1
3RS-04116-0 5-35
3RS-04302-0 5-43
3RS-04314-0 5-39
3RS-04322-0 5-40
3RS-05007-0 6-12
3RS-05012-0 6-10
3RS-05019-0 6-15
3RS-05090-0 6-1
3RS-05105-0 6-2
3RS-05207-0 6-19
3RS-05259-0 12-70
3RS-05913-0 6-9
3RS-06001-0 7-1-1
3RS-06008-0 7-9
3RS-06023-0 7-2-1
3RS-06040-0 7-26
3RS-06071-0 7-3
3RS-06128-0 19-17
3RS-06308-1 6-23
3RS-06322-0 7-16
3RS-06401-0 7-14-3
3RS-06410-0 7-15
3RS-06830-0 12-44
3RS-06869-0 12-42
3RS-06899-0 7-35-1
3RS-06901-0 7-36
3RS-06901-0 20-7-8
3RS-07600-0 3-27
3RS-07636-0 1-2
3RS-07653-0 3-28
3RS-07653-0 20-3-12
3RS-07707-0 2-4-2
3RS-07708-0 2-4-1
3RS-07710-0 1-25
3RS-07720-0 4-2
3RS-07721-0 4-1
3RS-07731-0 3-36
3RS-07734-0 5-78
3RS-07810-0 3-6
3RS-07895-0 20-10-1
3RS-07896-0 20-11-1
3RS-07901-0 3-15
3RS-07901-0 20-10-2
3RS-07902-0 3-16
3RS-07902-0 20-11-2
3RS-07903-0 3-17
3RS-07905-0 3-20
3RS-07920-0 3-11
3RS-07935-0 3-8
3RS-07939-0 3-14
3RS-10045-0 4-14
3RS-10095-0 5-46
3RS-10100-0 5-13
3RS-10150-0 5-30
3RS-10154-0 5-47
3RS-10157-0 5-42
3RS-10172-0 5-49
3RS-10179-0 5-31
3RS-10180-0 5-32
3RS-10185-0 5-58
3RS-10200-0 5-1
3RS-10201-0 5-2
3RS-10211-0 5-14
3RS-10212-0 5-21
3RS-10214-0 5-15
3RS-10300-0 5-3
3RS-10320-0 6-26
3RS-10323-0 5-4
3RS-60041-0 9-13
3RS-60042-0 9-14
3RS-60213-0 9-17
3RS-61220-0 8-20
3RS-61301-0 10-60
3RS-61302-0 10-68
3RS-61307-0 10-62
3RS-61315-0 12-71
3RS-61333-0 10-63
3RS-61336-0 10-67
3RS-61337-0 10-66
3RS-62106-0 10-75
3RS-62114-0 8-18
3RS-62117-0 10-7
3RS-62123-0 10-15
3RS-62441-0 10-22
3RS-62445-0 10-25
3RS-62447-0 10-28
3RS-62448-1 10-30
3RS-62449-0 10-31
3RS-63102-0 12-53
3RS-63107-0 12-55
3RS-63108-0 12-54
3RS-63201-0 12-61
3RS-63508-0 12-6
3RS-63600-0 12-58
3RS-63610-0 12-8
3RS-63612-0 14-23
3RS-63617-0 12-9
3RS-63619-0 13-14
3RS-63621-0 13-22
3RS-63622-0 12-1
3RS-63751-0 14-22
3RS-64010-0 9-21
3RS-64020-0 9-22
3RS-64030-0 9-24
3RS-64211-0 9-26
3RS-64223-0 9-31
3RS-64231-0 9-58
3RS-64301-0 9-50-1
3RS-64302-0 9-50-2
3RS-64303-0 9-50-3
3RS-64303-0 20-8-9
3RS-65002-0 9-37
3RS-65016-0 9-34
3RS-65020-0 9-39
3RS-65020-0 20-4-7
3RS-65022-0 9-33
3RS-65022-0 20-5-4
3RS-65022-0 20-9-6
3RS-65025-0 9-40
3RS-65025-0 20-5-6
3RS-65025-0 20-6-5
3RS-65025-0 20-9-7
3RS-65029-0 9-41
3RS-65029-0 20-4-2
3RS-65029-0 20-5-2
3RS-65029-0 20-6-2
3RS-65029-0 20-9-8
3RS-65100-0 8-8-1
3RS-65110-0 8-8-2
3RS-65120-0 8-8-3
3RS-65120-0 20-8-8
3RS-65203-0 8-10
3RS-65210-0 5-76
3RS-65231-0 20-6-1
3RS-66012-0 9-52-1
3RS-66014-0 9-52-2
3RS-66014-0 20-8-10
3RS-66021-0 9-45
3RS-66021-0 20-4-8
3RS-66033-0 9-44
3RS-66043-0 12-12
3RS-66110-0 12-64
3RS-66122-0 14-15
3RS-66124-0 12-3
3RS-66124-0 14-24
3RS-66130-0 12-16
3RS-66134-0 14-20
3RS-66145-0 12-17
3RS-66214-0 12-20-1
3RS-66215-0 12-20-2
3RS-66260-0 13-6
3RS-66311-0 10-39
3RS-66312-0 10-53
3RS-66313-0 10-48
3RS-66324-0 10-49
3RS-66331-0 10-54
3RS-66351-0 10-47
3RS-67116-0 8-22
3RS-67143-0 1-28
3RS-67144-0 1-30
3RS-67147-0 8-16
3RS-67485-0 13-21
3RS-67501-0 13-32
3RS-67503-0 6-20
3RS-67512-0 13-8
3RS-67573-1 15-10
3RS-70020-0 16-22
3RS-70021-0 . . . . . 16-22a
3RS-70167-0 16-12-2
3RS-72404-0 8-15
3RS-72582-0 7-45
3RS-72583-0 7-46
3RS-72615-0 12-47
3RS-76009-0 7-70
3RS-76009-0 20-7-16
3RS-76010-0 7-56
3RS-76010-0 20-7-15
3RS-76015-0 7-62
3RS-76060-0 7-74
3RS-76060-0 19-20
3RS-76060-0 20-7-20
3RS-76079-0 5-26
3RS-76079-0 5-53
3RS-76079-0 7-53
3RS-76079-0 20-7-12
3RS-76081-0 12-25
3RS-76081-0 20-7-33
3RS-76110-0 7-23-1
3RS-76117-0 5-72
3RS-76141-0 7-85
3RS-76141-0 20-7-30
3RS-76160-0 19-19
3RS-76163-0 7-76
3RS-76163-0 19-22
3RS-76163-0 20-7-22
3RS-76300-1 20-7-1
3RS-77180-0 11-60
3RS-77192-0 11-61
3RS-77216-0 11-33
3RS-77217-0 11-32
3RS-83732-0 13-33
3RS-83732-0 14-8
3RS-83820-0 14-9
3RS-83830-0 14-26
3RS-83880-0 14-7
3RS-87121-0 20-3-1
3RS-87123-1 2-7
3RS-87123-1 2-11
3RS-87321-0 20-4-1
3RS-87322-0 20-5-1
3RS-87326-0 9-57
3RS-87500-0 20-9-1
3RS-87801-1 15-6-3
3RSB01000-0 3-2
3RSB01001-0 3-3
3RSB01020-0 3-34
3RSB01100-0 1-1
3RSB02301-0 1-17
3RSB87090-0 20-2
3RSQ60000-0 9-1
3RSQ60100-1 9-15
3RSQ61020-0 8-1-1
3RSQ61030-0 8-1-2
3RSQ61110-0 8-23
3RSQ61110-0 20-8-2
3RSQ61209-0 8-17
3RSQ61401-0 10-69
3RSQ61402-0 10-70
3RSQ62001-0 12-59
3RSQ62010-0 10-56-2
3RSQ62102-0 10-76
3RSQ62105-0 10-73
3RSQ62108-0 10-74
3RSQ62112-0 10-1
3RSQ62113-0 10-2
3RSQ62309-0 10-17-2
3RSQ62993-0 10-32
3RSQ63003-0 12-27
3RSQ67003-0 13-18
3RSQ67004-0 13-19
3RSQ67010-0 13-1
3RSQ67640-0 15-2
3RSQ67645-1 15-1
3RSQ77151-0 11-38

3RSQ77208-0 11-12-1
3RSQ87301-0 20-1-1
3RSQ87302-0 20-1-2
3RSQ87304-0 20-1-3
3RSQ87314-0 20-8-1
3RT-02418-0 5-28-1
3RT-03116-0 5-45
3RT-03536-0 5-29-1
3RT-04080-0 5-65-1
3RT-06023-0 7-2-2
3RT-06023-0 19-18
3RT-06023-0 20-7-2
3RT-06191-0 7-1-2
3RT-06191-0 20-7-3
3RT-06322-0 7-17
3RT-06401-0 7-14-2
3RT-06869-0 1-14
3RT-06899-0 7-35-2
3RT-10185-0 5-59
3RT-60213-0 9-51
3RT-63201-0 12-62
3RT-65210-0 5-77
3RT-65212-0 5-75
3RT-66033-0 9-43
3RT-66134-0 12-68
3RT-66145-0 12-18
3RT-67143-0 1-29
3RT-76110-0 7-23-2
3RT-76110-0 20-7-4
3RT-87801-1 15-6-2
3RTQ61020-0. 8-1-3
3RTQ62010-0. 10-56-1
3RTQ62309-0. 10-17-1
3RTQ63003-0. 12-28
3RTQ67004-0. 13-20
3RTQ77208-0. 11-12-2
3RU-02418-0 5-28-3
3RU-03536-0 5-29-2
3RU-04080-0 5-82-1
3RU-06401-0 7-14-1
3RU-10185-0 5-60
3RU-76110-0 7-23-3
3RU-87801-1 15-6-1
3RV-83914-0 14-29
3SY-72615-0 13-27
3SY-76032-0 13-29
3SY-76035-0 13-30
3T1-06915-0 5-73
3T1-72405-0 19-28
3T5-06437-0 15-4
3T5-10046-0 3-24
3T5-10068-2 4-10
3T5-10098-0 5-5
3T5-10099-0 5-6
3T5-10131-0 7-5
3T5-10161-0 5-7
3T5-10162-0 4-3
3T5-10162-0 5-8
3T5-10169-0 5-9
3T5-76247-0 7-24
3T5-76247-0 19-26
3T5-84398-0 7-51
3U2-06973-0 17-50
3U2-63506-0 17-47
3U2-72187-0 17-51
3U2-72200-0 18-16
3U2-72615-0 18-12
3U2-77367-0 17-49
3U2-84331-0 18-6
3U2-84334-0 18-17
3U2-84336-0 18-7
3U2-84339-0 17-24
3U2-84343-0 17-18
3U2-84371-0 17-31
3U2-84375-0 17-26
3U2-84398-0 18-9
3U2-84401-0 17-15
3U2-84404-0 17-17
3U2-84427-0 17-6
3U2-84431-0 17-35
3U2-84442-0 17-37
3U2-84452-0 17-53
3U2-84917-0 17-48
3U2B84312-0. 17-39
3U2B84330-0. 17-1-1
3U2B84340-0. 17-1-2
3U2B84366-0. 17-14
3U2B84440-0. 17-52
3U2B84441-0. 17-13
3UA-67523-0 15-3
3UA-67524-0 15-5
3UA-70167-0 16-12-1
3V1-06133-0 7-32
3V1-07221-0 3-18
3V1-07221-0 20-10-3
3V1-07221-0 20-11-3
3V1-63035-1 12-38
3V1-63036-0 12-40
3V1-63041-0 12-32
3V1-63077-0 12-39
3V1-63102-0 12-52
3V1-64332-0 8-26
3V1-64332-0 20-8-6
3V1-64333-0 11-59
3V1-65204-0 8-11
3V1-65206-0 8-9
3V1-76032-0 12-48
3V5-62442-0 10-26
3V5-62442-0 11-4
3V9-67578-4 12-63
3VK-63107-0 17-46
3VK-84375-0 17-27
3VL-84375-0 17-28
3Y0-76145-0 7-81
3Y0-76145-0 20-7-28
3Y1-66117-0 12-14
3Y1-76145-0 7-47
3Y2-07935-0 3-7
3Z0-62476-2 11-13
3Z0-77076-0 11-21
3Z0-77076-0 11-23
3Z0-77101-1 11-26
3Z0-77115-0 11-8
3Z0-77167-0 11-64
3Z0-77179-0 11-43
3Z0-77179-0 11-47
3Z0-77186-0 11-68
3Z0-77187-0 11-63
3Z0-77190-0 11-70
3Z0-77191-0 11-62
3Z0-77195-0 11-72
3Z0-77221-0 11-39
3Z0-77431-0 11-54
3Z0-77460-0 11-48
3Z0-84398-0 11-19
3Z0Q77211-2. 11-6
3Z0Q77212-0. 11-7
3Z0S64514-3 9-56-7
3Z1-84398-1 11-58
910103-0525 17-11
910103-0612 8-14
910103-0612 13-24
910103-0620 5-23
910103-0625 5-55
910103-0625 7-55
910103-0625 14-19
910103-0625 20-7-14
910103-0640 12-5
910103-0640 14-25
910103-5512 7-4
910103-5512 9-48
910103-5610 7-38
910103-5610 20-7-10
910103-5612 4-4
910103-5612 5-10
910103-5612 5-71
910103-5612 7-13
910103-5612 7-25
910103-5612 7-49
910103-5612 7-73
910103-5612 7-77
910103-5612 7-79
910103-5612 7-84
910103-5612 10-80
910103-5612 11-37
910103-5612 12-15
910103-5612 19-23
910103-5612 19-24
910103-5612 20-7-19
910103-5612 20-7-23
910103-5612 20-7-24
910103-5612 20-7-26
910103-5616 7-18
910103-5616 11-9
910103-5616 12-7
910103-5616 12-26
910103-5616 13-4
910103-5616 14-10
910103-5616 20-7-34
910103-5620 7-75
910103-5620 9-10
910103-5620 10-6
910103-5620 12-19
910103-5620 19-21
910103-5620 20-7-21
910103-5625 5-11
910103-5625 5-63
910103-5625 7-8
910103-5625 7-10
910103-5625 7-28
910103-5630 5-24
910103-5820 1-10
910103-5825 7-72
910103-5825 20-7-18
9101E3-0512 8-19
9101E3-0612 11-25
9101E3-0620 12-67
9101E3-0625 12-41
9101E3-0630 13-17
9101E3-0820 11-27
9101E3-0885 10-71
9101E3-0885 11-29
9101E3-5612 5-81
9101E3-5612 8-12
9101E3-5612 8-27
9101E3-5612 10-29
9101E3-5612 20-8-7
9101E3-5616 8-21
9101E3-5616 11-36
9101E3-5625 3-39
9101E3-5625 9-46
9101E3-5635 3-29
9101E3-5652 9-47
9101E3-5652 20-5-7
9101E3-5818 10-36
9101E3-5830 10-61
9111E3-1030 14-27
9161F9-0630 1-6
9161F9-0640 3-32
921503-0406 3-37
921503-0406 17-40
921503-0408 5-33
921503-0408 5-48
921503-0430 9-7
921503-0516 5-51
921503-0530 3-26
921503-5316 18-11
921503-5510 5-16
921503-5516 5-17
921521-5512 11-67
921521-6408 7-65
9215E3-0512 12-51
9215E3-0516 12-49
9215E3-0612 12-37
9215E3-0612 12-43
9215E3-5512 11-71
9215E3-5512 13-31
921603-0512 17-23
921803-0520 12-35
930103-0500 12-11
930103-0500 12-22
930103-0500 17-10
930103-0600 5-18
930103-0600 7-40
930103-0600 7-43
930103-0600 17-32
9301E3-0600 10-10
9301E3-0600 12-56
9301E3-0800 11-30
930203-0600 7-57
930403-0400 9-8
930403-0600 9-11
931121-1600 7-6
940103-0600 5-19
940103-0600 7-68
940103-0800 17-36
9401E3-0600 10-8
9401E3-0600 10-9
9401E3-0800 10-43
9401E3-0800 11-31
9401E3-1000 11-15
9401E3-1000 14-28
940221-0500 7-61
9402E3-0600 1-7
9402E3-0600 1-16
9402E3-0600 1-20
9402E3-0600 3-33
9402E3-0600 12-57
9402E3-1000 10-65
941303-0600 7-41
941303-0600 7-44
941303-0600 7-59
941321-0500 7-60
945303-0600 10-50
945303-0600 10-79
945303-0600 11-35
945303-0600 17-4
951403-0540 10-33
951403-0622 10-77
951403-3516 11-16
951407-0310 9-54
951407-2512 9-55
951503-0212 10-52
951503-0322 9-61
951503-0322 20-9-12
951603-0500 12-69
951603-0800 14-14
951603-0800 14-21
9701-1-1103 3-1
9701-1-1103 20-9-13
98AB-701600. 16-8-2
98AB-70-700 16-7-2
98AH-95-150 1-27
99AA-4-0330 1-3

Note

Note

Note

Note


Note

Copyright © 2018 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means without the express written permission of Tohatsu Corporation.

2018 PARTS CATALOG

MFS 9.9E
MFS 15E
MFS 20E
Models

Serial Number 000001 AH～
OB No.002-21057-0AH 3RS 1801



トーハツ株式会社

〒174-0051
東京都板橋区小豆沢 3-5-4
Tel: 03 (3966) 3116

TOHATSU CORPORATION

5-4, Azusawa 3-Chome, Itabashi-Ku
Tokyo 174-0051, Japan
Tel: +81-3-3966-3117 Fax: +81-3-3966-2951
www.tohatsu.com