2019 PARTS CATALOG

TOHATSU
Feel the Wind™

BFT 200D
BFT 225D
BFT 250D
Models

OB NO.002-13ZVJ-0AK 1812 EU/EX



BACKS YOU UP™

TOHATSU CORPORATION

Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of December 1, 2018.**

- See the Service Bulletin for any revision that is made after December 1, 2018.

- **Always specify the part number when ordering a part.**
  - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
  - Note that the illustrations (part drawings) can differ from the actual parts in shape.
    Illustrations are given just to help you to refer to the parts.

- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times.**

Initial version issue date December 1, 2018

CONTENTS

E-1	CYLINDER HEAD COVER	1
E-3	CYLINDER BLOCK	3
E-3-10	CRANKCASE	7
E-4	EXHAUST MANIFOLD/THERMOSTAT	9
E-5	OIL PUMP/FLYWHEEL	11
E-6	OIL PAN	13
E-6-10	MOUNT CASE	15
E-7	CRANKSHAFT/PISTON	19
E-9	CYLINDER HEAD	23
E-9-10	CAMSHAFT/ROCKER ARM	25
E-13	TIMING BELT	27
E-13-10	TIMING BELT COVER	31
E-14	FUEL PIPE/INJECTOR	33
E-14-10	INTAKE MANIFOLD	37
E-15	THROTTLE BODY	39
E-18	VAPOR SEPARATOR ASSY	41
E-18-1	FUEL STRAINER	45
E-18-10	PIPING	47
E-19	A.C. GENERATOR	51
E-20	SPARK PLUG	53
E-20-10	ELECTRONIC CONTROL UNIT	55
E-21	STARTER MOTOR	57
F-2	SHIFT SHAFT	59
F-3	GEAR CASE	63
F-3-10	GEAR CASE ASSY	65
F-3-20	EXTENSION CASE	67
F-3-30	UNDER COVER	71
F-4	WATER PUMP/VERTICAL SHAFT	73
F-5	PROPELLER SHAFT	77
F-5-1	PROPELLER SHAFT (COUNTER ROTATION)	81
F-6	FUEL TUBE	85
F-7	WIRE HARNESS	87
F-7-10	STARTER CABLE	89
F-7-20	FUSE BOX/RELAY	91
F-8	ENGINE COVER	93
F-10	STERN BRACKET/SWIVEL CASE	95
F-11	POWER TRIM-TILT	101
F-12	LABEL	105
F-13	TOOL	107
FOP-1	RIGGING HOSE KIT	109
FOP-2	WATER PUMP IMPELLER SET	111
FOP-3	REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT)	113
FOP-3-1	REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)	117
FOP-3-2	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)	119
FOP-3-3	REMOTE CONTROL (NHK MEC)	123
FOP-4	METER	129
FOP-5	SWITCH PANEL KIT (1)	131
FOP-5-1	SWITCH PANEL KIT (2)	133
FOP-5-2	SWITCH PANEL KIT (3)	135
FOP-5-3	SWITCH PANEL KIT (4)	137
FOP-5-4	SWITCH PANEL KIT (5)	141
FOP-7	INTERFACE CABLE KIT	143
FOP-10	CABLE KIT	145
FOP-12	BOLT KIT	147
FOP-14	TRIM ADJUST PLATE SET	149
FOP-15	PROPELLER	151
FOP-17	GEAR CASE KIT	155
INDEX		157
INDEX (Parts Number)		163

How to refer to the part information

A. Reference with “Illustrated index”





Fig. Number

Ref. Number/Part Number/Parts Name




39

Ref.No.		Part No.	Description	Q'ty BF250A	Remarks
E-15	1	HZYC-16016-003	SCREW SET	1	
E-15	2	HZYC-16176-000	GASKET, THROTTLE BODY	1	
E-15	3	HZY3-16400-A01	THROTTLE BODY ASSY,	1	
E-15	4	HZXC-16404-000	SPACER, THROTTLE BODY	1	
E-15	5	HZYC-16405-000	GASKET, EAC VALVE	1	
E-15	7	HPYC-17249-000	SPRING, AIR FLOW TUBE	1	
E-15	8	HZYC-17315-000	BAND, AIR FLOW	1	
E-15	9	HZXC-17374-000	GROMMET, SILENCER	1	
E-15	10	HZYC-17910-013	CABLE COMP., THROTTLE	2	
E-15	16	HZW3-28665-003	SENSOR ASSY., AIR TEMP	1	
E-15	17	HZYC-36550-003	VALVE ASSY., EAC	1	
E-15	18	HZYC-40102-000	GROMMET, UNDER CASE	4	
E-15	19	HZWT-60013-000	BOLT-WASHER, 6X25	2	
E-15	20	HZYB-90017-000	BOLT-WASHER, 5X30	1	
E-15	21	HZYC-90030-000	BOLT, FLANGE, 6X22	2	
E-15	22	HZYC-90034-000	BOLT, FLANGE, 6X60	2	
E-15	23	HZYC-90037-000	BOLT, FLANGE, 8X65	4	
E-15	24	HZYC-90508-000	WASHER, PLAIN, 6MM	2	
E-15	25	HPBA-91303-A02	O-RING	1	
E-15	26	HZVC-91553-010	COLLAR, C.D.I. UNIT CASE	4	
E-15	28	HCC-94301-06100	DOWEL PIN, 6X10	2	
E-15	29	HZXC-19540-010	COVER ASSY., COOLING FAN	1	

40


B. Reference with “Parts number index”



INDEX (Parts Number)

1H2-11534-0 15-15
3D9-00131-0 6-7
3D9-00972-0 5-20
3D9-00972-0 6-13
3D9-00972-0 6-37
3D9-00972-0 9-36
3D9-05033-0 6-42
3E2-60005-2 3-36
3E2-60005-2 ..... 11A-3
3E2-60009-0 5-37
3E2-60009-0 ..... 11A-4
3E2-60009-0 28-9-2
3E2-60103-0 ..... 11B-5
3E2-60103-0 28-9-3
3E2-62101-1 1-2-36
3E2-62101-1 1-2-47
3E2-64221-0 ..... 11B-16
3E2-65022-0 ..... 11A-16
3E2-65022-0 28-9-3
3E2-66021-0 ..... 11A-13
3E2-66021-0 28-9-7
3S2-70701-0 20-11
3S2-70710-1 1-2-34
3A4-00131-0 8-3
3A4-00131-0 ..... 11A-26
3B4-66973-0 13-23
3B4-66973-0 23-49-12
3B4-66974-0 23-47
3A6-64088-0 ..... 11A-28-3
3A6-64088-0 ..... 11A-28-4
3A6-64121-0 ..... 11B-23
3A6-64121-0 ..... 11B-24
3A6-64211-4 ..... 11B-13
3A6-64211-4 ..... 11B-15
3A6-64219-0 ..... 11B-18
3A6-64231-0 ..... 11B-23
3A6-64303-0 ..... 11A-13-2
3A6-64303-0 ..... 11A-13-3
3A6-64303-0 28-7-6
3A6-64327-0 ..... 11A-11
3A6-64328-0 ..... 11A-12
3A6-65015-0 ..... 11A-21
3A6-65015-0 28-9-4
3A6-65017-0 ..... 11A-20
3A6-66037-0 ..... 11A-17
3A6-66037-0 28-7-10
3A6-66321-0 1-2-70
3A6-66322-0 12-60
3A6-66323-0 1-2-61
3A6-66331-0 1-2-62-2
3A6-66339-0 1-2-22
3A6-66339-0 10-74
3A6-66339-0 1-2-21
3A6-67115-0 6-21
3A6-67115-0 16-2
3A6-67116-1 6-23
3B9-52433-1 13-44
3B9-54081-1 ..... 11B-19-1
3B9-54082-1 ..... 11B-19-2
3B9-84398-0 6-75
3B9-84398-0 8-31
3B9-84398-0 8-32
3B9-84398-0 10-5
3B9-85004-0 16-13
3B6-56830-0 16-27
3B9-86972-0 8-14
3B6-52396-1 12-18
3B9-52394-1 13-5
3B6-76085-0 16-26
3B9-76085-0 28-6-10
3A9-76079-0 1-2-28
3A9-76079-0 1-2-4
3A9-76079-0 8-24
3A9-76079-0 9-43
3A1-60223-0 ..... 11A-46
3A3-60835-0 22-9
3A3-62396-1 12-47
3A3-72560-0 22-5
3A3-72597-0 22-7
3A3-76037-0 8-28-1
3A3-76037-0 8-29-2
3A3-76037-0 9-10
3A3-76084-1 22-6
3A3-76115-1 22-11


C. Reference with “Parts name index”



INDEX

<A>
ADJUST SCREW 21-28
ADJUSTING NUT 3-9
ADJUSTING SCREW 3-8
ADJUSTING SCREW 11-12
AIR FILTER 9-31
AIR VENT ASSY 6-47
ALTERNATOR ASSY 8-2
ANODE 1-14
ANODE 1-2-3
ANODE 1-3-5
ANODE PLUG 1-2-2
APRON 10-28
ASSIST CORD (BLK) L=200 21-46-2
ASSIST CORD (BLU) L=200 21-46-1
ASSIST CORD (RED) L=200 21-2-1
ASSIST CORD (RED) L=200 21-46-3
<B>
BACK-UP RING 14-16
BALL 14-21
BALL 3/8 ..... 11B-20
BALL BEARING 6203 ..... 11B-5
BALL JOINT CONNECTOR 17-22
BAND 22-17
BAND 104 8-29
BAND 104 8-30
BAND 158 6-71
BAND 158 8-31
BOLT 9-33
BOLT 6-44
BOLT 10-20
BOLT 10-26
BOLT 10-34
BOLT 10-35
BOLT 11A-9
BOLT 11A-27
BOLT 11A-35
BOLT 11A-38
BOLT 11A-39
BOLT 11B-8
BOLT 12-6
BOLT 12-19
BOLT 12-24
BOLT 12-31
BOLT 12-40
BOLT 12-46
BOLT 12-48
BOLT 12-50
BOLT 12-58
BOLT 12-63
BOLT 13-8
BOLT 13-9
BOLT 13-19
BOLT 14-26
BOLT 14-32

Part catalogue structure




Ref.No.		Part No.	Description	Q'ty BF250A	Remarks
E-15	1	HZY3-16016-000	SCREW SET	1	
E-15	2	HZY3-16170-000	GASKET, THROTTLE BODY	1	
E-15	3	HZY3-16400-A01	THROTTLE BODY ASSY.	1	
E-15	4	HZX2-16404-000	SPACER, THROTTLE BODY	1	
E-15	5	HZY3-16405-000	GASKET, EAC VALVE	1	
E-15	7	HPY3-17248-000	SPRING, AIR FLOW TUBE	1	
E-15	8	HZY3-17315-000	BAND, AIR FLOW	1	
E-15	9	HZX2-17374-000	GROMMET, SILENCER	1	
E-15	10	HZY3-17910-013	CABLE COMP., THROTTLE	2	
E-15	16	HZW3-35665-003	SENSOR ASSY., AIR TEMP	1	
E-15	17	HZY3-38590-003	VALVE ASSY., EAC	1	
E-15	18	HZV3-40102-000	GROMMET, UNDER CASE	4	
E-15	19	HZW1-90013-000	BOLT-WASHER, 6X25	2	
E-15	20	HZY3-90017-000	BOLT-WASHER, 5X30	1	
E-15	21	HZY3-90030-000	BOLT, FLANGE, 6X22	2	
E-15	22	HZY3-90034-000	BOLT, FLANGE, 6X60	2	
E-15	23	HZY3-90037-000	BOLT, FLANGE, 6X65	4	
E-15	24	HZY3-90593-000	WASHER, PLAIN, 6MM	2	
E-15	25	HP0A-61303-A02	O-RING	1	
E-15	28	HZV3-91553-010	COLLAR, C.D.I. UNIT CASE	4	
E-15	29	HCC-94301-06100	DOWEL PIN, 6X10	2	
E-15	39	HZX2-19540-010	COVER ASSY., COOLING FAN	1	

① Fig. Number
② Fig. Title
③ Ref. Number
④ Parts Number
⑤ Parts Name
⑥ Q.ty
⑦ Remarks
⑧ Defferent specification
⑨ Direction Arrow
⑩ Parts enclosed within a doted line are sub assembly parts.
⑪ A solid arrow indicates the block No. the part in question is connected to.

How to check the part block and serial numbers

Part block	Engine parts E-1~	Frame parts F-2~
Numbers needed	Stamped engine number	Stamped frame number
Check point	①	②



Models, parts catalogue codes and applicable serial numbers

• Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Type	Parts catalogue type	Engine		Applicable engine serial No.	Applicable frame serial No.
			Model	Type		
BFT200D	LRU	LRU	BF200D	SE2	BEBRJ-1000001~	BBRJ-6000001~
	XCRU	XCRU				BBRJ-7000001~
	XRD	XRD				BBRJ-6000001~
	XRU	XRU				
BFT225D	XCRU	XCRU	BF225D		BEBPJ-1000001~	BBPJ-7000001~
	XRD	XRD				BBPJ-6000001~
	XRU	XRU				
BFT250D	XCRU	XCRU	BF250D		BEBNJ-1000001~	BBNJ-7000001~
	XRD	XRD				BBNJ-6000001~
	XRU	XRU				

Features of each type

• See the following table for the features of each type. (Items in brackets are optional)

Specifications \ Model / Type		BFT 200D				BFT 225D			BFT 250D		
		LRU	XCRU	XRD	XRU	XCRU	XRD	XRU	XCRU	XRD	XRU
Transom height	508 mm	●									
	635 mm		●	●	●	●	●	●	●	●	●
Counter rotation			●			●			●		

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets ( ) underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name. (For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

Bulk part number of fuel hose, general purpose hose and vinyl hose.

Example: 95001-75001-50M

Bulk part number:
Refers to the bulk part.

Marking code (fuel hose and general purpose hose)
Change code (Vinyl hose)
Indicates number mark or change sequence, however, the code for the bulk part must be strictly 0 (zero).

Types of code:

- Fuel hose
  - 2: Red outside braid (3 mm inside dia. only)
  - 5: Black inside braid
  - 3: Red (3 mm inside dia. only)
  - 4: Ash gray with red stripe (3 mm inside dia. only)
  - 6: Black
- General hose
  - 1: Ash gray
  - 2: Ash gray
  - 3: Black
  - 5: Black
- Vinyl hose
  - 1: Clear
  - 2: Black
  - 3: Light red
  - 6: Light red
  - 7: Pale black

Lengths:
001: 1 m (standard)
003: 3 m
008: 8 m
} Application or specification of some parts is not settled.

I.D code: (fuel hose and general purpose hose)

30: 3.0 mm	35: 3.5 mm	45: 4.5 mm
50: 5.0 mm	55: 5.3 mm, 5.5 mm	65: 6.5 mm
70: 7.0 mm	75: 7.3 mm, 7.5 mm	80: 8.0 mm
11: 11 mm	91: 12 (outside dia. 15) mm	92: 12 (outside dia. 16) mm
12: 12 (outside dia. 17) mm	14: 14 mm	17: 17 mm

ID./OD. code: (vinyl hose)


01: ID. 2.9, OD. 6.8 mm	02: ID. 3.0, OD. 6.0 mm	03: ID. 3.5, OD. 6.5 mm
07: ID. 4.0, OD. 7.0 mm	08: ID. 4.5, OD. 6.5 mm	09: ID. 4.5, OD. 8.0 mm
12: ID. 5.0, OD. 7.0 mm	10: ID. 5.0, OD. 8.0 mm	11: ID. 5.0, OD. 9.0 mm
14: ID. 6.0, OD. 9.0 mm	17: ID. 7.0, OD. 9.0 mm	19: ID. 7.0, OD. 11.0 mm
21: ID. 8.0, OD. 9.0 mm	23: ID. 8.0, OD. 12.0 mm	25: ID. 9.0, OD. 11.0 mm
27: ID. 9.0, OD. 13.0 mm	33: ID. 10.0, OD. 14.0 mm	36: ID. 11.0, OD. 13.0 mm
37: ID. 11.0, OD. 15.0 mm	38: ID. 12.0, OD. 13.0 mm	39: ID. 12.0, OD. 14.0 mm
40: ID. 12.0, OD. 16.0 mm	43: ID. 13.0, OD. 15.0 mm	45: ID. 14.0, OD. 18.0 mm
50: ID. 16.0, OD. 19.0 mm	55: ID. 17.5, OD. 20.5 mm	60: ID. 22.0, OD. 27.0 mm

Hose type:
1: Fuel hose
3: Vinyl hose
5: General hose


CAUTION: It is DANGEROUS to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.


E-1 CYLINDER HEAD COVER




E-3 CYLINDER BLOCK




E-3-10 CRANKCASE




E-4 EXHAUST MANIFOLD/THERMOSTAT




E-5 OIL PUMP/FLYWHEEL




E-6 OIL PAN




E-6-10 MOUNT CASE




E-7 CRANKSHAFT/PISTON




E-9 CYLINDER HEAD




E-9-10 CAMSHAFT/ROCKER ARM




E-13 TIMING BELT




E-13-10 TIMING BELT COVER




E-14 FUEL PIPE/INJECTOR




E-14-10 INTAKE MANIFOLD




E-15 THROTTLE BODY




E-18 VAPOR SEPARATOR ASSY




E-18-1 FUEL STRAINER




E-18-10 PIPING




E-19 A.C.GENERATOR




E-20 SPARK PLUG




E-20-10 ELECTRONIC CONTROL UNIT




E-21 STARTER MOTOR




F-2 SHIFT SHAFT




F-3 GEAR CASE




F-3-10 GEAR CASE ASSY




F-3-20 EXTENSION CASE




F-3-30 UNDER COVER




F-4 WATER PUMP/VERTICAL SHAFT




F-5 PROPELLER SHAFT




F-5-1 PROPELLER SHAFT (COUNTER ROTATION)




F-6 FUEL TUBE




F-7 WIRE HARNESS




F-7-10 STARTER CABLE




F-7-20 FUSE BOX/RELAY




F-8 ENGINE COVER




F-10 STERN BRACKET/SWIVEL CASE




F-11 POWER TRIM-TILT




F-12 LABEL




F-13 TOOL




FOP-1 RIGGING HOSE KIT




FOP-2 WATER PUMP IMPELLER SET




FOP-3 RIGGING HOSE KIT (TOP MOUNT SINGLE TYPE) (RIGHT)




FOP-3-1 REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)




FOP-3-2 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)




FOP-3-3 REMOTE CONTROL (NHK MEC)




FOP-4 METER




FOP-5 SWITCH PANEL KIT (1)




FOP-5-1 SWITCH PANEL KIT (2)




FOP-5-2 SWITCH PANEL KIT (3)




FOP-5-3 SWITCH PANEL KIT (4)




FOP-5-4 SWITCH PANEL KIT (5)




FOP-7 INTERFACE CABLE KIT




FOP-10 CABLE KIT




FOP-12 BOLT KIT




FOP-14 TRIM ADJUST PLATE SET




FOP-15 PROPELLER



FOP-17 GEAR CASE KIT




E-1 CYLINDER HEAD COVER




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-1	1	HZVL-12310-405ZA	COVER COMP., CYLINDER HEAD(R.)	1	1	1	*NH8*
E-1	2	HZY3-12312-000	PACKING, HEAD COVER	2	2	2	
E-1	3	HZVL-12320-405ZA	COVER COMP., CYLINDER HEAD(L.)	1	1	1	*NH8*
E-1	4	HP08-12342-004	SEAL, SPARK PLUG TUBE(NOK)	6	6	6	
E-1	5	HZY3-15425-010	TUBE, OIL	2	2	2	
E-1	6	HZVL-16916-000	STAY B, FUEL STRAINER	1	1	1	
E-1	7	HMT2-17193-000	T-JOINT	1	1	1	
E-1	8	HZVL-32104-000	BRACKET, FUEL PUMP COUPLER	1	1	1	
E-1	9	HZVL-32114-000	BRACKET, CLIP B	1	1	1	
E-1	10	HZY3-32129-000	BRACKET C, HARNESS CLIP	3	3	3	
E-1	11	HHE0-50310-003	CLIP A, WIRE	1	1	1	
E-1	12	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	6	6	6	
E-1	13	HZZ5-90019-M00	BOLT, FLANGE, 6X35	16	16	16	
E-1	14	HZY3-90602-020	CLAMP, TUBE(D32.5)	2	2	2	
E-1	15	HSA0-90683-003	CLIP, WIRE HARNESS, 25MM	1	1	1	
E-1	16	HZY3-91401-A00	TUBE COMP. A, BREATHER	1	1	1	
E-1	17	HZY3-91402-030	TUBE B, BREATHER	1	1	1	
E-1	18	HZY3-91403-000	TUBE C, BREATHER	1	1	1	
E-1	19	HSK7-91566-003	CLIP D, WASHER TUBE	1	1	1	

E-3 CYLINDER BLOCK




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-3	1	HZVL-11200-000	COVER ASSY., CRANKCASE UPPER	1	1	1	
E-3	2	HZY3-11300-C00	CASE ASSY., OIL SEAL	1	1	1	
E-3	3	HZVL-12000-000ZA	BLOCK ASSY., CYLINDER	1	1	1	*NH8*
E-3	4	HZV4-12155-A00	METAL, ANODE	6	6	6	
E-3	5	HZY3-12155-000	METAL, ANODE	2	2	2	
E-3	6	HZY3-12164-000	BOLT, SEALING, 22MM	6	6	6	
E-3	7	HZY3-12171-305	WASHER, SEALING, 22MM	6	6	6	
E-3	8	HZV5-12214-000	WASHER, SEALING(22MM)	1	1	1	
E-3	9	HP8A-15115-A01	PACKING, OIL HOLE	1	1	1	
E-3	10	HP8A-15140-A00	ORIFICE ASSY., OIL CONTROL	2	2	2	
E-3	11	HP8A-15142-A00	O-RING, 8.8X2.4	2	2	2	
E-3	12	HP8A-15150-A00	JOINT ASSY., OIL PIPE	1	1	1	
E-3	13	HR70-15280-A00	BODY, OIL JET	3	3	3	
E-3	14	HRJA-15290-000	BOLT COMP., OIL JET	3	3	3	
E-3	15	HZVL-15655-000	GAUGE COMP., OIL LEVEL	1	1	1	
E-3	16	HZVL-15656-000	COVER, OIL LEVEL GAUGE	1	1	1	
E-3	17	HZY3-15657-000	PACKING, OIL LEVEL GAUGE	1	1	1	
E-3	18	HZY2-15810-000ZA	VALVE ASSY., SPOOL	1	-	-	*NH8*
E-3	18	HZVL-15810-003ZA	VALVE ASSY., SPOOL	-	1	1	*NH8*
E-3	19	HZY2-15825-000	FILTER ASSY., SPOOL VALVE	1	-	-	
E-3	19	HZY3-15825-003	FILTER ASSY., SPOOL VALVE	-	1	1	
E-3	20	H5YS-30530-J01	SENSOR, KNOCK	1	1	1	
E-3	21	HZVL-32114-000	BRACKET, CLIP B	1	1	1	
E-3	22	HZVL-32193-000	CORD, SWITCH	1	1	1	
E-3	23	HZY3-35673-003	SENSOR ASSY., WATER	1	1	1	
E-3	24	HRNA-37260-A01	SENSOR, OIL PRESSURE	1	1	1	
E-3	25	HPNB-37500-003	SENSOR ASSY., CRANK	1	1	1	
E-3	26	HZVL-90001-000	BOLT, FLANGE, 12X95	2	2	2	
E-3	27	HZVL-90006-003	BOLT-WASHER, 10X109	1	1	1	


E-3 CYLINDER BLOCK




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-3	28	HZVL-90008-003	BOLT-WASHER, 10X60	5	5	5	
E-3	29	HZVL-90009-003	BOLT-WASHER, 10X80	2	2	2	
E-3	30	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	1	1	1	
E-3	31	HRCA-90014-A01	BOLT-WASHER, 11X105	8	8	8	
E-3	32	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	1	
E-3	33	HZZ5-90019-M00	BOLT, FLANGE, 6X35	7	7	7	
E-3	34	HZVL-90020-000	BOLT, FLANGE, 8X50	2	2	2	
E-3	35	HZVL-90028-000	BOLT, FLANGE, 6X18	4	4	4	
E-3	36	HZZ5-90030-M00	BOLT, FLANGE, 6X22	8	8	8	
E-3	37	HZVL-90038-000	BOLT, FLANGE, 8X75	1	1	1	
E-3	38	HZY9-90054-M00	BOLT, FLANGE, 8X35	1	1	1	
E-3	39	HZZ5-90081-M00	BOLT, SEALING, 22MM	1	1	1	
E-3	40	HPH7-90715-000	DOWEL PIN, 13X37	8	8	8	
E-3	41	HZY3-91212-003	OIL SEAL, 41X66X8	1	1	1	
E-3	42	HPNA-91214-014	OIL SEAL, 80X98X10(ARAI)	1	1	1	
E-3	43	HZVL-91303-000	O-RING, 8.8X1.9	2	2	2	
E-3	44	HPNA-91307-003	O-RING, 9.5X1.9	1	1	1	
E-3	45	HP8A-91308-A01	O-RING, 18.3X3.5	1	1	1	
E-3	46	HPK1-91308-003	O-RING, 26.2X2.4(NOK)	1	1	1	
E-3	47	HP8A-91309-A01	O-RING, 16.3X3.5	1	1	1	
E-3	48	HPR3-91319-003	O-RING, 13X1.5(ARAI)	1	1	1	
E-3	49	HP0X-91321-003	O-RING, 25X2.4(NOK)	1	1	1	
E-3	50	HPNA-91333-003	O-RING, 15X1.9	1	1	1	
E-3	51	HCO-93500-05016-4J	SCREW, PAN, 5X16	2	2	2	
E-3	52	HCO-93500-05020-4J	SCREW, PAN, 5X20	6	6	6	
E-3	53	HCO-94301-06100	DOWEL PIN, 6X10	4	4	4	


FR.
5
17
6
7
18
15
2
9
13
3
14
10
11
4
8
1
19
12
16
10
19


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-3-10	1	HZVL-11100-000	CRANKCASE COMP.	1	1	1	
E-3-10	2	HZX2-11911-000	HANGER, ENGINE	1	1	1	
E-3-10	3	HZV5-12214-000	WASHER, SEALING(22MM)	1	1	1	
E-3-10	4	HRTA-15400-003	CARTRIDGE, OIL FILTER	1	1	1	
E-3-10	5	HZY9-15600-M00	CAP ASSY., OIL FILLER	1	1	1	
E-3-10	6	HZY9-15631-000	EXTENSION, OIL FILLER	1	1	1	
E-3-10	7	HZZ5-90014-M00	BOLT, FLANGE, 6X25	2	2	2	
E-3-10	8	HPH1-90015-013	HOLDER, OIL FILTER	1	1	1	
E-3-10	9	HZZ5-90032-M00	BOLT, FLANGE, 6X32	15	15	15	
E-3-10	10	HZVL-90041-000	BOLT, FLANGE, 10X55	2	2	2	
E-3-10	11	HZZ5-90047-M00	BOLT, FLANGE, 6X55	2	2	2	
E-3-10	12	HZVL-90063-000	BOLT, FLANGE, 6X37	2	2	2	
E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM	1	1	1	
E-3-10	14	HZY3-90082-003	CAP, BOLT, 10MM	1	1	1	
E-3-10	15	HZZ0-90151-M00	BOLT, FLANGE, 8X25	2	2	2	
E-3-10	16	HZVL-90204-000	NUT, FLANGE CAP, 10MM	2	2	2	
E-3-10	17	HMAL-91302-601	O-RING, 18.1X3.6	1	1	1	
E-3-10	18	HPF4-91324-004	O-RING, 28.3X2.4(NOK)	1	1	1	
E-3-10	19	HCO-94301-08140	DOWEL PIN, 8X14	2	2	2	


FR.
7
17
13
20
18
16
20
14
11
10
23
24
12
9
4
19
19
22
1
25
21
1
25
8
15
17
20
7
13
11
10
14
20
23
3
19
1
6
25
2
19
25
1
16
18
22
21
8
5


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-4	1	HZV5-12155-000	METAL, ANODE	4	4	4	*NH8*
E-4	2	HZVL-18110-000ZA	MANIFOLD COMP., R. EX.	1	1	1	
E-4	3	HZY3-18115-003	GASKET, R. EX. MANIFOLD	1	1	1	
E-4	4	HZVL-18120-000ZA	MANIFOLD COMP., L. EX.	1	1	1	*NH8*
E-4	5	HZY3-18125-003	GASKET, L. EX. MANIFOLD	1	1	1	
E-4	6	HZVL-19255-000	TUBE, R. WATER RETURN	1	1	1	
E-4	7	HZY3-19256-010	TUBE, WATER RELIEF	2	2	2	
E-4	8	HZY3-19257-000	TUBE, WATER	2	2	2	
E-4	9	HZY3-19261-000	TUBE, L. WATER RETURN	1	1	1	
E-4	10	HZX2-19300-003	THERMOSTAT ASSY.	2	2	2	
E-4	11	HZX2-19303-003	RUBBER, RING	2	2	2	
E-4	12	HZVL-19313-000ZA	SPACER, THERMOSTAT COVER	1	1	1	*NH8*
E-4	13	HZVL-19315-000ZA	COVER, THERMOSTAT	2	2	2	*NH8*
E-4	14	HZY3-35673-003	SENSOR ASSY., WATER	2	2	2	
E-4	15	HZZ5-90019-M00	BOLT, FLANGE, 6X35	1	1	1	
E-4	16	HZY9-90027-M00	BOLT, FLANGE, 8X60	8	8	8	
E-4	17	HZVL-90034-000	BOLT, FLANGE, 6X60	5	5	5	
E-4	18	HZZ5-90055-M00	BOLT, FLANGE, 8X40	8	8	8	
E-4	19	HZY3-90601-030	CLAMP, TUBE(D10.5)	4	4	4	
E-4	20	HZY3-90603-020	CLAMP, TUBE(D29)	4	4	4	
E-4	21	HZY3-90604-020	CLAMP, TUBE(D21)	2	2	2	
E-4	22	HZY3-91301-003	O-RING, 66.4X3.1	2	2	2	
E-4	23	HPNA-91307-003	O-RING, 9.5X1.9	2	2	2	
E-4	24	HSD4-91356-952	O-RING, 31.5X2.4(ARAI)	1	1	1	
E-4	25	HCO-93500-06018-4J	SCREW, PAN, 6X18	4	4	4	


FR.
11
13
13
12
14
14
2
1
6
16
21
25
17
25
5
19
7
4
15
23
18
23
20
20
22
20
20
20
15
22
20
8
20
10
3
9
24


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-5	1	HZVL-15100-000ZA	PUMP ASSY., OIL	1	1	1	*NH8*
E-5	2	HZY3-15112-013	PACKING, OIL PUMP BODY	1	1	1	
E-5	3	HZY3-15113-000	RUBBER, OIL PUMP	1	1	1	
E-5	4	HZY3-15121-000	COVER, OIL PUMP	1	1	1	
E-5	5	HZY3-15131-405	ROTOR, OIL PUMP INNER	1	1	1	
E-5	6	HZY3-15132-405	ROTOR, OIL PUMP OUTER	1	1	1	
E-5	7	HZY3-15220-020	STRAINER COMP., OIL	1	1	1	
E-5	8	HPE0-15231-000	VALVE, RELIEF	1	1	1	
E-5	9	HPG6-15232-000	SPRING, RELIEF VALVE	1	1	1	
E-5	10	HPC6-15233-000	BOLT, SEALING, 18MM	1	1	1	
E-5	11	HZX2-31110-000ZA	FLYWHEEL COMP.	1	1	1	*TBLACK*
E-5	12	HZY3-31116-000	BOSS, FLYWHEEL	1	1	1	
E-5	13	HZX2-90001-000	BOLT, 12MM	8	8	8	
E-5	14	HZW5-90002-013	BOLT, SPECIAL, 8MM	8	8	8	
E-5	15	HZZ5-90081-M00	BOLT, SEALING, 22MM	2	2	2	
E-5	16	HPW5-90701-000	DOWEL PIN, 14X15	1	1	1	
E-5	17	HZW5-91201-003	OIL SEAL, 46X60X9	1	1	1	
E-5	18	HP01-91212-003	OIL SEAL, 31X46X7(NOK)	1	1	1	
E-5	19	HPC6-91324-000	O-RING, 20.6X2.6	1	1	1	
E-5	20	HCO-93600-06016-0A	SCREW, FLAT, 6X16	8	8	8	
E-5	21	HCO-94302-10160	PIN B, DOWEL, 10X16	1	1	1	
E-5	22	HCO-95701-06014-09	BOLT, FLANGE, 6X14	2	2	2	
E-5	23	HCO-95701-06018-09	BOLT, FLANGE, 6X18	2	2	2	
E-5	24	HCO-95701-08030-09	BOLT, FLANGE, 8X30	4	4	4	
E-5	25	HCO-96220-50080	ROLLER, 5X8	2	2	2	


FR.
6
7
10
2
F-4
1
8
11
12
4
5
9
4
3
9


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-6	1	HZVL-11310-000ZA	PAN ASSY., OIL	1	1	1	*TGRAY*
E-6	2	HZVL-11381-003	PACKING, OIL PAN	1	1	1	
E-6	3	HZY3-18330-020	PIPE COMP., R. EX.	1	1	1	
E-6	4	HZVL-18333-003	GASKET, EX. PIPE	2	2	2	
E-6	5	HZY3-18340-020	PIPE COMP., L. EX.	1	1	1	
E-6	6	HZY3-19252-000	GROMMET, WATER TUBE	1	1	1	
E-6	7	HZY3-19254-000	PLATE, WATER TUBE	1	1	1	
E-6	8	HZVL-90070-000	BOLT-WASHER, 8X35(SUS)	21	21	21	
E-6	9	HZVL-90071-000	BOLT-WASHER, 8X28(SUS)	6	6	6	
E-6	10	HZV4-90127-000	BOLT, HEX., 6X16	1	1	1	
E-6	11	HZV5-90131-000	BOLT, DRAIN PLUG	1	1	1	
E-6	12	HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	1	1	1	


FR.
41
49
9
10
2
12
18
45
8
36
41
23
F-3-20
22
21
5
22
6
5
46
4
37
3
46
4
37
E-18-10
32
32
31
19
16
17
11
13
20
48
47
50
1
51
42
44
44
25
43
33
24
E-18-10
32
31
32
15
16
17
11
13
14
47
48
7
40
F-3-20
35
35
34
34
34
34
34
34
34
34
35
35
E-18-10
30
39
30
39
28
38
29
27
39
27
38
38
52
52
53
53
26


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-6-10	1	HZY3-12155-000	METAL, ANODE	2	2	2	
E-6-10	2	HGHB-16163-610	CLIP, TUBE	1	1	1	
E-6-10	3	HZY3-18141-A00ZA	GUIDE, R. EX.	1	1	1	*TGRAY*
E-6-10	4	HZY3-18148-003	SEAL, EXHAUST GUIDE	2	2	2	
E-6-10	5	HZY3-18149-A01	SEAL B, EX. GUIDE	2	2	2	
E-6-10	6	HZY3-18151-A00ZA	GUIDE, L. EX.	1	1	1	*TGRAY*
E-6-10	7	HZVL-19257-000	TUBE, WATER	1	1	1	
E-6-10	8	HZY3-19277-000ZA	COVER, FLUSH VALVE	1	1	1	*NH8*
E-6-10	9	HZY3-19278-000	CASE, FLUSH VALVE	1	1	1	
E-6-10	10	HZW9-19279-010	SPRING, FLUSH VALVE	1	1	1	
E-6-10	11	HZW5-19291-000	VALVE, RELIEF	2	2	2	
E-6-10	12	HZW9-19291-000	VALVE, FLASH	1	1	1	
E-6-10	13	HZW5-19292-000	SPRING, RELIEF VALVE	2	2	2	
E-6-10	14	HZY3-19294-000ZB	SPACER, R. RELIEF VALVE	1	1	1	*TGRAY*
E-6-10	15	HZY3-19295-000	COVER, R. RELIEF VALVE	1	1	1	
E-6-10	16	HZY3-19296-000	PACKING, RELIEF VALVE COVER	2	2	2	
E-6-10	17	HZW5-19297-000	PACKING, RELIEF VALVE	2	2	2	
E-6-10	18	HZW9-19297-000	PACKING, FLASH VALVE	1	1	1	
E-6-10	19	HZY3-19297-000	COVER, L. RELIEF VALVE	1	1	1	
E-6-10	20	HZY3-19298-000ZB	SPACER, L. RELIEF VALVE	1	1	1	*TGRAY*
E-6-10	21	HZVL-19361-000	COVER, R. WATER JACKET	1	1	1	
E-6-10	22	HZVL-19362-000	PACKING, WATER JACKET COVER	2	2	2	
E-6-10	23	HZVL-19366-000	COVER, L. WATER JACKET	1	1	1	
E-6-10	24	HZVL-23170-000ZA	CASE COMP., MOUNT	1	1	1	*NH8*
E-6-10	25	HZVL-23172-003	GASKET, MOUNT CASE	1	1	1	
E-6-10	26	H371-90009-015	BOLT, FLANGE, 10X120(SATO)	1	1	1	
E-6-10	27	HZY3-90010-000	BOLT, HEX., 12X120	2	2	2	
E-6-10	28	HZY3-90011-000	BOLT, HEX., 12X65	1	1	1	
E-6-10	29	HZY3-90013-000	BOLT, HEX., 10X85	1	1	1	


FR.
41
49
9
10
2
12
18
45
8
36
41
23
F-3-20
22
21
5
22
6
5
46
4
37
3
46
4
37
E-18-10
32
32
31
19
16
17
11
13
20
48
47
50
1
51
42
44
44
25
43
33
24
E-18-10
32
31
32
15
16
17
11
13
14
47
48
7
40
F-3-20
35
35
34
34
34
34
34
34
34
34
35
35
E-18-10
30
39
30
39
28
38
29
27
39
27
38
38
52
52
53
53
26

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-6-10	30	HZY3-90015-000	BOLT, HEX., 10X60	2	2	2	
E-6-10	31	HZZ5-90030-M00	BOLT, FLANGE, 6X22	2	2	2	
E-6-10	32	HZZ5-90032-M00	BOLT, FLANGE, 6X32	4	4	4	
E-6-10	33	HZVL-90045-000	BOLT, STUD, 10X45	2	2	2	
E-6-10	34	HZVL-90046-000	BOLT, FLANGE, 8X120	8	8	8	
E-6-10	35	HZVL-90049-000	BOLT, FLANGE, 8X30	4	4	4	
E-6-10	36	HZY3-90059-000	BOLT-WASHER, 6X29	1	1	1	
E-6-10	37	HHW1-90207-671	BOLT, FLANGE, 6X40	2	2	2	
E-6-10	38	HZV5-90559-000	WASHER, PLAIN, 12MM	3	3	3	
E-6-10	39	HZV5-90563-000	WASHER, PLAIN, 10MM	3	3	3	
E-6-10	40	HZY3-90601-030	CLAMP, TUBE(D10.5)	1	1	1	
E-6-10	41	HZV4-90605-000	CLIP, TUBE(B12.5)	2	2	2	
E-6-10	42	HPW5-90701-000	DOWEL PIN, 14X15	1	1	1	
E-6-10	43	HZY3-91001-003	BEARING, NEEDLE, 20X28X13	1	1	1	
E-6-10	44	HZW5-91202-003	SEAL, WATER, 22X35X7	2	2	2	
E-6-10	45	H800-91303-000	O-RING, 16MM	1	1	1	
E-6-10	46	HZY3-91304-000	O-RING, 49.4X3.1	2	2	2	
E-6-10	47	HZY3-91305-003	O-RING, 33.5X2	2	2	2	
E-6-10	48	HZY3-91306-003	O-RING, 23.5X2	2	2	2	
E-6-10	49	HZY3-91405-000	TUBE, FLUSH VALVE	1	1	1	
E-6-10	50	HCO-93500-05016-4J	SCREW, PAN, 5X16	2	2	2	
E-6-10	51	HCO-94302-10160	PIN B, DOWEL, 10X16	1	1	1	
E-6-10	52	HCO-95701-10070-09	BOLT, FLANGE, 10X70	2	2	2	
E-6-10	53	HCO-95701-12120-09	BOLT, FLANGE, 12X120	2	2	2	



FR.
11
9
8
10
10
12
14
13
6
5
7
7
1
4
2
3
4
4
3
5
2
7
6
7
4
1

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-7	1	HZX2-13010-000	RING SET, PISTON(STD.)(RIKEN)	6	6	6	
E-7	1	HZX2-13011-000	RING SET, PISTON(0.25)(RIKEN)	6	6	6	
E-7	2	HZX2-13101-000	PISTON	6	6	6	
E-7	2	HZX2-13102-000	PISTON(0.25)	6	6	6	
E-7	3	HPEA-13111-000	PIN, PISTON	6	6	6	
E-7	4	HP5A-13115-000	CLIP, PISTON PIN	12	12	12	
E-7	5	HP8A-13204-A01	BOLT, CONNECTING ROD	12	12	12	
E-7	6	HRKG-13210-000	ROD COMP., CONNECTING	6	6	6	
E-7	7	HRYE-13211-A01	BEARING A, CONNECTING ROD	12	12	12	
E-7	7	HRYE-13212-A01	BEARING B, CONNECTING ROD	12	12	12	
E-7	7	HRYE-13213-A01	BEARING C, CONNECTING ROD	12	12	12	
E-7	7	HRYE-13214-A01	BEARING D, CONNECTING ROD	12	12	12	
E-7	7	HRYE-13215-A01	BEARING E, CONNECTING ROD	12	12	12	
E-7	8	HZX2-13310-000	CRANKSHAFT COMP.	1	1	1	
E-7	9	HZX2-13321-003	BEARING A, MAIN UPPER(BLACK)	4	4	4	
E-7	9	HZX2-13322-003	BEARING B, MAIN UPPER(BROWN)	4	4	4	
E-7	9	HZX2-13323-003	BEARING C, MAIN UPPER(GREEN)	4	4	4	
E-7	9	HZX2-13324-003	BEARING D, MAIN UPPER(YELLOW)	4	4	4	
E-7	9	HZX2-13325-003	BEARING E, MAIN UPPER(PINK)	4	4	4	
E-7	9	HZX2-13326-003	BEARING F, MAIN UPPER(RED)	4	4	4	
E-7	10	HZY3-13331-A06	WASHER, THRUST	2	2	2	
E-7	11	HZX2-13341-003	BEARING A, MAIN LOWER(BLACK)	4	4	4	
E-7	11	HZX2-13342-003	BEARING B, MAIN LOWER(BROWN)	4	4	4	
E-7	11	HZX2-13343-003	BEARING C, MAIN LOWER(GREEN)	4	4	4	
E-7	11	HZX2-13344-003	BEARING D, MAIN LOWER(YELLOW)	4	4	4	
E-7	11	HZX2-13345-003	BEARING E, MAIN LOWER(PINK)	4	4	4	
E-7	11	HZX2-13346-003	BEARING F, MAIN LOWER(RED)	4	4	4	
E-7	12	HZY3-13391-010	RETAINER, SPRING	1	1	1	
E-7	13	HZX2-13392-000	SEAT, SPRING(250)	1	1	1	



FR.
11
9
8
10
10
12
14
13
6
5
7
7
1
4
2
3
4
4
3
5
2
7
6
7
4
1

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-7	14	HZY3-13398-003	SPRING, SUPPORT	1	1	1	


E-9 CYLINDER HEAD




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-9	1	HZY3-11911-010	HANGER, ENGINE	2	2	2	
E-9	2	HPJ7-12204-305	GUIDE, IN. VALVE(O.S.)	12	12	12	
E-9	3	HPJ7-12205-305	GUIDE, EX. VALVE(O.S.)	12	12	12	
E-9	4	HPZ1-12210-004	SEAL A, VALVE STEM(NOK)	12	12	12	
E-9	5	HZVL-12210-000ZA	HEAD COMP., CYLINDER	2	2	2	*NH8*
E-9	6	HPZ1-12211-004	SEAL B, VALVE STEM(NOK)	12	12	12	
E-9	7	HZVL-12231-000	COVER, R. CAMSHAFT THRUST	1	1	1	
E-9	8	HZY3-12241-000	COVER, L. CAMSHAFT THRUST	1	1	1	
E-9	9	HZY3-12251-A01	GASKET COMP., CYLINDER HEAD	2	2	2	
E-9	10	HP8F-14820-A01	MOTION COMP., LOST	-	6	6	
E-9	11	HPT0-90005-003	BOLT-WASHER, 12X163	16	16	16	
E-9	12	HZY9-90026-M00	BOLT, FLANGE, 8X20	4	4	4	
E-9	13	HZVL-90035-000	BOLT, FLANGE, 8X28	4	4	4	
E-9	14	HP8A-90701-A00	DOWEL PIN, 6X10	4	4	4	
E-9	15	HPT0-90705-000	DOWEL PIN, 16X22	4	4	4	
E-9	16	HRKG-91213-003	OIL SEAL, 39X53X8(NOK)	2	2	2	
E-9	17	HP8A-91301-A00	O-RING, 48.5X2.4	2	2	2	
E-9	18	HCO-94302-06100	PIN B, DOWEL, 6X10	4	4	4	


FR.
23
14
6
9
14
23
5
4
14
23
14
23
8
7
2
10
13
13
3
22
22
10
21
20
12
18
16
17
19
19
6
14
23
9
14
5
23
1
15
18
17
19
19
11
4
14
23
23
14
10
22
13
22
13
3
10
7
8
20
21


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-9-10	1	HZVJ-14111-000	CAMSHAFT, R.	1	–	–	
E-9-10	1	HZX2-14111-000	CAMSHAFT, R.	–	1	1	
E-9-10	2	HZVJ-14211-000	CAMSHAFT, L.	1	–	–	
E-9-10	2	HZX2-14211-000	CAMSHAFT, L.	–	1	1	
E-9-10	3	HRDV-14610-J00	ARM ASSY., FR. INTAKE ROCKER	6	–	–	
E-9-10	4	HP8A-14620-A01	ARM ASSY., INTAKE ROCKER	–	6	6	
E-9-10	5	HP8A-14626-A00	ARM COMP. A, EX. ROCKER	6	6	6	
E-9-10	6	HP8A-14627-A00	ARM COMP. B, EX. ROCKER	6	6	6	
E-9-10	7	HRDV-14631-J00	SHAFT COMP., FR. INTAKE ROCKER	2	–	–	
E-9-10	7	HP8A-14631-A00	SHAFT COMP., INTAKE ROCKER ARM	–	2	2	
E-9-10	8	HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM	2	2	2	
E-9-10	9	HP8A-14645-A01	SPRING, ROCKER ARM	6	6	6	
E-9-10	10	HRDV-14646-J00	WASHER, THRUST	12	–	–	
E-9-10	11	HRJA-14711-000	VALVE, IN.	12	12	12	
E-9-10	12	HRJA-14721-E00	VALVE, EX.	12	12	12	
E-9-10	13	HPM3-14744-000	SCREW, TAPPET ADJUSTING	12	–	–	
E-9-10	14	HPT0-14744-004	SCREW, TAPPET ADJUSTING	12	24	24	
E-9-10	15	HRKG-14761-003	SPRING, VALVE(PINK)	12	12	12	
E-9-10	16	HP8E-14762-A01	SPRING, EX. VALVE	12	12	12	
E-9-10	17	HRDV-14765-J00	RETAINER, VALVE SPRING	24	24	24	
E-9-10	18	HPM3-14775-000	SEAT, VALVE SPRING	24	24	24	
E-9-10	19	HRGM-14781-A01	COTTER, VALVE(FUJI VALVE)	48	48	48	
E-9-10	20	HP8A-90003-A00	BOLT, FLANGE, 8X30	12	12	12	
E-9-10	21	HP8A-90004-A00	BOLT, FLANGE, 8X40	8	8	8	
E-9-10	22	HPM3-90206-004	NUT, TAPPET ADJUSTING	12	–	–	
E-9-10	23	HPT0-90206-004	NUT, TAPPET ADJUSTING	12	24	24	


FR.
8
8
9
20
14
27
7
12
18
26
21
24
10
11
30
25
29
5
28
1
19
25
29
4
6
2
23
16
22
3
8
13
15
17


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-13	1	HZY3-13621-C01	PULLEY, TIMING BELT DRIVE	1	1	1	
E-13	2	HZVL-13622-000	PLATE, CRANK PULSER	1	1	1	
E-13	3	HZX2-13811-000	PULLEY, CRANKSHAFT	1	1	1	
E-13	4	HZY3-14261-C00	PULLEY COMP., R. TIMING BELT	1	1	1	
E-13	5	HZVL-14270-000	PULLEY COMP., L. TIMING BELT	1	1	1	
E-13	6	HP8A-14400-A01	BELT, TIMING(197YU26 B-323)	1	1	1	
E-13	7	HZY3-14510-003	TENSIONER COMP., TIMING BELT	1	1	1	
E-13	8	HZY3-14515-000	CAP, TIMING BELT TENSIONER	3	3	3	
E-13	9	HZY3-14520-000	SPRING COMP., TIMING BELT	1	1	1	
E-13	10	HZVL-14526-405ZA	BASE COMP., TIMING BELT	1	1	1	*NH8*
E-13	11	HZY3-14529-000	O-RING, TIMING BELT TENSIONER	1	1	1	
E-13	12	HZY3-14550-003	IDLER, TIMING BELT(KOYO SEIKO)	1	1	1	
E-13	13	HP8A-14551-A01	BOLT, IDLER	1	1	1	
E-13	14	HZVL-14553-003	BOLT, TIMING BELT IDLER	1	1	1	
E-13	15	HZY3-14555-003	IDLER B, TIMING BELT	1	1	1	
E-13	16	HZX2-19511-000	FAN, COOLING	1	1	1	
E-13	17	HZY3-31638-003	BELT, A.C. GENERATOR	1	1	1	
E-13	18	HZVL-32111-000	BRACKET, COUPLER D	1	1	1	
E-13	19	HZV0-41122-000	PIN, VERTICAL SHAFT	1	1	1	
E-13	20	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	1	1	1	
E-13	21	HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTING	1	1	1	
E-13	22	HRJA-90017-003	BOLT-WASHER, 16X49	1	1	1	
E-13	23	HZZ5-90017-M00	BOLT, FLANGE, 6X16	4	4	4	
E-13	24	HZZ5-90030-M00	BOLT, FLANGE, 6X22	1	1	1	
E-13	25	HP8A-90031-A01	BOLT-WASHER, 12X35	2	2	2	
E-13	26	HZVL-90039-000	BOLT, FLANGE, 10X40	3	3	3	
E-13	27	HZVL-90040-000	BOLT, FLANGE, 10X43	1	1	1	
E-13	28	HRCA-90704-A00	KEY, 4.5X24	1	1	1	
E-13	29	HZY3-90741-000	KEY, SPECIAL	2	2	2	


FR.
8
8
9
20
14
27
7
12
18
26
21
24
10
11
30
25
29
5
28
1
19
25
29
4
6
2
23
16
22
3
17
8
13
15


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-13	30	HCO-94301-06100	DOWEL PIN, 6X10	1	1	1	


FR.
8
8
1
10
3
9
4
6
7
8
8
10
1
2
9
5


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-13-10	1	HP8A-11812-A00	GROMMET, TIMING BELT COVER	2	2	2	
E-13-10	2	HZVL-11820-000	COVER ASSY., R. TIMING BELT	1	1	1	
E-13-10	3	HZVL-11840-000	COVER ASSY., L. TIMING BELT	1	1	1	
E-13-10	4	HZVL-11861-000	PLATE, L. TIMING BELT COVER	1	1	1	
E-13-10	5	HZY3-11871-000	PLATE, R. TIMING BELT COVER	1	1	1	
E-13-10	6	HR70-37840-A01	SENSOR ASSY., TDC	1	1	1	
E-13-10	7	HZVL-90004-000	BOLT-WASHER, 5X16	1	1	1	
E-13-10	8	HZVL-90007-000	BOLT, TIMING BELT COVER	4	4	4	
E-13-10	9	HP8A-90017-A01	BOLT, SPECIAL, 8X29	4	4	4	
E-13-10	10	HZVL-91508-000	COLLAR, TIMING BELT COVER	2	2	2	


FR.
35
28
19
18
30
29
32
9
2
27
3
23
25
31
26
16
17
35
24
15
12
22
13
14
10
33
34
1
E-18-10
8
E-14-10
6
7
4
5
20
21
11


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-14	1	HZY6-16450-003	INJECTOR ASSY., FUEL	6	6	6	
E-14	2	HZY3-16451-000	CLIP, INJECTOR	6	6	6	
E-14	3	HZY3-16611-A00	PIPE, R. FUEL	1	1	1	
E-14	4	HP5G-16614-003	MESH, FUEL FILTER	1	1	1	
E-14	5	HZY3-16620-A00	PIPE COMP., L. FUEL	1	1	1	
E-14	6	HZY3-16740-A01	REGULATOR ASSY., PRESSURE	1	1	1	
E-14	7	HPG7-16741-005	O-RING, PRESSURE REGULATOR	1	1	1	
E-14	8	HZVL-16748-000	TUBE, PRESSURE REGULATOR	1	1	1	
E-14	9	HZY3-16752-A00	JOINT, FUEL PIPE	3	3	3	
E-14	10	HZVL-16755-003	HOSE COMP., FUEL	1	1	1	
E-14	11	HZY3-16757-003	HOSE COMP., FUEL JOINT	1	1	1	
E-14	12	HZVL-16765-003	HOSE COMP. B, FUEL	1	1	1	
E-14	13	HZVL-16910-003	STRAINER COMP., FUEL(HIGH)	1	1	1	
E-14	14	HZVL-16917-000	SUSPENSION, STRAINER	1	1	1	
E-14	15	HVM0-16965-771	CLAMP, HOSE	1	1	1	
E-14	16	HZY3-17051-A00	BASE, R. INJECTOR	1	1	1	
E-14	17	HRCA-17055-A01	GASKET, FR. INJECTOR BASE	1	1	1	
E-14	18	HZY3-17061-A00	BASE, L. INJECTOR	1	1	1	
E-14	19	HRCA-17065-A01	GASKET, RR. INJECTOR BASE	1	1	1	
E-14	20	HP8E-17105-A01	GASKET, INTAKE MANIFOLD	1	1	1	
E-14	21	HZY3-17108-000	SPACER, INTAKE MANIFOLD	1	1	1	
E-14	22	HS0X-17711-931	RETAINER(BLUE GREEN)(TOKAI)	2	2	2	
E-14	23	HZY3-32112-000	BRACKET, HARNESS CLIP A	4	4	4	
E-14	24	HZZ5-90014-M00	BOLT, FLANGE, 6X25	4	4	4	
E-14	25	HZZ5-90019-M00	BOLT, FLANGE, 6X35	4	4	4	
E-14	26	HZZ5-90021-M00	BOLT, FLANGE, 6X14	6	6	6	
E-14	27	HZY9-90042-M00	BOLT, FLANGE, 6X10	6	6	6	
E-14	28	HZVL-90043-000	BOLT, STUD, 8X28	8	8	8	
E-14	29	HZY3-90044-000	BOLT, STUD, 8X45	2	2	2	


FR.
35
28
19
18
30
29
32
9
2
27
3
23
25
31
26
16
17
35
24
15
12
22
13
14
10
33
34
1
E-18-10
8
E-14-10
6
7
4
5
20
21
11

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-14	30	HZY9-90205-M00	NUT, FLANGE, 8MM	8	8	8	
E-14	31	HSB2-90650-003	CLIP, WIRE HARNESS, 10MM	4	4	4	
E-14	32	HMJ0-91301-003	O-RING, 7.8X1.9(ARAI)	6	6	6	
E-14	33	HPLC-91301-000	O-RING, 7.47X3.6	6	6	6	
E-14	34	HPNA-91302-003	O-RING, 7.45X3.61(NOK)	6	6	6	
E-14	35	HCO-94301-10120	DOWEL PIN, 10X12	4	4	4	



FR.
11
7
10
8
18
17
6
9
12
2
1
E-14
5
3
4
15
16
13
15
15
15
14
16

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-14-10	1	HZY3-17105-004	GASKET, INTAKE MANIFOLD	1	1	1	
E-14-10	2	HZY3-17109-004	PACKING, THROTTLE BODY	1	1	1	
E-14-10	3	HZVL-17110-003	MANIFOLD COMP., INLET	1	1	1	
E-14-10	4	HZVL-17131-000ZA	COVER, INTAKE MANIFOLD UPPER	1	1	1	*NH8*
E-14-10	5	HZY3-17138-004	PACKING, INTAKE MANIFOLD UP	1	1	1	
E-14-10	6	HRNA-37830-A01	SENSOR ASSY., MAP	1	1	1	
E-14-10	7	HZVL-37831-000	STAY, MAP SENSOR	1	1	1	
E-14-10	8	HZVL-37832-000	COLLAR, 5.5X6.8	1	1	1	
E-14-10	9	HPGK-37835-A01	O-RING	1	1	1	
E-14-10	10	HMB9-83551-000	GROMMET	1	1	1	
E-14-10	11	HZVL-90013-000	BOLT-WASHER, 5X12	1	1	1	
E-14-10	12	HZVL-90014-000	BOLT-WASHER, 5X28	1	1	1	
E-14-10	13	HZVL-90023-000	BOLT, FLANGE, 6X22	10	10	10	
E-14-10	14	HZY3-90031-000	BOLT, FLANGE, 6X32	1	1	1	
E-14-10	15	HZW4-90156-000	BOLT, FLANGE, 8X50	7	7	7	
E-14-10	16	HZY3-90205-000	NUT, FLANGE, 8MM	2	2	2	
E-14-10	17	HZZ5-90301-M00	NUT, FLANGE, 5MM	1	1	1	
E-14-10	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	1	1	1	


FR.
15
18
13
20
10
18
13
20
13
20
8
7
6
E-1
9
9
14
14
3
17
1
4
11
21
2
19
5
12
16


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-15	1	HZY3-16016-003	SCREW SET	1	1	1	
E-15	2	HZY3-16176-000	GASKET, THROTTLE BODY	1	1	1	
E-15	3	HZVK-16400-003	THROTTLE BODY ASSY.	1	1	-	
E-15	3	HZY3-16400-A01	THROTTLE BODY ASSY.	-	-	1	
E-15	4	HZX2-16404-000	SPACER, THROTTLE BODY	1	1	1	
E-15	5	HZY3-16405-000	GASKET, EAC VALVE	1	1	1	
E-15	6	HPY3-17249-000	SPRING, AIR FLOW TUBE	1	1	1	
E-15	7	HZY9-17315-M00	BAND, AIR FLOW	1	1	1	
E-15	8	HZX2-17374-000	GROMMET, SILENCER	1	1	1	
E-15	9	HZVL-17910-003	CABLE COMP., THROTTLE	2	2	2	
E-15	10	HZVL-19540-000	COVER ASSY., COOLING FAN	1	1	1	
E-15	11	HZW5-35665-003	SENSOR ASSY., AIR TEMPERATURE	1	1	1	
E-15	12	HZY3-36550-003	VALVE ASSY., EAC	1	1	1	
E-15	13	HZV5-40102-000	GROMMET, UNDER CASE	4	4	4	
E-15	14	HS0X-46392-A01	CLIP, BRAKE PIPE	2	2	2	
E-15	15	HZZ5-90013-M00	BOLT-WASHER, 6X25	2	2	2	
E-15	16	HZZ5-90030-M00	BOLT, FLANGE, 6X22	2	2	2	
E-15	17	HZVL-90037-000	BOLT, FLANGE, 8X65	4	4	4	
E-15	18	HZVL-90072-000	BOLT-WASHER, 6X60	2	2	2	
E-15	19	HP0A-91303-A02	O-RING	1	1	1	
E-15	20	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	4	4	4	
E-15	21	HC0-94301-06100	DOWEL PIN, 6X10	2	2	2	

E-18 VAPOR SEPARATOR ASSY




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-18	1	HZY3-16011-A01	VALVE SET, FLOAT	1	1	1	
E-18	2	HZY3-16013-000	FLOAT SET	1	1	1	
E-18	3	HZVL-16015-000	BODY	1	1	1	
E-18	4	HZVL-16020-003	COVER COMP.	1	1	1	
E-18	5	HZY3-16024-000	SCREW SET, DRAIN	1	1	1	
E-18	6	HZY3-16026-000	JOINT SET	1	1	1	
E-18	7	HZVL-16030-003	PUMP UNIT SET A, FUEL	1	1	1	
E-18	8	HZY3-16031-010	STAY, PLATE	1	1	1	
E-18	9	HZY3-16036-003	PUMP UNIT SET B, FUEL	1	1	1	
E-18	10	HZY3-16041-000	PLATE	1	1	1	
E-18	11	HZY3-16042-000	HOLDER	1	1	1	
E-18	12	HZY3-16061-000	COVER, WATER JACKET	1	1	1	
E-18	13	HZY3-16072-000	O-RING	1	1	1	
E-18	14	HZY3-16073-000	O-RING	1	1	1	
E-18	15	HZY3-16074-000	O-RING	1	1	1	
E-18	16	HZY3-16075-000	O-RING	1	1	1	
E-18	17	HZY3-16076-000	O-RING	1	1	1	
E-18	18	HZY3-16077-000	O-RING	2	2	2	
E-18	19	HZY3-16078-000	O-RING	1	1	1	
E-18	20	HZW5-16081-010	SCREW-WASHER	21	21	21	
E-18	21	HZY3-16082-000	SCREW, PAN	2	2	2	
E-18	22	HZY3-16083-000	SCREW, WASHER	1	1	1	
E-18	23	HZW5-16086-000	COLLAR, SET	8	8	8	
E-18	24	HZW5-16087-000	WASHER, PLAIN	8	8	8	
E-18	25	HZY3-16087-000	WASHER, PLAIN	1	1	1	
E-18	26	HZY3-16088-000	COLLAR	1	1	1	
E-18	27	HZVL-16700-003	PUMP ASSY., FUEL	1	1	1	
E-18	28	HZX2-16701-003	CASE COMP., PUMP	1	1	1	
E-18	29	HZY3-16708-000	COVER, PUMP	1	1	1	

E-18 VAPOR SEPARATOR ASSY




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-18	30	HZVL-16710-000	RUBBER, FUEL PUMP	2	2	2	
E-18	31	HZW5-16715-023	COVER, PUMP(A)	1	1	1	
E-18	32	HZY6-16718-013	INSULATOR COMP.	1	1	1	
E-18	33	HZY3-16721-000	INSULATOR	1	1	1	
E-18	34	HZY6-16723-003	RING	1	1	1	
E-18	35	HZVL-16725-000	STAY COMP. A, FUEL PUMP	1	1	1	
E-18	36	HZVL-16726-000	STAY COMP. B, FUEL PUMP	1	1	1	
E-18	37	HZVL-16730-013	SEPARATOR ASSY., VAPOR	1	1	1	
E-18	38	HZW5-16733-000	GROMMET, VAPOR SEPARATOR	1	1	1	
E-18	39	HZY3-16733-000	GROMMET, VAPOR SEPARATOR	2	2	2	
E-18	40	HZY3-16734-000	STAY, PLATE	1	1	1	
E-18	41	HZY3-16735-004	PUMP UNIT, FUEL	1	1	1	
E-18	42	HZY3-16752-000	JOINT, FUEL PIPE	1	1	1	
E-18	43	HZX2-32166-003	HARNESS COMP.	1	1	1	
E-18	44	HZW5-32168-003	BAND	1	1	1	
E-18	45	HPP4-90009-E01	BOLT, SEALING, 6MM	1	1	1	
E-18	46	HZY9-90014-M00	BOLT-WASHER, 8X35	3	3	3	
E-18	47	HZZ5-90014-M00	BOLT, FLANGE, 6X25	2	2	2	
E-18	48	HZZ5-90016-M00	BOLT, FLANGE, 6X28	2	2	2	
E-18	49	HZZ5-90017-M00	BOLT, FLANGE, 6X16	2	2	2	
E-18	50	HZZ5-90021-M00	BOLT, FLANGE, 6X14	2	2	2	
E-18	51	HPD6-90430-003	WASHER, SEALING, 6MM	1	1	1	
E-18	52	HZB7-90691-003	CLIP, HARNESS	2	2	2	
E-18	53	HMJ0-91301-003	O-RING, 7.8X1.9(ARAI)	2	2	2	
E-18	54	HZY9-91504-M00	COLLAR, 8.5X14.5	3	3	3	


E-18-1 FUEL STRAINER




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-18-1	1	HZY3-16818-003	O-RING	1	1	1	
E-18-1	2	HZVL-16840-000	TUBE COMP. A, FUEL	1	1	1	
E-18-1	3	HZVL-16841-000	STAY, FUEL TUBE	1	1	1	
E-18-1	4	HZVL-16850-000	TUBE COMP. B, FUEL	1	1	1	
E-18-1	5	HZY9-16896-003	CLAMP B, FUEL TUBE	5	5	5	
E-18-1	6	HZVL-16900-003	STRAINER ASSY., FUEL(LOW)	1	1	1	
E-18-1	7	HZY3-16901-003	STRAINER, FUEL	1	1	1	
E-18-1	8	HZY3-16904-003	SCREW, PAN, 5X12	3	3	3	
E-18-1	9	HZVL-16914-000	STAY A, FUEL STRAINER	1	1	1	
E-18-1	10	HZY3-16915-010	SUSPENSION, STRAINER	1	1	1	
E-18-1	11	HZY3-16918-003	O-RING	1	1	1	
E-18-1	12	HZY3-16919-003	PLATE	1	1	1	
E-18-1	13	HZY3-17738-000	PLUG, FUEL TUBE	1	1	1	
E-18-1	14	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1	1	1	
E-18-1	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10	2	2	2	
E-18-1	16	HZW5-90602-030	CLAMP, TUBE(D12)	1	1	1	
E-18-1	17	HZV0-90604-000	CLIP, TUBE(B12)	2	2	2	
E-18-1	18	HSTK-91540-003	CLIP, HARNESS BAND(BLACK)	1	1	1	
E-18-1	19	HZVL-16805-003	CUP SET, WATER SEPARATER	1	1	1	


18
25
16
FR.
E-14
16
16
25
17
16
25
19
16
25
2
1
23
22
16
30
4
5
16
15
24
14
26
21
E-6-10
3
13
E-18
28
29
28
28
20
26
10
7
26
26
E-6-10
27
27
28
28
8
12
11
31
28
E-18-1
6
27
9
28


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-18-10	1	HZY3-16193-A00	CLAMP, CHECK VALVE	1	1	1	
E-18-10	2	HZY3-16196-A00	TUBE, CHECK VALVE	1	1	1	
E-18-10	3	HZY3-16197-000	TUBE A, AIR VENT	1	1	1	
E-18-10	4	HZY3-16198-A00	TUBE B, AIR VENT	1	1	1	
E-18-10	5	HZY3-16199-A00	TUBE COMP., AIR VENT	1	1	1	
E-18-10	6	HRMA-16723-E00	JOINT, FUEL FEED HOSE	1	1	1	
E-18-10	7	HZVL-16760-003	VALVE COMP., RELIEF	1	1	1	
E-18-10	8	HZVL-16770-000	TUBE, RELIEF	1	1	1	
E-18-10	9	HZVL-16860-000	TUBE COMP. C, FUEL	1	1	1	
E-18-10	10	HZVL-16870-000	TUBE D, FUEL	1	1	1	
E-18-10	11	HZVL-16875-000	JOINT, THREE WAY	1	1	1	
E-18-10	12	HZVL-16880-000	TUBE E, FUEL	1	1	1	
E-18-10	13	HZVL-16890-000	TUBE F, FUEL	1	1	1	
E-18-10	14	H759-16911-003	STRAINER, FUEL PUMP	1	1	1	
E-18-10	15	HZW5-16915-000	SUSPENSION, STRAINER	1	1	1	
E-18-10	16	HVM0-16965-771	CLAMP, HOSE	7	7	7	
E-18-10	17	HZY3-17721-000	JOINT, FUEL RETURN	1	1	1	
E-18-10	18	HZY3-17723-A01	HOSE A, PRESSURE REGULATOR	1	1	1	
E-18-10	19	HZY3-17724-010	HOSE B, PRESSURE REGULATOR	1	1	1	
E-18-10	20	HZY3-19258-010	TUBE, WATER IN.	1	1	1	
E-18-10	21	HZY3-19259-000	TUBE, WATER OUTLET	1	1	1	
E-18-10	22	HZY6-19269-000	T-JOINT	1	1	1	
E-18-10	23	HZY6-36135-003	VALVE, CHECK	1	1	1	
E-18-10	24	HSE0-53740-953	CLIP, SENSOR HOSE	1	1	1	
E-18-10	25	HZW5-90601-030	CLAMP, TUBE(D10.7)	4	4	4	
E-18-10	26	HZY3-90601-030	CLAMP, TUBE(D10.5)	4	4	4	
E-18-10	27	HZW5-90602-030	CLAMP, TUBE(D12)	3	3	3	
E-18-10	28	HZV0-90604-000	CLIP, TUBE(B12)	7	7	7	
E-18-10	29	HZW5-90652-003	CLAMP, 6MM-12MM	1	1	1	


18
25
16
FR.
E-14
16
16
25
17
16
25
19
16
25
2
1
23
22
30
4
16
5
16
15
24
14
26
21
E-6-10
3
13
E-18
28
29
28
28
20
26
10
7
26
26
E-6-10
27
28
27
28
8
12
11
31
28
E-18-1
6
27
9
28


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-18-10	30	HCO-95001-35055-40	TUBE, FUEL, 3.5X55	1	1	1	
E-18-10	31	HCO-95003-05060-31	TUBE, VINYL, 3.5X6.5X600	1	1	1	


FR.
21
7
6
25
14
3
8
8
9
9
9
9
26
26
24
16
23
22
15
2
5
27
18
1
12
12
19
20
12
12
11
13
17
4
4
26
26
26
10


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-19	1	HPR7-31105-A01	HOLDER ASSY., BRUSH	1	1	1	
E-19	2	HPT0-31111-003	BEARING, RR. GENERATOR	1	1	1	
E-19	3	HPT0-31114-013	BEARING, FR. GENERATOR	1	1	1	
E-19	4	HPT0-31118-003	BUSH, INSULATION	4	4	4	
E-19	5	HPD1-31138-004	COVER, BEARING	1	1	1	
E-19	6	HP13-31141-003	PULLEY	1	1	1	
E-19	7	HPD1-31142-004	NUT, PULLEY LOCK	1	1	1	
E-19	8	HPD1-31145-004	BOLT, STUD, 6X68	4	4	4	
E-19	9	HPT0-31146-003	SCREW	4	4	4	
E-19	10	HP13-31147-003	SCREW	1	1	1	
E-19	11	HPT0-31147-003	SCREW-WASHER	3	3	3	
E-19	12	HP13-31148-003	SCREW, WAVE WASHER	4	4	4	
E-19	13	HPT0-31148-003	SCREW, WAVE WASHER	2	2	2	
E-19	14	HZY3-31630-013	GENERATOR ASSY., A.C.	1	1	1	
E-19	15	HZY3-31631-003	ROTOR ASSY.	1	1	1	
E-19	16	HZVL-31637-000	STAY, A.C. GENERATOR	1	1	1	
E-19	17	HZY3-31639-003	END COVER, RR.	1	1	1	
E-19	18	HZY3-31694-003	BUSH, INSULATION	1	1	1	
E-19	19	HZY3-31710-003	RECTIFIER ASSY.	1	1	1	
E-19	20	HZY3-31750-003	REGULATOR ASSY.	1	1	1	
E-19	21	HZX2-90002-000	BOLT, FLANGE, 10X90	1	1	1	
E-19	22	HZVL-90011-000	BOLT, SPECIAL ADJUSTER	1	1	1	
E-19	23	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	1	
E-19	24	HZY3-90055-000	BOLT, TENSIONER	1	1	1	
E-19	25	HZW5-90203-010	NUT, FLANGE, 8MM	1	1	1	
E-19	26	HPD1-90231-014	NUT-WASHER, 5MM	7	7	7	
E-19	27	HCO-94001-06080-0S	NUT, HEX., 6MM	1	1	1	


5
2
4
7
6
1
3
FR.
3
7
4
6
1
2
5

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-20	1	HZVL-30520-003	COIL ASSY., PLUG TOP	6	6	6	
E-20	2	HZVL-30525-000	STAY COMP., PLUG TOP COIL	6	6	6	
E-20	3	HZX2-31916-003	PLUG, SPARK(ZFR6K-11E)(NGK)	6	6	6	
E-20	3	HCO-9807B-5617C	PLUG, SPARK(IZFR6K-11E)(NGK)	6	6	6	
E-20	4	HZY9-38553-003	GROMMET, RELAY BRACKET	6	6	6	
E-20	5	HZVL-90015-000	BOLT-WASHER, 6X27	6	6	6	
E-20	6	HZZ5-90018-M00	BOLT, FLANGE, 6X20	6	6	6	
E-20	7	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	6	6	6	



9
6
8
7
10
5
2
12
8
2
12
1
2
12
2
12
10
4
8
8
2
12
3
10
3
10
3
10
8
11
FR.

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-20-10	1	HZVL-30416-000	CASE, ELECTRONIC PARTS	1	1	1	
E-20-10	2	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	8	8	8	
E-20-10	3	HZVL-32101-000	BRACKET, A.C. GENERATOR FUSE	4	4	4	
E-20-10	4	HZVL-32102-000	BRACKET, COUPLER A	1	1	1	
E-20-10	5	HZW9-32117-000	BRACKET, COUPLER D	-	1	1	
E-20-10	6	HZVJ-34750-901	CONTROL UNIT, ELECTRONIC	1	-	-	
E-20-10	6	HZVK-34750-901	CONTROL UNIT, ELECTRONIC	-	1	-	
E-20-10	6	HZVL-34750-901	CONTROL UNIT, ELECTRONIC	-	-	1	
E-20-10	7	HZVL-34754-000	CASE, ELECTRONIC CONTROL UNIT	1	1	1	
E-20-10	8	HZVL-90015-000	BOLT-WASHER, 6X27	8	8	8	
E-20-10	9	HZZ0-90102-M00	BOLT, TORX(M6X20)	2	2	2	
E-20-10	10	HZZ0-90103-M00	BOLT, FLANGE, 6X10	5	6	6	
E-20-10	11	HSA0-90683-003	CLIP, WIRE HARNESS, 25MM	1	1	1	
E-20-10	12	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	8	8	8	


14
21
12
10
1
7
2
5
18
4
4
4
15
6
16
3
9
13
20
17
19
11
8
22
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
E-21	1	HZY3-31200-003	MOTOR ASSY., STARTER	1	1	1	
E-21	2	HP5A-31201-005	ROTOR COMP.	1	1	1	
E-21	3	HZY9-31207-H01	CLUTCH COMP., OVERRUNNING	1	1	1	
E-21	4	HPY3-31215-004	GEAR ASSY., PLANETARY	3	3	3	
E-21	5	HZY3-31216-003	YOKE COMP.	1	1	1	
E-21	6	HPY3-31218-004	BALL, STEEL	1	1	1	
E-21	7	HZY3-31226-003	BRUSH SET	1	1	1	
E-21	8	HZY9-31226-H01	SCREW, PAN, 6X22	2	2	2	
E-21	9	HZY9-31229-H01	STOPPER SET, SLEEVE	1	1	1	
E-21	10	HZY3-31232-003	HOLDER COMP., BRUSH	1	1	1	
E-21	11	HZY3-31235-003	BRACKET, FR.	1	1	1	
E-21	12	HZY3-31236-003	BRACKET, RR.	1	1	1	
E-21	13	HZY3-31241-003	SWITCH ASSY., MAGNET	1	1	1	
E-21	14	HP5A-31243-005	BOLT A, THROUGH	2	2	2	
E-21	15	HZY3-31243-003	SHAFT ASSY., CLUTCH	1	1	1	
E-21	16	HZY9-31246-H01	SHAFT ASSY., GEAR	1	1	1	
E-21	17	HZY3-31250-003	LEVER SET	1	1	1	
E-21	18	HZY3-31251-003	GEAR ASSY., INTERNAL	1	1	1	
E-21	19	HZVL-90003-000	BOLT, FLANGE, 10X110	1	1	1	
E-21	20	HZVL-90005-000	BOLT, FLANGE, 10X90	1	1	1	
E-21	21	HZW1-90107-004	SCREW, PAN, 5X8	2	2	2	
E-21	22	HZY3-91303-000	O-RING, 59.4X3.1	1	1	1	

F-2 SHIFT SHAFT




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-2	1	HKN5-17224-670	WASHER, AIR CLEANER COVER	2	2	2	
F-2	2	HZVL-17877-900	PLATE, REMOTE CONTROL CABLE	1	1	1	
F-2	3	HZVL-17878-900	COVER, REMOTE CONTROL CABLE	1	1	1	
F-2	4	HZY3-17931-000	ARM, THROTTLE	1	1	1	
F-2	5	HZVL-17932-900	SHAFT, THROTTLE ARM	1	1	1	
F-2	6	H921-17936-000	WASHER, PIVOT	3	3	3	
F-2	7	HZW1-24210-010	SPRING COMP., CLICK	1	1	1	
F-2	8	HZY3-24221-000	SPRING, CLICK ASSIST	1	1	1	
F-2	9	HZW1-24327-000	RING, STOPPER	1	1	1	
F-2	10	HZY3-24610-A00	SHAFT COMP., SHIFT(A)	1	1	1	
F-2	11	HZVL-24612-900	ARM, SHIFT(MECH)	1	1	1	
F-2	12	HZVL-24613-900	ROD COMP., LINK(MECH)	1	1	1	
F-2	13	HZY3-24617-000	COLLAR, SHIFT SLIDER	2	2	2	
F-2	14	HZY3-24618-000	PIVOT, SHIFT	1	1	1	
F-2	15	HZY3-24619-000	PLATE, LOCK	1	1	1	
F-2	16	HZY3-24620-000	SHAFT COMP., SHIFT(B)	1	1	1	
F-2	17	HZVL-24621-000	PIVOT, THROTTLE	1	1	1	
F-2	18	HZVL-24622-000	PLATE, LOCK	1	1	1	
F-2	19	HZY3-24623-000	BUSH, SHIFT ARM	1	1	1	
F-2	20	HZVL-24627-900	GUIDE, SHIFT LINK(MECH)	1	1	1	
F-2	21	HZVL-24628-900	BRACKET, SHIFT LINK(MECH)	1	1	1	
F-2	22	HZW1-24629-000	HOLDER, SEAL	1	1	1	
F-2	23	HZX2-35470-013	SWITCH ASSY., NEUTRAL	1	1	1	
F-2	24	HZY3-35476-010	BRACKET, NEUTRAL SWITCH	1	1	1	
F-2	25	HZVL-35477-000	COVER, NEUTRAL SWITCH	1	1	1	
F-2	26	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	1	
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14	4	4	4	
F-2	28	HZX2-90101-C00	BOLT-WASHER, 6X16	3	3	3	
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11	2	2	2	


F-2 SHIFT SHAFT




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-2	30	H881-90114-000	BOLT, HEX., 6X40	1	1	1	
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM	2	2	2	
F-2	32	HZV5-90302-003	NUT, HEX., 20MM	1	1	1	
F-2	33	HHA0-90402-000	WASHER, THRUST, 14MM	1	1	1	
F-2	34	H958-90428-000	WASHER B, THRUST, 14MM	1	1	1	
F-2	35	HZV7-90508-000	WASHER	1	1	1	
F-2	36	HZZ5-90508-M00	WASHER, PLAIN, 6MM	1	1	1	
F-2	37	HZV4-90511-000	WASHER, PLAIN, 6MM	1	1	1	
F-2	38	HZV4-90512-000	WASHER, PLAIN, 6MM	1	1	1	
F-2	39	HSD2-90705-931	PIN, SNAP, 6MM	1	1	1	
F-2	40	HZY3-90751-000	PIN, LINK	1	1	1	
F-2	41	HZY3-91152-003	RING, INNER(15X20X23)	1	1	1	
F-2	42	HZW5-91251-003	OIL SEAL, 14X26X6	1	1	1	
F-2	43	HZY3-91255-003	SEAL, WATER(14X26X8)	1	1	1	
F-2	44	HPF0-91302-003	O-RING, 26.9X2.4(NOK)	1	1	1	
F-2	45	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)	1	1	1	
F-2	46	HCO-94540-04029	E-RING, 4MM	3	3	3	
F-2	47	HCO-94540-12029	E-RING, 12MM	2	2	2	


3
1
16
8
15
20
4
F-4
10
20
21
7
17
5
12
19
18
8
22
13
2
9
21
14
6
11
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-3	1	HZW1-19286-B00	PLATE, RUBBER SETTING	1	1	1	
F-3	2	HZX2-41101-C01ZC	CASE, GEAR	1	1	1	*T107*
F-3	3	HZW1-41102-B00	GROMMET, GEAR CASE	1	1	1	
F-3	4	HZX2-41102-E00ZC	COVER, GEAR CASE	1	1	1	*T107* XCRU
F-3	5	HZY3-41104-C01	SCREEN, R. WATER	1	1	1	
F-3	6	HZY3-41105-C01	SCREEN, L. WATER	1	1	1	
F-3	7	HZX2-41107-C00ZC	TAB, TRIM	1	1	1	*T107*LRU,XRD,XRU
F-3	8	HZW1-41109-B00	METAL COMP., ANODE	2	2	2	
F-3	9	HZX2-41110-305ZB	CASE COMP., GEAR	1	1	1	*T107*
F-3	10	HZW9-90101-003	BOLT, OIL CHECK	1	1	1	
F-3	11	HZZ0-90101-000	SCREW, FLAT, 5X55	1	1	1	
F-3	12	HZY6-90103-000	BOLT-WASHER, 10X32	1	1	1	
F-3	13	HZX2-90107-C00	BOLT-WASHER, 10X47	6	6	6	
F-3	14	HZY3-90120-000	BOLT, DRAIN PLUG	1	1	1	
F-3	15	HZY3-90124-000	BOLT, STUD, 12X40	1	1	1	
F-3	16	HZY1-90205-000	NUT, SELF-LOCK, 6MM	1	1	1	
F-3	17	HZV4-90302-000	NUT, SELF-LOCK, 5MM	1	1	1	
F-3	18	HZW1-90308-003	NUT, SELF-LOCK, 12MM	1	1	1	
F-3	19	HZV5-90559-000	WASHER, PLAIN, 12MM	1	1	1	
F-3	20	HZV5-90756-000	DOWEL PIN, 6X10	2	2	2	
F-3	21	HZW4-91301-003	O-RING, 6.9X1.45	2	2	2	
F-3	22	HCO-92101-06055-4J	BOLT, HEX., 6X55	1	1	1	


1
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-3-10	1	HZVL-41100-700ZA	CASE ASSY., GEAR(XL)	1	1	1	*T107* XRD,XRU
F-3-10	1	HZVL-41100-000ZA	CASE ASSY., GEAR(XL)	1	1	1	*T107* XRD,XRU
F-3-10	1	HZVL-41100-900ZA	CASE ASSY., GEAR(L)	1	-	-	*T107* LRU


12
E-6-10
11
10
26
53
26
17
28
25
32
36
53
49
49
26
25
29
29
28
49
53
53
29
25
53
25
29
25
43
53
50
25
E-6-10
3
30
25
50
4
31
50
5
2
47
E-6-10
1
7
13
16
54
35
52
30
30
33
9
8
41
7
27
41
34
54
7
41
14
6
41
38
41
41
42
15
51
51
20
37
39
55
22
19
18
23
44
24
F-10
22
55
37
21
46
45
48
40
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-3-20	1	HGHB-16075-830	O-RING, 1.9X10	1	1	1	
F-3-20	2	HZY3-19270-000	NUT, WATER MOUTH	1	1	1	
F-3-20	3	HZY3-19271-000	JOINT, WATER HOSE	1	1	1	
F-3-20	4	HZY3-19272-000	SEAT, WATER MOUTH	1	1	1	
F-3-20	5	HZVL-19274-000	SEAT, WATER JOINT	1	1	1	
F-3-20	6	HZY3-19289-000	CAP, WATER JOINT	1	1	1	
F-3-20	7	HZY3-23173-010	RUBBER, MOUNT CASE SEAL	3	3	3	
F-3-20	8	HZY3-35640-013	SWITCH ASSY., POWER TILT	1	1	1	
F-3-20	9	HZY9-35645-000	STAY, POWER TILT SWITCH	1	1	1	
F-3-20	10	HZVL-40100-000	CASE ASSY., ENGINE UNDER	1	1	1	
F-3-20	11	HZVL-40102-000	SEAL A, UNDER CASE	1	1	1	
F-3-20	12	HZVL-40103-000	SEAL B, UNDER CASE	1	1	1	
F-3-20	13	HZVL-40105-900	GROMMET, UNDER CASE(MECH)	1	1	1	
F-3-20	14	HZVL-40110-000	STAY COMP., HARNESS	1	1	1	
F-3-20	15	HZVL-40116-000	PORT, IDLE EXHAUST	1	1	1	
F-3-20	16	HZVL-40151-000	COVER, SEPARATE	1	1	1	
F-3-20	17	HZVL-40154-000	BRACKET, UNDER CASE FR.	1	1	1	
F-3-20	18	HZVL-40201-000	CASE, EXTENSION(XL)	1	1	1	XCRU,XRD,XRU
F-3-20	19	HZVL-40201-900	CASE, EXTENSION(L)	1	–	–	LRU
F-3-20	20	HZVL-40209-000	RUBBER, DRAIN PLUG	1	1	1	
F-3-20	21	HZY3-40210-610	BUSH COMP., VERTICAL SHAFT	1	1	1	XCRU,XRD,XRU
F-3-20	22	HZY3-50111-020	HOUSING, LOWER MOUNTING	2	2	2	
F-3-20	23	HZY3-50155-000	MOUNT COMP., LOWER RUBBER	2	2	2	
F-3-20	24	HZY3-50157-010	STOPPER, LOWER MOUNT	2	2	2	
F-3-20	25	H121-51640-730	RUBBER, FR. CARRIER CUSHION	6	6	6	
F-3-20	26	HZVL-63119-000	SPRING, LEVER RETURN	3	3	3	
F-3-20	27	HZVL-63210-000	LEVER, COVER LOCK FR.	1	1	1	
F-3-20	28	HZVL-63212-000	HOOK COMP., COVER LOCK R.	2	2	2	
F-3-20	29	HZVL-63213-000	COLLAR A, COVER LOCK	3	3	3	


12
E-6-10
11
10
26
53
26
17
28
25
32
36
53
49
49
26
25
29
29
28
49
53
53
29
25
53
25
29
25
43
53
50
25
E-6-10
3
30
25
50
4
31
50
5
2
47
E-6-10
1
7
13
16
54
35
52
30
30
33
9
8
41
7
27
41
34
54
7
41
14
6
41
38
41
41
42
15
51
51
20
37
39
55
22
19
18
23
44
24
F-10
22
55
37
21
46
45
48
40
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-3-20	30	HZVL-63214-000	COLLAR B, COVER LOCK	3	3	3	
F-3-20	31	HZVL-63220-000	LEVER, COVER LOCK R.	1	1	1	
F-3-20	32	HZVL-63222-000	HOOK COMP., COVER LOCK L.	1	1	1	
F-3-20	33	HZVL-63230-000	LEVER, COVER LOCK L.	1	1	1	
F-3-20	34	HZC0-63515-700	CAP, L. SIDE COVER	1	1	1	
F-3-20	35	HZVL-82873-000	GROMMET, WATER CHECK	1	1	1	
F-3-20	36	HZZ5-90051-M00	BOLT, FLANGE, 8X18	2	2	2	
F-3-20	37	HZVL-90102-000	BOLT-WASHER, 10X35	6	6	6	
F-3-20	38	HZW9-90102-000	BOLT, FLANGE, 6X12	1	1	1	
F-3-20	39	HZVL-90103-000	BOLT-WASHER, 12X50	11	11	11	
F-3-20	40	HZY3-90105-010	BOLT, HEX., 14X180	2	2	2	
F-3-20	41	HZVL-90107-000	BOLT-WASHER, 8X35	6	6	6	
F-3-20	42	HZVL-90109-000	BOLT, FLANGE, 6X25	2	2	2	
F-3-20	43	H921-90302-000	NUT, HEX., 16MM	1	1	1	
F-3-20	44	HZY3-90302-000	NUT, SELF-LOCK, 14MM	2	2	2	
F-3-20	45	HZY3-90503-610	WASHER, 30MM	1	1	1	XCRU,XRD,XRU
F-3-20	46	HZY3-90511-000	WASHER, PLAIN, 14MM	2	2	2	
F-3-20	47	HZV4-90605-000	CLIP, TUBE(B12.5)	1	1	1	
F-3-20	48	HZY3-90652-000	CIRCLIP, INTERNAL, 43	1	1	1	XCRU,XRD,XRU
F-3-20	49	HZVL-90751-000	PIN, SPRING, 6X22	3	3	3	
F-3-20	50	HZVL-90752-000	PIN, LOCK SPRING	3	3	3	
F-3-20	51	HZV5-90756-000	DOWEL PIN, 6X10	2	2	2	
F-3-20	52	HZVL-91451-000	TUBE, WATER JOINT	1	1	1	
F-3-20	53	HZY9-91504-M00	COLLAR, 8.5X14.5	6	6	6	
F-3-20	54	HZZ0-91601-M00	GROMMET, 1WAY	2	2	2	
F-3-20	55	HC0-95011-63000	RUBBER C, STAND STOPPER	2	2	2	


10
2
8
9
11
1
4
9
9
3
10
8
7
10
8
2
11
1
10
8
11
1
5
9
11
1
9
9
9
2
9
9
10
8
11
1
9
2
6
9
9
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-3-30	1	HZV5-40102-000	GROMMET, UNDER CASE	5	5	5	
F-3-30	2	H196-47117-000	RUBBER, STOPPER	2	2	2	
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R.	1	1	1	*T107* XCRU,XRD,XRU
F-3-30	4	HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R.	1	–	–	*T107* LRU
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L.	1	1	1	*T107* XCRU,XRD,XRU
F-3-30	6	HZVL-63715-900ZA	COVER COMP., ENGINE UNDER L.	1	–	–	*T107* LRU
F-3-30	7	HZVL-63721-000	COVER, RR.	1	1	1	
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25	5	5	5	
F-3-30	9	HZY3-90111-000	BOLT, SPECIAL, 6X17	14	14	14	XCRU,XRD,XRU
F-3-30	9	HZY3-90111-000	BOLT, SPECIAL, 6X17	12	–	–	LRU
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM	5	5	5	
F-3-30	11	HZVL-91551-000	COLLAR, 12X6.5	5	5	5	


28
28
12
29
10
21
35
11
9
17
17
33
8
17
33
17
2
33
33
30
3
1
23
4
5
24
18
6
24
31
32
27
27
19
26
22
7
15
25
34
16
14
13
20
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-4	1	HZY3-19210-003	IMPELLER, PUMP	1	1	1	
F-4	2	HZY3-19221-010	HOUSING, IMPELLER	1	1	1	
F-4	3	HZY3-19223-000	LINER, PUMP	1	1	1	
F-4	4	HZY3-19231-000	COVER, IMPELLER	1	1	1	
F-4	5	HZX2-19234-C00	GASKET B, IMPELLER	1	1	1	
F-4	6	HZVL-19241-000	HOUSING, WATER PUMP	1	1	1	
F-4	7	HZY3-19251-611	TUBE, WATER(XL)	1	1	1	XCRU,XRD,XRU
F-4	7	HZY3-19251-000	TUBE, WATER(L)	1	–	–	LRU
F-4	8	HZY3-19253-000	RING, WATER TUBE SEAL	1	1	1	
F-4	9	HZY3-24310-C00	ROD COMP., SHIFT	1	1	1	LRU,XRD,XRU
F-4	9	HZY3-24310-E00	ROD COMP., SHIFT	1	1	1	XCRU
F-4	10	HZY3-24318-000	SPRING, SHIFT ROD	1	1	1	
F-4	11	HZY6-24320-610	ROD COMP. A, SHIFT(XL)	1	1	1	XCRU,XRD,XRU
F-4	11	HZY6-24320-000	ROD COMP. A, SHIFT(L)	1	–	–	LRU
F-4	12	HZW1-24343-B02	HOLDER, SHIFT ROD	1	1	1	
F-4	13	HZY3-40204-000	GROMMET, EXTENSION CASE	1	1	1	
F-4	14	HZX2-41112-C10	SHAFT, VERTICAL(XL)	1	1	1	XCRU,XRD,XRU
F-4	14	HZX2-41112-C00	SHAFT, VERTICAL(L)	1	–	–	LRU
F-4	15	HZY3-41116-000	SLINGER, OIL	1	1	1	
F-4	16	HZX2-41131-C00	GEAR, PINION	1	1	1	LRU,XRD,XRU
F-4	16	HZX2-41131-E00	GEAR, PINION(COUNTER ROTATION)	1	1	1	XCRU
F-4	17	HZX2-90105-C00	BOLT-WASHER, 8X60	4	4	4	
F-4	18	HHW1-90215-671	BOLT, FLANGE, 6X16	1	1	1	
F-4	19	HZX2-90301-C00	NUT, LOCK, 68MM	1	1	1	
F-4	20	HZX2-90303-C00	NUT, HEX., 18MM	1	1	1	
F-4	21	H723-90472-000	WASHER, PLAIN, 12MM	1	1	1	
F-4	22	HZX2-90518-C00	SHIM A, GEAR(0.10)	1	1	1	
F-4	22	HZX2-90519-C00	SHIM B, GEAR(0.15)	1	1	1	
F-4	22	HZX2-90520-C00	SHIM C, GEAR(0.30)	1	1	1	


28
28
12
29
10
21
35
11
9
17
17
33
8
17
33
17
2
33
33
30
3
1
23
4
5
24
18
6
24
31
32
27
27
19
26
22
7
15
25
34
16
14
13
20
FR.

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-4	22	HZX2-90521-C00	SHIM D, GEAR(0.50)	1	1	1	
F-4	23	HZY3-90752-003	KEY, WOODRUFF	1	1	1	
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10	2	2	2	
F-4	25	HZX2-91053-C01	BEARING, NEEDLE, 30.5X47X37	1	1	1	
F-4	26	HZX2-91056-C01	BEARING, TAPER ROLLER,	1	1	1	
F-4	27	HZY3-91251-C01	SEAL, WATER, 26X42X7	2	2	2	
F-4	28	HZY3-91254-003	SEAL, WATER, 12X21X6	2	2	2	
F-4	29	HMJ0-91308-003	O-RING	1	1	1	
F-4	30	HZY3-91356-003	O-RING, WATER PUMP	1	1	1	
F-4	31	HZX2-91358-C00	O-RING, WATER PUMP HOUSING	1	1	1	
F-4	32	HZX2-91359-C00	O-RING, 65.4X2.4	1	1	1	
F-4	33	HZY3-91551-000	COLLAR, DISTANCE	4	4	4	
F-4	34	HCO-94520-47000	CIRCLIP, INTERNAL, 47MM	1	1	1	
F-4	35	HCO-94540-10019	E-RING, 10MM	1	1	1	



32
4
3
28
1
33
8
7
6
5
19
6
33
32
31
26
21
24
18
23
16
10
2
12
18
25
9
22
15
17
29
13
20
27
14
29
11
30
13
20
FR.

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-5	1	HZX2-24101-C00	SHIFTER, CLUTCH	1	1	1	LRU,XRD,XRU
F-5	2	HZY3-24102-000	PIN, SHIFTER, 8X50	1	1	1	LRU,XRD,XRU
F-5	3	HZY3-24103-000	RING, CROSS PIN	1	1	1	LRU,XRD,XRU
F-5	4	HZY3-24113-A01	SLIDER COMP., SHIFT	1	1	1	LRU,XRD,XRU
F-5	5	HZY3-24122-A01	SLIDER, SHIFT	1	1	1	LRU,XRD,XRU
F-5	6	HZY3-24123-000	SPRING, SHIFT	2	2	2	LRU,XRD,XRU
F-5	7	HZY3-24124-310	PLATE, SHIFT	1	1	1	LRU,XRD,XRU
F-5	8	HZX2-41140-C00	GEAR COMP., BEVEL(FORWARD)	1	1	1	LRU,XRD,XRU
F-5	9	HZX2-41151-C00	GEAR, BEVEL(REVERSE)(24T)	1	1	1	LRU,XRD,XRU
F-5	10	HZX2-41161-C00	SHAFT, PROPELLER	1	1	1	LRU,XRD,XRU
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT	1	1	1	*T107* LRU,XRD,XRU
F-5	12	HZX2-41202-C00	HOLDER, BEARING	1	1	1	LRU,XRD,XRU
F-5	13	HZY3-90123-000	BOLT, HEX., 12X45	2	2	2	LRU,XRD,XRU
F-5	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	1	LRU,XRD,XRU
F-5	15	HZX2-90506-C00	WASHER, PROPELLER THRUST	1	1	1	LRU,XRD,XRU
F-5	16	HZW5-90509-711	WASHER, THRUST BEARING	1	1	1	LRU,XRD,XRU
F-5	17	HZX2-90512-C00	WASHER, PROPELLER	1	1	1	LRU,XRD,XRU
F-5	18	HZX2-90528-C00	SHIM A, BEVEL(0.10)	2	2	2	LRU,XRD,XRU
F-5	18	HZX2-90529-C00	SHIM B, BEVEL(0.15)	2	2	2	LRU,XRD,XRU
F-5	18	HZX2-90530-C00	SHIM C, BEVEL(0.30)	2	2	2	LRU,XRD,XRU
F-5	18	HZX2-90531-C00	SHIM D, BEVEL(0.50)	2	2	2	LRU,XRD,XRU
F-5	19	HZY3-90548-000	SHIM A, THRUST(2.75)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90549-000	SHIM B, THRUST(2.80)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90550-000	SHIM C, THRUST(2.85)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90551-000	SHIM D, THRUST(2.90)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90552-000	SHIM E, THRUST(2.95)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90553-000	SHIM F, THRUST(3.00)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90554-000	SHIM G, THRUST(3.05)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90555-000	SHIM H, THRUST(3.10)	1	1	1	LRU,XRD,XRU


32
4
3
28
1
33
8
7
6
5
19
6
33
32
31
26
21
24
18
23
16
10
2
12
18
25
9
22
15
17
29
13
20
27
14
29
11
30
13
20
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-5	19	HZY3-90556-000	SHIM I, THRUST(2.70)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90557-000	SHIM J, THRUST(2.65)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90558-000	SHIM K, THRUST(2.60)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90559-000	SHIM L, THRUST(2.55)	1	1	1	LRU,XRD,XRU
F-5	19	HZY3-90560-000	SHIM M, THRUST(2.50)	1	1	1	LRU,XRD,XRU
F-5	20	HZV5-90559-000	WASHER, PLAIN, 12MM	2	2	2	LRU,XRD,XRU
F-5	21	HZX2-90651-C00	RING, SETTING(39)	1	1	1	LRU,XRD,XRU
F-5	22	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	1	LRU,XRD,XRU
F-5	23	HPT2-91005-N01	BEARING, THRUST(F)	1	1	1	LRU,XRD,XRU
F-5	24	HZX2-91051-C01	BEARING, TAPER ROLLER,	1	1	1	LRU,XRD,XRU
F-5	25	HZX2-91055-C01	BEARING, RADIAL BALL,	1	1	1	LRU,XRD,XRU
F-5	26	HZY3-91056-711	BEARING, NEEDLE, 28X39X30	1	1	1	LRU,XRD,XRU
F-5	27	HZY3-91057-003	BEARING, NEEDLE, 32X42X30	1	1	1	LRU,XRD,XRU
F-5	28	HZY3-91151-000	ROLLER, 3X13.8	1	1	1	LRU,XRD,XRU
F-5	29	HZZ3-91252-003	SEAL, WATER, 30X45X7	2	2	2	LRU,XRD,XRU
F-5	30	HZX2-91351-C00	O-RING, 121X3.1	1	1	1	LRU,XRD,XRU
F-5	31	HCO-94510-15000	CIRCLIP, EXTERNAL, 15MM	1	1	1	LRU,XRD,XRU
F-5	32	HCO-96211-07000	BALL, STEEL, #7(7/32)	2	2	2	LRU,XRD,XRU
F-5	33	HCO-96211-12000	BALL, STEEL, #12(3/8)	2	2	2	LRU,XRD,XRU

F-5-1 PROPELLER SHAFT
(COUNTER ROTATION)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-5-1	1	HZX2-24101-C00	SHIFTER, CLUTCH	1	1	1	XCRU
F-5-1	2	HZY3-24102-000	PIN, SHIFTER, 8X50	1	1	1	XCRU
F-5-1	3	HZY3-24103-000	RING, CROSS PIN	1	1	1	XCRU
F-5-1	4	HZY3-24113-A01	SLIDER COMP., SHIFT	1	1	1	XCRU
F-5-1	5	HZY3-24122-A01	SLIDER, SHIFT	1	1	1	XCRU
F-5-1	6	HZY3-24123-000	SPRING, SHIFT	2	2	2	XCRU
F-5-1	7	HZY3-24124-310	PLATE, SHIFT	1	1	1	XCRU
F-5-1	8	HZX2-41141-E00	GEAR, BEVEL(FORWARD)(24T)	1	1	1	XCRU
F-5-1	9	HZX2-41150-E00	GEAR COMP., BEVEL(REVERSE)	1	1	1	XCRU
F-5-1	10	HZX2-41161-E00	SHAFT, PROPELLER	1	1	1	XCRU
F-5-1	11	HZX2-41200-E00	HOLDER ASSY., BEARING	1	1	1	XCRU
F-5-1	12	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT	1	1	1	*T107* XCRU
F-5-1	13	HZY3-90123-000	BOLT, HEX., 12X45	2	2	2	XCRU
F-5-1	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	1	XCRU
F-5-1	15	HZX2-90506-C00	WASHER, PROPELLER THRUST	1	1	1	XCRU
F-5-1	16	HZW5-90509-711	WASHER, THRUST BEARING	1	1	1	XCRU
F-5-1	17	HZX2-90512-C00	WASHER, PROPELLER	1	1	1	XCRU
F-5-1	18	HZX2-90528-C00	SHIM A, BEVEL(0.10)	1	1	1	XCRU
F-5-1	18	HZX2-90529-C00	SHIM B, BEVEL(0.15)	1	1	1	XCRU
F-5-1	18	HZX2-90530-C00	SHIM C, BEVEL(0.30)	1	1	1	XCRU
F-5-1	18	HZX2-90531-C00	SHIM D, BEVEL(0.50)	1	1	1	XCRU
F-5-1	19	HZX2-90528-E00	SHIM A, BEVEL(0.10)	1	1	1	XCRU
F-5-1	19	HZX2-90529-E00	SHIM B, BEVEL(0.15)	1	1	1	XCRU
F-5-1	19	HZX2-90530-E00	SHIM C, BEVEL(0.30)	1	1	1	XCRU
F-5-1	19	HZX2-90531-E00	SHIM D, BEVEL(0.50)	1	1	1	XCRU
F-5-1	20	HZX2-90541-E01	WASHER, THRUST, 85X110X2	1	1	1	XCRU
F-5-1	21	HZX2-90542-E01	WASHER, THRUST, 48X74X3	1	1	1	XCRU
F-5-1	22	HZV5-90559-000	WASHER, PLAIN, 12MM	2	2	2	XCRU
F-5-1	23	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	1	XCRU

F-5-1 PROPELLER SHAFT
(COUNTER ROTATION)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-5-1	24	HPT2-91005-N01	BEARING, THRUST(F)	1	1	1	XCRU
F-5-1	25	HPG4-91033-013	BEARING, NEEDLE, 50X72X4.5	1	1	1	XCRU
F-5-1	26	HZX2-91054-E01	BEARING, THRUST NEEDLE,	1	1	1	XCRU
F-5-1	27	HZX2-91055-C01	BEARING, RADIAL BALL,	1	1	1	XCRU
F-5-1	28	HZY3-91056-711	BEARING, NEEDLE, 28X39X30	1	1	1	XCRU
F-5-1	29	HZY3-91057-003	BEARING, NEEDLE, 32X42X30	1	1	1	XCRU
F-5-1	30	HZY3-91151-000	ROLLER, 3X13.8	1	1	1	XCRU
F-5-1	31	HZZ3-91252-003	SEAL, WATER, 30X45X7	2	2	2	XCRU
F-5-1	32	HZX2-91351-C00	O-RING, 121X3.1	1	1	1	XCRU
F-5-1	33	HCO-94510-15000	CIRCLIP, EXTERNAL, 15MM	1	1	1	XCRU
F-5-1	34	HCO-96211-07000	BALL, STEEL, #7(7/32)	2	2	2	XCRU
F-5-1	35	HCO-96211-12000	BALL, STEEL, #12(3/8)	2	2	2	XCRU


F-6 FUEL TUBE




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-6	1	3T1-70200-1	PRIMER BULB ASSY	1	1	1	
F-6							
F-6	2	3C7-70220-1	* JOINT ASSY (INLET)	1	1	1	
F-6	3	3C7-70224-1	* JOINT ASSY (OUTLET)	1	1	1	
F-6	4	3C7-70211-1	* PRIMER BULB	1	1	1	
F-6							
F-6	5	3C7-70217-0	* CLAMP	2	2	2	
F-6	6	98AB-70-700	* HOSE	1	1	1	98AB-701000
F-6							
F-6	7	98AB-701600	* HOSE	1	1	1	98AB-701000×2
F-6							
F-6	8	332-70201-0	* CLAMP	2	2	2	


FR.
7
9
4
6
2
8
3
1
5


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-7	1	HZVJ-32100-900	HARNESS ASSY., MAIN WIRE	1	-	-	
F-7	1	HZVL-32100-900	HARNESS ASSY., MAIN WIRE	-	1	1	
F-7	2	HZVL-32106-000	BRACKET, JUNCTION CONNECTOR	1	1	1	
F-7	3	HZVL-32108-003	DUMMY, WATER PROOF CONNECTOR	1	1	1	
F-7	4	HZZ3-32127-000	SUSPENSION, COUPLER	1	1	1	
F-7	5	HK44-32606-V01	CAP, DUMMY(WPC 4P 090 M)(RED)	1	1	1	
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1	1	1	
F-7	7	HZZ5-90105-M00	BOLT, FLANGE, 6X12	2	2	2	
F-7	8	HZY3-90653-003	CLIP, WIRE HARNESS	3	3	3	
F-7	9	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)	12	13	13	


25
1
12
25
1
14
2
24
11
15
2
15
13
14
26
10
16
22
23
15
23
8



19
5
9
5
7
16
16
6
18
20
18
17
16
26
3
21
4


FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-7-10	1	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	3	3	3	
F-7-10	2	HZVL-32103-000	BRACKET, COUPLER C	2	2	2	
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER	1	1	1	
F-7-10	4	HZY3-32411-003	COVER, STARTER TERMINAL	1	1	1	
F-7-10	5	HZX2-32414-300	COVER B, TERMINAL(L)	2	2	2	
F-7-10	6	HZY6-32414-640	COVER B, TERMINAL	1	1	1	
F-7-10	7	HZX2-32415-000	CABLE ASSY., POWER TILT RELAY	1	1	1	
F-7-10	8	HZVL-32421-000	PLATE, STARTER CABLE	1	1	1	
F-7-10	9	HZX2-32435-000	CORD, A.C. GENERATOR	1	1	1	
F-7-10	10	HZVL-38550-003	RELAY ASSY., POWER TILT	1	1	1	
F-7-10	11	HZW1-38551-000	GROMMET, RELAY	2	2	2	
F-7-10	12	HZX2-38552-000	CASE, POWER TILT RELAY	1	1	1	
F-7-10	13	HZZ5-90013-M00	BOLT-WASHER, 6X25	2	2	2	
F-7-10	14	HZVL-90015-000	BOLT-WASHER, 6X27	3	3	3	
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10	3	3	3	
F-7-10	16	HZZ5-90105-M00	BOLT, FLANGE, 6X12	4	4	4	
F-7-10	17	HZY3-90107-000	BOLT, FLANGE, 8X18	1	1	1	
F-7-10	18	HZW1-90203-000	NUT-WASHER, 8MM	2	2	2	
F-7-10	19	HZY3-90304-000	NUT-WASHER, 6MM	1	1	1	
F-7-10	20	HZY3-90405-000	WASHER, PLAIN, 8MM	1	1	1	
F-7-10	21	HKV6-90651-003	BAND, WIRE, 165MM(BLACK)	1	1	1	
F-7-10	22	H763-90681-A01	CLIP, WIRE HARNESS	1	1	1	
F-7-10	23	HZX2-90683-003	CLIP, WIRE HARNESS	2	2	2	
F-7-10	24	HZZ5-91501-000	COLLAR, MOUNTING(6MM)	2	2	2	
F-7-10	25	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	3	3	3	
F-7-10	26	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)	3	3	3	


E-20-10
7
1
3
8
10
9
11
5
6
9
10
11
3
2
6
4
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-7-20	1	HZY3-32370-H01	BOX ASSY., JUNCTION	1	1	1	
F-7-20	2	HZY3-32371-H01	COVER COMP., FUSE	1	1	1	
F-7-20	3	HZX2-38228-003	FUSE, BLOCK(150A)	2	2	2	
F-7-20	4	HZY6-38235-004	PULLER, MINI FUSE	1	1	1	
F-7-20	5	HSDA-39794-004	RELAY ASSY., FUEL PUMP(DENSO)	1	1	1	
F-7-20	6	HZY6-39794-003	RELAY ASSY., POWER(12V-20A)	2	2	2	
F-7-20	7	HZZ5-90018-M00	BOLT, FLANGE, 6X20	4	4	4	
F-7-20	8	HZY6-90135-004	SCREW-WASHER, 5X15	2	2	2	
F-7-20	9	HCO-98200-41000	FUSE, MINI(10A)	5	5	5	
F-7-20	10	HCO-98200-41500	FUSE, MINI(15A)	6	6	6	
F-7-20	11	HCO-98200-43000	FUSE, MINI(30A)	3	3	3	


1
8
11
11
5
8
11
10
9
7
3
4
7
4
10
2
11
8
9
3
8
11
6
9
11
10
4
7
3
11
8
11
8
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-8	1	HZVL-63100-P00ZA	COVER ASSY., ENGINE	1	1	1	*T107*
F-8	2	HZVL-63107-000	BRACKET, HOOK FR.	1	1	1	
F-8	3	HZVL-63108-000	GROMMET, LOCK HOOK	3	3	3	
F-8	4	HZVL-63109-000	ROLLER, HOOK	3	3	3	
F-8	5	HZVL-63112-000	BRACKET, HOOK R.	1	1	1	
F-8	6	HZVL-63117-000	BRACKET, HOOK L.	1	1	1	
F-8	7	HZVL-90101-000	BOLT, SOCKET, 6X25	3	3	3	
F-8	8	HZX1-90101-R00	BOLT, SOCKET, 6X20	6	6	6	
F-8	9	HZY1-90205-000	NUT, SELF-LOCK, 6MM	3	3	3	
F-8	10	HZV4-90506-000	WASHER, PLAIN, 6MM	3	3	3	
F-8	11	HZY3-91556-000	COLLAR, DISTANCE, 6.5X9X3	8	8	8	


FR.
10
6
79
77
35
78
18
6
12
11
40
40
40
50
14
50
15
16
59
15
13
16
59
41
41
24
23
72
67
7
27
75
73
72
58
44
34
26
43
57
21
20
54
76
22
76
8
30
28
37
5
29
38
68
37
45
4
71
2
62
65
21
46
49
57
63
56
33
62
65
70
63
63
49
56
33
28
30
53
53
25
60
51
31
64
74
19
31
32
32
74
65
65
48
20
42
69
55
52
61
F-11
36
1
36
F-3-20
47
17
9
39
66


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-10	1	HZW1-06411-020	METAL KIT, ANODE	1	1	1	
F-10	2	HZY3-06532-U00	ROD KIT, STEERING	1	1	1	
F-10	3	H747-16731-003	CLIP, TUBE	1	1	1	
F-10	4	HZV1-24210-010	SPRING COMP., CLICK	1	1	1	
F-10	5	HZV4-24221-010	SPRING, CLICK ASSIST	1	1	1	
F-10	6	HKM3-32161-003	BAND, WIRE	2	2	2	
F-10	7	HZY3-35660-003	SENSOR ASSY., TRIM ANGLE	1	1	1	
F-10	8	HZZ3-35745-743	SWITCH ASSY., TILT LIMIT	1	1	1	
F-10	9	HZY3-40219-023	WIRE, LEAD(1.5X116MM)	1	1	1	
F-10	10	HZV5-41171-000	END, NIPPLE	1	1	1	
F-10	11	HZV5-41172-000	NIPPLE, SENSOR	1	1	1	
F-10	12	HZV5-41172-000	NIPPLE, SENSOR	1	1	1	
F-10	13	HZVL-50100-000	FRAME COMP., MOUNTING(XL)	1	1	1	XCRU,XRD,XRU
F-10	13	HZVL-50100-900	FRAME COMP., MOUNTING(L)	1	–	–	LRU
F-10	14	HZVL-50109-000	HOUSING, UPPER MOUNTING	1	1	1	
F-10	15	HZY3-50151-000	MOUNT COMP., UPPER RUBBER	2	2	2	
F-10	16	HZY3-50153-000	RUBBER, UPPER MOUNT STOPPER	2	2	2	
F-10	17	HZY3-50161-610	HOUSING, LOWER CENTER MOUNTING	1	1	1	XCRU,XRD,XRU
F-10	17	HZY3-50161-000ZD	HOUSING, LOWER CENTER MOUNTING	1	–	–	*T107* LRU
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT	1	1	1	
F-10	19	HZVL-50201-000ZA	CASE, SWIVEL(XL)	1	1	1	*T107* XCRU,XRD,XRU
F-10	19	HZVL-50201-900ZA	CASE, SWIVEL(L)	1	–	–	*T107*LRU
F-10	20	HZY3-50211-000	LINER, SWIVEL CASE	2	2	2	
F-10	21	HZY3-50214-000	BUSH, SWIVEL CASE	2	2	2	
F-10	22	HZVL-50222-000	BRACKET, TILT LIMIT SWITCH	1	1	1	
F-10	23	HZZ3-50223-000	CAM A, TILT LIMIT ANGLE	1	1	1	
F-10	24	HZZ3-50224-000	CAM B, TILT LIMIT ANGLE	1	1	1	
F-10	25	HZY3-50301-030ZC	BRACKET, R. STERN	1	1	1	*T107*
F-10	26	HZVL-50311-000ZA	BRACKET, L. STERN	1	1	1	*T107*


FR.
10
6
79
77
35
78
18
6
12
11
40
40
40
50
14
50
15
16
59
15
13
16
59
41
41
24
23
72
67
7
27
75
73
72
58
44
34
26
43
57
21
20
54
76
22
76
8
30
28
37
5
29
38
68
37
45
4
71
2
62
65
21
46
49
57
63
56
33
62
65
70
63
63
49
56
33
28
30
53
53
25
60
51
31
64
74
19
31
32
32
74
65
65
48
20
42
69
55
61
52
F-11
36
1
36
F-3-20
47
17
9
39
66


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-10	27	HZVL-50381-000	SHAFT, TILTING	1	1	1	
F-10	28	HZY3-50522-000	BUSH, TILT ARM	2	2	2	
F-10	29	HZY3-50527-000	BRACKET, TILTING	1	1	1	
F-10	30	HZVL-50529-000	STOPPER, TILT	2	2	2	
F-10	31	HZY3-56516-A00	RECEIVER, THRUST	2	2	2	
F-10	32	HZY3-56518-A00	BUSH A, THRUST RECEIVE	2	2	2	
F-10	33	HZY3-56519-A00	BUSH B, THRUST RECEIVE	2	2	2	
F-10	34	HZVL-56539-000	SHAFT, LOWER CYLINDER	1	1	1	
F-10	35	HZW9-90005-010	BOLT, FLANGE, 6X20	7	7	7	
F-10	36	HZW9-90009-000	BOLT, FLANGE, 6X23	2	2	2	
F-10	37	HZW1-90102-000	BOLT, 1/4-28UNF	2	2	2	
F-10	38	HZW9-90102-000	BOLT, FLANGE, 6X12	1	1	1	
F-10	39	HZW9-90103-010	BOLT, FLANGE, 6X12	1	1	1	
F-10	40	HZY6-90103-000	BOLT-WASHER, 10X32	3	3	3	
F-10	41	HZY3-90104-010	BOLT, HEX., 12X200	2	2	2	
F-10	42	HZVL-90105-000	BOLT, STUD, 10X28	1	1	1	
F-10	43	HZW9-90105-000	BOLT, FLANGE, 6X20	2	2	2	
F-10	44	HZY3-90106-A00	BOLT, FLANGE, 8X22	1	1	1	
F-10	45	H881-90110-000	BOLT, HEX., 6X14	1	1	1	
F-10	46	HZY3-90117-000	BOLT, 3/8-24UNF	1	1	1	
F-10	47	HZV5-90119-000	SCREW, PAN, 6X8	1	1	1	
F-10	48	HZX2-90129-000	BOLT, HEX., 12X130	6	6	6	
F-10	49	HZY1-90205-000	NUT, SELF-LOCK, 6MM	2	2	2	
F-10	50	HZW5-90302-003	NUT, FLANGE, 12MM	2	2	2	
F-10	51	HZV5-90304-013	NUT, SELF-LOCK(7/8-14UNF)	1	1	1	
F-10	52	HZW4-90306-003	NUT, FLANGE, 10MM	1	1	1	
F-10	53	HZV5-90307-003	NUT, SELF-LOCK(3/8-24UNF)	2	2	2	
F-10	54	HZW4-90401-000	WASHER, PLAIN, 4MM	1	1	1	
F-10	55	HZV5-90501-000	WASHER, WAVE, 40MM	1	1	1	


FR.
10
6
79
77
35
78
6
18
12
11
40
40
40
50
14
50
15
16
59
15
13
16
59
41
41
24
23
72
67
7
27
75
73
72
58
44
34
26
43
57
21
20
54
76
22
76
8
30
28
37
5
29
38
68
37
45
4
71
2
62
65
21
46
49
57
63
56
33
62
65
70
63
63
49
56
33
28
30
53
53
25
60
51
31
64
74
19
31
32
32
74
65
65
48
20
42
69
55
61
52
F-11
36
1
36
F-3-20
47
17
9
39
66


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-10	56	HZY3-90501-A00	WASHER, WAVE, 12MM	2	2	2	
F-10	57	HZV5-90502-000	WASHER, WAVE, 26MM	2	2	2	
F-10	58	HZV5-90504-000	WASHER, THRUST, 34MM	1	1	1	
F-10	59	HZX2-90504-C00	WASHER, UPPER MOUNTING STOPPER	2	2	2	
F-10	60	HZY3-90509-000	WASHER, 7/8"	1	1	1	
F-10	61	H921-90511-000	WASHER, PLAIN, 10MM	1	1	1	
F-10	62	HZV4-90512-000	WASHER, PLAIN, 6MM	2	2	2	
F-10	63	HZV4-90514-000	WASHER, 10MM	3	3	3	
F-10	64	HZV5-90552-000	WASHER, PLAIN, 12MM	6	6	6	
F-10	65	HZV5-90559-000	WASHER, PLAIN, 12MM	14	14	14	
F-10	66	HZV5-90651-000	CIRCLIP, EXTERNAL, 39MM	1	1	1	
F-10	67	H763-90681-A01	CLIP, WIRE HARNESS	1	1	1	
F-10	68	HZV7-90951-010	NIPPLE, GREASE	6	6	6	
F-10	69	HZV5-91256-003	OIL SEAL, 39.5X52X6(ARAI)	1	1	1	
F-10	70	HZY3-91560-000	COLLAR, STEERING ROD	1	1	1	
F-10	71	HCO-93500-04014-4J	SCREW, PAN, 4X14	1	1	1	
F-10	72	HCO-93500-05020-4J	SCREW, PAN, 5X20	2	2	2	
F-10	73	HCO-94001-05490-0S	NUT, HEX., 5MM	2	2	2	
F-10	74	HCO-94001-12490-0S	NUT, HEX., 12MM	12	12	12	
F-10	75	HCO-94002-04490-0S	NUT, HEX., 4MM	1	1	1	
F-10	76	HCO-94305-30203	PIN, SPRING, 3X20	2	2	2	
F-10	77	HCO-95005-50045-30	TUBE, 5X45(95005-50001-30M)	1	1	1	
F-10	78	HCO-95005-50250-30	TUBE, 5X250(95005-50001-30M)	1	-	-	LRU
F-10	79	HCO-95005-50340-30	TUBE, 5X340(95005-50001-30M)	1	1	1	XCRU,XRD,XRU



FR.
20
3
10
4
32
32
32
36
7
8
2
1
9
35
6
5
9
44
45
17
41
15
43
16
34
23
14
31
37
18
30
31
25
47
25
26
47
46
39
24
42
21
38
22
19
38
12
39
28
27
40
29
11
33
F-10
12

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-11	1	HZX2-30280-003	BREAKER ASSY.	1	1	1	
F-11	2	HZX2-31106-003	BRUSH ASSY.	1	1	1	
F-11	3	HMG9-35701-950	BAND(BLACK 3.5X140)	1	1	1	
F-11	4	HZVL-36104-000	TUBE, SPIRAL(12X14.6)	1	1	1	
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT	1	1	1	
F-11	6	HZX2-36122-003	BRACKET ASSY.	1	1	1	
F-11	7	HZY3-36123-013	ARMATURE COMP.	1	1	1	
F-11	8	HZX2-36129-003	YOKE ASSY.	1	1	1	
F-11	9	HZV5-36136-821	SPRING, MOTOR	2	2	2	
F-11	10	HZW1-40107-700	GROMMET, UNDER CASE(C)	1	1	1	
F-11	11	HZY3-40219-023	WIRE, LEAD(1.5X116MM)	1	1	1	
F-11	12	HZV5-50214-003	BUSH, SWIVEL CASE	2	2	2	
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER	1	1	1	
F-11	14	HZY3-56100-013	PUMP ASSY.	1	1	1	
F-11	15	HZW1-56110-701	ROD COMP., PISTON(B)	2	2	2	
F-11	16	HZW1-56113-701	JOINT, DRIVE	1	1	1	
F-11	17	HZY9-56115-023	GUIDE COMP., ROD	2	2	2	
F-11	18	HZW1-56116-701	FILTER B	1	1	1	
F-11	19	HZV5-56117-821	RING, BACK UP	1	1	1	
F-11	20	HZV5-56118-820	BUSH, MOTOR CODE	1	1	1	
F-11	21	HZY3-56120-023	ROD COMP., PISTON	1	1	1	
F-11	22	HZW1-56130-702	PISTON COMP., FREE	1	1	1	
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL	1	1	1	
F-11	24	HZW1-56180-701	VALVE COMP., RESERVOIR	1	1	1	
F-11	25	HZV5-56513-000	BUSH, LOWER CYLINDER	2	2	2	
F-11	26	HZX2-56532-C00	PIN, UPPER CYLINDER	1	1	1	
F-11	27	HZW1-56851-703	TANK, OIL	1	1	1	
F-11	28	HZW1-56860-701	CAP COMP., OIL TANK	1	1	1	
F-11	29	HZW1-90113-702	BOLT, RECESSED	3	3	3	



FR.
20
3
10
4
32
32
32
36
7
8
2
1
9
9
35
6
5
44
45
17
41
44
45
17
41
16
34
23
14
31
37
18
30
31
13
15
43
15
43
25
47
25
26
47
46
39
39
39
24
39
39
42
21
38
22
19
38
12
39
28
27
40
29
11
33
F-10
12

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-11	30	HZW1-90114-702	BOLT, SOCKET(A)	1	1	1	
F-11	31	HZW1-90115-702	BOLT, SOCKET(B)	2	2	2	
F-11	32	HZW1-90116-702	BOLT, HEX.	4	4	4	
F-11	33	HZV5-90119-000	SCREW, PAN, 6X8	1	1	1	
F-11	34	HZW1-90652-702	CIRCLIP, INTERNAL	1	1	1	
F-11	35	HZV5-91203-821	OIL SEAL	1	1	1	
F-11	36	HZW1-91207-013	O-RING, 2.0X70.5	1	1	1	
F-11	37	HZV5-91302-821	O-RING, 1.8X69.6	1	1	1	
F-11	38	HZV5-91316-821	O-RING, 3.5X38.7	2	2	2	
F-11	39	HZX2-91352-003	O-RING, 1.68X7.25	6	6	6	
F-11	40	HZW1-91353-703	O-RING, 1.9X11	1	1	1	
F-11	41	HZW1-91354-701	O-RING, 3.5X35.7	2	2	2	
F-11	42	HZW1-91355-701	O-RING, 3.5X41.7	1	1	1	
F-11	43	HZW1-91357-701	O-RING SET, 3.5X31.7	2	2	2	
F-11	44	HZX2-91358-003	SEAL, WATER	2	2	2	
F-11	45	HZW1-91361-701	PACKING	2	2	2	
F-11	46	HZW1-91557-701	COLLAR, ORIFICE	1	1	1	
F-11	47	HCO-94540-15029	E-RING, 15MM	2	2	2	



2
3
4
5
TOHATSU
200
225
250
TOHATSU


10
6
7
8
9
1
5
200
225
250
TOHATSU
TOHATSU


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-12	1	HZVL-87117-L00	LABEL, FUSE & OIL CAUTION(EF)	1	1	1	
F-12	2	HZVJ-87121-P00	MARK, RR.(BFT200)	1	–	–	
F-12	3	HZVK-87121-P00	MARK, RR.(BFT225)	–	1	–	
F-12	4	HZVL-87121-P00	MARK, RR.(BFT250)	–	–	1	
F-12	5	HZVL-87132-P00	MARK, SIDE STRIPE	2	2	2	
F-12	6	HZVJ-87301-P00	MARK, FR.(BFT200)	1	–	–	
F-12	7	HZVK-87301-P00	MARK, FR.(BFT225)	–	1	–	
F-12	8	HZVL-87301-P00	MARK, FR.(BFT250)	–	–	1	
F-12	9	HZVL-87302-P00	MARK, FR. EMBLEM	1	1	1	
F-12	10	HZY9-87538-U80	LABEL, WARNING OPERATOR(EU)	1	1	1	


2
1
2
8
7
6
5
4
3
9

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-13	1	HMR5-16966-000	JOINT, FUEL TUBE	1	1	1	
F-13	2	HZV4-17704-010	BAND, TUBE CLIP, 12.5MM	2	2	2	
F-13	3	HSF4-89216-000	WRENCH, PLUG	1	1	1	LRU,XRD,XRU
F-13	4	H355-89217-000	WRENCH, BOX(10MM)	1	1	1	LRU,XRD,XRU
F-13	5	H371-89221-000	WRENCH, HEX., 6MM	1	1	1	LRU,XRD,XRU
F-13	6	HCO-99003-10000	DRIVER 1, PLUS SCREW(NO.2)	1	1	1	LRU,XRD,XRU
F-13	7	HCO-99003-50000	GRIP, SCREW DRIVER	1	1	1	LRU,XRD,XRU
F-13	8	HCO-99006-19000	WRENCH, EYE, 19MM	1	1	1	LRU,XRD,XRU
F-13	9	HCO-99008-02000	BAG, TOOL, 200MM	1	1	1	LRU,XRD,XRU



1
3
2

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-1	1	HZY3-06177-U02	HOSE KIT, RIGGING	1	1	1	
FOP-1	2	HZY3-17748-U01	CLAMP	1	1	1	
FOP-1	3	HZY3-17749-U01	SCREW, TAPPING	3	3	3	


9
14
8
4
11
5
2
3
10
6
7
12
13
11
3
10
1
7
FR.


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-2	1	HZX2-06192-C00	PUMP KIT, IMPELLER	1	1	1	
FOP-2	2	HZX2-06193-C00	PUMP KIT, IMPELLER	1	1	1	
FOP-2	3	HZY3-19210-003	IMPELLER, PUMP	1	1	1	
FOP-2	4	HZY3-19221-010	HOUSING, IMPELLER	1	1	1	
FOP-2	5	HZY3-19223-000	LINER, PUMP	1	1	1	
FOP-2	6	HZY3-19231-000	COVER, IMPELLER	1	1	1	
FOP-2	7	HZX2-19234-C00	GASKET B, IMPELLER	1	1	1	
FOP-2	8	HZY3-19253-000	RING, WATER TUBE SEAL	1	1	1	
FOP-2	9	HZX2-90105-C00	BOLT-WASHER, 8X60	4	4	4	
FOP-2	10	HZY3-90752-003	KEY, WOODRUFF	1	1	1	
FOP-2	11	HZY3-91356-003	O-RING, WATER PUMP	1	1	1	
FOP-2	12	HZX2-91358-C00	O-RING, WATER PUMP HOUSING	1	1	1	
FOP-2	13	HZX2-91359-C00	O-RING, 65.4X2.4	1	1	1	
FOP-2	14	HZY3-91551-000	COLLAR, DISTANCE	4	4	4	

FOP-3 **REMOTE CONTROL**
(TOP MOUNT SINGLE TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-3	1	HZZ3-06240-R31	BOX KIT, REMOTE CONTROL	1	1	1	
FOP-3	2	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	1	
FOP-3	3	HZW5-24811-U01	HANDLE, REMOTE CONTROL	1	1	1	
FOP-3	4	HZW5-24812-U01	COVER, L. GRIP	1	1	1	
FOP-3	5	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	1	1	1	
FOP-3	6	HZW5-24814-U01	CAP, GRIP	1	1	1	
FOP-3	7	HZW5-24815-U01	CAP, SWITCH	1	1	1	
FOP-3	8	HZW5-24816-U01	BUTTON, THROTTLE	1	1	1	
FOP-3	9	HZW5-24817-U01	PLATE, HANDLE	1	1	1	
FOP-3	10	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	
FOP-3	11	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	2	2	
FOP-3	12	HZZ3-24820-R12	HOUSING COMP., REMOTE CONTROL	1	1	1	
FOP-3	13	HZW5-24825-U01	HOUSING, LEAD	1	1	1	
FOP-3	14	HZW5-24826-U01	PLATE, DWELL	1	1	1	
FOP-3	15	HZW5-24831-U01	TERMINAL, CABLE	2	2	2	
FOP-3	16	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	1	
FOP-3	17	HZW5-24834-U01	PACKING, SINGLE	1	1	1	
FOP-3	18	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	1	1	
FOP-3	19	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
FOP-3	20	HZZ3-87703-R82	MARK, REMOTE CONTROL(SINGLE)	1	1	1	
FOP-3	21	HZW5-90101-U00	SCREW, PAN, 5X16	2	2	2	
FOP-3	22	HZW5-90102-U00	SCREW, PAN, 5X10	1	1	1	
FOP-3	23	HZW5-90103-U01	SCREW, PAN, 5X20	2	2	2	
FOP-3	24	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	
FOP-3	25	HZW5-90105-U01	SCREW, PAN, 4X10	2	2	2	
FOP-3	26	HZW5-90106-U00	SCREW, PAN, 6X18	2	2	2	
FOP-3	27	HZW5-90107-U00	SCREW, PAN, 5X40	4	4	4	
FOP-3	28	HZW5-90301-U00	NUT, HEX., 5MM	4	4	4	
FOP-3	29	HZW5-90501-U00	WASHER, LOCK, 5MM	4	4	4	

FOP-3 **REMOTE CONTROL**
(TOP MOUNT SINGLE TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-3	30	HZW5-90502-U00	WASHER, LOCK, 6MM	2	2	2	
FOP-3	31	HZW5-90503-U00	WASHER, PLAIN, 5MM	4	4	4	
FOP-3	32	HCO-94540-06029	E-RING, 6MM	2	2	2	

FOP-3-1 REMOTE CONTROL
(FLUSH MOUNT TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-3-1	1	HZZ3-06240-R41	BOX KIT, REMOTE CONTROL	1	1	1	
FOP-3-1	2	HZW7-24810-U01	HOUSING ASSY., R. INNER	1	1	1	
FOP-3-1	3	HZW7-24811-U01	HANDLE, REMOTE CONTROL	1	1	1	
FOP-3-1	4	HZW7-24812-U01	COVER, GRIP	1	1	1	
FOP-3-1	5	HZW7-24813-U01	ARM, NEUTRAL LOCK	1	1	1	
FOP-3-1	6	HZW7-24814-U01	COVER, LOCK ARM	1	1	1	
FOP-3-1	7	HZW7-24815-U01	SPRING, NEUTRAL LOCK ARM	1	1	1	
FOP-3-1	8	HZW5-24816-U01	BUTTON, THROTTLE	1	1	1	
FOP-3-1	9	HZW7-24817-U01	SHAFT, THROTTLE BUTTON	1	1	1	
FOP-3-1	10	HZW5-24826-U01	PLATE, DWELL	1	1	1	
FOP-3-1	11	HZZ3-24830-R42	COVER ASSY.	1	1	1	
FOP-3-1	12	HZW5-24831-U01	TERMINAL, CABLE	2	2	2	
FOP-3-1	13	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	1	
FOP-3-1	14	HZW7-24832-U01	HOLDER, NEUTRAL LOCK	1	1	1	
FOP-3-1	15	HZW7-24833-U01	BASE	1	1	1	
FOP-3-1	16	HZW7-32530-U20	SUB HARNESS ASSY., POWER	1	1	1	
FOP-3-1	17	HZW7-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
FOP-3-1	18	HZZ3-87701-R41	MARK, HANDLE FLUSH MOUNT	1	1	1	
FOP-3-1	19	HZW7-87703-U00	MARK, FLUSH MOUNT	1	1	1	
FOP-3-1	20	HZW5-90101-U00	SCREW, PAN, 5X16	1	1	1	
FOP-3-1	21	HZW7-90101-U01	SCREW, TRUSS, 4X12	1	1	1	
FOP-3-1	22	HZW7-90102-U01	SCREW, PAN, 5X30	4	4	4	
FOP-3-1	23	HZW7-90103-U01	SCREW, PAN, 6X35	3	3	3	
FOP-3-1	24	HZW7-90104-U01	SCREW, TAPPING, 6X30	3	3	3	
FOP-3-1	25	HZW7-90301-U01	NUT, HEX., 6MM	3	3	3	
FOP-3-1	26	HZW5-90501-U00	WASHER, LOCK, 5MM	4	4	4	
FOP-3-1	27	HZW7-90502-U00	WASHER, PLAIN, 6MM	3	3	3	
FOP-3-1	28	HCO-94540-06029	E-RING, 6MM	2	2	2	

FOP-3-2 REMOTE CONTROL
(TOP MOUNT DUAL TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-3-2	1	HZZ3-06240-R61	BOX KIT, REMOTE CONTROL	1	1	1	
FOP-3-2	2	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	1	
FOP-3-2	3	HZW5-24810-U11	HOUSING ASSY., R. INNER	1	1	1	
FOP-3-2	4	HZW5-24811-U01	HANDLE, REMOTE CONTROL	2	2	2	
FOP-3-2	5	HZW5-24812-U01	COVER, L. GRIP	1	1	1	
FOP-3-2	6	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	2	2	2	
FOP-3-2	7	HZW5-24813-U21	COVER, DUAL GRIP	1	1	1	
FOP-3-2	8	HZW5-24814-U01	CAP, GRIP	2	2	2	
FOP-3-2	9	HZW5-24816-U01	BUTTON, THROTTLE	2	2	2	
FOP-3-2	10	HZW5-24817-U01	PLATE, HANDLE	2	2	2	
FOP-3-2	11	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	
FOP-3-2	12	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	2	2	
FOP-3-2	13	HZZ3-24820-R22	HOUSING COMP., REMOTE CONTROL	1	1	1	
FOP-3-2	14	HZW5-24825-U01	HOUSING, LEAD	2	2	2	
FOP-3-2	15	HZW5-24826-U01	PLATE, DWELL	2	2	2	
FOP-3-2	16	HZW5-24831-U01	TERMINAL, CABLE	4	4	4	
FOP-3-2	17	HZW5-24832-U01	SPACER, CABLE CLAMP	2	2	2	
FOP-3-2	18	HZW5-24834-U21	PACKING, DUAL	1	1	1	
FOP-3-2	19	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	1	1	
FOP-3-2	20	HZW7-32530-U10	SUB HARNESS ASSY., POWER	1	1	1	
FOP-3-2	21	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
FOP-3-2	22	HZW5-35370-U12	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
FOP-3-2	23	HZZ3-87703-R02	MARK, REMOTE CONTROL(DUAL)	1	1	1	
FOP-3-2	24	HZW5-90101-U00	SCREW, PAN, 5X16	3	3	3	
FOP-3-2	25	HZW5-90102-U00	SCREW, PAN, 5X10	2	2	2	
FOP-3-2	26	HZW5-90103-U01	SCREW, PAN, 5X20	4	4	4	
FOP-3-2	27	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	
FOP-3-2	28	HZW5-90105-U01	SCREW, PAN, 4X10	4	4	4	
FOP-3-2	29	HZW5-90106-U00	SCREW, PAN, 6X18	4	4	4	

FOP-3-2 REMOTE CONTROL
(TOP MOUNT DUAL TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-3-2	30	HZW5-90107-U00	SCREW, PAN, 5X40	4	4	4	
FOP-3-2	31	HZW5-90108-U00	SCREW, PAN, 5X55	3	3	3	
FOP-3-2	32	HZW5-90301-U00	NUT, HEX., 5MM	4	4	4	
FOP-3-2	33	HZW5-90302-U21	NUT, HEX., 5MM	1	1	1	
FOP-3-2	34	HZW5-90501-U00	WASHER, LOCK, 5MM	8	8	8	
FOP-3-2	35	HZW5-90502-U00	WASHER, LOCK, 6MM	4	4	4	
FOP-3-2	36	HZW5-90503-U00	WASHER, PLAIN, 5MM	4	4	4	
FOP-3-2	37	HCO-94540-06029	E-RING, 6MM	4	4	4	

FOP-3-3 REMOTE CONTROL
(NHK MEC)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-3-3	1	HZZ3-24800-P04	BOX ASSY., REMOTE CONTROL	1	1	1	LRU,XCRU,XRU
FOP-3-3	1	HZZ3-24800-P14	BOX ASSY., REMOTE CONTROL	1	1	1	XRD
FOP-3-3	2	HZZ5-24810-D01	PLATE ASSY.	1	1	1	
FOP-3-3	3	HZZ5-24811-D01	LEVER, HAND	1	1	1	
FOP-3-3	4	HZZ5-24812-D01	ARM, NEUTRAL LOCK	1	1	1	
FOP-3-3	5	HZZ5-24813-D01	GRIP	1	1	1	
FOP-3-3	6	HZZ5-24814-D01	COVER, LEVER	1	1	1	
FOP-3-3	7	HZZ5-24815-D01	ARM ASSY., BRAKE	1	1	1	
FOP-3-3	8	HZZ5-24816-D01	SPRING(2)	1	1	1	
FOP-3-3	9	HZZ5-24817-D01	CLIP, DETENT	1	1	1	
FOP-3-3	10	HZZ5-24818-D01	SPACER(1)	1	1	1	(LOOSE PARTS)
FOP-3-3	11	HZZ5-24819-D01	BRACKET	1	1	1	
FOP-3-3	12	HZZ5-24821-D01	HOUSING, FR.	1	1	1	
FOP-3-3	13	HZZ5-24822-D01	HOUSING, RR.	1	1	1	
FOP-3-3	14	HZZ5-24823-D01	PANEL, BACK	1	1	1	
FOP-3-3	15	HZZ5-24824-D01	BRACKET, WIRE CLAMP	1	1	1	
FOP-3-3	16	HZZ5-24826-D01	CAP, RUBBER	1	1	1	
FOP-3-3	17	HZZ5-24827-D01	ADJUSTER	1	1	1	
FOP-3-3	18	HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	1	1	1	
FOP-3-3	19	HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	1	1	1	(LOOSE PARTS)
FOP-3-3	20	HZZ5-24829-D01	SEAL, RUBBER	1	1	1	
FOP-3-3	21	HZZ5-24831-D01	HOLDER, NEUTRAL LOCK	1	1	1	
FOP-3-3	22	HZZ5-24832-D01	GROMMET, WIRE(14)	1	1	1	
FOP-3-3	23	HZZ5-24833-D01	CAP, TROLLING CONTROL SWITCH	1	1	1	
FOP-3-3	24	HZZ5-24845-D01	GEAR ASSY., SHIFT	1	1	1	
FOP-3-3	25	HZZ5-24850-D01	GEAR, DRIVE	1	1	1	
FOP-3-3	26	HZZ5-24855-D01	TERMINAL, CABLE	2	2	2	(LOOSE PARTS)
FOP-3-3	27	HZZ5-24875-D01	DRUM ASSY., FREE THROTTLE	1	1	1	
FOP-3-3	28	HZZ5-24876-D01	SPRING(1)	1	1	1	

FOP-3-3 REMOTE CONTROL
(NHK MEC)





Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-3-3	29	HZZ5-24878-D01	LEVER, FREE THROTTLE	1	1	1	
FOP-3-3	30	HZZ5-24883-D01	SPRING, DETENT	5	5	5	
FOP-3-3	31	HZZ5-32530-D01	CABLE ASSY., REMOTE CONTROL(B)	1	1	1	
FOP-3-3	32	HZV5-32823-003	PLUG, INNER CONNECTOR	7	7	7	
FOP-3-3	33	HZV5-32824-003	PLUG, OUTER CONNECTOR	1	1	1	
FOP-3-3	34	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	
FOP-3-3	35	HZZ5-35370-D02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
FOP-3-3	36	HZZ3-35645-A41	PLATE, SWITCH	1	1	1	
FOP-3-3	37	HZZ5-35701-D01	BAND, WIRE	1	1	1	
FOP-3-3	38	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-3-3	39	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	
FOP-3-3	40	HZZ5-37210-D02	LAMP ASSY., INDICATION	1	1	1	
FOP-3-3	41	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	
FOP-3-3	42	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	
FOP-3-3	43	HZZ5-87701-790	PLATE, REMOTE CONTROL(REVERSE)	1	1	1	
FOP-3-3	44	HZZ5-87701-D00	MARK, FAST IDLE	1	1	1	
FOP-3-3	45	HZZ5-87702-D00	MARK, EMERGENCY STOP	1	1	1	LRU,XCRU,XRU
FOP-3-3	45	HZZ5-87702-A00	MARK, EMERGENCY STOP(US)	1	1	1	XRD
FOP-3-3	46	HZZ5-87702-A00	MARK, EMERGENCY STOP(US)	1	1	1	(LOOSE PARTS) XRD
FOP-3-3	47	HZZ5-87702-D00	MARK, EMERGENCY STOP	1	1	1	(LOOSE PARTS) LRU,XCRU,XRU
FOP-3-3	48	HZZ5-87703-P01	MARK, EMBLEM	1	1	1	
FOP-3-3	49	HZZ5-87704-D01	LABEL, SIGP	1	1	1	
FOP-3-3	50	HZZ5-90101-D01	SCREW, 5X18	7	7	7	
FOP-3-3	51	HZZ5-90102-D01	SCREW, 4X6	2	2	2	
FOP-3-3	52	HZZ5-90103-D01	SCREW, 5X10	1	1	1	
FOP-3-3	53	HZZ5-90104-D01	SCREW, 4X10	2	2	2	
FOP-3-3	54	HZZ5-90106-D01	SCREW, 5X12	2	2	2	
FOP-3-3	55	HZZ5-90107-D01	SCREW, 6X90	3	3	3	(LOOSE PARTS)
FOP-3-3	56	HZZ5-90108-D01	BOLT, 8X50	1	1	1	


FOP-3-3 REMOTE CONTROL
(NHK MEC)




Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-3-3	57	HZZ5-90109-D01	BOLT, 5X25	1	1	1	
FOP-3-3	58	HZZ5-90301-D01	NUT, 6MM	3	3	3	(LOOSE PARTS)
FOP-3-3	59	H921-90302-000	NUT, HEX., 16MM	1	1	1	
FOP-3-3	60	HZZ5-90302-D01	NUT, 5MM	1	1	1	
FOP-3-3	61	HZZ5-90501-D01	BEARING(1)	1	1	1	
FOP-3-3	62	HZZ5-90502-D01	WASHER(3)	1	1	1	
FOP-3-3	63	HZZ5-90503-D01	WASHER(4)	2	2	2	
FOP-3-3	64	HZZ5-90504-D01	WASHER(5)	1	1	1	
FOP-3-3	65	HZZ5-90506-D01	WASHER, 8MM	1	1	1	
FOP-3-3	66	HZZ5-90507-D01	WASHER(7)	3	3	3	(LOOSE PARTS)
FOP-3-3	67	HZZ5-90508-D01	WASHER, WAVE	1	1	1	
FOP-3-3	68	HZZ5-90509-D01	SPACER(2)	3	3	3	(LOOSE PARTS)
FOP-3-3	69	HZZ5-90651-D01	E-RING, 6MM	2	2	2	(LOOSE PARTS)
FOP-3-3	70	HZZ5-91151-D01	ROLLER, DRIVE GEAR CAM	1	1	1	
FOP-3-3	71	HZZ5-91152-D01	ROLLER	1	1	1	
FOP-3-3	72	HZZ5-91153-D01	BEARING(2)	1	1	1	
FOP-3-3	73	HZZ5-91154-D01	BEARING(3)	2	2	2	
FOP-3-3	74	HZZ5-91156-D01	ROLLER, FREE THROTTLE	1	1	1	
FOP-3-3	75	HZZ5-91157-D01	CLIP, ROLLER	1	1	1	


1
TOHATSU



2
TOHATSU
RPM
X1000


3


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-4	1	3PU-72571-0	TRIM METER ASSY	1	1	1	White
FOP-4	1	3PV-72571-0	TRIM METER ASSY	1	1	1	Black
FOP-4	2	3PU-72637-0	TACHOMETER HOUR METER	1	1	1	White
FOP-4	2	3PV-72637-0	TACHOMETER HOUR METER	1	1	1	Black
FOP-4	3	3PU-72537-0	METER LEAD WIRE	1	1	1	


7
6
4
8
2
11
13
9
12
17
15
3
14
10
16
18
19
5
1


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-5	1	HZY6-06323-R80	PANEL KIT, SWITCH(SINGLE)	1	1	1	LRU,XCRU,XRU
FOP-5	1	HZY6-06323-R00	PANEL KIT, SWITCH(SINGLE)	1	1	1	XRD
FOP-5	2	HZY6-32340-R81	PANEL ASSY., CONTROL(SINGLE)	1	1	1	LRU,XCRU,XRU
FOP-5	2	HZY6-32340-R01	PANEL ASSY., CONTROL(SINGLE)	1	1	1	XRD
FOP-5	3	HZY6-32346-R81	PANEL, CONTROL(SINGLE)	1	1	1	LRU,XCRU,XRU
FOP-5	3	HZY6-32346-R01	PANEL, CONTROL(SINGLE)	1	1	1	XRD
FOP-5	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	1	1	1	
FOP-5	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	1	1	1	
FOP-5	6	HZV5-32823-003	PLUG, INNER CONNECTOR	9	9	9	
FOP-5	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	7	7	7	
FOP-5	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	1	1	1	
FOP-5	9	HZY6-36180-003	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	
FOP-5	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	1	1	1	
FOP-5	13	HZY9-38410-A01	BUZZER COMP., WARNING	1	1	1	
FOP-5	14	HZY6-38414-003	BRACKET	1	1	1	
FOP-5	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	
FOP-5	16	HZZ5-90301-M00	NUT, FLANGE, 5MM	4	4	4	
FOP-5	17	HZY6-90302-003	NUT	1	1	1	
FOP-5	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	4	4	4	
FOP-5	19	HZZ5-90502-M00	WASHER, SPRING, 5MM	4	4	4	


7
6
4
8
2
9
13
11
17
3
12
15
16
14
10
18
5
19
1


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-5-1	1	HZY6-06323-R90	PANEL KIT, SWITCH(TWIN)	1	1	1	LRU,XCRU,XRU
FOP-5-1	1	HZY6-06323-R10	PANEL KIT, SWITCH(TWIN)	1	1	1	XRD
FOP-5-1	2	HZY6-32340-R91	PANEL ASSY., CONTROL(TWIN)	1	1	1	LRU,XCRU,XRU
FOP-5-1	2	HZY6-32340-R11	PANEL ASSY., CONTROL(TWIN)	1	1	1	XRD
FOP-5-1	3	HZY6-32346-R91	PANEL, CONTROL(TWIN)	1	1	1	LRU,XCRU,XRU
FOP-5-1	3	HZY6-32346-R11	PANEL, CONTROL(TWIN)	1	1	1	XRD
FOP-5-1	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	2	2	2	
FOP-5-1	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	2	2	2	
FOP-5-1	6	HZV5-32823-003	PLUG, INNER CONNECTOR	18	18	18	
FOP-5-1	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	14	14	14	
FOP-5-1	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	2	2	2	
FOP-5-1	9	HZY6-36180-712	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5-1	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	
FOP-5-1	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5-1	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	2	2	2	
FOP-5-1	13	HZY9-38410-A01	BUZZER COMP., WARNING	2	2	2	
FOP-5-1	14	HZY6-38414-003	BRACKET	2	2	2	
FOP-5-1	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	
FOP-5-1	16	HZZ5-90301-M00	NUT, FLANGE, 5MM	4	4	4	
FOP-5-1	17	HZY6-90302-003	NUT	1	1	1	
FOP-5-1	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	4	4	4	
FOP-5-1	19	HZZ5-90502-M00	WASHER, SPRING, 5MM	4	4	4	


7
6
4
2
8
9
13
11
3
12
17
15
16
14
10
18
5
19
1


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-5-2	1	HZY6-06323-R30	PANEL KIT, SWITCH(TRIPLE)	1	1	1	LRU,XCRU,XRU
FOP-5-2	1	HZY6-06323-R20	PANEL KIT, SWITCH(TRIPLE)	1	1	1	XRD
FOP-5-2	2	HZY6-32340-R31	PANEL ASSY., CONTROL(TRIPLE)	1	1	1	LRU,XCRU,XRU
FOP-5-2	2	HZY6-32340-R21	PANEL ASSY., CONTROL(TRIPLE)	1	1	1	XRD
FOP-5-2	3	HZY6-32346-R31	PANEL, CONTROL(TRIPLE)	1	1	1	LRU,XCRU,XRU
FOP-5-2	3	HZY6-32346-R21	PANEL, CONTROL(TRIPLE)	1	1	1	XRD
FOP-5-2	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	3	3	3	
FOP-5-2	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	3	3	3	
FOP-5-2	6	HZV5-32823-003	PLUG, INNER CONNECTOR	27	27	27	
FOP-5-2	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	21	21	21	
FOP-5-2	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	3	3	3	
FOP-5-2	9	HZY6-36180-612	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5-2	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	
FOP-5-2	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5-2	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	3	3	3	
FOP-5-2	13	HZY9-38410-A01	BUZZER COMP., WARNING	3	3	3	
FOP-5-2	14	HZY6-38414-003	BRACKET	3	3	3	
FOP-5-2	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	
FOP-5-2	16	HZZ5-90301-M00	NUT, FLANGE, 5MM	4	4	4	
FOP-5-2	17	HZY6-90302-003	NUT	1	1	1	
FOP-5-2	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	4	4	4	
FOP-5-2	19	HZZ5-90502-M00	WASHER, SPRING, 5MM	4	4	4	


2
22
19
21
18
1
13
14
5
17
16
15
7
8
19
22
21
18
6
23
3
9
4
7
8
20
19
22
21
18
10
11
12


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-5-3	1	HZZ3-06323-R03	PANEL KIT, SWITCH(B)(4-LED)	1	1	1	LRU,XCRU,XRU
FOP-5-3	1	HZZ3-06323-R23	PANEL KIT, SWITCH(B)(4-LED)	1	1	1	XRD
FOP-5-3	2	HZZ5-06352-M00	SWITCH KIT, LIGHT	1	–	–	LRU
FOP-5-3	3	HZZ3-32341-R02	PANEL ASSY., SWITCH	1	1	1	LRU,XCRU,XRU
FOP-5-3	3	HZZ3-32341-R32	PANEL ASSY., SWITCH	1	1	1	XRD
FOP-5-3	4	HZZ3-32346-R02	PANEL, CONTROL	1	1	1	LRU,XCRU,XRU
FOP-5-3	4	HZZ3-32346-R22	PANEL, CONTROL	1	1	1	XRD
FOP-5-3	5	HZZ3-32347-R02	PANEL, CONTROL	1	1	1	
FOP-5-3	6	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	1	
FOP-5-3	7	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	8	
FOP-5-3	8	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	3	
FOP-5-3	9	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	
FOP-5-3	10	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5-3	11	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	
FOP-5-3	12	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5-3	13	HZZ3-37205-R03	PANEL ASSY., INDICATOR(4-LED)	1	1	1	
FOP-5-3	14	HZZ5-37210-763	LAMP ASSY., INDICATION(4-LED)	1	1	1	
FOP-5-3	15	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	
FOP-5-3	16	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	
FOP-5-3	17	HZZ5-38414-003	BRACKET, BUZZER	1	1	1	
FOP-5-3	18	HZW5-90109-000	SCREW, PAN, 5X40	8	8	8	XCRU,XRD,XRU
FOP-5-3	18	HZW5-90109-000	SCREW, PAN, 5X40	12	–	–	LRU
FOP-5-3	19	HZZ5-90301-M00	NUT, FLANGE, 5MM	8	8	8	XCRU,XRD,XRU
FOP-5-3	19	HZZ5-90301-M00	NUT, FLANGE, 5MM	12	–	–	LRU
FOP-5-3	20	H921-90302-000	NUT, HEX., 16MM	1	1	1	
FOP-5-3	21	HZZ5-90501-M00	WASHER, PLAIN, 5MM	8	8	8	XCRU,XRD,XRU
FOP-5-3	21	HZZ5-90501-M00	WASHER, PLAIN, 5MM	12	–	–	LRU
FOP-5-3	22	HZZ5-90502-M00	WASHER, SPRING, 5MM	8	8	8	XCRU,XRD,XRU
FOP-5-3	22	HZZ5-90502-M00	WASHER, SPRING, 5MM	12	–	–	LRU


2
22
19
21
18
1
13
14
5
17
16
15
7
8
19
22
21
18
6
23
3
9
4
7
8
20
19
22
21
10
11
12
18


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-5-3	23	HSC2-90649-003	BAND, WIRE HARNESS(NATURAL)	1	1	1	



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-5-4	1	HZZ3-06323-R13	PANEL KIT, SWITCH(4-LED)	1	1	1	LRU,XCRU,XRU
FOP-5-4	1	HZZ3-06323-R33	PANEL KIT, SWITCH(4-LED)	1	1	1	XRD
FOP-5-4	2	HZZ3-32346-R12	PANEL, CONTROL	1	1	1	LRU,XCRU,XRU
FOP-5-4	2	HZZ3-32346-R32	PANEL, CONTROL	1	1	1	XRD
FOP-5-4	3	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	1	
FOP-5-4	4	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	8	
FOP-5-4	5	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	3	
FOP-5-4	6	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	
FOP-5-4	7	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5-4	8	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	
FOP-5-4	9	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5-4	10	HZZ5-37210-713	LAMP ASSY., INDICATION(4-LED)	1	1	1	
FOP-5-4	11	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	
FOP-5-4	12	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	
FOP-5-4	13	HZZ5-38414-003	BRACKET, BUZZER	1	1	1	
FOP-5-4	14	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	
FOP-5-4	15	HZZ5-90301-M00	NUT, FLANGE, 5MM	4	4	4	
FOP-5-4	16	H921-90302-000	NUT, HEX., 16MM	1	1	1	
FOP-5-4	17	HZZ5-90501-M00	WASHER, PLAIN, 5MM	4	4	4	
FOP-5-4	18	HZZ5-90502-M00	WASHER, SPRING, 5MM	4	4	4	
FOP-5-4	19	HSC2-90649-003	BAND, WIRE HARNESS(NATURAL)	1	1	1	


1
6
6
3
2
4
5


Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-7	1	HZVL-06328-601	CABLE KIT, INTERFACE(10FT)	1	1	1	
FOP-7	1	HZVL-06328-701	CABLE KIT, INTERFACE(16FT)	1	1	1	
FOP-7	1	HZZ3-06328-764	KIT, CABLE(NMEA)(6FT)	1	1	1	
FOP-7	2	HZVL-32800-600	CABLE ASSY., INTERFACE(10FT)	1	1	1	
FOP-7	2	HZVL-32800-700	CABLE ASSY., INTERFACE(16FT)	1	1	1	
FOP-7	2	HZZ3-32800-000	CABLE ASSY., INTERFACE(6FT)	1	1	1	
FOP-7	3	HZZ3-32805-000	CONNECTOR(T)	1	1	1	
FOP-7	4	HZY1-90650-003	TIE, CABLE	2	2	2	
FOP-7	5	HSTK-91540-003	CLIP, HARNESS BAND(BLACK)	2	2	2	
FOP-7	6	HCO-93901-446J0	SCREW, TAPPING, 4X25	2	2	2	


5


2



3
1
4

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-10	1	HZVL-06328-800	CONNECTOR KIT, TERMINATOR	1	1	1	
FOP-10	2	HZVL-32580-900	CABLE ASSY., PANEL INDICATOR	1	1	1	
FOP-10	2	HZVL-32580-910	CABLE ASSY., PANEL INDICATOR	1	1	1	
FOP-10	2	HZVL-32580-920	CABLE ASSY., PANEL INDICATOR	1	1	1	
FOP-10	3	HZVL-32806-000	TERMINATOR(M)	1	1	1	
FOP-10	4	HZVL-32807-000	TERMINATOR(F)	1	1	1	
FOP-10	5	HZVL-32590-900	CABLE ASSY., CONVERSION(6FT)	1	1	1	
FOP-10	5	HZVL-32590-910	CABLE ASSY., CONVERSION(10FT)	1	1	1	



2
3
4
1

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-12	1	HZW5-06900-U00	BOLT KIT, SIDE REMOTE CONTROL	1	1	1	
FOP-12	2	HZW5-90021-U00	BOLT, SPECIAL, 6X220	3	3	3	
FOP-12	3	HZW5-90511-U00	COLLAR, DISTANCE(A)	3	3	3	
FOP-12	4	HZW5-90512-U00	COLLAR, DISTANCE(B)	3	3	3	


FOP-14 TRIM ADJUST PLATE SET



Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-14	1	HZY3-50388-U00	PLATE SET, TRIM ADJUST	1	1	1	
FOP-14	2	HZY3-50388-U10	PLATE SET, TRANSOM(5.5MM FLAT)	1	1	1	



1

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-15	1	HZY3-58130-T00	PROPELLER COMP., THREE BLADES	1	1	-	LRU,XRD,XRU
FOP-15	1	HZY3-58130-T10	PROPELLER COMP., THREE BLADES	1	1	-	LRU,XRD,XRU
FOP-15	1	HZY3-58130-T20	PROPELLER COMP., THREE BLADES	1	1	-	LRU,XRD,XRU
FOP-15	1	HZY3-58130-T30	PROPELLER COMP., THREE BLADES	1	1	-	LRU,XRD,XRU
FOP-15	1	HZY3-58130-T40	PROPELLER COMP., THREE BLADES	1	1	-	LRU,XRD,XRU
FOP-15	1	HZY3-58130-T50	PROPELLER COMP., THREE BLADES	1	1	-	LRU,XRD,XRU
FOP-15	1	HZY3-58130-V01ZA	PROPELLER COMP., THREE BLADES	1	1	-	*NH283* LRU,XRD,XRU
FOP-15	1	HZY3-58130-V12ZA	PROPELLER COMP., THREE BLADES	1	1	-	*NH283* LRU,XRD,XRU
FOP-15	1	HZY3-58130-V22ZA	PROPELLER COMP., THREE BLADES	1	1	-	*NH283* LRU,XRD,XRU
FOP-15	1	HZY3-58130-V32ZA	PROPELLER COMP., THREE BLADES	1	1	-	*NH283* LRU,XRD,XRU
FOP-15	1	HZY3-58130-V42ZA	PROPELLER COMP., THREE BLADES	1	1	-	*NH283* LRU,XRD,XRU
FOP-15	1	HZY3-58130-V52ZA	PROPELLER COMP., THREE BLADES	1	1	-	*NH283* LRU,XRD,XRU
FOP-15	1	HZY3-58180-T00	PROPELLER COMP., THREE BLADES	1	1	-	XCRU
FOP-15	1	HZY3-58180-T10	PROPELLER COMP., THREE BLADES	1	1	-	XCRU
FOP-15	1	HZY3-58180-T20	PROPELLER COMP., THREE BLADES	1	1	-	XCRU
FOP-15	1	HZY3-58180-T30	PROPELLER COMP., THREE BLADES	1	1	-	XCRU
FOP-15	1	HZY3-58180-T40	PROPELLER COMP., THREE BLADES	1	1	-	XCRU
FOP-15	1	HZX2-58180-T01	PROPELLER COMP., THREE BLADES	-	-	1	XCRU
FOP-15	1	HZX2-58180-T11	PROPELLER COMP., THREE BLADES	-	-	1	XCRU
FOP-15	1	HZX2-58180-T21	PROPELLER COMP., THREE BLADES	-	-	1	XCRU
FOP-15	1	HZX2-58180-T31	PROPELLER COMP., THREE BLADES	-	-	1	XCRU
FOP-15	1	HZX2-58180-T41	PROPELLER COMP., THREE BLADES	-	-	1	XCRU
FOP-15	1	HZX2-58180-T51	PROPELLER COMP., THREE BLADES	-	-	1	XCRU
FOP-15	1	HZX2-58180-T61	PROPELLER COMP., THREE BLADES	-	-	1	XCRU
FOP-15	1	HZX2-58130-T01	PROPELLER COMP., THREE BLADES	-	-	1	XRD,XRU
FOP-15	1	HZX2-58130-T11	PROPELLER COMP., THREE BLADES	-	-	1	XRD,XRU
FOP-15	1	HZX2-58130-T21	PROPELLER COMP., THREE BLADES	-	-	1	XRD,XRU
FOP-15	1	HZX2-58130-T31	PROPELLER COMP., THREE BLADES	-	-	1	XRD,XRU
FOP-15	1	HZX2-58130-T41	PROPELLER COMP., THREE BLADES	-	-	1	XRD,XRU


1

Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-15	1	HZX2-58130-T51	PROPELLER COMP., THREE BLADES	-	-	1	XRD,XRU
FOP-15	1	HZX2-58130-T61	PROPELLER COMP., THREE BLADES	-	-	1	XRD,XRU

FOP-17 GEAR CASE KIT



Ref.No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-17	1	HZX2-06125-C00	CASE KIT, GEAR	1	1	1	
FOP-17	2	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	1	
FOP-17	3	HZY3-91251-C01	SEAL, WATER, 26X42X7	2	2	2	
FOP-17	4	HZZ3-91252-003	SEAL, WATER, 30X45X7	2	2	2	
FOP-17	5	HZY3-91254-003	SEAL, WATER, 12X21X6	2	2	2	
FOP-17	6	HZW4-91301-003	O-RING, 6.9X1.45	1	1	1	
FOP-17	7	HMJ0-91308-003	O-RING	1	1	1	
FOP-17	8	HZX2-91351-C00	O-RING, 121X3.1	1	1	1	

INDEX

<A>
ADJUSTER..... FOP-3-3-17
ARM ASSY., BRAKE..... FOP-3-3-7
ARM ASSY., FR. INTAKE ROCKER E-9-10-3
ARM ASSY., INTAKE ROCKER..... E-9-10-4
ARM COMP. A, EX. ROCKER..... E-9-10-5
ARM COMP. B, EX. ROCKER..... E-9-10-6
ARM, NEUTRAL LOCK FOP-3-1-5
ARM, NEUTRAL LOCK FOP-3-3-4
ARM, SHIFT(MECH) F-2-11
ARM, THROTTLE F-2-4
ARMATURE COMP..... F-11-7
<B>
BAG, TOOL, 200MM..... F-13-9
BALL, STEEL E-21-6
BALL, STEEL, #12(3/8)..... F-5-33
BALL, STEEL, #12(3/8)..... F-5-1-35
BALL, STEEL, #7(7/32)..... F-5-32
BALL, STEEL, #7(7/32)..... F-5-1-34
BAND E-18-44
BAND(BLACK 3.5X140)..... F-11-3
BAND, AIR FLOW E-15-7
BAND, TUBE CLIP, 12.5MM F-13-2
BAND, WIRE F-10-6
BAND, WIRE FOP-3-3-37
BAND, WIRE HARNESS(NATURAL) FOP-5-3-23
BAND, WIRE HARNESS(NATURAL) FOP-5-4-19
BAND, WIRE, 165MM(BLACK)..... F-7-10-21
BASE FOP-3-1-15
BASE COMP., TIMING BELT E-13-10
BASE, L. INJECTOR E-14-18
BASE, R. INJECTOR..... E-14-16
BEARING A, CONNECTING ROD..... E-7-7
BEARING A, MAIN LOWER(BLACK) E-7-11
BEARING A, MAIN UPPER(BLACK)..... E-7-9
BEARING B, CONNECTING ROD..... E-7-7
BEARING B, MAIN LOWER(BROWN) E-7-11
BEARING B, MAIN UPPER(BROWN)..... E-7-9
BEARING C, CONNECTING ROD..... E-7-7
BEARING C, MAIN LOWER(GREEN) E-7-11
BEARING C, MAIN UPPER(GREEN)..... E-7-9
BEARING D, CONNECTING ROD..... E-7-7
BEARING D, MAIN LOWER(YELLOW) ... E-7-11
BEARING D, MAIN UPPER(YELLOW).... E-7-9
BEARING E, CONNECTING ROD E-7-7
BEARING E, MAIN LOWER(PINK) E-7-11
BEARING E, MAIN UPPER(PINK)..... E-7-9
BEARING F, MAIN LOWER(RED) E-7-11
BEARING F, MAIN UPPER(RED)..... E-7-9
BEARING(1)..... FOP-3-3-61
BEARING(2)..... FOP-3-3-72
BEARING(3)..... FOP-3-3-73
BEARING, FR. GENERATOR..... E-19-3
BEARING, NEEDLE, 20X28X13 ..... E-6-10-43
BEARING, NEEDLE, 28X39X30 ..... F-5-26
BEARING, NEEDLE, 28X39X30 ..... F-5-1-28
BEARING, NEEDLE, 30.5X47X37..... F-4-25
BEARING, NEEDLE, 32X42X30 ..... F-5-27
BEARING, NEEDLE, 32X42X30 ..... F-5-1-29
BEARING, NEEDLE, 50X72X4.5..... F-5-1-25
BEARING, RADIAL BALL,..... F-5-25
BEARING, RADIAL BALL,..... F-5-1-27
BEARING, RR. GENERATOR E-19-2
BEARING, TAPER ROLLER, ... F-4-26
BEARING, TAPER ROLLER, ... F-5-24
BEARING, THRUST NEEDLE,..... F-5-1-26
BEARING, THRUST(F)..... F-5-23
BEARING, THRUST(F)..... F-5-1-24
BELT, A.C. GENERATOR..... E-13-17
BELT, TIMING(197YU26 B-323)..... E-13-6
BLOCK ASSY., CYLINDER E-3-3
BODY E-18-3
BODY, OIL JET E-3-13
BOLT A, THROUGH..... E-21-14
BOLT COMP., OIL JET..... E-3-14
BOLT KIT, SIDE REMOTE CONTROL..... FOP-12-1
BOLT, 1/4-28UNF F-10-37
BOLT, 12MM..... E-5-13
BOLT, 3/8-24UNF F-10-46
BOLT, 5X25..... FOP-3-3-57
BOLT, 8X50..... FOP-3-3-56
BOLT, CONNECTING ROD E-7-5
BOLT, DRAIN PLUG E-6-11
BOLT, DRAIN PLUG F-3-14
BOLT, FLANGE, 10X110 ..... E-21-19
BOLT, FLANGE, 10X120(SATO)..... E-6-10-26
BOLT, FLANGE, 10X40..... E-13-26
BOLT, FLANGE, 10X43..... E-13-27
BOLT, FLANGE, 10X55..... E-3-10-10
BOLT, FLANGE, 10X70..... E-6-10-52
BOLT, FLANGE, 10X90..... E-19-21
BOLT, FLANGE, 10X90..... E-21-20
BOLT, FLANGE, 12X120 ..... E-6-10-53
BOLT, FLANGE, 12X95..... E-3-26
BOLT, FLANGE, 6X10..... E-14-27
BOLT, FLANGE, 6X10..... E-18-1-15
BOLT, FLANGE, 6X10..... E-20-10-10
BOLT, FLANGE, 6X10..... F-7-10-15
BOLT, FLANGE, 6X11..... F-2-29
BOLT, FLANGE, 6X12..... F-3-20-38
BOLT, FLANGE, 6X12..... F-7-7
BOLT, FLANGE, 6X12..... F-7-10-16
BOLT, FLANGE, 6X12..... F-10-38
BOLT, FLANGE, 6X12..... F-10-39
BOLT, FLANGE, 6X14..... E-5-22
BOLT, FLANGE, 6X14..... E-14-26
BOLT, FLANGE, 6X14..... E-18-50
BOLT, FLANGE, 6X14..... E-18-1-14
BOLT, FLANGE, 6X14..... F-2-27
BOLT, FLANGE, 6X14..... F-7-6
BOLT, FLANGE, 6X14(CT200) E-1-12
BOLT, FLANGE, 6X14(CT200) E-3-30
BOLT, FLANGE, 6X14(CT200) E-13-20
BOLT, FLANGE, 6X16..... E-3-32
BOLT, FLANGE, 6X16..... E-13-23
BOLT, FLANGE, 6X16..... E-18-49
BOLT, FLANGE, 6X16..... E-19-23
BOLT, FLANGE, 6X16..... F-2-26
BOLT, FLANGE, 6X16..... F-4-18
BOLT, FLANGE, 6X18..... E-3-35
BOLT, FLANGE, 6X18..... E-5-23
BOLT, FLANGE, 6X20..... E-20-6
BOLT, FLANGE, 6X20..... F-7-20-7
BOLT, FLANGE, 6X20..... F-10-35
BOLT, FLANGE, 6X20..... F-10-43
BOLT, FLANGE, 6X22..... E-3-36
BOLT, FLANGE, 6X22..... E-6-10-31
BOLT, FLANGE, 6X22..... E-13-24
BOLT, FLANGE, 6X22..... E-14-10-13
BOLT, FLANGE, 6X22..... E-15-16
BOLT, FLANGE, 6X23..... F-10-36
BOLT, FLANGE, 6X25..... E-3-10-7
BOLT, FLANGE, 6X25..... E-14-24
BOLT, FLANGE, 6X25..... E-18-47
BOLT, FLANGE, 6X25..... F-3-20-42
BOLT, FLANGE, 6X25..... F-3-30-8
BOLT, FLANGE, 6X28..... E-18-48
BOLT, FLANGE, 6X32..... E-3-10-9
BOLT, FLANGE, 6X32..... E-6-10-32
BOLT, FLANGE, 6X32..... E-14-10-14
BOLT, FLANGE, 6X35..... E-1-13
BOLT, FLANGE, 6X35..... E-3-33
BOLT, FLANGE, 6X35..... E-4-15
BOLT, FLANGE, 6X35..... E-14-25
BOLT, FLANGE, 6X37..... E-3-10-12
BOLT, FLANGE, 6X40..... E-6-10-37
BOLT, FLANGE, 6X55..... E-3-10-11
BOLT, FLANGE, 6X60..... E-4-17
BOLT, FLANGE, 8X120..... E-6-10-34
BOLT, FLANGE, 8X18..... F-3-20-36
BOLT, FLANGE, 8X18..... F-7-10-17
BOLT, FLANGE, 8X20..... E-9-12
BOLT, FLANGE, 8X22..... F-10-44
BOLT, FLANGE, 8X25..... E-3-10-15
BOLT, FLANGE, 8X28..... E-9-13
BOLT, FLANGE, 8X30..... E-5-24
BOLT, FLANGE, 8X30..... E-6-10-35
BOLT, FLANGE, 8X30..... E-9-10-20
BOLT, FLANGE, 8X35..... E-3-38
BOLT, FLANGE, 8X40..... E-4-18
BOLT, FLANGE, 8X40..... E-9-10-21
BOLT, FLANGE, 8X50..... E-3-34
BOLT, FLANGE, 8X50..... E-14-10-15
BOLT, FLANGE, 8X60..... E-4-16
BOLT, FLANGE, 8X65..... E-15-17
BOLT, FLANGE, 8X75..... E-3-37
BOLT, HEX. F-11-32
BOLT, HEX., 10X60 ..... E-6-10-30
BOLT, HEX., 10X85 ..... E-6-10-29
BOLT, HEX., 12X120..... E-6-10-27
BOLT, HEX., 12X130..... F-10-48
BOLT, HEX., 12X200..... F-10-41
BOLT, HEX., 12X45 ..... F-5-13
BOLT, HEX., 12X45 ..... F-5-1-13
BOLT, HEX., 12X65 ..... E-6-10-28
BOLT, HEX., 14X180..... F-3-20-40
BOLT, HEX., 6X14 ..... F-10-45
BOLT, HEX., 6X16 ..... E-6-10
BOLT, HEX., 6X40 ..... F-2-30
BOLT, HEX., 6X55 ..... F-3-22
BOLT, IDLER E-13-13
BOLT, OIL CHECK F-3-10
BOLT, RECESSED..... F-11-29
BOLT, SEALING, 18MM E-5-10
BOLT, SEALING, 22MM E-3-6
BOLT, SEALING, 22MM E-3-39
BOLT, SEALING, 22MM E-3-10-13
BOLT, SEALING, 22MM E-5-15
BOLT, SEALING, 6MM E-18-45
BOLT, SOCKET(A) F-11-30
BOLT, SOCKET(B) F-11-31
BOLT, SOCKET, 6X20 ..... F-8-8
BOLT, SOCKET, 6X25 ..... F-8-7
BOLT, SPECIAL ADJUSTER E-19-22
BOLT, SPECIAL, 6X17..... F-3-30-9
BOLT, SPECIAL, 6X17..... F-3-30-9
BOLT, SPECIAL, 6X220..... FOP-12-2
BOLT, SPECIAL, 8MM..... E-5-14
BOLT, SPECIAL, 8X29..... E-13-10-9
BOLT, STUD, 10X28 ..... F-10-42
BOLT, STUD, 10X45 ..... E-6-10-33
BOLT, STUD, 12X40 ..... F-3-15
BOLT, STUD, 6X68 ..... E-19-8
BOLT, STUD, 8X28 ..... E-14-28
BOLT, STUD, 8X45 ..... E-14-29
BOLT, TENSIONER..... E-19-24
BOLT, TIMING BELT ADJUSTING E-13-21
BOLT, TIMING BELT COVER E-13-10-8
BOLT, TIMING BELT IDLER E-13-14
BOLT, TORX(M6X20) E-20-10-9
BOLT-WASHER, 10X109 ..... E-3-27
BOLT-WASHER, 10X32 ..... F-3-12
BOLT-WASHER, 10X32 ..... F-10-40
BOLT-WASHER, 10X35 ..... F-3-20-37
BOLT-WASHER, 10X47 ..... F-3-13
BOLT-WASHER, 10X60 ..... E-3-28
BOLT-WASHER, 10X80 ..... E-3-29
BOLT-WASHER, 11X105 ..... E-3-31
BOLT-WASHER, 12X163 ..... E-9-11
BOLT-WASHER, 12X35 ..... E-13-25
BOLT-WASHER, 12X50 ..... F-3-20-39
BOLT-WASHER, 16X49 ..... E-13-22
BOLT-WASHER, 5X12 ..... E-14-10-11
BOLT-WASHER, 5X16 ..... E-13-10-7
BOLT-WASHER, 5X28 ..... E-14-10-12
BOLT-WASHER, 6X16 ..... F-2-28
BOLT-WASHER, 6X25 ..... E-15-15
BOLT-WASHER, 6X25 ..... F-7-10-13
BOLT-WASHER, 6X27 ..... E-20-5
BOLT-WASHER, 6X27 ..... E-20-10-8
BOLT-WASHER, 6X27 ..... F-7-10-14
BOLT-WASHER, 6X29 ..... E-6-10-36
BOLT-WASHER, 6X60 ..... E-15-18
BOLT-WASHER, 8X28(SUS) E-6-9
BOLT-WASHER, 8X35 ..... E-18-46
BOLT-WASHER, 8X35 ..... F-3-20-41
BOLT-WASHER, 8X35(SUS) E-6-8
BOLT-WASHER, 8X60 ..... F-4-17
BOLT-WASHER, 8X60 ..... FOP-2-9
BOSS, FLYWHEEL E-5-12
BOX ASSY., JUNCTION F-7-20-1
BOX ASSY., REMOTE CONTROL FOP-3-3-1
BOX ASSY., REMOTE CONTROL FOP-3-3-1
BOX KIT, REMOTE CONTROL..... FOP-3-1
BOX KIT, REMOTE CONTROL..... FOP-3-1-1
BOX KIT, REMOTE CONTROL..... FOP-3-2-1
BRACKET FOP-3-3-11
BRACKET FOP-5-14
BRACKET FOP-5-1-14
BRACKET FOP-5-2-14
BRACKET ASSY..... F-11-6
BRACKET C, HARNESS CLIP E-1-10

BRACKET, A.C. GENERATOR FUSE E-20-10-3
BRACKET, BUZZER FOP-5-3-17
BRACKET, BUZZER FOP-5-4-13
BRACKET, CLIP B E-1-9
BRACKET, CLIP B E-3-21
BRACKET, COUPLER A E-20-10-4
BRACKET, COUPLER C F-7-10-2
BRACKET, COUPLER D E-13-18
BRACKET, COUPLER D E-20-10-5
BRACKET, FR. E-21-11
BRACKET, FUEL PUMP COUPLER E-1-8
BRACKET, HARNESS CLIP A E-14-23
BRACKET, HOOK FR. F-8-2
BRACKET, HOOK L F-8-6
BRACKET, HOOK R F-8-5
BRACKET, JUNCTION CONNECTOR F-7-2
BRACKET, L. STERN F-10-26
BRACKET, NEUTRAL SWITCH F-2-24
BRACKET, R. STERN F-10-25
BRACKET, REMOTE CONTROL FOP-3-11
BRACKET, REMOTE CONTROL FOP-3-2-12
BRACKET, RR. E-21-12
BRACKET, SHIFT LINK(MECH) F-2-21
BRACKET, TILT LIMIT SWITCH F-10-22
BRACKET, TILTING F-10-29
BRACKET, UNDER CASE FR. F-3-20-17
BRACKET, WIRE CLAMP FOP-3-3-15
BREAKER ASSY. F-11-1
BRUSH ASSY. F-11-2
BRUSH SET E-21-7
BUSH A, THRUST RECEIVE F-10-32
BUSH B, THRUST RECEIVE F-10-33
BUSH COMP., VERTICAL SHAFT F-3-20-21
BUSH, INSULATION E-19-4
BUSH, INSULATION E-19-18
BUSH, LOWER CYLINDER F-11-25
BUSH, MOTOR CODE F-11-20
BUSH, SHIFT ARM F-2-19
BUSH, SWIVEL CASE F-10-21
BUSH, SWIVEL CASE F-11-12
BUSH, TILT ARM F-10-28
BUTTON, THROTTLE FOP-3-8
BUTTON, THROTTLE FOP-3-1-8
BUTTON, THROTTLE FOP-3-2-9
BUZZER COMP., WARNING FOP-3-3-42
BUZZER COMP., WARNING FOP-5-13
BUZZER COMP., WARNING FOP-5-1-13
BUZZER COMP., WARNING FOP-5-2-13
BUZZER COMP., WARNING FOP-5-3-16
BUZZER COMP., WARNING FOP-5-4-12
<C>
CABLE ASSY., CONVERSION(10FT) FOP-10-5
CABLE ASSY., CONVERSION(6FT) FOP-10-5
CABLE ASSY., INTERFACE(10FT) FOP-7-2
CABLE ASSY., INTERFACE(16FT) FOP-7-2
CABLE ASSY., INTERFACE(6FT) FOP-7-2
CABLE ASSY., PANEL INDICATOR FOP-10-2
CABLE ASSY., PANEL INDICATOR FOP-10-2
CABLE ASSY., PANEL INDICATOR FOP-10-2
CABLE ASSY., POWER TILT RELAY F-7-10-7
CABLE ASSY., REMOTE CONTROL(B) FOP-3-3-31
CABLE ASSY., STARTER F-7-10-3
CABLE COMP., THROTTLE E-15-9
CABLE KIT, INTERFACE(10FT) FOP-7-1
CABLE KIT, INTERFACE(16FT) FOP-7-1
CAM A, TILT LIMIT ANGLE F-10-23
CAM B, TILT LIMIT ANGLE F-10-24
CAMSHAFT, L. E-9-10-2
CAMSHAFT, L. E-9-10-2
CAMSHAFT, R. E-9-10-1
CAMSHAFT, R. E-9-10-1
CAP ASSY., OIL FILLER E-3-10-5
CAP COMP., OIL TANK F-11-28
CAP, BOLT, 10MM E-3-10-14
CAP, DUMMY(WPC 4P 090 M)(RED) F-7-5
CAP, GRIP FOP-3-6
CAP, GRIP FOP-3-2-8
CAP, L. SIDE COVER F-3-20-34
CAP, RUBBER FOP-3-3-16
CAP, SWITCH FOP-3-7
CAP, TIMING BELT TENSIONER E-13-8
CAP, TROLLING CONTROL SWITCH FOP-3-3-23
CAP, WATER JOINT F-3-20-6
CARTRIDGE, OIL FILTER E-3-10-4
CASE ASSY., ENGINE UNDER F-3-20-10
CASE ASSY., GEAR(L) F-3-10-1
CASE ASSY., GEAR(XL) F-3-10-1
CASE ASSY., GEAR(XL) F-3-10-1
CASE ASSY., OIL SEAL E-3-2
CASE COMP., GEAR F-3-9
CASE COMP., MOUNT E-6-10-24
CASE COMP., PUMP E-18-28
CASE KIT, GEAR FOP-17-1
CASE, ELECTRONIC CONTROL UNIT E-20-10-7
CASE, ELECTRONIC PARTS E-20-10-1
CASE, EXTENSION(L) F-3-20-19
CASE, EXTENSION(XL) F-3-20-18
CASE, FLUSH VALVE E-6-10-9
CASE, GEAR F-3-2
CASE, POWER TILT RELAY F-7-10-12
CASE, SWIVEL(L) F-10-19
CASE, SWIVEL(XL) F-10-19
CIRCLIP, EXTERNAL, 15MM F-5-31
CIRCLIP, EXTERNAL, 15MM F-5-1-33
CIRCLIP, EXTERNAL, 39MM F-10-66
CIRCLIP, INTERNAL F-11-34
CIRCLIP, INTERNAL, 43 ..... F-3-20-48
CIRCLIP, INTERNAL, 47MM F-4-34
CLAMP F-6-5
CLAMP F-6-8
CLAMP FOP-1-2
CLAMP B, FUEL TUBE E-18-1-5
CLAMP, 6MM-12MM E-18-10-29
CLAMP, CHECK VALVE E-18-10-1
CLAMP, HOSE E-14-15
CLAMP, HOSE E-18-10-16
CLAMP, TUBE(D10.5) E-4-19
CLAMP, TUBE(D10.5) E-6-10-40
CLAMP, TUBE(D10.5) E-18-10-26
CLAMP, TUBE(D10.7) E-18-10-25
CLAMP, TUBE(D12) E-18-1-16
CLAMP, TUBE(D12) E-18-10-27
CLAMP, TUBE(D21) E-4-21
CLAMP, TUBE(D29) E-4-20
CLAMP, TUBE(D32.5) E-1-14
CLIP A, WIRE E-1-11
CLIP D, WASHER TUBE E-1-19
CLIP, BRAKE PIPE E-15-14
CLIP, DETENT FOP-3-3-9
CLIP, EMERGENCY LOCK FOP-5-11
CLIP, EMERGENCY LOCK FOP-5-1-11
CLIP, EMERGENCY LOCK FOP-5-2-11
CLIP, EMERGENCY LOCK FOP-5-3-12
CLIP, EMERGENCY LOCK FOP-5-4-9
CLIP, HARNESS E-18-52
CLIP, HARNESS BAND(BLACK) E-18-1-18
CLIP, HARNESS BAND(BLACK) F-2-45
CLIP, HARNESS BAND(BLACK) F-7-9
CLIP, HARNESS BAND(BLACK) F-7-10-26
CLIP, HARNESS BAND(BLACK) FOP-7-5
CLIP, INJECTOR E-14-2
CLIP, PISTON PIN E-7-4
CLIP, ROLLER FOP-3-3-75
CLIP, SENSOR HOSE E-18-10-24
CLIP, TUBE E-6-10-2
CLIP, TUBE F-10-3
CLIP, TUBE(B12) E-18-1-17
CLIP, TUBE(B12) E-18-10-28
CLIP, TUBE(B12.5) E-6-10-41
CLIP, TUBE(B12.5) F-3-20-47
CLIP, WIRE HARNESS F-7-8
CLIP, WIRE HARNESS F-7-10-22
CLIP, WIRE HARNESS F-7-10-23
CLIP, WIRE HARNESS F-10-67
CLIP, WIRE HARNESS, 10MM E-14-31
CLIP, WIRE HARNESS, 25MM E-1-15
CLIP, WIRE HARNESS, 25MM E-20-10-11
CLUTCH COMP., OVERRUNNING E-21-3
COIL ASSY., PLUG TOP E-20-1
COLLAR E-18-26
COLLAR A, COVER LOCK F-3-20-29
COLLAR B, COVER LOCK F-3-20-30
COLLAR, 12X6.5 ..... F-3-30-11
COLLAR, 5.5X6.8 ..... E-14-10-8
COLLAR, 8.5X14.5 ..... E-18-54
COLLAR, 8.5X14.5 ..... F-3-20-53
COLLAR, C.D.I. UNIT CASE E-15-20
COLLAR, C.D.I. UNIT CASE E-20-7
COLLAR, C.D.I. UNIT CASE E-20-10-12
COLLAR, C.D.I. UNIT CASE F-7-10-25
COLLAR, DISTANCE F-4-33
COLLAR, DISTANCE FOP-2-14
COLLAR, DISTANCE(A) FOP-12-3
COLLAR, DISTANCE(B) FOP-12-4
COLLAR, DISTANCE, 6.5X9X3 ..... F-8-11
COLLAR, MOUNTING(6MM) F-7-10-24
COLLAR, ORIFICE F-11-46
COLLAR, SET E-18-23
COLLAR, SHIFT SLIDER F-2-13
COLLAR, STEERING ROD F-10-70
COLLAR, TIMING BELT COVER E-13-10-10
CONNECTOR KIT, TERMINATOR FOP-10-1
CONNECTOR(T) FOP-7-3
CONTROL UNIT, ELECTRONIC E-20-10-6
CONTROL UNIT, ELECTRONIC E-20-10-6
CONTROL UNIT, ELECTRONIC E-20-10-6
CORD COMP., EMERGENCY FOP-3-3-39
CORD COMP., EMERGENCY FOP-5-10
CORD COMP., EMERGENCY FOP-5-1-10
CORD COMP., EMERGENCY FOP-5-2-10
CORD COMP., EMERGENCY FOP-5-3-11
CORD COMP., EMERGENCY FOP-5-4-8
CORD, A.C. GENERATOR F-7-10-9
CORD, SWITCH E-3-22
COTTER, VALVE(FUJI VALVE) E-9-10-19
COVER ASSY. FOP-3-1-11
COVER ASSY., COOLING FAN E-15-10
COVER ASSY., CRANKCASE UPPER E-3-1
COVER ASSY., ENGINE F-8-1
COVER ASSY., L. TIMING BELT E-13-10-3
COVER ASSY., R. TIMING BELT E-13-10-2
COVER B, TERMINAL F-7-10-6
COVER B, TERMINAL(L) F-7-10-5
COVER COMP. E-18-4
COVER COMP., CYLINDER HEAD(L.) E-1-3
COVER COMP., CYLINDER HEAD(R.) E-1-1
COVER COMP., ENGINE UNDER L F-3-30-5
COVER COMP., ENGINE UNDER L F-3-30-6
COVER COMP., ENGINE UNDER R F-3-30-3
COVER COMP., ENGINE UNDER R F-3-30-4
COVER COMP., FUSE F-7-20-2
COVER, BEARING E-19-5
COVER, DUAL GRIP FOP-3-2-7
COVER, FLUSH VALVE E-6-10-8
COVER, GEAR CASE F-3-4
COVER, GRIP FOP-3-1-4
COVER, IMPELLER F-4-4
COVER, IMPELLER FOP-2-6
COVER, INTAKE MANIFOLD UPPER E-14-10-4
COVER, L. CAMSHAFT THRUST E-9-8
COVER, L. GRIP FOP-3-4
COVER, L. GRIP FOP-3-2-5
COVER, L. RELIEF VALVE E-6-10-19
COVER, L. WATER JACKET E-6-10-23
COVER, LEVER FOP-3-3-6
COVER, LOCK ARM FOP-3-1-6
COVER, NEUTRAL SWITCH F-2-25
COVER, OIL LEVEL GAUGE E-3-16
COVER, OIL PUMP E-5-4
COVER, POWER TRIM-TILT WIRE FOP-3-3-18
COVER, POWER TRIM-TILT WIRE FOP-3-3-19
COVER, PUMP E-18-29
COVER, PUMP(A) E-18-31
COVER, R. CAMSHAFT THRUST E-9-7
COVER, R. RELIEF VALVE E-6-10-15
COVER, R. WATER JACKET E-6-10-21
COVER, REMOTE CONTROL CABLE F-2-3
COVER, RR. F-3-30-7
COVER, SEPARATE F-3-20-16
COVER, STARTER TERMINAL F-7-10-4
COVER, THERMOSTAT E-4-13
COVER, UPPER MOUNT E-10-18
COVER, WATER JACKET E-18-12
CRANKCASE COMP. E-3-10-1
CRANKSHAFT COMP. E-7-8
CUP SET, WATER SEPARATER E-18-1-19
<D>
DOWEL PIN, 10X12 ..... E-14-35
DOWEL PIN, 13X37 ..... E-3-40
DOWEL PIN, 14X15 ..... E-5-16
DOWEL PIN, 14X15 ..... E-6-10-42
DOWEL PIN, 16X22 ..... E-9-15
DOWEL PIN, 6X10 ..... E-3-53
DOWEL PIN, 6X10 ..... E-9-14
DOWEL PIN, 6X10 ..... E-13-30
DOWEL PIN, 6X10 ..... E-15-21
DOWEL PIN, 6X10 ..... F-3-20
DOWEL PIN, 6X10 ..... F-3-20-51
DOWEL PIN, 6X10 ..... F-4-24
DOWEL PIN, 8X14 ..... E-3-10-19
DRIVER 1, PLUS SCREW(NO.2) F-13-6
DRUM ASSY., FREE THROTTLE FOP-3-3-27
DUMMY, WATER PROOF CONNECTOR F-7-3
DUMMY, WATER PROOF CONNECTOR FOP-5-5

DUMMY, WATER PROOF CONNECTOR . FOP-5-1-5
DUMMY, WATER PROOF CONNECTOR . FOP-5-2-5
<E>
END COVER, RR. E-19-17
END, NIPPLE..... F-10-10
E-RING, 10MM..... F-4-35
E-RING, 12MM..... F-2-47
E-RING, 15MM..... F-11-47
E-RING, 4MM F-2-46
E-RING, 6MM FOP-3-32
E-RING, 6MM FOP-3-1-28
E-RING, 6MM FOP-3-2-37
E-RING, 6MM FOP-3-3-69
EXTENSION, OIL FILLER E-3-10-6
<F>
FAN, COOLING..... E-13-16
FILTER ASSY., SPOOL VALVE..... E-3-19
FILTER ASSY., SPOOL VALVE..... E-3-19
FILTER B..... F-11-18
FLOAT SET..... E-18-2
FLYWHEEL COMP. E-5-11
FRAME COMP., MOUNTING(L) F-10-13
FRAME COMP., MOUNTING(XL)..... F-10-13
FUSE, BLOCK(150A)..... F-7-20-3
FUSE, MINI(10A) F-7-20-9
FUSE, MINI(15A) F-7-20-10
FUSE, MINI(30A) F-7-20-11
<G>
GASKET B, IMPELLER..... F-4-5
GASKET B, IMPELLER..... FOP-2-7
GASKET COMP., CYLINDER HEAD E-9-9
GASKET, EAC VALVE E-15-5
GASKET, EX. PIPE..... E-6-4
GASKET, FR. INJECTOR BASE..... E-14-17
GASKET, INTAKE MANIFOLD..... E-14-20
GASKET, INTAKE MANIFOLD..... E-14-10-1
GASKET, L. EX. MANIFOLD..... E-4-5
GASKET, MOUNT CASE..... E-6-10-25
GASKET, R. EX. MANIFOLD..... E-4-3
GASKET, RR. INJECTOR BASE..... E-14-19
GASKET, THROTTLE BODY..... E-15-2
GAUGE COMP., OIL LEVEL E-3-15
GEAR ASSY., INTERNAL..... E-21-18
GEAR ASSY., PLANETARY..... E-21-4
GEAR ASSY., SHIFT..... FOP-3-3-24
GEAR COMP., BEVEL(FORWARD)..... F-5-8
GEAR COMP., BEVEL(REVERSE)..... F-5-1-9
GEAR, BEVEL(FORWARD)(24T)..... F-5-1-8
GEAR, BEVEL(REVERSE)(24T)..... F-5-9
GEAR, DRIVE..... FOP-3-3-25
GEAR, PINION F-4-16
GEAR, PINION(COUNTER ROTATION) .. F-4-16
GENERATOR ASSY., A.C..... E-19-14
GRIP FOP-3-3-5
GRIP, REMOTE CONTROL HANDLE FOP-3-5
GRIP, REMOTE CONTROL HANDLE FOP-3-2-6
GRIP, SCREW DRIVER..... F-13-7
GROMMET E-14-10-10
GROMMET, 1WAY..... F-3-20-54
GROMMET, ELECTRONIC PARTS CASE . E-20-10-2
GROMMET, ELECTRONIC PARTS CASE . F-7-10-1
GROMMET, EXTENSION CASE F-4-13
GROMMET, GEAR CASE F-3-3
GROMMET, LOCK HOOK F-8-3
GROMMET, RELAY F-7-10-11
GROMMET, RELAY BRACKET..... E-20-4
GROMMET, SILENCER..... E-15-8
GROMMET, TIMING BELT COVER..... E-13-10-1
GROMMET, UNDER CASE..... E-15-13
GROMMET, UNDER CASE..... F-3-30-1
GROMMET, UNDER CASE(C)..... F-11-10
GROMMET, UNDER CASE(MECH) F-3-20-13
GROMMET, VAPOR SEPARATOR E-18-38
GROMMET, VAPOR SEPARATOR E-18-39
GROMMET, WATER CHECK F-3-20-35
GROMMET, WATER TUBE..... E-6-6
GROMMET, WIRE(14)..... FOP-3-3-22
GUIDE COMP., ROD F-11-17
GUIDE, EX. VALVE(O.S.)..... E-9-3
GUIDE, IN. VALVE(O.S.) E-9-2
GUIDE, L. EX..... E-6-10-6
GUIDE, R. EX. E-6-10-3
GUIDE, SHIFT LINK(MECH)..... F-2-20
<H>
HANDLE, REMOTE CONTROL..... FOP-3-3
HANDLE, REMOTE CONTROL..... FOP-3-1-3
HANDLE, REMOTE CONTROL..... FOP-3-2-4
HANGER, ENGINE..... E-3-10-2
HANGER, ENGINE..... E-9-1
HARNESS ASSY., MAIN WIRE..... F-7-1
HARNESS ASSY., MAIN WIRE..... F-7-1
HARNESS ASSY., SWITCH PANEL..... FOP-5-4
HARNESS ASSY., SWITCH PANEL..... FOP-5-1-4
HARNESS ASSY., SWITCH PANEL..... FOP-5-2-4
HARNESS ASSY., SWITCH PANEL..... FOP-5-3-6
HARNESS ASSY., SWITCH PANEL..... FOP-5-4-3
HARNESS COMP..... E-18-43
HEAD COMP., CYLINDER E-9-5
HOLDER..... E-18-11
HOLDER ASSY., BEARING..... F-5-1-11
HOLDER ASSY., BRUSH..... E-19-1
HOLDER COMP., BRUSH..... E-21-10
HOLDER, BEARING..... F-5-12
HOLDER, NEUTRAL LOCK FOP-3-1-14
HOLDER, NEUTRAL LOCK FOP-3-3-21
HOLDER, OIL FILTER E-3-10-8
HOLDER, PROPELLER SHAFT F-5-11
HOLDER, PROPELLER SHAFT F-5-1-12
HOLDER, SEAL..... F-2-22
HOLDER, SHIFT ROD F-4-12
HOOK COMP., COVER LOCK L..... F-3-20-32
HOOK COMP., COVER LOCK R..... F-3-20-28
HOSE..... F-6-6
HOSE..... F-6-7
HOSE A, PRESSURE REGULATOR..... E-18-10-18
HOSE B, PRESSURE REGULATOR E-18-10-19
HOSE COMP. B, FUEL..... E-14-12
HOSE COMP., FUEL E-14-10
HOSE COMP., FUEL JOINT E-14-11
HOSE KIT, RIGGING FOP-1-1
HOUSING ASSY., L. INNER FOP-3-2
HOUSING ASSY., L. INNER FOP-3-2-2
HOUSING ASSY., R. INNER FOP-3-1-2
HOUSING ASSY., R. INNER FOP-3-2-3
HOUSING COMP., REMOTE CONTROL.. FOP-3-12
HOUSING COMP., REMOTE CONTROL.. FOP-3-2-13
HOUSING, FR..... FOP-3-3-12
HOUSING, IMPELLER..... F-4-2
HOUSING, IMPELLER..... FOP-2-4
HOUSING, LEAD FOP-3-13
HOUSING, LEAD FOP-3-2-14
HOUSING, LOWER CENTER MOUNTING F-10-17
HOUSING, LOWER CENTER MOUNTING F-10-17
HOUSING, LOWER MOUNTING F-3-20-22
HOUSING, RR. FOP-3-3-13
HOUSING, UPPER MOUNTING..... F-10-14
HOUSING, WATER PUMP F-4-6
<I>
IDLER B, TIMING BELT E-13-15
IDLER, TIMING BELT(KOYO SEIKO) E-13-12
IMPELLER, PUMP F-4-1
IMPELLER, PUMP FOP-2-3
INJECTOR ASSY., FUEL E-14-1
INSULATOR..... E-18-33
INSULATOR COMP..... E-18-32
<J>
JOINT ASSY (INLET) F-6-2
JOINT ASSY (OUTLET)..... F-6-3
JOINT ASSY., OIL PIPE E-3-12
JOINT SET E-18-6
JOINT, DRIVE F-11-16
JOINT, FUEL FEED HOSE..... E-18-10-6
JOINT, FUEL PIPE E-14-9
JOINT, FUEL PIPE E-18-42
JOINT, FUEL RETURN..... E-18-10-17
JOINT, FUEL TUBE..... F-13-1
JOINT, THREE WAY..... E-18-10-11
JOINT, WATER HOSE F-3-20-3
<K>
KEY, 4.5X24..... E-13-28
KEY, SPECIAL E-13-29
KEY, WOODRUFF F-4-23
KEY, WOODRUFF FOP-2-10
KIT, CABLE(NMEA)(6FT) FOP-7-1
<L>
LABEL, FUSE & OIL CAUTION(EF)..... F-12-1
LABEL, SIGP FOP-3-3-49
LABEL, WARNING OPERATOR(EU)..... F-12-10
LAMP ASSY., INDICATION FOP-3-3-40
LAMP ASSY., INDICATION(4-LED) FOP-5-3-14
LAMP ASSY., INDICATION(4-LED) FOP-5-4-10
LEVER SET..... E-21-17
LEVER, COVER LOCK FR..... F-3-20-27
LEVER, COVER LOCK L..... F-3-20-33
LEVER, COVER LOCK R..... F-3-20-31
LEVER, FREE THROTTLE FOP-3-3-29
LEVER, HAND..... FOP-3-3-3
LINER, PUMP F-4-3
LINER, PUMP FOP-2-5
LINER, SWIVEL CASE F-10-20
<M>
MANIFOLD COMP., INLET E-14-10-3
MANIFOLD COMP., L. EX..... E-4-4
MANIFOLD COMP., R. EX..... E-4-2
MARK, EMBLEM..... FOP-3-3-48
MARK, EMERGENCY STOP FOP-3-3-45
MARK, EMERGENCY STOP FOP-3-3-47
MARK, EMERGENCY STOP(US)..... FOP-3-3-45
MARK, EMERGENCY STOP(US)..... FOP-3-3-46
MARK, FAST IDLE FOP-3-3-44
MARK, FLUSH MOUNT FOP-3-1-19
MARK, FR. EMBLEM F-12-9
MARK, FR.(BFT200)..... F-12-6
MARK, FR.(BFT225)..... F-12-7
MARK, FR.(BFT250)..... F-12-8
MARK, HANDLE FLUSH MOUNT FOP-3-1-18
MARK, REMOTE CONTROL(DUAL) FOP-3-2-23
MARK, REMOTE CONTROL(SINGLE) FOP-3-20
MARK, RR.(BFT200) F-12-2
MARK, RR.(BFT225) F-12-3
MARK, RR.(BFT250) F-12-4
MARK, SIDE STRIPE..... F-12-5
MESH, FUEL FILTER E-14-4
METAL COMP., ANODE..... F-3-8
METAL KIT, ANODE F-10-1
METAL, ANODE..... E-3-4
METAL, ANODE..... E-3-5
METAL, ANODE..... E-4-1
METAL, ANODE..... E-6-10-1
METER LEAD WIRE..... FOP-4-3
MOTION COMP., LOST E-9-10
MOTOR ASSY., POWER TILT..... F-11-5
MOTOR ASSY., STARTER..... E-21-1
MOUNT COMP., LOWER RUBBER..... F-3-20-23
MOUNT COMP., UPPER RUBBER F-10-15
<N>
NIPPLE, GREASE F-10-68
NIPPLE, SENSOR F-10-11
NIPPLE, SENSOR F-10-12
NUT..... FOP-5-17
NUT..... FOP-5-1-17
NUT..... FOP-5-2-17
NUT, 5MM..... FOP-3-3-60
NUT, 6MM..... FOP-3-3-58
NUT, CASTLE, 18MM F-5-14
NUT, CASTLE, 18MM F-5-1-14
NUT, FLANGE CAP, 10MM E-3-10-16
NUT, FLANGE, 10MM..... F-10-52
NUT, FLANGE, 12MM..... F-10-50
NUT, FLANGE, 5MM..... E-14-10-17
NUT, FLANGE, 5MM..... FOP-5-16
NUT, FLANGE, 5MM..... FOP-5-1-16
NUT, FLANGE, 5MM..... FOP-5-2-16
NUT, FLANGE, 5MM..... FOP-5-3-19
NUT, FLANGE, 5MM..... FOP-5-3-19
NUT, FLANGE, 5MM..... FOP-5-4-15
NUT, FLANGE, 6MM..... F-2-31
NUT, FLANGE, 8MM..... E-14-30
NUT, FLANGE, 8MM..... E-14-10-16
NUT, FLANGE, 8MM..... E-19-25
NUT, HEX., 12MM F-10-74
NUT, HEX., 16MM F-3-20-43
NUT, HEX., 16MM FOP-3-3-59
NUT, HEX., 16MM FOP-5-3-20
NUT, HEX., 16MM FOP-5-4-16
NUT, HEX., 18MM F-4-20
NUT, HEX., 20MM F-2-32
NUT, HEX., 4MM F-10-75
NUT, HEX., 5MM F-10-73
NUT, HEX., 5MM FOP-3-28
NUT, HEX., 5MM FOP-3-2-32
NUT, HEX., 5MM FOP-3-2-33
NUT, HEX., 6MM E-19-27
NUT, HEX., 6MM FOP-3-1-25
NUT, LOCK, 68MM F-4-19
NUT, PULLEY LOCK E-19-7
NUT, SELF-LOCK(3/8-24UNF)..... F-10-53
NUT, SELF-LOCK(7/8-14UNF)..... F-10-51
NUT, SELF-LOCK, 12MM..... F-3-18
NUT, SELF-LOCK, 14MM..... F-3-20-44
NUT, SELF-LOCK, 5MM..... F-3-17
NUT, SELF-LOCK, 6MM..... F-3-16
NUT, SELF-LOCK, 6MM..... F-8-9
NUT, SELF-LOCK, 6MM..... F-10-49

NUT, TAPPET ADJUSTING E-9-10-22
NUT, TAPPET ADJUSTING E-9-10-23
NUT, WATER MOUTH F-3-20-2
NUT-WASHER, 5MM E-19-26
NUT-WASHER, 6MM F-7-10-19
NUT-WASHER, 8MM F-7-10-18
<O>
OIL SEAL F-11-35
OIL SEAL, 14X26X6 ..... F-2-42
OIL SEAL, 31X46X7(NOK)..... E-5-18
OIL SEAL, 39.5X52X6(ARAI)..... F-10-69
OIL SEAL, 39X53X8(NOK)..... E-9-16
OIL SEAL, 41X66X8 ..... E-3-41
OIL SEAL, 46X60X9 ..... E-5-17
OIL SEAL, 80X98X10(ARAI) E-3-42
ORIFICE ASSY., OIL CONTROL..... E-3-10
O-RING..... E-14-10-9
O-RING..... E-15-19
O-RING..... E-18-13
O-RING..... E-18-14
O-RING..... E-18-15
O-RING..... E-18-16
O-RING..... E-18-17
O-RING..... E-18-18
O-RING..... E-18-19
O-RING..... E-18-1-1
O-RING..... E-18-1-11
O-RING..... F-4-29
O-RING..... FOP-17-7
O-RING SET, 3.5X31.7 ..... F-11-43
O-RING, 1.68X7.25 ..... F-11-39
O-RING, 1.8X69.6 ..... F-11-37
O-RING, 1.9X10 ..... F-3-20-1
O-RING, 1.9X11 ..... F-11-40
O-RING, 121X3.1..... F-5-30
O-RING, 121X3.1..... F-5-1-32
O-RING, 121X3.1..... FOP-17-8
O-RING, 13X1.5(ARAI)..... E-3-48
O-RING, 15X1.9 ..... E-3-50
O-RING, 16.3X3.5 ..... E-3-47
O-RING, 16MM E-6-10-45
O-RING, 18.1X3.6 ..... E-3-10-17
O-RING, 18.3X3.5 ..... E-3-45
O-RING, 2.0X70.5 ..... F-11-36
O-RING, 20.6X2.6 ..... E-5-19
O-RING, 23.5X2 ..... E-6-10-48
O-RING, 25X2.4(NOK) E-3-49
O-RING, 26.2X2.4(NOK) E-3-46
O-RING, 26.9X2.4(NOK) F-2-44
O-RING, 28.3X2.4(NOK) E-3-10-18
O-RING, 3.5X35.7 ..... F-11-41
O-RING, 3.5X38.7 ..... F-11-38
O-RING, 3.5X41.7 ..... F-11-42
O-RING, 31.5X2.4(ARAI) E-4-24
O-RING, 33.5X2 ..... E-6-10-47
O-RING, 48.5X2.4 ..... E-9-17
O-RING, 49.4X3.1 ..... E-6-10-46
O-RING, 59.4X3.1 ..... E-21-22
O-RING, 6.9X1.45 ..... F-3-21
O-RING, 6.9X1.45 ..... FOP-17-6
O-RING, 65.4X2.4 ..... F-4-32
O-RING, 65.4X2.4 ..... FOP-2-13
O-RING, 66.4X3.1 ..... E-4-22
O-RING, 7.45X3.61(NOK) E-14-34
O-RING, 7.47X3.6 ..... E-14-33
O-RING, 7.8X1.9(ARAI) E-14-32
O-RING, 7.8X1.9(ARAI) E-18-53
O-RING, 8.8X1.9..... E-3-43
O-RING, 8.8X2.4..... E-3-11
O-RING, 9.5X1.9..... E-3-44
O-RING, 9.5X1.9..... E-4-23
O-RING, PRESSURE REGULATOR E-14-7
O-RING, TIMING BELT TENSIONER E-13-11
O-RING, WATER PUMP F-4-30
O-RING, WATER PUMP FOP-2-11
O-RING, WATER PUMP HOUSING F-4-31
O-RING, WATER PUMP HOUSING FOP-2-12
<P>
PACKING F-11-45
PACKING, DUAL FOP-3-2-18
PACKING, FLASH VALVE..... E-6-10-18
PACKING, HEAD COVER E-1-2
PACKING, INTAKE MANIFOLD UP E-14-10-5
PACKING, OIL HOLE..... E-3-9
PACKING, OIL LEVEL GAUGE..... E-3-17
PACKING, OIL PAN..... E-6-2
PACKING, OIL PUMP BODY..... E-5-2
PACKING, RELIEF VALVE..... E-6-10-17
PACKING, RELIEF VALVE COVER E-6-10-16
PACKING, SINGLE..... FOP-3-17
PACKING, THROTTLE BODY E-14-10-2
PACKING, WATER JACKET COVER..... E-6-10-22
PAN ASSY., OIL E-6-1
PANEL ASSY., CONTROL(SINGLE) FOP-5-2
PANEL ASSY., CONTROL(SINGLE) FOP-5-2
PANEL ASSY., CONTROL(TRIPLE)..... FOP-5-2-2
PANEL ASSY., CONTROL(TRIPLE)..... FOP-5-2-2
PANEL ASSY., CONTROL(TWIN)..... FOP-5-1-2
PANEL ASSY., CONTROL(TWIN)..... FOP-5-1-2
PANEL ASSY., INDICATOR(4-LED) FOP-5-3-13
PANEL ASSY., SWITCH..... FOP-5-3-3
PANEL ASSY., SWITCH..... FOP-5-3-3
PANEL KIT, SWITCH(4-LED)..... FOP-5-4-1
PANEL KIT, SWITCH(4-LED)..... FOP-5-4-1
PANEL KIT, SWITCH(B)(4-LED) FOP-5-3-1
PANEL KIT, SWITCH(B)(4-LED) FOP-5-3-1
PANEL KIT, SWITCH(SINGLE)..... FOP-5-1
PANEL KIT, SWITCH(SINGLE)..... FOP-5-1
PANEL KIT, SWITCH(TRIPLE) FOP-5-2-1
PANEL KIT, SWITCH(TRIPLE) FOP-5-2-1
PANEL KIT, SWITCH(TWIN) FOP-5-1-1
PANEL KIT, SWITCH(TWIN) FOP-5-1-1
PANEL, BACK..... FOP-3-3-14
PANEL, CONTROL..... FOP-5-3-4
PANEL, CONTROL..... FOP-5-3-4
PANEL, CONTROL..... FOP-5-3-5
PANEL, CONTROL..... FOP-5-4-2
PANEL, CONTROL..... FOP-5-4-2
PANEL, CONTROL(SINGLE) FOP-5-3
PANEL, CONTROL(SINGLE) FOP-5-3
PANEL, CONTROL(TRIPLE)..... FOP-5-2-3
PANEL, CONTROL(TRIPLE)..... FOP-5-2-3
PANEL, CONTROL(TWIN)..... FOP-5-1-3
PANEL, CONTROL(TWIN)..... FOP-5-1-3
PIN B, DOWEL, 10X16 ..... E-5-21
PIN B, DOWEL, 10X16 ..... E-6-10-51
PIN B, DOWEL, 6X10 ..... E-9-18
PIN, LINK F-2-40
PIN, LOCK SPRING F-3-20-50
PIN, PISTON E-7-3
PIN, SHIFTER, 8X50..... F-5-2
PIN, SHIFTER, 8X50..... F-5-1-2
PIN, SNAP, 6MM F-2-39
PIN, SPLIT, 4.0 ..... F-5-22
PIN, SPLIT, 4.0 ..... F-5-1-23
PIN, SPLIT, 4.0 ..... FOP-17-2
PIN, SPRING, 3X20 ..... F-10-76
PIN, SPRING, 6X22 ..... F-3-20-49
PIN, UPPER CYLINDER..... F-11-26
PIN, VERTICAL SHAFT E-13-19
PIPE COMP., L. EX..... E-6-5
PIPE COMP., L. FUEL..... E-14-5
PIPE COMP., R. EX. E-6-3
PIPE, R. FUEL..... E-14-3
PISTON..... E-7-2
PISTON COMP., FREE..... F-11-22
PISTON(0.25) E-7-2
PIVOT, SHIFT F-2-14
PIVOT, THROTTLE..... F-2-17
PLATE..... E-18-10
PLATE..... E-18-1-12
PLATE ASSY..... FOP-3-3-2
PLATE SET, TRANSOM(5.5MM FLAT) ... FOP-14-2
PLATE SET, TRIM ADJUST..... FOP-14-1
PLATE, CABLE CLAMP..... FOP-3-10
PLATE, CABLE CLAMP..... FOP-3-2-11
PLATE, CRANK PULSER..... E-13-2
PLATE, DWELL..... FOP-3-14
PLATE, DWELL..... FOP-3-1-10
PLATE, DWELL..... FOP-3-2-15
PLATE, HANDLE FOP-3-9
PLATE, HANDLE FOP-3-2-10
PLATE, L. TIMING BELT COVER..... E-13-10-4
PLATE, LOCK..... F-2-15
PLATE, LOCK..... F-2-18
PLATE, R. TIMING BELT COVER..... E-13-10-5
PLATE, REMOTE CONTROL CABLE F-2-2
PLATE, REMOTE CONTROL(REVERSE) .. FOP-3-3-43
PLATE, RUBBER SETTING F-3-1
PLATE, SHIFT F-5-7
PLATE, SHIFT F-5-1-7
PLATE, STARTER CABLE F-7-10-8
PLATE, SWITCH FOP-3-3-36
PLATE, WATER TUBE E-6-7
PLATE, WINKER BUZZER..... FOP-3-3-41
PLATE, WINKER BUZZER..... FOP-5-3-15
PLATE, WINKER BUZZER..... FOP-5-4-11
PLUG, FUEL TUBE..... E-18-1-13
PLUG, INNER CONNECTOR FOP-3-3-32
PLUG, INNER CONNECTOR FOP-5-6
PLUG, INNER CONNECTOR FOP-5-1-6
PLUG, INNER CONNECTOR FOP-5-2-6
PLUG, INNER CONNECTOR FOP-5-3-7
PLUG, INNER CONNECTOR FOP-5-4-4
PLUG, OUTER CONNECTOR..... FOP-3-3-33
PLUG, OUTER CONNECTOR..... FOP-5-7
PLUG, OUTER CONNECTOR..... FOP-5-1-7
PLUG, OUTER CONNECTOR..... FOP-5-2-7
PLUG, OUTER CONNECTOR..... FOP-5-3-8
PLUG, OUTER CONNECTOR..... FOP-5-4-5
PLUG, SPARK(IZFR6K-11E)(NGK)..... E-20-3
PLUG, SPARK(ZFR6K-11E)(NGK) E-20-3
PORT, IDLE EXHAUST F-3-20-15
PRIMER BULB..... F-6-4
PRIMER BULB ASSY F-6-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PROPELLER COMP., THREE BLADES FOP-15-1
PULLER, MINI FUSE F-7-20-4
PULLEY..... E-19-6
PULLEY COMP., L. TIMING BELT..... E-13-5
PULLEY COMP., R. TIMING BELT..... E-13-4
PULLEY, CRANKSHAFT E-13-3
PULLEY, TIMING BELT DRIVE..... E-13-1
PUMP ASSY..... F-11-14
PUMP ASSY., FUEL E-18-27
PUMP ASSY., OIL..... E-5-1
PUMP KIT, IMPELLER..... FOP-2-1
PUMP KIT, IMPELLER..... FOP-2-2
PUMP UNIT SET A, FUEL..... E-18-7
PUMP UNIT SET B, FUEL..... E-18-9
PUMP UNIT, FUEL..... E-18-41
<R>
RECEIVER, THRUST..... F-10-31
RECTIFIER ASSY. E-19-19
REGULATOR ASSY..... E-19-20
REGULATOR ASSY., PRESSURE..... E-14-6
RELAY ASSY., FUEL PUMP(DENSO)..... F-7-20-5
RELAY ASSY., POWER TILT..... F-7-10-10
RELAY ASSY., POWER(12V-20A)..... F-7-20-6
RETAINER(BLUE GREEN)(TOKAI) E-14-22
RETAINER, SPRING..... E-7-12
RETAINER, VALVE SPRING E-9-10-17
RING..... E-18-34
RING SET, PISTON(0.25)(RIKEN)..... E-7-1
RING SET, PISTON(STD.)(RIKEN)..... E-7-1
RING, BACK UP F-11-19
RING, CROSS PIN..... F-5-3
RING, CROSS PIN..... F-5-1-3
RING, INNER(15X20X23)..... F-2-41
RING, SETTING(39)..... F-5-21
RING, STOPPER F-2-9
RING, WATER TUBE SEAL..... F-4-8
RING, WATER TUBE SEAL..... FOP-2-8
ROD COMP. A, SHIFT(L) F-4-11
ROD COMP. A, SHIFT(XL) F-4-11

ROD COMP., CONNECTING E-7-6
ROD COMP., LINK(MECH) F-2-12
ROD COMP., PISTON F-11-21
ROD COMP., PISTON(B) F-11-15
ROD COMP., SHIFT F-4-9
ROD COMP., SHIFT F-4-9
ROD KIT, STEERING F-10-2
ROLLER FOP-3-3-71
ROLLER, 3X13.8 ..... F-5-28
ROLLER, 3X13.8 ..... F-5-1-30
ROLLER, 5X8 ..... E-5-25
ROLLER, DRIVE GEAR CAM FOP-3-3-70
ROLLER, FREE THROTTLE FOP-3-3-74
ROLLER, HOOK F-8-4
ROTOR ASSY. E-19-15
ROTOR COMP. E-21-2
ROTOR, OIL PUMP INNER E-5-5
ROTOR, OIL PUMP OUTER E-5-6
RUBBER C, STAND STOPPER F-3-20-55
RUBBER, DRAIN PLUG F-3-20-20
RUBBER, FR. CARRIER CUSHION F-3-20-25
RUBBER, FUEL PUMP E-18-30
RUBBER, MOUNT CASE SEAL F-3-20-7
RUBBER, OIL PUMP E-5-3
RUBBER, RING E-4-11
RUBBER, STOPPER F-3-30-2
RUBBER, UPPER MOUNT STOPPER F-10-16
<S>
SCREEN, L. WATER F-3-6
SCREEN, R. WATER F-3-5
SCREW E-19-9
SCREW E-19-10
SCREW SET E-15-1
SCREW SET, DRAIN E-18-5
SCREW, 4X10 ..... FOP-3-3-53
SCREW, 4X6 ..... FOP-3-3-51
SCREW, 5X10 ..... FOP-3-3-52
SCREW, 5X12 ..... FOP-3-3-54
SCREW, 5X18 ..... FOP-3-3-50
SCREW, 6X90 ..... FOP-3-3-55
SCREW, FLAT, 5X55 ..... F-3-11
SCREW, FLAT, 6X16 ..... E-5-20
SCREW, PAN E-18-21
SCREW, PAN, 4X10 ..... FOP-3-25
SCREW, PAN, 4X10 ..... FOP-3-2-28
SCREW, PAN, 4X14 ..... F-10-71
SCREW, PAN, 5X10 ..... FOP-3-22
SCREW, PAN, 5X10 ..... FOP-3-2-25
SCREW, PAN, 5X12 ..... E-18-1-8
SCREW, PAN, 5X16 ..... E-3-51
SCREW, PAN, 5X16 ..... E-6-10-50
SCREW, PAN, 5X16 ..... FOP-3-21
SCREW, PAN, 5X16 ..... FOP-3-1-20
SCREW, PAN, 5X16 ..... FOP-3-2-24
SCREW, PAN, 5X18 ..... FOP-3-24
SCREW, PAN, 5X18 ..... FOP-3-2-27
SCREW, PAN, 5X20 ..... E-3-52
SCREW, PAN, 5X20 ..... F-10-72
SCREW, PAN, 5X20 ..... FOP-3-23
SCREW, PAN, 5X20 ..... FOP-3-2-26
SCREW, PAN, 5X30 ..... FOP-3-1-22
SCREW, PAN, 5X40 ..... FOP-3-27
SCREW, PAN, 5X40 ..... FOP-3-2-30
SCREW, PAN, 5X40 ..... FOP-5-15
SCREW, PAN, 5X40 ..... FOP-5-1-15
SCREW, PAN, 5X40 ..... FOP-5-2-15
SCREW, PAN, 5X40 ..... FOP-5-3-18
SCREW, PAN, 5X40 ..... FOP-5-3-18
SCREW, PAN, 5X40 ..... FOP-5-4-14
SCREW, PAN, 5X55 ..... FOP-3-2-31
SCREW, PAN, 5X8 ..... E-21-21
SCREW, PAN, 6X18 ..... E-4-25
SCREW, PAN, 6X18 ..... FOP-3-26
SCREW, PAN, 6X18 ..... FOP-3-2-29
SCREW, PAN, 6X22 ..... E-21-8
SCREW, PAN, 6X35 ..... FOP-3-1-23
SCREW, PAN, 6X8 ..... F-10-47
SCREW, PAN, 6X8 ..... F-11-33
SCREW, TAPPET ADJUSTING E-9-10-13
SCREW, TAPPET ADJUSTING E-9-10-14
SCREW, TAPPING FOP-1-3
SCREW, TAPPING, 4X25 ..... FOP-7-6
SCREW, TAPPING, 6X30 ..... FOP-3-1-24
SCREW, TRUSS, 4X12 ..... FOP-3-1-21
SCREW, WASHER E-18-22
SCREW, WAVE WASHER E-19-12
SCREW, WAVE WASHER E-19-13
SCREW-WASHER E-18-20
SCREW-WASHER E-19-11
SCREW-WASHER, 5X15 ..... F-7-20-8
SEAL A, UNDER CASE F-3-20-11
SEAL A, VALVE STEM(NOK) E-9-4
SEAL B, EX. GUIDE E-6-10-5
SEAL B, UNDER CASE F-3-20-12
SEAL B, VALVE STEM(NOK) E-9-6
SEAL, EXHAUST GUIDE E-6-10-4
SEAL, RUBBER FOP-3-3-20
SEAL, SPARK PLUG TUBE(NOK) E-1-4
SEAL, WATER F-11-44
SEAL, WATER(14X26X8) F-2-43
SEAL, WATER, 12X21X6 ..... F-4-28
SEAL, WATER, 12X21X6 ..... FOP-17-5
SEAL, WATER, 22X35X7 ..... E-6-10-44
SEAL, WATER, 26X42X7 ..... F-4-27
SEAL, WATER, 26X42X7 ..... FOP-17-3
SEAL, WATER, 30X45X7 ..... F-5-29
SEAL, WATER, 30X45X7 ..... F-5-1-31
SEAL, WATER, 30X45X7 ..... FOP-17-4
SEAT, SPRING(250) E-7-13
SEAT, VALVE SPRING E-9-10-18
SEAT, WATER JOINT F-3-20-5
SEAT, WATER MOUTH F-3-20-4
SENSOR ASSY., AIR TEMPERATURE E-15-11
SENSOR ASSY., CRANK E-3-25
SENSOR ASSY., MAP E-14-10-6
SENSOR ASSY., TDC E-13-10-6
SENSOR ASSY., TRIM ANGLE F-10-7
SENSOR ASSY., WATER E-3-23
SENSOR ASSY., WATER E-4-14
SENSOR, KNOCK E-3-20
SENSOR, OIL PRESSURE E-3-24
SEPARATOR ASSY., VAPOR E-18-37
SHAFT ASSY., CLUTCH E-21-15
SHAFT ASSY., GEAR E-21-16
SHAFT COMP., EX. ROCKER ARM E-9-10-8
SHAFT COMP., FR. INTAKE ROCKER E-9-10-7
SHAFT COMP., INTAKE ROCKER ARM E-9-10-7
SHAFT COMP., SHIFT(A) F-2-10
SHAFT COMP., SHIFT(B) F-2-16
SHAFT, LOWER CYLINDER F-10-34
SHAFT, PROPELLER F-5-10
SHAFT, PROPELLER F-5-1-10
SHAFT, THROTTLE ARM F-2-5
SHAFT, THROTTLE BUTTON FOP-3-1-9
SHAFT, TILTING F-10-27
SHAFT, VERTICAL(L) F-4-14
SHAFT, VERTICAL(XL) F-4-14
SHIFTER, CLUTCH F-5-1
SHIFTER, CLUTCH F-5-1-1
SHIM A, BEVEL(0.10) F-5-18
SHIM A, BEVEL(0.10) F-5-1-18
SHIM A, BEVEL(0.10) F-5-1-19
SHIM A, GEAR(0.10) F-4-22
SHIM A, THRUST(2.75) F-5-19
SHIM B, BEVEL(0.15) F-5-18
SHIM B, BEVEL(0.15) F-5-1-18
SHIM B, BEVEL(0.15) F-5-1-19
SHIM B, GEAR(0.15) F-4-22
SHIM B, THRUST(2.80) F-5-19
SHIM C, BEVEL(0.30) F-5-18
SHIM C, BEVEL(0.30) F-5-1-18
SHIM C, BEVEL(0.30) F-5-1-19
SHIM C, GEAR(0.30) F-4-22
SHIM C, THRUST(2.85) F-5-19
SHIM D, BEVEL(0.50) F-5-18
SHIM D, BEVEL(0.50) F-5-1-18
SHIM D, BEVEL(0.50) F-5-1-19
SHIM D, GEAR(0.50) F-4-22
SHIM D, THRUST(2.90) F-5-19
SHIM E, THRUST(2.95) F-5-19
SHIM F, THRUST(3.00) F-5-19
SHIM G, THRUST(3.05) F-5-19
SHIM H, THRUST(3.10) F-5-19
SHIM I, THRUST(2.70) F-5-19
SHIM J, THRUST(2.65) F-5-19
SHIM K, THRUST(2.60) F-5-19
SHIM L, THRUST(2.55) F-5-19
SHIM M, THRUST(2.50) F-5-19
SLIDER COMP., SHIFT F-5-4
SLIDER COMP., SHIFT F-5-1-4
SLIDER, SHIFT F-5-5
SLIDER, SHIFT F-5-1-5
SLINGER, OIL F-4-15
SPACER(1) FOP-3-3-10
SPACER(2) FOP-3-3-68
SPACER, CABLE CLAMP FOP-3-16
SPACER, CABLE CLAMP FOP-3-1-13
SPACER, CABLE CLAMP FOP-3-2-17
SPACER, INTAKE MANIFOLD E-14-21
SPACER, L. RELIEF VALVE E-6-10-20
SPACER, R. RELIEF VALVE E-6-10-14
SPACER, THERMOSTAT COVER E-4-12
SPACER, THROTTLE BODY E-15-4
SPRING COMP., CLICK F-2-7
SPRING COMP., CLICK F-10-4
SPRING COMP., TIMING BELT E-13-9
SPRING(1) FOP-3-3-28
SPRING(2) FOP-3-3-8
SPRING, AIR FLOW TUBE E-15-6
SPRING, CLICK ASSIST F-2-8
SPRING, CLICK ASSIST F-10-5
SPRING, DETENT FOP-3-3-30
SPRING, EX. VALVE E-9-10-16
SPRING, FLUSH VALVE E-6-10-10
SPRING, LEVER RETURN F-3-20-26
SPRING, MOTOR F-11-9
SPRING, NEUTRAL LOCK ARM FOP-3-1-7
SPRING, RELIEF VALVE E-5-9
SPRING, RELIEF VALVE E-6-10-13
SPRING, ROCKER ARM E-9-10-9
SPRING, SHIFT F-5-6
SPRING, SHIFT F-5-1-6
SPRING, SHIFT ROD F-4-10
SPRING, SUPPORT E-7-14
SPRING, VALVE(PINK) E-9-10-15
STAY A, FUEL STRAINER E-18-1-9
STAY B, FUEL STRAINER E-1-6
STAY COMP. A, FUEL PUMP E-18-35
STAY COMP. B, FUEL PUMP E-18-36
STAY COMP., HARNESS F-3-20-14
STAY COMP., PLUG TOP COIL E-20-2
STAY, A.C. GENERATOR E-19-16
STAY, FUEL TUBE E-18-1-3
STAY, MAP SENSOR E-14-10-7
STAY, PLATE E-18-8
STAY, PLATE E-18-40
STAY, POWER TILT SWITCH F-3-20-9
STOPPER SET, SLEEVE E-21-9
STOPPER, LOWER MOUNT F-3-20-24
STOPPER, TILT F-10-30
STRAINER ASSY., FUEL(LOW) E-18-1-6
STRAINER COMP., FUEL(HIGH) E-14-13
STRAINER COMP., OIL E-5-7
STRAINER, FUEL E-18-1-7
STRAINER, FUEL PUMP E-18-10-14
SUB HARNESS ASSY., POWER FOP-3-18
SUB HARNESS ASSY., POWER FOP-3-1-16
SUB HARNESS ASSY., POWER FOP-3-2-19
SUB HARNESS ASSY., POWER FOP-3-2-20
SUSPENSION, AUDIBLE PILOT FOP-5-12
SUSPENSION, AUDIBLE PILOT FOP-5-1-12
SUSPENSION, AUDIBLE PILOT FOP-5-2-12
SUSPENSION, COUPLER F-7-4
SUSPENSION, STRAINER E-14-14
SUSPENSION, STRAINER E-18-1-10
SUSPENSION, STRAINER E-18-10-15
SWITCH ASSY., COMBINATION FOP-3-3-34
SWITCH ASSY., COMBINATION FOP-5-8
SWITCH ASSY., COMBINATION FOP-5-1-8
SWITCH ASSY., COMBINATION FOP-5-2-8
SWITCH ASSY., COMBINATION FOP-5-3-9
SWITCH ASSY., COMBINATION FOP-5-4-6
SWITCH ASSY., EMERGENCY STOP FOP-3-3-38
SWITCH ASSY., EMERGENCY STOP FOP-5-9
SWITCH ASSY., EMERGENCY STOP FOP-5-1-9
SWITCH ASSY., EMERGENCY STOP FOP-5-2-9
SWITCH ASSY., EMERGENCY STOP FOP-5-3-10
SWITCH ASSY., EMERGENCY STOP FOP-5-4-7
SWITCH ASSY., MAGNET E-21-13
SWITCH ASSY., NEUTRAL F-2-23
SWITCH ASSY., POWER TILT F-3-20-8
SWITCH ASSY., POWER TRIM-TILT FOP-3-19
SWITCH ASSY., POWER TRIM-TILT FOP-3-1-17
SWITCH ASSY., POWER TRIM-TILT FOP-3-2-21
SWITCH ASSY., POWER TRIM-TILT FOP-3-2-22
SWITCH ASSY., POWER TRIM-TILT FOP-3-3-35
SWITCH ASSY., TILT LIMIT F-10-8
SWITCH KIT, LIGHT FOP-5-3-2
<T>
TAB, TRIM F-3-7
TACHOMETER HOUR METER FOP-4-2
TACHOMETER HOUR METER FOP-4-2
TANK, OIL F-11-27
TENSIONER COMP., TIMING BELT E-13-7

TERMINAL, CABLE FOP-3-15
TERMINAL, CABLE FOP-3-1-12
TERMINAL, CABLE FOP-3-2-16
TERMINAL, CABLE FOP-3-3-26
TERMINATOR(F) FOP-10-4
TERMINATOR(M) FOP-10-3
THERMOSTAT ASSY. E-4-10
THROTTLE BODY ASSY. E-15-3
THROTTLE BODY ASSY. E-15-3
TIE, CABLE FOP-7-4
T-JOINT E-1-7
T-JOINT E-18-10-22
TRIM METER ASSY FOP-4-1
TRIM METER ASSY FOP-4-1
TRIM-TILT ASSY., POWER F-11-13
TUBE A, AIR VENT E-18-10-3
TUBE B, AIR VENT E-18-10-4
TUBE B, BREATHER E-1-17
TUBE C, BREATHER E-1-18
TUBE COMP. A, BREATHER E-1-16
TUBE COMP. A, FUEL E-18-1-2
TUBE COMP. B, FUEL E-18-1-4
TUBE COMP. C, FUEL E-18-10-9
TUBE COMP., AIR VENT E-18-10-5
TUBE D, FUEL E-18-10-10
TUBE E, FUEL E-18-10-12
TUBE F, FUEL E-18-10-13
TUBE, 5X250(95005-50001-30M) F-10-78
TUBE, 5X340(95005-50001-30M) F-10-79
TUBE, 5X45(95005-50001-30M) F-10-77
TUBE, CHECK VALVE E-18-10-2
TUBE, FLUSH VALVE E-6-10-49
TUBE, FUEL, 3.5X55 ..... E-18-10-30
TUBE, L. WATER RETURN E-4-9
TUBE, OIL E-1-5
TUBE, PRESSURE REGULATOR E-14-8
TUBE, R. WATER RETURN E-4-6
TUBE, RELIEF E-18-10-8
TUBE, SPIRAL(12X14.6) F-11-4
TUBE, VINYL, 3.5X6.5X600 ..... E-18-10-31
TUBE, WATER E-4-8
TUBE, WATER E-6-10-7
TUBE, WATER IN. E-18-10-20
TUBE, WATER JOINT F-3-20-52
TUBE, WATER OUTLET E-18-10-21
TUBE, WATER RELIEF E-4-7
TUBE, WATER(L) F-4-7
TUBE, WATER(XL) F-4-7
<V>
VALVE ASSY., EAC E-15-12
VALVE ASSY., SPOOL E-3-18
VALVE ASSY., SPOOL E-3-18
VALVE COMP., MANUAL F-11-23
VALVE COMP., RELIEF E-18-10-7
VALVE COMP., RESERVOIR F-11-24
VALVE SET, FLOAT E-18-1
VALVE, CHECK E-18-10-23
VALVE, EX. E-9-10-12
VALVE, FLASH E-6-10-12
VALVE, IN. E-9-10-11
VALVE, RELIEF E-5-8
VALVE, RELIEF E-6-10-11
<W>
WASHER F-2-35
WASHER B, THRUST, 14MM F-2-34
WASHER(3) FOP-3-3-62
WASHER(4) FOP-3-3-63
WASHER(5) FOP-3-3-64
WASHER(7) FOP-3-3-66
WASHER, 10MM F-10-63
WASHER, 30MM F-3-20-45
WASHER, 7/8 ..... F-10-60
WASHER, 8MM FOP-3-3-65
WASHER, AIR CLEANER COVER F-2-1
WASHER, DRAIN PLUG, 12MM E-6-12
WASHER, LOCK, 5MM FOP-3-29
WASHER, LOCK, 5MM FOP-3-1-26
WASHER, LOCK, 5MM FOP-3-2-34
WASHER, LOCK, 6MM FOP-3-30
WASHER, LOCK, 6MM FOP-3-2-35
WASHER, PIVOT F-2-6
WASHER, PLAIN E-18-24
WASHER, PLAIN E-18-25
WASHER, PLAIN, 10MM E-6-10-39
WASHER, PLAIN, 10MM F-10-61
WASHER, PLAIN, 12MM E-6-10-38
WASHER, PLAIN, 12MM F-3-19
WASHER, PLAIN, 12MM F-4-21
WASHER, PLAIN, 12MM F-5-20
WASHER, PLAIN, 12MM F-5-1-22
WASHER, PLAIN, 12MM F-10-64
WASHER, PLAIN, 12MM F-10-65
WASHER, PLAIN, 14MM F-3-20-46
WASHER, PLAIN, 4MM F-10-54
WASHER, PLAIN, 5MM E-14-10-18
WASHER, PLAIN, 5MM FOP-3-31
WASHER, PLAIN, 5MM FOP-3-2-36
WASHER, PLAIN, 5MM FOP-5-18
WASHER, PLAIN, 5MM FOP-5-1-18
WASHER, PLAIN, 5MM FOP-5-2-18
WASHER, PLAIN, 5MM FOP-5-3-21
WASHER, PLAIN, 5MM FOP-5-3-21
WASHER, PLAIN, 5MM FOP-5-4-17
WASHER, PLAIN, 6MM F-2-36
WASHER, PLAIN, 6MM F-2-37
WASHER, PLAIN, 6MM F-2-38
WASHER, PLAIN, 6MM F-3-30-10
WASHER, PLAIN, 6MM F-8-10
WASHER, PLAIN, 6MM F-10-62
WASHER, PLAIN, 6MM FOP-3-1-27
WASHER, PLAIN, 8MM F-7-10-20
WASHER, PROPELLER F-5-17
WASHER, PROPELLER F-5-1-17
WASHER, PROPELLER THRUST F-5-15
WASHER, PROPELLER THRUST F-5-1-15
WASHER, SEALING(22MM) E-3-8
WASHER, SEALING(22MM) E-3-10-3
WASHER, SEALING, 22MM E-3-7
WASHER, SEALING, 6MM E-18-51
WASHER, SPRING, 5MM FOP-5-19
WASHER, SPRING, 5MM FOP-5-1-19
WASHER, SPRING, 5MM FOP-5-2-19
WASHER, SPRING, 5MM FOP-5-3-22
WASHER, SPRING, 5MM FOP-5-3-22
WASHER, SPRING, 5MM FOP-5-4-18
WASHER, THRUST E-7-10
WASHER, THRUST E-9-10-10
WASHER, THRUST BEARING F-5-16
WASHER, THRUST BEARING F-5-1-16
WASHER, THRUST, 14MM F-2-33
WASHER, THRUST, 34MM F-10-58
WASHER, THRUST, 48X74X3 ..... F-5-1-21
WASHER, THRUST, 85X110X2 ..... F-5-1-20
WASHER, UPPER MOUNTING STOPPER F-10-59
WASHER, WAVE FOP-3-3-67
WASHER, WAVE, 12MM F-10-56
WASHER, WAVE, 26MM F-10-57
WASHER, WAVE, 40MM F-10-55
WIRE, LEAD(1.5X116MM) F-10-9
WIRE, LEAD(1.5X116MM) F-11-11
WRENCH, BOX(10MM) F-13-4
WRENCH, EYE, 19MM F-13-8
WRENCH, HEX., 6MM F-13-5
WRENCH, PLUG F-13-3
<Y>
YOKE ASSY. F-11-8
YOKE COMP. E-21-5

INDEX (Parts Number)

332-70201-0 . . . . . .F-6-8
3C7-70211-1 . . . . . .F-6-4
3C7-70217-0 . . . . . .F-6-5
3C7-70220-1 . . . . . .F-6-2
3C7-70224-1 . . . . . .F-6-3
3PU-72537-0 . . . . . .FOP-4-3
3PU-72571-0 . . . . . .FOP-4-1
3PU-72637-0 . . . . . .FOP-4-2
3PV-72571-0 . . . . . .FOP-4-1
3PV-72637-0 . . . . . .FOP-4-2
3T1-70200-1 . . . . . .F-6-1
98AB-701600. . . . . .F-6-7
98AB-70-700 . . . . . .F-6-6
H121-51640-730. . . . . .F-3-20-25
H196-47117-000. . . . . .F-3-30-2
H341-38403-672. . . . . .FOP-3-3-41
H341-38403-672. . . . . .FOP-5-3-15
H341-38403-672. . . . . .FOP-5-4-11
H355-89217-000. . . . . .F-13-4
H371-89221-000. . . . . .F-13-5
H371-90009-015. . . . . .E-6-10-26
H5YS-30530-J01 . . . . . .E-3-20
H723-90472-000. . . . . .F-4-21
H747-16731-003. . . . . .F-10-3
H759-16911-003. . . . . .E-18-10-14
H763-90681-A01 . . . . .F-7-10-22
H763-90681-A01 . . . . .F-10-67
H800-91303-000. . . . . .E-6-10-45
H881-90110-000. . . . . .F-10-45
H881-90114-000. . . . . .F-2-30
H921-17936-000. . . . . .F-2-6
H921-90302-000. . . . . .F-3-20-43
H921-90302-000. . . . . .FOP-3-3-59
H921-90302-000. . . . . .FOP-5-3-20
H921-90302-000. . . . . .FOP-5-4-16
H921-90511-000. . . . . .F-10-61
H958-90428-000. . . . . .F-2-34
HCO-92101-06055-4J. . .F-3-22
HCO-93500-04014-4J. . .F-10-71
HCO-93500-05016-4J. . .E-3-51
HCO-93500-05016-4J. . .E-6-10-50
HCO-93500-05020-4J. . .E-3-52
HCO-93500-05020-4J. . .F-10-72
HCO-93500-06018-4J. . .E-4-25
HCO-93600-06016-0A . .E-5-20
HCO-93901-446J0. . . . .FOP-7-6
HCO-94001-05490-0S . .F-10-73
HCO-94001-06080-0S . .E-19-27
HCO-94001-12490-0S . .F-10-74
HCO-94002-04490-0S . .F-10-75
HCO-94301-06100 . . . .E-3-53
HCO-94301-06100 . . . .E-13-30
HCO-94301-06100 . . . .E-15-21
HCO-94301-08140 . . . .E-3-10-19
HCO-94301-10120 . . . .E-14-35
HCO-94302-06100 . . . .E-9-18
HCO-94302-10160 . . . .E-5-21
HCO-94302-10160 . . . .E-6-10-51
HCO-94305-30203 . . . .F-10-76
HCO-94510-15000 . . . .F-5-31
HCO-94510-15000 . . . .F-5-1-33
HCO-94520-47000 . . . .F-4-34
HCO-94540-04029 . . . .F-2-46
HCO-94540-06029 . . . .FOP-3-32
HCO-94540-06029 . . . .FOP-3-1-28
HCO-94540-06029 . . . .FOP-3-2-37
HCO-94540-10019 . . . .F-4-35
HCO-94540-12029 . . . .F-2-47
HCO-94540-15029 . . . .F-11-47
HCO-95001-35055-40 . .E-18-10-30
HCO-95003-05060-31 . .E-18-10-31
HCO-95005-50045-30 . .F-10-77
HCO-95005-50250-30 . .F-10-78
HCO-95005-50340-30 . .F-10-79
HCO-95011-63000 . . . .F-3-20-55
HCO-95701-06014-09 . .E-5-22
HCO-95701-06018-09 . .E-5-23
HCO-95701-08030-09 . .E-5-24
HCO-95701-10070-09 . .E-6-10-52
HCO-95701-12120-09 . .E-6-10-53
HCO-96211-07000 . . . .F-5-32
HCO-96211-07000 . . . .F-5-1-34
HCO-96211-12000 . . . .F-5-33
HCO-96211-12000 . . . .F-5-1-35
HCO-96220-50080 . . . .E-5-25
HCO-9807B-5617C E-20-3
HCO-98200-41000 . . . .F-7-20-9
HCO-98200-41500 . . . .F-7-20-10
HCO-98200-43000 . . . .F-7-20-11
HCO-99003-10000 . . . .F-13-6
HCO-99003-50000 . . . .F-13-7
HCO-99006-19000 . . . .F-13-8
HCO-99008-02000 . . . .F-13-9
HGC1-38402-000 . . . . .FOP-5-12
HGC1-38402-000 . . . . .FOP-5-1-12
HGC1-38402-000 . . . . .FOP-5-2-12
HGHB-16075-830 . . . . .F-3-20-1
HGHB-16163-610 . . . . .E-6-10-2
HHA0-90402-000 . . . . .F-2-33
HHE0-50310-003 . . . . .E-1-11
HHW1-90207-671 . . . . .E-6-10-37
HHW1-90215-671 . . . . .F-4-18
HK44-32606-V01. . . . . .F-7-5
HKM3-32161-003 . . . . .F-10-6
HKN5-17224-670 . . . . .F-2-1
HKV6-90651-003. . . . . .F-7-10-21
HMAL-91302-601 . . . . .E-3-10-17
HMB9-83551-000 . . . . .E-14-10-10
HMG9-35701-950 . . . . .F-11-3
HMJ0-91301-003 . . . . .E-14-32
HMJ0-91301-003 . . . . .E-18-53
HMJ0-91308-003 . . . . .F-4-29
HMJ0-91308-003 . . . . .FOP-17-7
HMR5-16966-000 . . . . .F-13-1
HMT2-17193-000 . . . . .E-1-7
HP01-91212-003. . . . . .E-5-18
HP08-12342-004. . . . . .E-1-4
HP0A-91303-A02 . . . . .E-15-19
HP0X-91321-003. . . . . .E-3-49
HP13-31141-003. . . . . .E-19-6
HP13-31147-003. . . . . .E-19-10
HP13-31148-003. . . . . .E-19-12
HP5A-13115-000 . . . . .E-7-4
HP5A-31201-005 . . . . .E-21-2
HP5A-31243-005 . . . . .E-21-14
HP5G-16614-003 . . . . .E-14-4
HP8A-11812-A00 . . . . .E-13-10-1
HP8A-13204-A01 . . . . .E-7-5
HP8A-14400-A01 . . . . .E-13-6
HP8A-14551-A01 . . . . .E-13-13
HP8A-14620-A01 . . . . .E-9-10-4
HP8A-14626-A00 . . . . .E-9-10-5
HP8A-14627-A00 . . . . .E-9-10-6
HP8A-14631-A00 . . . . .E-9-10-7
HP8A-14645-A01 . . . . .E-9-10-9
HP8A-15115-A01 . . . . .E-3-9
HP8A-15140-A00 . . . . .E-3-10
HP8A-15142-A00 . . . . .E-3-11
HP8A-15150-A00 . . . . .E-3-12
HP8A-90003-A00 . . . . .E-9-10-20
HP8A-90004-A00 . . . . .E-9-10-21
HP8A-90017-A01 . . . . .E-13-10-9
HP8A-90031-A01 . . . . .E-13-25
HP8A-90701-A00 . . . . .E-9-14
HP8A-91301-A00 . . . . .E-9-17
HP8A-91308-A01 . . . . .E-3-45
HP8A-91309-A01 . . . . .E-3-47
HP8E-14762-A01 . . . . .E-9-10-16
HP8E-17105-A01 . . . . .E-14-20
HP8F-14820-A01. . . . . .E-9-10
HPC6-15233-000. . . . . .E-5-10
HPC6-91324-000. . . . . .E-5-19
HPD1-31138-004 . . . . .E-19-5
HPD1-31142-004 . . . . .E-19-7
HPD1-31145-004 . . . . .E-19-8
HPD1-90231-014 . . . . .E-19-26
HPD6-90430-003 . . . . .E-18-51
HPE0-15231-000. . . . . .E-5-8
HPEA-13111-000 . . . . .E-7-3
HPF0-91302-003. . . . . .F-2-44
HPF4-91324-004. . . . . .E-3-10-18
HPG4-91033-013 . . . . .F-5-1-25
HPG6-15232-000 . . . . .E-5-9
HPG7-16741-005 . . . . .E-14-7
HPGK-37835-A01 . . . . .E-14-10-9
HPH1-90015-013 . . . . .E-3-10-8
HPH7-90715-000 . . . . .E-3-40
HPJ7-12204-305 . . . . . .E-9-2
HPJ7-12205-305 . . . . . .E-9-3
HPK1-91308-003. . . . . .E-3-46
HPLC-91301-000. . . . . .E-14-33
HPM3-14744-000 . . . . .E-9-10-13
HPM3-14775-000 . . . . .E-9-10-18
HPM3-90206-004 . . . . .E-9-10-22
HPNA-91214-014 . . . . .E-3-42
HPNA-91302-003 . . . . .E-14-34
HPNA-91307-003 . . . . .E-3-44
HPNA-91307-003 . . . . .E-4-23
HPNA-91333-003 . . . . .E-3-50
HPNB-37500-003 . . . . .E-3-25
HPP4-90009-E01. . . . . .E-18-45
HPR3-91319-003. . . . . .E-3-48
HPR7-31105-A01 . . . . .E-19-1
HPT0-14744-004. . . . . .E-9-10-14
HPT0-31111-003. . . . . .E-19-2
HPT0-31114-013. . . . . .E-19-3
HPT0-31118-003. . . . . .E-19-4
HPT0-31146-003. . . . . .E-19-9
HPT0-31147-003. . . . . .E-19-11
HPT0-31148-003. . . . . .E-19-13
HPT0-90005-003. . . . . .E-9-11
HPT0-90206-004. . . . . .E-9-10-23
HPT0-90705-000. . . . . .E-9-15
HPT2-91005-N01 . . . . .F-5-23
HPT2-91005-N01 . . . . .F-5-1-24
HPW5-90701-000 . . . . .E-5-16
HPW5-90701-000 . . . . .E-6-10-42
HPY3-17249-000. . . . . .E-15-6
HPY3-31215-004. . . . . .E-21-4
HPY3-31218-004. . . . . .E-21-6
HPZ1-12210-004. . . . . .E-9-4
HPZ1-12211-004. . . . . .E-9-6
HR70-15280-A00 . . . . .E-3-13
HR70-37840-A01 . . . . .E-13-10-6
HRCA-14632-A00 . . . . .E-9-10-8
HRCA-17055-A01 . . . . .E-14-17
HRCA-17065-A01 . . . . .E-14-19
HRCA-90014-A01 . . . . .E-3-31
HRCA-90704-A00 . . . . .E-13-28
HRDV-14610-J00. . . . . .E-9-10-3
HRDV-14631-J00. . . . . .E-9-10-7
HRDV-14646-J00. . . . . .E-9-10-10
HRDV-14765-J00. . . . . .E-9-10-17
HRGM-14781-A01. . . . . .E-9-10-19
HRJA-14711-000. . . . . .E-9-10-11
HRJA-14721-E00. . . . . .E-9-10-12
HRJA-15290-000. . . . . .E-3-14
HRJA-90017-003. . . . . .E-13-22
HRKG-13210-000 . . . . .E-7-6
HRKG-14761-003 . . . . .E-9-10-15
HRKG-91213-003 . . . . .E-9-16
HRMA-16723-E00 . . . . .E-18-10-6
HRNA-37260-A01 . . . . .E-3-24
HRNA-37830-A01 . . . . .E-14-10-6
HRTA-15400-003. . . . . .E-3-10-4
HRYE-13211-A01 . . . . .E-7-7
HRYE-13212-A01 . . . . .E-7-7
HRYE-13213-A01 . . . . .E-7-7
HRYE-13214-A01 . . . . .E-7-7
HRYE-13215-A01 . . . . .E-7-7
HS0A-91541-003. . . . . .F-2-45
HS0A-91541-003. . . . . .F-7-9
HS0A-91541-003. . . . . .F-7-10-26
HS0X-17711-931. . . . . .E-14-22
HS0X-46392-A01 . . . . .E-15-14
HSA0-90683-003. . . . . .E-1-15
HSA0-90683-003. . . . . .E-20-10-11
HSB2-90650-003. . . . . .E-14-31
HSC2-90649-003. . . . . .FOP-5-3-23
HSC2-90649-003. . . . . .FOP-5-4-19
HSD2-90705-931 . . . . .F-2-39
HSD4-91356-952 . . . . .E-4-24
HSDA-39794-004 . . . . .F-7-20-5
HSE0-53740-953. . . . . .E-18-10-24
HSF4-89216-000. . . . . .F-13-3
HSK7-91566-003. . . . . .E-1-19
HSTK-91540-003. . . . . .E-18-1-18
HSTK-91540-003. . . . . .FOP-7-5
HVM0-16965-771 . . . . .E-14-15
HVM0-16965-771 . . . . .E-18-10-16
HZB7-90691-003. . . . . .E-18-52
HZC0-63515-700 . . . . .F-3-20-34
HZE2-90601-000. . . . . .E-6-12
HZV0-41122-000. . . . . .E-13-19
HZV0-90604-000. . . . . .E-18-1-17
HZV0-90604-000. . . . . .E-18-10-28
HZV1-24210-010. . . . . .F-10-4
HZV4-12155-A00 . . . . .E-3-4
HZV4-17704-010. . . . . .F-13-2
HZV4-24221-010. . . . . .F-10-5
HZV4-36182-651. . . . . .FOP-3-3-39
HZV4-36182-651. . . . . .FOP-5-3-11
HZV4-36182-651. . . . . .FOP-5-4-8
HZV4-36187-652. . . . . .FOP-5-3-12
HZV4-36187-652. . . . . .FOP-5-4-9
HZV4-90127-000. . . . . .E-6-10
HZV4-90302-000. . . . . .F-3-17
HZV4-90506-000. . . . . .F-8-10
HZV4-90511-000. . . . . .F-2-37
HZV4-90512-000. . . . . .F-2-38
HZV4-90512-000. . . . . .F-10-62
HZV4-90514-000. . . . . .F-10-63
HZV4-90605-000. . . . . .E-6-10-41
HZV4-90605-000. . . . . .F-3-20-47
HZV5-12155-000. . . . . .E-4-1
HZV5-12214-000. . . . . .E-3-8
HZV5-12214-000. . . . . .E-3-10-3
HZV5-32823-003. . . . . .FOP-3-3-32
HZV5-32823-003. . . . . .FOP-5-6
HZV5-32823-003. . . . . .FOP-5-1-6
HZV5-32823-003. . . . . .FOP-5-2-6
HZV5-32823-003. . . . . .FOP-5-3-7
HZV5-32823-003. . . . . .FOP-5-4-4
HZV5-32824-003. . . . . .FOP-3-3-33
HZV5-32824-003. . . . . .FOP-5-7
HZV5-32824-003. . . . . .FOP-5-1-7
HZV5-32824-003. . . . . .FOP-5-2-7
HZV5-32824-003. . . . . .FOP-5-3-8
HZV5-32824-003. . . . . .FOP-5-4-5
HZV5-36136-821. . . . . .F-11-9
HZV5-36180-033. . . . . .FOP-3-3-38
HZV5-36180-033. . . . . .FOP-5-3-10
HZV5-36180-033. . . . . .FOP-5-4-7
HZV5-38410-003. . . . . .FOP-3-3-42
HZV5-38410-003. . . . . .FOP-5-3-16
HZV5-38410-003. . . . . .FOP-5-4-12
HZV5-40102-000. . . . . .E-15-13
HZV5-40102-000. . . . . .F-3-30-1
HZV5-41171-000. . . . . .F-10-10
HZV5-41172-000. . . . . .F-10-11
HZV5-41172-000. . . . . .F-10-12
HZV5-50214-003. . . . . .F-11-12
HZV5-56117-821. . . . . .F-11-19
HZV5-56118-820. . . . . .F-11-20
HZV5-56513-000. . . . . .F-11-25
HZV5-90119-000. . . . . .F-10-47
HZV5-90119-000. . . . . .F-11-33
HZV5-90131-000. . . . . .E-6-11
HZV5-90302-003. . . . . .F-2-32
HZV5-90304-013. . . . . .F-10-51
HZV5-90307-003. . . . . .F-10-53
HZV5-90501-000. . . . . .F-10-55
HZV5-90502-000. . . . . .F-10-57
HZV5-90504-000. . . . . .F-10-58
HZV5-90552-000. . . . . .F-10-64
HZV5-90559-000. . . . . .E-6-10-38

HZV5-90559-000. . . . . F-3-19
HZV5-90559-000. . . . . F-5-20
HZV5-90559-000. . . . . F-5-1-22
HZV5-90559-000. . . . . F-10-65
HZV5-90563-000. . . . . E-6-10-39
HZV5-90651-000. . . . . F-10-66
HZV5-90756-000. . . . . F-3-20
HZV5-90756-000. . . . . F-3-20-51
HZV5-90756-000. . . . . F-4-24
HZV5-91203-821. . . . . F-11-35
HZV5-91256-003. . . . . F-10-69
HZV5-91302-821. . . . . F-11-37
HZV5-91316-821. . . . . F-11-38
HZV7-90508-000. . . . . F-2-35
HZV7-90951-010. . . . . F-10-68
HZVJ-14111-000. . . . . E-9-10-1
HZVJ-14211-000. . . . . E-9-10-2
HZVJ-32100-900. . . . . F-7-1
HZVJ-34750-901. . . . . E-20-10-6
HZVJ-87121-P00. . . . . F-12-2
HZVJ-87301-P00. . . . . F-12-6
HZVK-16400-003 . . . . . E-15-3
HZVK-34750-901 . . . . . E-20-10-6
HZVK-87121-P00 . . . . . F-12-3
HZVK-87301-P00 . . . . . F-12-7
HZVL-06328-601. . . . . FOP-7-1
HZVL-06328-701. . . . . FOP-7-1
HZVL-06328-800. . . . . FOP-10-1
HZVL-11100-000. . . . . E-3-10-1
HZVL-11200-000. . . . . E-3-1
HZVL-11310-000ZA. . . . E-6-1
HZVL-11381-003. . . . . E-6-2
HZVL-11820-000. . . . . E-13-10-2
HZVL-11840-000. . . . . E-13-10-3
HZVL-11861-000. . . . . E-13-10-4
HZVL-12000-000ZA. . . . E-3-3
HZVL-12210-000ZA. . . . E-9-5
HZVL-12231-000. . . . . E-9-7
HZVL-12310-405ZA. . . . E-1-1
HZVL-12320-405ZA. . . . E-1-3
HZVL-13622-000. . . . . E-13-2
HZVL-14270-000. . . . . E-13-5
HZVL-14526-405ZA. . . . E-13-10
HZVL-14553-003. . . . . E-13-14
HZVL-15100-000ZA. . . . E-5-1
HZVL-15655-000. . . . . E-3-15
HZVL-15656-000. . . . . E-3-16
HZVL-15810-003ZA. . . . E-3-18
HZVL-16015-000. . . . . E-18-3
HZVL-16020-003. . . . . E-18-4
HZVL-16030-003. . . . . E-18-7
HZVL-16700-003. . . . . E-18-27
HZVL-16710-000. . . . . E-18-30
HZVL-16725-000. . . . . E-18-35
HZVL-16726-000. . . . . E-18-36
HZVL-16730-013. . . . . E-18-37
HZVL-16748-000. . . . . E-14-8
HZVL-16755-003. . . . . E-14-10
HZVL-16760-003. . . . . E-18-10-7
HZVL-16765-003. . . . . E-14-12
HZVL-16770-000. . . . . E-18-10-8
HZVL-16805-003. . . . . E-18-1-19
HZVL-16840-000. . . . . E-18-1-2
HZVL-16841-000. . . . . E-18-1-3
HZVL-16850-000. . . . . E-18-1-4
HZVL-16860-000. . . . . E-18-10-9
HZVL-16870-000. . . . . E-18-10-10
HZVL-16875-000. . . . . E-18-10-11
HZVL-16880-000. . . . . E-18-10-12
HZVL-16890-000. . . . . E-18-10-13
HZVL-16900-003. . . . . E-18-1-6
HZVL-16910-003. . . . . E-14-13
HZVL-16914-000. . . . . E-18-1-9
HZVL-16916-000. . . . . E-1-6
HZVL-16917-000. . . . . E-14-14
HZVL-17110-003. . . . . E-14-10-3
HZVL-17131-000ZA. . . . E-14-10-4
HZVL-17877-900. . . . . F-2-2
HZVL-17878-900. . . . . F-2-3
HZVL-17910-003. . . . . E-15-9
HZVL-17932-900. . . . . F-2-5
HZVL-18110-000ZA. . . . E-4-2
HZVL-18120-000ZA. . . . E-4-4
HZVL-18333-003. . . . . E-6-4
HZVL-19241-000. . . . . F-4-6
HZVL-19255-000. . . . . E-4-6
HZVL-19257-000. . . . . E-6-10-7
HZVL-19274-000. . . . . F-3-20-5
HZVL-19313-000ZA. . . . E-4-12
HZVL-19315-000ZA. . . . E-4-13
HZVL-19361-000. . . . . E-6-10-21
HZVL-19362-000. . . . . E-6-10-22
HZVL-19366-000. . . . . E-6-10-23
HZVL-19540-000. . . . . E-15-10
HZVL-23170-000ZA. . . . E-6-10-24
HZVL-23172-003. . . . . E-6-10-25
HZVL-24612-900. . . . . F-2-11
HZVL-24613-900. . . . . F-2-12
HZVL-24621-000. . . . . F-2-17
HZVL-24622-000. . . . . F-2-18
HZVL-24627-900. . . . . F-2-20
HZVL-24628-900. . . . . F-2-21
HZVL-30416-000. . . . . E-20-10-1
HZVL-30520-003. . . . . E-20-1
HZVL-30525-000. . . . . E-20-2
HZVL-31637-000. . . . . E-19-16
HZVL-32100-900. . . . . F-7-1
HZVL-32101-000. . . . . E-20-10-3
HZVL-32102-000. . . . . E-20-10-4
HZVL-32103-000. . . . . F-7-10-2
HZVL-32104-000. . . . . E-1-8
HZVL-32106-000. . . . . F-7-2
HZVL-32108-003. . . . . F-7-3
HZVL-32111-000. . . . . E-13-18
HZVL-32114-000. . . . . E-1-9
HZVL-32114-000. . . . . E-3-21
HZVL-32193-000. . . . . E-3-22
HZVL-32410-000. . . . . F-7-10-3
HZVL-32421-000. . . . . F-7-10-8
HZVL-32580-900. . . . . FOP-10-2
HZVL-32580-910. . . . . FOP-10-2
HZVL-32580-920. . . . . FOP-10-2
HZVL-32590-900. . . . . FOP-10-5
HZVL-32590-910. . . . . FOP-10-5
HZVL-32800-600. . . . . FOP-7-2
HZVL-32800-700. . . . . FOP-7-2
HZVL-32806-000. . . . . FOP-10-3
HZVL-32807-000. . . . . FOP-10-4
HZVL-34750-901. . . . . E-20-10-6
HZVL-34754-000. . . . . E-20-10-7
HZVL-35477-000. . . . . F-2-25
HZVL-36104-000. . . . . F-11-4
HZVL-37831-000. . . . . E-14-10-7
HZVL-37832-000. . . . . E-14-10-8
HZVL-38550-003. . . . . F-7-10-10
HZVL-40100-000. . . . . F-3-20-10
HZVL-40102-000. . . . . F-3-20-11
HZVL-40103-000. . . . . F-3-20-12
HZVL-40105-900. . . . . F-3-20-13
HZVL-40110-000. . . . . F-3-20-14
HZVL-40116-000. . . . . F-3-20-15
HZVL-40151-000. . . . . F-3-20-16
HZVL-40154-000. . . . . F-3-20-17
HZVL-40201-000. . . . . F-3-20-18
HZVL-40201-900. . . . . F-3-20-19
HZVL-40209-000. . . . . F-3-20-20
HZVL-41100-000ZA. . . . F-3-10-1
HZVL-41100-700ZA. . . . F-3-10-1
HZVL-41100-900ZA. . . . F-3-10-1
HZVL-41201-000ZA. . . . F-5-11
HZVL-41201-000ZA. . . . F-5-1-12
HZVL-50100-000. . . . . F-10-13
HZVL-50100-900. . . . . F-10-13
HZVL-50109-000. . . . . F-10-14
HZVL-50166-000. . . . . F-10-18
HZVL-50201-000ZA. . . . F-10-19
HZVL-50201-900ZA. . . . F-10-19
HZVL-50222-000. . . . . F-10-22
HZVL-50311-000ZA. . . . F-10-26
HZVL-50381-000. . . . . F-10-27
HZVL-50529-000. . . . . F-10-30
HZVL-56539-000. . . . . F-10-34
HZVL-63100-P00ZA. . . . F-8-1
HZVL-63107-000. . . . . F-8-2
HZVL-63108-000. . . . . F-8-3
HZVL-63109-000. . . . . F-8-4
HZVL-63112-000. . . . . F-8-5
HZVL-63117-000. . . . . F-8-6
HZVL-63119-000. . . . . F-3-20-26
HZVL-63210-000. . . . . F-3-20-27
HZVL-63212-000. . . . . F-3-20-28
HZVL-63213-000. . . . . F-3-20-29
HZVL-63214-000. . . . . F-3-20-30
HZVL-63220-000. . . . . F-3-20-31
HZVL-63222-000. . . . . F-3-20-32
HZVL-63230-000. . . . . F-3-20-33
HZVL-63710-000ZA. . . . F-3-30-3
HZVL-63710-900ZA. . . . F-3-30-4
HZVL-63715-000ZA. . . . F-3-30-5
HZVL-63715-900ZA. . . . F-3-30-6
HZVL-63721-000. . . . . F-3-30-7
HZVL-82873-000. . . . . F-3-20-35
HZVL-87117-L00. . . . . F-12-1
HZVL-87121-P00. . . . . F-12-4
HZVL-87132-P00. . . . . F-12-5
HZVL-87301-P00. . . . . F-12-8
HZVL-87302-P00. . . . . F-12-9
HZVL-90001-000. . . . . E-3-26
HZVL-90003-000. . . . . E-21-19
HZVL-90004-000. . . . . E-13-10-7
HZVL-90005-000. . . . . E-21-20
HZVL-90006-003. . . . . E-3-27
HZVL-90007-000. . . . . E-13-10-8
HZVL-90008-003. . . . . E-3-28
HZVL-90009-003. . . . . E-3-29
HZVL-90011-000. . . . . E-19-22
HZVL-90013-000. . . . . E-14-10-11
HZVL-90014-000. . . . . E-14-10-12
HZVL-90015-000. . . . . E-20-5
HZVL-90015-000. . . . . E-20-10-8
HZVL-90015-000. . . . . F-7-10-14
HZVL-90020-000. . . . . E-3-34
HZVL-90023-000. . . . . E-14-10-13
HZVL-90028-000. . . . . E-3-35
HZVL-90034-000. . . . . E-4-17
HZVL-90035-000. . . . . E-9-13
HZVL-90037-000. . . . . E-15-17
HZVL-90038-000. . . . . E-3-37
HZVL-90039-000. . . . . E-13-26
HZVL-90040-000. . . . . E-13-27
HZVL-90041-000. . . . . E-3-10-10
HZVL-90043-000. . . . . E-14-28
HZVL-90045-000. . . . . E-6-10-33
HZVL-90046-000. . . . . E-6-10-34
HZVL-90049-000. . . . . E-6-10-35
HZVL-90063-000. . . . . E-3-10-12
HZVL-90070-000. . . . . E-6-8
HZVL-90071-000. . . . . E-6-9
HZVL-90072-000. . . . . E-15-18
HZVL-90101-000. . . . . F-8-7
HZVL-90102-000. . . . . F-3-20-37
HZVL-90103-000. . . . . F-3-20-39
HZVL-90105-000. . . . . F-10-42
HZVL-90107-000. . . . . F-3-20-41
HZVL-90109-000. . . . . F-3-20-42
HZVL-90109-000. . . . . F-3-30-8
HZVL-90204-000. . . . . E-3-10-16
HZVL-90512-000. . . . . F-3-30-10
HZVL-90751-000. . . . . F-3-20-49
HZVL-90752-000. . . . . F-3-20-50
HZVL-91303-000. . . . . E-3-43
HZVL-91451-000. . . . . F-3-20-52
HZVL-91508-000. . . . . E-13-10-10
HZVL-91551-000. . . . . F-3-30-11
HZW1-06411-020 . . . . . F-10-1
HZW1-19286-B00 . . . . . F-3-1
HZW1-24210-010 . . . . . F-2-7
HZW1-24327-000 . . . . . F-2-9
HZW1-24343-B02 . . . . . F-4-12
HZW1-24629-000 . . . . . F-2-22
HZW1-38551-000 . . . . . F-7-10-11
HZW1-40107-700 . . . . . F-11-10
HZW1-41102-B00 . . . . . F-3-3
HZW1-41109-B00 . . . . . F-3-8
HZW1-56110-701 . . . . . F-11-15
HZW1-56113-701 . . . . . F-11-16
HZW1-56116-701 . . . . . F-11-18
HZW1-56130-702 . . . . . F-11-22
HZW1-56180-701 . . . . . F-11-24
HZW1-56851-703 . . . . . F-11-27
HZW1-56860-701 . . . . . F-11-28
HZW1-90102-000 . . . . . F-10-37
HZW1-90107-004 . . . . . E-21-21
HZW1-90113-702 . . . . . F-11-29
HZW1-90114-702 . . . . . F-11-30
HZW1-90115-702 . . . . . F-11-31
HZW1-90116-702 . . . . . F-11-32
HZW1-90203-000 . . . . . F-7-10-18
HZW1-90301-B00 . . . . . F-5-14
HZW1-90301-B00 . . . . . F-5-1-14
HZW1-90308-003 . . . . . F-3-18
HZW1-90652-702 . . . . . F-11-34
HZW1-90758-B00 . . . . . F-5-22
HZW1-90758-B00 . . . . . F-5-1-23
HZW1-90758-B00 . . . . . FOP-17-2
HZW1-91207-013 . . . . . F-11-36
HZW1-91353-703 . . . . . F-11-40
HZW1-91354-701 . . . . . F-11-41
HZW1-91355-701 . . . . . F-11-42
HZW1-91357-701 . . . . . F-11-43
HZW1-91361-701 . . . . . F-11-45
HZW1-91557-701 . . . . . F-11-46
HZW4-90156-000 . . . . . E-14-10-15
HZW4-90306-003 . . . . . F-10-52
HZW4-90401-000 . . . . . F-10-54
HZW4-91301-003 . . . . . F-3-21
HZW4-91301-003 . . . . . FOP-17-6
HZW5-06900-U00 . . . . . FOP-12-1
HZW5-16081-010 . . . . . E-18-20
HZW5-16086-000 . . . . . E-18-23
HZW5-16087-000 . . . . . E-18-24
HZW5-16715-023 . . . . . E-18-31
HZW5-16733-000 . . . . . E-18-38
HZW5-16915-000 . . . . . E-18-10-15
HZW5-19291-000 . . . . . E-6-10-11
HZW5-19292-000 . . . . . E-6-10-13
HZW5-19297-000 . . . . . E-6-10-17
HZW5-24810-U01 . . . . . FOP-3-2
HZW5-24810-U01 . . . . . FOP-3-2-2
HZW5-24810-U11 . . . . . FOP-3-2-3
HZW5-24811-U01 . . . . . FOP-3-3
HZW5-24811-U01 . . . . . FOP-3-2-4
HZW5-24812-U01 . . . . . FOP-3-4
HZW5-24812-U01 . . . . . FOP-3-2-5
HZW5-24813-U01 . . . . . FOP-3-5
HZW5-24813-U01 . . . . . FOP-3-2-6
HZW5-24813-U21 . . . . . FOP-3-2-7
HZW5-24814-U01 . . . . . FOP-3-6
HZW5-24814-U01 . . . . . FOP-3-2-8
HZW5-24815-U01 . . . . . FOP-3-7
HZW5-24816-U01 . . . . . FOP-3-8
HZW5-24816-U01 . . . . . FOP-3-1-8
HZW5-24816-U01 . . . . . FOP-3-2-9
HZW5-24817-U01 . . . . . FOP-3-9
HZW5-24817-U01 . . . . . FOP-3-2-10
HZW5-24818-U01 . . . . . FOP-3-10
HZW5-24818-U01 . . . . . FOP-3-2-11
HZW5-24819-U01 . . . . . FOP-3-11
HZW5-24819-U01 . . . . . FOP-3-2-12
HZW5-24825-U01 . . . . . FOP-3-13
HZW5-24825-U01 . . . . . FOP-3-2-14
HZW5-24826-U01 . . . . . FOP-3-14
HZW5-24826-U01 . . . . . FOP-3-1-10
HZW5-24826-U01 . . . . . FOP-3-2-15
HZW5-24831-U01 . . . . . FOP-3-15
HZW5-24831-U01 . . . . . FOP-3-1-12
HZW5-24831-U01 . . . . . FOP-3-2-16
HZW5-24832-U01 . . . . . FOP-3-16
HZW5-24832-U01 . . . . . FOP-3-1-13
HZW5-24832-U01 . . . . . FOP-3-2-17
HZW5-24834-U01 . . . . . FOP-3-17
HZW5-24834-U21 . . . . . FOP-3-2-18
HZW5-32168-003 . . . . . E-18-44
HZW5-35370-U02 . . . . . FOP-3-19
HZW5-35370-U02 . . . . . FOP-3-2-21
HZW5-35370-U12 . . . . . FOP-3-2-22
HZW5-35665-003 . . . . . E-15-11
HZW5-90002-013 . . . . . E-5-14
HZW5-90021-U00 . . . . . FOP-12-2
HZW5-90101-U00 . . . . . FOP-3-21
HZW5-90101-U00 . . . . . FOP-3-1-20
HZW5-90101-U00 . . . . . FOP-3-2-24

HZW5-90102-U00 . . . . .FOP-3-22
HZW5-90102-U00 . . . . .FOP-3-2-25
HZW5-90103-U01 . . . . .FOP-3-23
HZW5-90103-U01 . . . . .FOP-3-2-26
HZW5-90104-U00 . . . . .FOP-3-24
HZW5-90104-U00 . . . . .FOP-3-2-27
HZW5-90105-U01 . . . . .FOP-3-25
HZW5-90105-U01 . . . . .FOP-3-2-28
HZW5-90106-U00 . . . . .FOP-3-26
HZW5-90106-U00 . . . . .FOP-3-2-29
HZW5-90107-U00 . . . . .FOP-3-27
HZW5-90107-U00 . . . . .FOP-3-2-30
HZW5-90108-U00 . . . . .FOP-3-2-31
HZW5-90109-000 . . . . .FOP-5-15
HZW5-90109-000 . . . . .FOP-5-1-15
HZW5-90109-000 . . . . .FOP-5-2-15
HZW5-90109-000 . . . . .FOP-5-3-18
HZW5-90109-000 . . . . .FOP-5-3-18
HZW5-90109-000 . . . . .FOP-5-4-14
HZW5-90203-010 . . . . .E-19-25
HZW5-90301-U00 . . . . .FOP-3-28
HZW5-90301-U00 . . . . .FOP-3-2-32
HZW5-90302-003 . . . . .F-10-50
HZW5-90302-U21 . . . . .FOP-3-2-33
HZW5-90501-U00 . . . . .FOP-3-29
HZW5-90501-U00 . . . . .FOP-3-1-26
HZW5-90501-U00 . . . . .FOP-3-2-34
HZW5-90502-U00 . . . . .FOP-3-30
HZW5-90502-U00 . . . . .FOP-3-2-35
HZW5-90503-U00 . . . . .FOP-3-31
HZW5-90503-U00 . . . . .FOP-3-2-36
HZW5-90509-711 . . . . .F-5-16
HZW5-90509-711 . . . . .F-5-1-16
HZW5-90511-U00 . . . . .FOP-12-3
HZW5-90512-U00 . . . . .FOP-12-4
HZW5-90601-030 . . . . .E-18-10-25
HZW5-90602-030 . . . . .E-18-1-16
HZW5-90602-030 . . . . .E-18-10-27
HZW5-90652-003 . . . . .E-18-10-29
HZW5-91201-003 . . . . .E-5-17
HZW5-91202-003 . . . . .E-6-10-44
HZW5-91251-003 . . . . .F-2-42
HZW7-24810-U01 . . . . .FOP-3-1-2
HZW7-24811-U01 . . . . .FOP-3-1-3
HZW7-24812-U01 . . . . .FOP-3-1-4
HZW7-24813-U01 . . . . .FOP-3-1-5
HZW7-24814-U01 . . . . .FOP-3-1-6
HZW7-24815-U01 . . . . .FOP-3-1-7
HZW7-24817-U01 . . . . .FOP-3-1-9
HZW7-24832-U01 . . . . .FOP-3-1-14
HZW7-24833-U01 . . . . .FOP-3-1-15
HZW7-32530-U00 . . . . .FOP-3-18
HZW7-32530-U00 . . . . .FOP-3-2-19
HZW7-32530-U10 . . . . .FOP-3-2-20
HZW7-32530-U20 . . . . .FOP-3-1-16
HZW7-35370-U02 . . . . .FOP-3-1-17
HZW7-87703-U00 . . . . .FOP-3-1-19
HZW7-90101-U01 . . . . .FOP-3-1-21
HZW7-90102-U01 . . . . .FOP-3-1-22
HZW7-90103-U01 . . . . .FOP-3-1-23
HZW7-90104-U01 . . . . .FOP-3-1-24
HZW7-90301-U01 . . . . .FOP-3-1-25
HZW7-90502-U00 . . . . .FOP-3-1-27
HZW9-19279-010 . . . . .E-6-10-10
HZW9-19291-000 . . . . .E-6-10-12
HZW9-19297-000 . . . . .E-6-10-18
HZW9-32117-000 . . . . .E-20-10-5
HZW9-90005-010 . . . . .F-10-35
HZW9-90009-000 . . . . .F-10-36
HZW9-90101-003 . . . . .F-3-10
HZW9-90102-000 . . . . .F-3-20-38
HZW9-90102-000 . . . . .F-10-38
HZW9-90103-010 . . . . .F-10-39
HZW9-90105-000 . . . . .F-10-43
HZX1-90101-R00 . . . . .F-8-8
HZX2-06125-C00 . . . . .FOP-17-1
HZX2-06192-C00 . . . . .FOP-2-1
HZX2-06193-C00 . . . . .FOP-2-2
HZX2-11911-000 . . . . .E-3-10-2
HZX2-13010-000 . . . . .E-7-1
HZX2-13011-000 . . . . .E-7-1
HZX2-13101-000 . . . . .E-7-2
HZX2-13102-000 . . . . .E-7-2
HZX2-13310-000 . . . . .E-7-8
HZX2-13321-003 . . . . .E-7-9
HZX2-13322-003 . . . . .E-7-9
HZX2-13323-003 . . . . .E-7-9
HZX2-13324-003 . . . . .E-7-9
HZX2-13325-003 . . . . .E-7-9
HZX2-13326-003 . . . . .E-7-9
HZX2-13341-003 . . . . .E-7-11
HZX2-13342-003 . . . . .E-7-11
HZX2-13343-003 . . . . .E-7-11
HZX2-13344-003 . . . . .E-7-11
HZX2-13345-003 . . . . .E-7-11
HZX2-13346-003 . . . . .E-7-11
HZX2-13392-000 . . . . .E-7-13
HZX2-13811-000 . . . . .E-13-3
HZX2-14111-000 . . . . .E-9-10-1
HZX2-14211-000 . . . . .E-9-10-2
HZX2-16404-000 . . . . .E-15-4
HZX2-16701-003 . . . . .E-18-28
HZX2-17374-000 . . . . .E-15-8
HZX2-19234-C00 . . . . .F-4-5
HZX2-19234-C00 . . . . .FOP-2-7
HZX2-19300-003 . . . . .E-4-10
HZX2-19303-003 . . . . .E-4-11
HZX2-19511-000 . . . . .E-13-16
HZX2-24101-C00 . . . . .F-5-1
HZX2-24101-C00 . . . . .F-5-1-1
HZX2-30280-003 . . . . .F-11-1
HZX2-31106-003 . . . . .F-11-2
HZX2-31110-000ZA. . . .E-5-11
HZX2-31916-003 . . . . .E-20-3
HZX2-32166-003 . . . . .E-18-43
HZX2-32414-300 . . . . .F-7-10-5
HZX2-32415-000 . . . . .F-7-10-7
HZX2-32435-000 . . . . .F-7-10-9
HZX2-35470-013 . . . . .F-2-23
HZX2-36120-013 . . . . .F-11-5
HZX2-36122-003 . . . . .F-11-6
HZX2-36129-003 . . . . .F-11-8
HZX2-38228-003 . . . . .F-7-20-3
HZX2-38552-000 . . . . .F-7-10-12
HZX2-41101-C01ZC. . . .F-3-2
HZX2-41102-E00ZC. . . .F-3-4
HZX2-41107-C00ZC. . . .F-3-7
HZX2-41110-305ZB. . . .F-3-9
HZX2-41112-C00 . . . . .F-4-14
HZX2-41112-C10 . . . . .F-4-14
HZX2-41131-C00 . . . . .F-4-16
HZX2-41131-E00. . . . . .F-4-16
HZX2-41140-C00 . . . . .F-5-8
HZX2-41141-E00. . . . . .F-5-1-8
HZX2-41150-E00. . . . . .F-5-1-9
HZX2-41151-C00 . . . . .F-5-9
HZX2-41161-C00 . . . . .F-5-10
HZX2-41161-E00. . . . . .F-5-1-10
HZX2-41200-E00. . . . . .F-5-1-11
HZX2-41202-C00 . . . . .F-5-12
HZX2-56000-043 . . . . .F-11-13
HZX2-56532-C00 . . . . .F-11-26
HZX2-58130-T01. . . . . .FOP-15-1
HZX2-58130-T11. . . . . .FOP-15-1
HZX2-58130-T21. . . . . .FOP-15-1
HZX2-58130-T31. . . . . .FOP-15-1
HZX2-58130-T41. . . . . .FOP-15-1
HZX2-58130-T51. . . . . .FOP-15-1
HZX2-58130-T61. . . . . .FOP-15-1
HZX2-58180-T01. . . . . .FOP-15-1
HZX2-58180-T11. . . . . .FOP-15-1
HZX2-58180-T21. . . . . .FOP-15-1
HZX2-58180-T31. . . . . .FOP-15-1
HZX2-58180-T41. . . . . .FOP-15-1
HZX2-58180-T51. . . . . .FOP-15-1
HZX2-58180-T61. . . . . .FOP-15-1
HZX2-90001-000 . . . . .E-5-13
HZX2-90002-000 . . . . .E-19-21
HZX2-90101-C00 . . . . .F-2-28
HZX2-90105-C00 . . . . .F-4-17
HZX2-90105-C00 . . . . .FOP-2-9
HZX2-90107-C00 . . . . .F-3-13
HZX2-90129-000 . . . . .F-10-48
HZX2-90301-C00 . . . . .F-4-19
HZX2-90303-C00 . . . . .F-4-20
HZX2-90504-C00 . . . . .F-10-59
HZX2-90506-C00 . . . . .F-5-15
HZX2-90506-C00 . . . . .F-5-1-15
HZX2-90512-C00 . . . . .F-5-17
HZX2-90512-C00 . . . . .F-5-1-17
HZX2-90518-C00 . . . . .F-4-22
HZX2-90519-C00 . . . . .F-4-22
HZX2-90520-C00 . . . . .F-4-22
HZX2-90521-C00 . . . . .F-4-22
HZX2-90528-C00 . . . . .F-5-18
HZX2-90528-C00 . . . . .F-5-1-18
HZX2-90528-E00. . . . . .F-5-1-19
HZX2-90529-C00 . . . . .F-5-18
HZX2-90529-C00 . . . . .F-5-1-18
HZX2-90529-E00. . . . . .F-5-1-19
HZX2-90530-C00 . . . . .F-5-18
HZX2-90530-C00 . . . . .F-5-1-18
HZX2-90530-E00. . . . . .F-5-1-19
HZX2-90531-C00 . . . . .F-5-18
HZX2-90531-C00 . . . . .F-5-1-18
HZX2-90531-E00. . . . . .F-5-1-19
HZX2-90541-E01. . . . . .F-5-1-20
HZX2-90542-E01. . . . . .F-5-1-21
HZX2-90651-C00 . . . . .F-5-21
HZX2-90683-003 . . . . .F-7-10-23
HZX2-91051-C01 . . . . .F-5-24
HZX2-91053-C01 . . . . .F-4-25
HZX2-91054-E01. . . . . .F-5-1-26
HZX2-91055-C01 . . . . .F-5-25
HZX2-91055-C01 . . . . .F-5-1-27
HZX2-91056-C01 . . . . .F-4-26
HZX2-91351-C00 . . . . .F-5-30
HZX2-91351-C00 . . . . .F-5-1-32
HZX2-91351-C00 . . . . .FOP-17-8
HZX2-91352-003 . . . . .F-11-39
HZX2-91358-003 . . . . .F-11-44
HZX2-91358-C00 . . . . .F-4-31
HZX2-91358-C00 . . . . .FOP-2-12
HZX2-91359-C00 . . . . .F-4-32
HZX2-91359-C00 . . . . .FOP-2-13
HZY1-90205-000. . . . . .F-3-16
HZY1-90205-000. . . . . .F-8-9
HZY1-90205-000. . . . . .F-10-49
HZY1-90650-003. . . . . .FOP-7-4
HZY2-15810-000ZA. . . .E-3-18
HZY2-15825-000. . . . . .E-3-19
HZY3-06177-U02 . . . . .FOP-1-1
HZY3-06532-U00 . . . . .F-10-2
HZY3-11300-C00 . . . . .E-3-2
HZY3-11871-000. . . . . .E-13-10-5
HZY3-11911-010. . . . . .E-9-1
HZY3-12155-000. . . . . .E-3-5
HZY3-12155-000. . . . . .E-6-10-1
HZY3-12164-000. . . . . .E-3-6
HZY3-12171-305. . . . . .E-3-7
HZY3-12241-000. . . . . .E-9-8
HZY3-12251-A01 . . . . .E-9-9
HZY3-12312-000. . . . . .E-1-2
HZY3-13331-A06 . . . . .E-7-10
HZY3-13391-010. . . . . .E-7-12
HZY3-13398-003. . . . . .E-7-14
HZY3-13621-C01 . . . . .E-13-1
HZY3-14261-C00 . . . . .E-13-4
HZY3-14510-003. . . . . .E-13-7
HZY3-14515-000. . . . . .E-13-8
HZY3-14520-000. . . . . .E-13-9
HZY3-14529-000. . . . . .E-13-11
HZY3-14550-003. . . . . .E-13-12
HZY3-14555-003. . . . . .E-13-15
HZY3-15112-013. . . . . .E-5-2
HZY3-15113-000. . . . . .E-5-3
HZY3-15121-000. . . . . .E-5-4
HZY3-15131-405. . . . . .E-5-5
HZY3-15132-405. . . . . .E-5-6
HZY3-15220-020. . . . . .E-5-7
HZY3-15425-010. . . . . .E-1-5
HZY3-15657-000. . . . . .E-3-17
HZY3-15825-003. . . . . .E-3-19
HZY3-16011-A01 . . . . .E-18-1
HZY3-16013-000. . . . . .E-18-2
HZY3-16016-003. . . . . .E-15-1
HZY3-16024-000. . . . . .E-18-5
HZY3-16026-000. . . . . .E-18-6
HZY3-16031-010. . . . . .E-18-8
HZY3-16036-003. . . . . .E-18-9
HZY3-16041-000. . . . . .E-18-10
HZY3-16042-000. . . . . .E-18-11
HZY3-16061-000. . . . . .E-18-12
HZY3-16072-000. . . . . .E-18-13
HZY3-16073-000. . . . . .E-18-14
HZY3-16074-000. . . . . .E-18-15
HZY3-16075-000. . . . . .E-18-16
HZY3-16076-000. . . . . .E-18-17
HZY3-16077-000. . . . . .E-18-18
HZY3-16078-000. . . . . .E-18-19
HZY3-16082-000. . . . . .E-18-21
HZY3-16083-000. . . . . .E-18-22
HZY3-16087-000. . . . . .E-18-25
HZY3-16088-000. . . . . .E-18-26
HZY3-16176-000. . . . . .E-15-2
HZY3-16193-A00 . . . . .E-18-10-1
HZY3-16196-A00 . . . . .E-18-10-2
HZY3-16197-000. . . . . .E-18-10-3
HZY3-16198-A00 . . . . .E-18-10-4
HZY3-16199-A00 . . . . .E-18-10-5
HZY3-16400-A01 . . . . .E-15-3
HZY3-16405-000. . . . . .E-15-5
HZY3-16451-000. . . . . .E-14-2
HZY3-16611-A00 . . . . .E-14-3
HZY3-16620-A00 . . . . .E-14-5
HZY3-16708-000. . . . . .E-18-29
HZY3-16721-000. . . . . .E-18-33
HZY3-16733-000. . . . . .E-18-39
HZY3-16734-000. . . . . .E-18-40
HZY3-16735-004. . . . . .E-18-41
HZY3-16740-A01 . . . . .E-14-6
HZY3-16752-000. . . . . .E-18-42
HZY3-16752-A00 . . . . .E-14-9
HZY3-16757-003. . . . . .E-14-11
HZY3-16818-003. . . . . .E-18-1-1
HZY3-16901-003. . . . . .E-18-1-7
HZY3-16904-003. . . . . .E-18-1-8
HZY3-16915-010. . . . . .E-18-1-10
HZY3-16918-003. . . . . .E-18-1-11
HZY3-16919-003. . . . . .E-18-1-12
HZY3-17051-A00 . . . . .E-14-16
HZY3-17061-A00 . . . . .E-14-18
HZY3-17105-004. . . . . .E-14-10-1
HZY3-17108-000. . . . . .E-14-21
HZY3-17109-004. . . . . .E-14-10-2
HZY3-17138-004. . . . . .E-14-10-5
HZY3-17721-000. . . . . .E-18-10-17
HZY3-17723-A01 . . . . .E-18-10-18
HZY3-17724-010. . . . . .E-18-10-19
HZY3-17738-000. . . . . .E-18-1-13
HZY3-17748-U01 . . . . .FOP-1-2
HZY3-17749-U01 . . . . .FOP-1-3
HZY3-17931-000. . . . . .F-2-4
HZY3-18115-003. . . . . .E-4-3
HZY3-18125-003. . . . . .E-4-5
HZY3-18141-A00ZA. . . .E-6-10-3
HZY3-18148-003. . . . . .E-6-10-4
HZY3-18149-A01 . . . . .E-6-10-5
HZY3-18151-A00ZA. . . .E-6-10-6
HZY3-18330-020. . . . . .E-6-3
HZY3-18340-020. . . . . .E-6-5
HZY3-19210-003. . . . . .F-4-1
HZY3-19210-003. . . . . .FOP-2-3
HZY3-19221-010. . . . . .F-4-2
HZY3-19221-010. . . . . .FOP-2-4
HZY3-19223-000. . . . . .F-4-3
HZY3-19223-000. . . . . .FOP-2-5
HZY3-19231-000. . . . . .F-4-4
HZY3-19231-000. . . . . .FOP-2-6
HZY3-19251-000. . . . . .F-4-7
HZY3-19251-611. . . . . .F-4-7
HZY3-19252-000. . . . . .E-6-6
HZY3-19253-000. . . . . .F-4-8
HZY3-19253-000. . . . . .FOP-2-8
HZY3-19254-000. . . . . .E-6-7
HZY3-19256-010. . . . . .E-4-7
HZY3-19257-000. . . . . .E-4-8
HZY3-19258-010. . . . . .E-18-10-20
HZY3-19259-000. . . . . .E-18-10-21
HZY3-19261-000. . . . . .E-4-9
HZY3-19270-000. . . . . .F-3-20-2
HZY3-19271-000. . . . . .F-3-20-3

HZY3-19272-000. . . . . F-3-20-4
HZY3-19277-000ZA. . . . E-6-10-8
HZY3-19278-000. . . . . E-6-10-9
HZY3-19289-000. . . . . F-3-20-6
HZY3-19294-000ZB. . . . E-6-10-14
HZY3-19295-000. . . . . E-6-10-15
HZY3-19296-000. . . . . E-6-10-16
HZY3-19297-000. . . . . E-6-10-19
HZY3-19298-000ZB. . . . E-6-10-20
HZY3-23173-010. . . . . F-3-20-7
HZY3-24102-000. . . . . F-5-2
HZY3-24102-000. . . . . F-5-1-2
HZY3-24103-000. . . . . F-5-3
HZY3-24103-000. . . . . F-5-1-3
HZY3-24113-A01 . . . . . F-5-4
HZY3-24113-A01 . . . . . F-5-1-4
HZY3-24122-A01 . . . . . F-5-5
HZY3-24122-A01 . . . . . F-5-1-5
HZY3-24123-000. . . . . F-5-6
HZY3-24123-000. . . . . F-5-1-6
HZY3-24124-310. . . . . F-5-7
HZY3-24124-310. . . . . F-5-1-7
HZY3-24221-000. . . . . F-2-8
HZY3-24310-C00 . . . . . F-4-9
HZY3-24310-E00. . . . . F-4-9
HZY3-24318-000. . . . . F-4-10
HZY3-24610-A00 . . . . . F-2-10
HZY3-24617-000. . . . . F-2-13
HZY3-24618-000. . . . . F-2-14
HZY3-24619-000. . . . . F-2-15
HZY3-24620-000. . . . . F-2-16
HZY3-24623-000. . . . . F-2-19
HZY3-31116-000. . . . . E-5-12
HZY3-31200-003. . . . . E-21-1
HZY3-31216-003. . . . . E-21-5
HZY3-31226-003. . . . . E-21-7
HZY3-31232-003. . . . . E-21-10
HZY3-31235-003. . . . . E-21-11
HZY3-31236-003. . . . . E-21-12
HZY3-31241-003. . . . . E-21-13
HZY3-31243-003. . . . . E-21-15
HZY3-31250-003. . . . . E-21-17
HZY3-31251-003. . . . . E-21-18
HZY3-31630-013. . . . . E-19-14
HZY3-31631-003. . . . . E-19-15
HZY3-31638-003. . . . . E-13-17
HZY3-31639-003. . . . . E-19-17
HZY3-31694-003. . . . . E-19-18
HZY3-31710-003. . . . . E-19-19
HZY3-31750-003. . . . . E-19-20
HZY3-32112-000. . . . . E-14-23
HZY3-32129-000. . . . . E-1-10
HZY3-32370-H01 . . . . . F-7-20-1
HZY3-32371-H01 . . . . . F-7-20-2
HZY3-32411-003. . . . . F-7-10-4
HZY3-35476-010. . . . . F-2-24
HZY3-35640-013. . . . . F-3-20-8
HZY3-35660-003. . . . . F-10-7
HZY3-35673-003. . . . . E-3-23
HZY3-35673-003. . . . . E-4-14
HZY3-36123-013. . . . . F-11-7
HZY3-36550-003. . . . . E-15-12
HZY3-40204-000. . . . . F-4-13
HZY3-40210-610. . . . . F-3-20-21
HZY3-40219-023. . . . . F-10-9
HZY3-40219-023. . . . . F-11-11
HZY3-41104-C01 . . . . . F-3-5
HZY3-41105-C01 . . . . . F-3-6
HZY3-41116-000. . . . . F-4-15
HZY3-50111-020. . . . . F-3-20-22
HZY3-50151-000. . . . . F-10-15
HZY3-50153-000. . . . . F-10-16
HZY3-50155-000. . . . . F-3-20-23
HZY3-50157-010. . . . . F-3-20-24
HZY3-50161-000ZD. . . . F-10-17
HZY3-50161-610. . . . . F-10-17
HZY3-50211-000. . . . . F-10-20
HZY3-50214-000. . . . . F-10-21
HZY3-50301-030ZC. . . . F-10-25
HZY3-50388-U00 . . . . . FOP-14-1
HZY3-50388-U10 . . . . . FOP-14-2
HZY3-50522-000. . . . . F-10-28
HZY3-50527-000. . . . . F-10-29
HZY3-56100-013. . . . . F-11-14
HZY3-56120-023. . . . . F-11-21
HZY3-56170-013. . . . . F-11-23
HZY3-56516-A00 . . . . . F-10-31
HZY3-56518-A00 . . . . . F-10-32
HZY3-56519-A00 . . . . . F-10-33
HZY3-58130-T00. . . . . FOP-15-1
HZY3-58130-T10. . . . . FOP-15-1
HZY3-58130-T20. . . . . FOP-15-1
HZY3-58130-T30. . . . . FOP-15-1
HZY3-58130-T40. . . . . FOP-15-1
HZY3-58130-T50. . . . . FOP-15-1
HZY3-58130-V01ZA. . . . FOP-15-1
HZY3-58130-V12ZA. . . . FOP-15-1
HZY3-58130-V22ZA. . . . FOP-15-1
HZY3-58130-V32ZA. . . . FOP-15-1
HZY3-58130-V42ZA. . . . FOP-15-1
HZY3-58130-V52ZA. . . . FOP-15-1
HZY3-58180-T00. . . . . FOP-15-1
HZY3-58180-T10. . . . . FOP-15-1
HZY3-58180-T20. . . . . FOP-15-1
HZY3-58180-T30. . . . . FOP-15-1
HZY3-58180-T40. . . . . FOP-15-1
HZY3-90010-000. . . . . E-6-10-27
HZY3-90011-000. . . . . E-6-10-28
HZY3-90013-000. . . . . E-6-10-29
HZY3-90015-000. . . . . E-6-10-30
HZY3-90031-000. . . . . E-14-10-14
HZY3-90044-000. . . . . E-14-29
HZY3-90055-000. . . . . E-19-24
HZY3-90059-000. . . . . E-6-10-36
HZY3-90082-003. . . . . E-3-10-14
HZY3-90104-010. . . . . F-10-41
HZY3-90105-010. . . . . F-3-20-40
HZY3-90106-A00 . . . . . F-10-44
HZY3-90107-000. . . . . F-7-10-17
HZY3-90111-000. . . . . F-3-30-9
HZY3-90111-000. . . . . F-3-30-9
HZY3-90117-000. . . . . F-10-46
HZY3-90120-000. . . . . F-3-14
HZY3-90123-000. . . . . F-5-13
HZY3-90123-000. . . . . F-5-1-13
HZY3-90124-000. . . . . F-3-15
HZY3-90205-000. . . . . E-14-10-16
HZY3-90302-000. . . . . F-3-20-44
HZY3-90304-000. . . . . F-7-10-19
HZY3-90405-000. . . . . F-7-10-20
HZY3-90501-A00 . . . . . F-10-56
HZY3-90503-610. . . . . F-3-20-45
HZY3-90509-000. . . . . F-10-60
HZY3-90511-000. . . . . F-3-20-46
HZY3-90548-000. . . . . F-5-19
HZY3-90549-000. . . . . F-5-19
HZY3-90550-000. . . . . F-5-19
HZY3-90551-000. . . . . F-5-19
HZY3-90552-000. . . . . F-5-19
HZY3-90553-000. . . . . F-5-19
HZY3-90554-000. . . . . F-5-19
HZY3-90555-000. . . . . F-5-19
HZY3-90556-000. . . . . F-5-19
HZY3-90557-000. . . . . F-5-19
HZY3-90558-000. . . . . F-5-19
HZY3-90559-000. . . . . F-5-19
HZY3-90560-000. . . . . F-5-19
HZY3-90601-030. . . . . E-4-19
HZY3-90601-030. . . . . E-6-10-40
HZY3-90601-030. . . . . E-18-10-26
HZY3-90602-020. . . . . E-1-14
HZY3-90603-020. . . . . E-4-20
HZY3-90604-020. . . . . E-4-21
HZY3-90652-000. . . . . F-3-20-48
HZY3-90653-003. . . . . F-7-8
HZY3-90741-000. . . . . E-13-29
HZY3-90751-000. . . . . F-2-40
HZY3-90752-003. . . . . F-4-23
HZY3-90752-003. . . . . FOP-2-10
HZY3-91001-003. . . . . E-6-10-43
HZY3-91056-711. . . . . F-5-26
HZY3-91056-711. . . . . F-5-1-28
HZY3-91057-003. . . . . F-5-27
HZY3-91057-003. . . . . F-5-1-29
HZY3-91151-000. . . . . F-5-28
HZY3-91151-000. . . . . F-5-1-30
HZY3-91152-003. . . . . F-2-41
HZY3-91212-003. . . . . E-3-41
HZY3-91251-C01 . . . . . F-4-27
HZY3-91251-C01 . . . . . FOP-17-3
HZY3-91254-003. . . . . F-4-28
HZY3-91254-003. . . . . FOP-17-5
HZY3-91255-003. . . . . F-2-43
HZY3-91301-003. . . . . E-4-22
HZY3-91303-000. . . . . E-21-22
HZY3-91304-000. . . . . E-6-10-46
HZY3-91305-003. . . . . E-6-10-47
HZY3-91306-003. . . . . E-6-10-48
HZY3-91356-003. . . . . F-4-30
HZY3-91356-003. . . . . FOP-2-11
HZY3-91401-A00 . . . . . E-1-16
HZY3-91402-030. . . . . E-1-17
HZY3-91403-000. . . . . E-1-18
HZY3-91405-000. . . . . E-6-10-49
HZY3-91551-000. . . . . F-4-33
HZY3-91551-000. . . . . FOP-2-14
HZY3-91556-000. . . . . F-8-11
HZY3-91560-000. . . . . F-10-70
HZY6-06323-R00. . . . . FOP-5-1
HZY6-06323-R10. . . . . FOP-5-1-1
HZY6-06323-R20. . . . . FOP-5-2-1
HZY6-06323-R30. . . . . FOP-5-2-1
HZY6-06323-R80. . . . . FOP-5-1
HZY6-06323-R90. . . . . FOP-5-1-1
HZY6-16450-003. . . . . E-14-1
HZY6-16718-013. . . . . E-18-32
HZY6-16723-003. . . . . E-18-34
HZY6-19269-000. . . . . E-18-10-22
HZY6-24320-000. . . . . F-4-11
HZY6-24320-610. . . . . F-4-11
HZY6-32340-R01. . . . . FOP-5-2
HZY6-32340-R11. . . . . FOP-5-1-2
HZY6-32340-R21. . . . . FOP-5-2-2
HZY6-32340-R31. . . . . FOP-5-2-2
HZY6-32340-R81. . . . . FOP-5-2
HZY6-32340-R91. . . . . FOP-5-1-2
HZY6-32346-R01. . . . . FOP-5-3
HZY6-32346-R11. . . . . FOP-5-1-3
HZY6-32346-R21. . . . . FOP-5-2-3
HZY6-32346-R31. . . . . FOP-5-2-3
HZY6-32346-R81. . . . . FOP-5-3
HZY6-32346-R91. . . . . FOP-5-1-3
HZY6-32414-640. . . . . F-7-10-6
HZY6-32545-003. . . . . FOP-5-4
HZY6-32545-003. . . . . FOP-5-1-4
HZY6-32545-003. . . . . FOP-5-2-4
HZY6-32606-000. . . . . FOP-5-5
HZY6-32606-000. . . . . FOP-5-1-5
HZY6-32606-000. . . . . FOP-5-2-5
HZY6-35100-R01. . . . . FOP-5-8
HZY6-35100-R01. . . . . FOP-5-1-8
HZY6-35100-R01. . . . . FOP-5-2-8
HZY6-36135-003. . . . . E-18-10-23
HZY6-36180-003. . . . . FOP-5-9
HZY6-36180-612. . . . . FOP-5-2-9
HZY6-36180-712. . . . . FOP-5-1-9
HZY6-36182-003. . . . . FOP-5-10
HZY6-36182-003. . . . . FOP-5-1-10
HZY6-36182-003. . . . . FOP-5-2-10
HZY6-36187-003. . . . . FOP-5-11
HZY6-36187-003. . . . . FOP-5-1-11
HZY6-36187-003. . . . . FOP-5-2-11
HZY6-38235-004. . . . . F-7-20-4
HZY6-38414-003. . . . . FOP-5-14
HZY6-38414-003. . . . . FOP-5-1-14
HZY6-38414-003. . . . . FOP-5-2-14
HZY6-39794-003. . . . . F-7-20-6
HZY6-90103-000. . . . . F-3-12
HZY6-90103-000. . . . . F-10-40
HZY6-90135-004. . . . . F-7-20-8
HZY6-90302-003. . . . . FOP-5-17
HZY6-90302-003. . . . . FOP-5-1-17
HZY6-90302-003. . . . . FOP-5-2-17
HZY9-15600-M00 . . . . . E-3-10-5
HZY9-15631-000. . . . . E-3-10-6
HZY9-16896-003. . . . . E-18-1-5
HZY9-17315-M00 . . . . . E-15-7
HZY9-30419-003. . . . . E-20-10-2
HZY9-30419-003. . . . . F-7-10-1
HZY9-31207-H01 . . . . . E-21-3
HZY9-31226-H01 . . . . . E-21-8
HZY9-31229-H01 . . . . . E-21-9
HZY9-31246-H01 . . . . . E-21-16
HZY9-35645-000. . . . . F-3-20-9
HZY9-38410-A01 . . . . . FOP-5-13
HZY9-38410-A01 . . . . . FOP-5-1-13
HZY9-38410-A01 . . . . . FOP-5-2-13
HZY9-38553-003. . . . . E-20-4
HZY9-56115-023. . . . . F-11-17
HZY9-87538-U80 . . . . . F-12-10
HZY9-90014-M00 . . . . . E-18-46
HZY9-90026-M00 . . . . . E-9-12
HZY9-90027-M00 . . . . . E-4-16
HZY9-90042-M00 . . . . . E-14-27
HZY9-90054-M00 . . . . . E-3-38
HZY9-90205-M00 . . . . . E-14-30
HZY9-91503-M00 . . . . . E-15-20
HZY9-91503-M00 . . . . . E-20-7
HZY9-91503-M00 . . . . . E-20-10-12
HZY9-91503-M00 . . . . . F-7-10-25
HZY9-91504-M00 . . . . . E-18-54
HZY9-91504-M00 . . . . . F-3-20-53
HZZ0-90101-000. . . . . F-3-11
HZZ0-90101-M00 . . . . . F-2-29
HZZ0-90102-M00 . . . . . E-20-10-9
HZZ0-90103-M00 . . . . . E-18-1-15
HZZ0-90103-M00 . . . . . E-20-10-10
HZZ0-90103-M00 . . . . . F-7-10-15
HZZ0-90151-M00 . . . . . E-3-10-15
HZZ0-91601-M00 . . . . . F-3-20-54
HZZ3-06240-R31 . . . . . FOP-3-1
HZZ3-06240-R41 . . . . . FOP-3-1-1
HZZ3-06240-R61 . . . . . FOP-3-2-1
HZZ3-06323-R03 . . . . . FOP-5-3-1
HZZ3-06323-R13 . . . . . FOP-5-4-1
HZZ3-06323-R23 . . . . . FOP-5-3-1
HZZ3-06323-R33 . . . . . FOP-5-4-1
HZZ3-06328-764. . . . . FOP-7-1
HZZ3-24800-P04. . . . . FOP-3-3-1
HZZ3-24800-P14. . . . . FOP-3-3-1
HZZ3-24820-R12 . . . . . FOP-3-12
HZZ3-24820-R22 . . . . . FOP-3-2-13
HZZ3-24830-R42 . . . . . FOP-3-1-11
HZZ3-32127-000. . . . . F-7-4
HZZ3-32341-R02 . . . . . FOP-5-3-3
HZZ3-32341-R32 . . . . . FOP-5-3-3
HZZ3-32346-R02 . . . . . FOP-5-3-4
HZZ3-32346-R12 . . . . . FOP-5-4-2
HZZ3-32346-R22 . . . . . FOP-5-3-4
HZZ3-32346-R32 . . . . . FOP-5-4-2
HZZ3-32347-R02 . . . . . FOP-5-3-5
HZZ3-32800-000. . . . . FOP-7-2
HZZ3-32805-000. . . . . FOP-7-3
HZZ3-35100-R12 . . . . . FOP-3-3-34
HZZ3-35100-R12 . . . . . FOP-5-3-9
HZZ3-35100-R12 . . . . . FOP-5-4-6
HZZ3-35645-A41 . . . . . FOP-3-3-36
HZZ3-35745-743. . . . . F-10-8
HZZ3-37205-R03 . . . . . FOP-5-3-13
HZZ3-50223-000. . . . . F-10-23
HZZ3-50224-000. . . . . F-10-24
HZZ3-87701-R41 . . . . . FOP-3-1-18
HZZ3-87703-R02 . . . . . FOP-3-2-23
HZZ3-87703-R82 . . . . . FOP-3-20
HZZ3-91252-003. . . . . F-5-29
HZZ3-91252-003. . . . . F-5-1-31
HZZ3-91252-003. . . . . FOP-17-4
HZZ5-06352-M00 . . . . . FOP-5-3-2
HZZ5-24810-D01 . . . . . FOP-3-3-2
HZZ5-24811-D01 . . . . . FOP-3-3-3
HZZ5-24812-D01 . . . . . FOP-3-3-4
HZZ5-24813-D01 . . . . . FOP-3-3-5
HZZ5-24814-D01 . . . . . FOP-3-3-6
HZZ5-24815-D01 . . . . . FOP-3-3-7
HZZ5-24816-D01 . . . . . FOP-3-3-8
HZZ5-24817-D01 . . . . . FOP-3-3-9
HZZ5-24818-D01 . . . . . FOP-3-3-10
HZZ5-24819-D01 . . . . . FOP-3-3-11
HZZ5-24821-D01 . . . . . FOP-3-3-12
HZZ5-24822-D01 . . . . . FOP-3-3-13
HZZ5-24823-D01 . . . . . FOP-3-3-14
HZZ5-24824-D01 . . . . . FOP-3-3-15

HZZ5-24826-D01 . . . . . FOP-3-3-16
HZZ5-24827-D01 . . . . . FOP-3-3-17
HZZ5-24828-D01 . . . . . FOP-3-3-18
HZZ5-24828-D01 . . . . . FOP-3-3-19
HZZ5-24829-D01 . . . . . FOP-3-3-20
HZZ5-24831-D01 . . . . . FOP-3-3-21
HZZ5-24832-D01 . . . . . FOP-3-3-22
HZZ5-24833-D01 . . . . . FOP-3-3-23
HZZ5-24845-D01 . . . . . FOP-3-3-24
HZZ5-24850-D01 . . . . . FOP-3-3-25
HZZ5-24855-D01 . . . . . FOP-3-3-26
HZZ5-24875-D01 . . . . . FOP-3-3-27
HZZ5-24876-D01 . . . . . FOP-3-3-28
HZZ5-24878-D01 . . . . . FOP-3-3-29
HZZ5-24883-D01 . . . . . FOP-3-3-30
HZZ5-32530-D01 . . . . . FOP-3-3-31
HZZ5-32545-000. . . . . FOP-5-3-6
HZZ5-32545-000. . . . . FOP-5-4-3
HZZ5-35370-D02 . . . . . FOP-3-3-35
HZZ5-35701-D01 . . . . . FOP-3-3-37
HZZ5-37210-713. . . . . FOP-5-4-10
HZZ5-37210-763. . . . . FOP-5-3-14
HZZ5-37210-D02 . . . . . FOP-3-3-40
HZZ5-38414-003. . . . . FOP-5-3-17
HZZ5-38414-003. . . . . FOP-5-4-13
HZZ5-87701-790. . . . . FOP-3-3-43
HZZ5-87701-D00 . . . . . FOP-3-3-44
HZZ5-87702-A00 . . . . . FOP-3-3-45
HZZ5-87702-A00 . . . . . FOP-3-3-46
HZZ5-87702-D00 . . . . . FOP-3-3-45
HZZ5-87702-D00 . . . . . FOP-3-3-47
HZZ5-87703-P01. . . . . FOP-3-3-48
HZZ5-87704-D01 . . . . . FOP-3-3-49
HZZ5-90011-M00 . . . . . E-1-12
HZZ5-90011-M00 . . . . . E-3-30
HZZ5-90011-M00 . . . . . E-13-20
HZZ5-90012-M01 . . . . . E-13-21
HZZ5-90013-M00 . . . . . E-15-15
HZZ5-90013-M00 . . . . . F-7-10-13
HZZ5-90014-M00 . . . . . E-3-10-7
HZZ5-90014-M00 . . . . . E-14-24
HZZ5-90014-M00 . . . . . E-18-47
HZZ5-90016-M00 . . . . . E-18-48
HZZ5-90017-M00 . . . . . E-3-32
HZZ5-90017-M00 . . . . . E-13-23
HZZ5-90017-M00 . . . . . E-18-49
HZZ5-90017-M00 . . . . . E-19-23
HZZ5-90017-M00 . . . . . F-2-26
HZZ5-90018-M00 . . . . . E-20-6
HZZ5-90018-M00 . . . . . F-7-20-7
HZZ5-90019-M00 . . . . . E-1-13
HZZ5-90019-M00 . . . . . E-3-33
HZZ5-90019-M00 . . . . . E-4-15
HZZ5-90019-M00 . . . . . E-14-25
HZZ5-90021-M00 . . . . . E-14-26
HZZ5-90021-M00 . . . . . E-18-50
HZZ5-90021-M00 . . . . . E-18-1-14
HZZ5-90021-M00 . . . . . F-2-27
HZZ5-90021-M00 . . . . . F-7-6
HZZ5-90030-M00 . . . . . E-3-36
HZZ5-90030-M00 . . . . . E-6-10-31
HZZ5-90030-M00 . . . . . E-13-24
HZZ5-90030-M00 . . . . . E-15-16
HZZ5-90032-M00 . . . . . E-3-10-9
HZZ5-90032-M00 . . . . . E-6-10-32
HZZ5-90047-M00 . . . . . E-3-10-11
HZZ5-90051-M00 . . . . . F-3-20-36
HZZ5-90055-M00 . . . . . E-4-18
HZZ5-90081-M00 . . . . . E-3-39
HZZ5-90081-M00 . . . . . E-3-10-13
HZZ5-90081-M00 . . . . . E-5-15
HZZ5-90101-D01 . . . . . FOP-3-3-50
HZZ5-90102-D01 . . . . . FOP-3-3-51
HZZ5-90103-D01 . . . . . FOP-3-3-52
HZZ5-90104-D01 . . . . . FOP-3-3-53
HZZ5-90105-M00 . . . . . F-7-7
HZZ5-90105-M00 . . . . . F-7-10-16
HZZ5-90106-D01 . . . . . FOP-3-3-54
HZZ5-90107-D01 . . . . . FOP-3-3-55
HZZ5-90108-D01 . . . . . FOP-3-3-56
HZZ5-90109-D01 . . . . . FOP-3-3-57
HZZ5-90201-M00 . . . . . F-2-31
HZZ5-90301-D01 . . . . . FOP-3-3-58
HZZ5-90301-M00 . . . . . E-14-10-17
HZZ5-90301-M00 . . . . . FOP-5-16
HZZ5-90301-M00 . . . . . FOP-5-1-16
HZZ5-90301-M00 . . . . . FOP-5-2-16
HZZ5-90301-M00 . . . . . FOP-5-3-19
HZZ5-90301-M00 . . . . . FOP-5-3-19
HZZ5-90301-M00 . . . . . FOP-5-4-15
HZZ5-90302-D01 . . . . . FOP-3-3-60
HZZ5-90501-D01 . . . . . FOP-3-3-61
HZZ5-90501-M00 . . . . . E-14-10-18
HZZ5-90501-M00 . . . . . FOP-5-18
HZZ5-90501-M00 . . . . . FOP-5-1-18
HZZ5-90501-M00 . . . . . FOP-5-2-18
HZZ5-90501-M00 . . . . . FOP-5-3-21
HZZ5-90501-M00 . . . . . FOP-5-3-21
HZZ5-90501-M00 . . . . . FOP-5-4-17
HZZ5-90502-D01 . . . . . FOP-3-3-62
HZZ5-90502-M00 . . . . . FOP-5-19
HZZ5-90502-M00 . . . . . FOP-5-1-19
HZZ5-90502-M00 . . . . . FOP-5-2-19
HZZ5-90502-M00 . . . . . FOP-5-3-22
HZZ5-90502-M00 . . . . . FOP-5-3-22
HZZ5-90502-M00 . . . . . FOP-5-4-18
HZZ5-90503-D01 . . . . . FOP-3-3-63
HZZ5-90504-D01 . . . . . FOP-3-3-64
HZZ5-90506-D01 . . . . . FOP-3-3-65
HZZ5-90507-D01 . . . . . FOP-3-3-66
HZZ5-90508-D01 . . . . . FOP-3-3-67
HZZ5-90508-M00 . . . . . F-2-36
HZZ5-90509-D01 . . . . . FOP-3-3-68
HZZ5-90651-D01 . . . . . FOP-3-3-69
HZZ5-91151-D01 . . . . . FOP-3-3-70
HZZ5-91152-D01 . . . . . FOP-3-3-71
HZZ5-91153-D01 . . . . . FOP-3-3-72
HZZ5-91154-D01 . . . . . FOP-3-3-73
HZZ5-91156-D01 . . . . . FOP-3-3-74
HZZ5-91157-D01 . . . . . FOP-3-3-75
HZZ5-91501-000. . . . . F-7-10-24

Note

Note

Note

Copyright © 2019 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means without the express written permission of Tohatsu Corporation.

2019 PARTS CATALOG

BFT 200D
BFT 225D
BFT 250D
Models

OB No.002-13ZVJ-0AK 1812 EU/EX



TOHATSU CORPORATION

5-4, Azusawa 3-Chome, Itabashi-Ku
Tokyo 174-0051, Japan
Tel: +81-3-3966-3117 Fax: +81-3-3966-2951
www.tohatsu.com