
2019 PARTS CATALOG

TOHATSU
Feel the Wind™

BFT 80AK1
BFT 100AK1
Models

OB NO.002-13ZZ0-0AK 1812 EU/EX



BACKS YOU UP™

TOHATSU CORPORATION

Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of December 1, 2018.**

- See the Service Bulletin for any revision that is made after December 1, 2018.

- **Always specify the part number when ordering a part.**
  - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
  - Note that the illustrations (part drawings) can differ from the actual parts in shape.
    Illustrations are given just to help you to refer to the parts.

- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times.**

Initial version issue date December 1, 2018

CONTENTS

E-1	CYLINDER HEAD COVER	1
E-2	CYLINDER HEAD	3
E-3	CYLINDER BLOCK	7
E-5	OIL PUMP	11
E-6	OIL CASE	13
E-6-10	MOUNT CASE	15
E-7	CRANKSHAFT/PISTON/FLYWHEEL	17
E-9	CAMSHAFT/VALVE/BELT	21
E-9-10	CHAIN CASE/THARMOSTAT	25
E-14	INLET MANIFOLD/INJECTOR	27
E-15	SILENCER CASE/THROTTLE BODY	29
E-18	FUEL PUMP	31
E-18-10	WATER SEPARATOR	33
E-18-20	VAPOR SEPARATOR	35
E-19	A.C. GENERATOR	39
E-20	PLUG TOP COIL	41
E-20-10	ELECTRONIC CONTROL UNIT	43
E-21	STARTER MOTOR	45
F-2	SHIFT SHAFT	47
F-3	EXTENSION CASE	51
F-3-10	GEAR CASE	55
F-3-20	GEAR CASE ASSY.	59
F-4	WATER PUMP/VERTICAL SHAFT	61
F-5	PROPELLER SHAFT	65
F-6	FUEL TUBE	69
F-7	MAIN WIRE HARNESS	71
F-7-10	STARTER CABLE	73
F-8	ENGINE COVER/UNDER COVER	75
F-10	STERN BRACKET/SWIVEL CASE	79
F-11	POWER TRIM-TILT	85
F-12	LABEL	89
F-13	TOOL	91
F-15	REMOTE CONTROL (NHK MEC) (HANDLE CAP = CHROME)	93
F-15-1	REMOTE CONTROL (PANEL MOUNT)	99
FOP-3	IMPELLER PUMP KIT	103
FOP-4	REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT)	105
FOP-4-2	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)	109
FOP-4-4	REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)	113
FOP-6	SWITCH PANEL KIT (1)	115
FOP-6-1	SWITCH PANEL KIT (2)	119
FOP-6-2	SWITCH PANEL KIT (3)	121
FOP-6-3	SWITCH PANEL KIT (4)	123
FOP-6-4	SWITCH PANEL KIT (5)	125
FOP-7	METER	127
FOP-8	PROPELLER	129
FOP-9	BOLT KIT	131
FOP-10	STEERING HANDLE KIT	133
FOP-10-1	STEERING HANDLE KIT (MULTI-FUNCTION) (2)	141
FOP-11	INTERFACE CABLE KIT	149
FOP-12	TROLLING CONTROL SWITCH	151
INDEX		153
INDEX (Parts Number)		159

How to refer to the part information

A. Reference with “Illustrated index”






Fig. Number

Ref. Number/Part Number/Parts Name



Ref.No.		Part No.	Description	Q'ty		Remarks
				EFTSAK	EFTSAK	
E-2	1	HZV9-12155-000	METAL, ANODE	2	2	
E-2	2	HPJ7-12204-305	GUIDE, IN. VALVE(OS)	8	8	
E-2	3	HPJ7-12205-305	GUIDE, EX. VALVE(OS)	8	8	
E-2	4	HPZ1-12210-004	SEAL A, VALVE STEM(NOK)	8	8	
E-2	5	HZY9-12210-H002A	HEAD COMP., CYLINDER	1	1	*NH6* DARK GRAY
E-2	6	HPZ1-12211-004	SEAL B, VALVE STEM(NOK)	8	8	
E-2	7	HZW1-12217-010	BOLT, SEALING, 20MM	2	2	
E-2	8	HZY9-12251-013	GASKET COMP., CYLINDER HEAD	1	1	
E-2	9	HPZA-14620-013	MOTION COMP., LOST		4	
E-2	10	HZZ0-15610-002ZA	VALVE ASSY., SPOOL		1	*NH6* DARK GRAY
E-2	11	HRAA-15615-A02	FILTER ASSY., SPOOL VALVE	1	1	
E-2	12	HZY9-15815-000	COVER ASSY., OIL PATH	1		
E-2	13	HZY9-16711-000	LIFTER, FUEL PUMP	1	1	
E-2	14	HZY9-16896-003	CLAMP B, FUEL TUBE	1	1	
E-2	15	HZY9-19300-003	THERMOSTAT ASSY.	1	1	
E-2	16	HZW1-19311-000	COVER, THERMOSTAT	1	1	
E-2	17	HZW1-19317-000	O-RING, THERMOSTAT COVER	1	1	
E-2	18	HZY9-19361-010	COVER, WATER JACKET	1	1	
E-2	19	HZY9-19371-000	PACKING, EX. WATER JACKET	1	1	COVER
E-2	20	HZY9-31750-003	RECTIFIER ASSY., REGULATOR	1	1	
E-2	21	HZY9-31754-000	PACKING, REGULATOR	1	1	
E-2	22	HZY9-32114-000	BRACKET D. HARNESS CLIP	1	1	
E-2	23	HZY9-35655-H01	SENSOR, OXYGEN	1	1	
E-2	24	HZY3-35672-003	SENSOR ASSY., WATER	1	1	TEMPERATURE
E-2	25	HZY9-35686-003	SENSOR ASSY., TDC	1	1	
E-2	26	HPWA-90008-003	BOLT-WASHER, 8X155	10	10	
E-2	27	HZY9-90011-000	BOLT, FLANGE, 8X95	1	1	
E-2	28	HZY9-90016-000	BOLT, FLANGE, 8X110	1	1	
E-2	29	HZY3-90017-000	BOLT, FLANGE, 8X16	1	1	


B. Reference with “Parts number index”



INDEX (Parts Number)

1H2-11534-0 15-15
3D6-00131-0 6-7
3D6-00972-0 5-20
3D6-00972-0 6-13
3D6-00972-0 6-37
3D6-00972-0 9-36
3D6-05033-0 6-42
3E2-00005-2 3-36
3E2-00005-2 ..... 11A-3
3E2-00006-0 3-37
3E2-00006-0 ..... 11A-4
3E2-00006-0 ..... 29-4x2
3E2-00103-0 ..... 11B-5
3E2-00103-0 ..... 29-4x3
3E2-62101-1 1-2-36
3E2-62101-1 1-2-37
3E2-66221-0 ..... 11B-16
3E2-66222-0 ..... 11A-16
3E2-66222-0 ..... 29-5x3
3E2-66321-0 ..... 11A-53
3E2-66321-0 ..... 29-5x7
3S2-70101-0 20-11
3S2-70101-0 1-2-34
3A4-00131-0 6-3
3A4-00131-0 ..... 11A-26
3B6-00972-0 13-23
3B6-00972-0 ..... 23-4x12
3B6-60007-0 23-47
3B6-64088-0 ..... 11A-47
3B6-64088-0 ..... 11A-48
3B6-64121-0 ..... 11A-23
3B6-64121-0 ..... 11B-24
3B6-64211-0 ..... 11B-13
3B6-64218-0 ..... 11B-15
3B6-64218-0 ..... 11B-18
3B6-64231-0 ..... 11B-23
3B6-64320-0 ..... 11A-13-2
3B6-64320-0 ..... 11A-13-3
3B6-64320-0 ..... 29-7x5
3B6-64327-0 ..... 11A-11
3B6-64328-0 ..... 11A-12
3B6-65015-0 ..... 11A-21
3B6-65015-0 ..... 29-9x4
3B6-65017-0 ..... 11A-20
3B6-66037-0 ..... 11A-17
3B6-66037-0 ..... 29-7x10
3B6-66321-0 1-2-70
3B6-66322-0 ..... 11A-60
3B6-66323-0 1-2-81
3B6-66337-0 ..... 13-62x2
3B6-66339-0 1-2-22
3B6-66339-0 13-74
3B6-66339-0 1-2-21
3B6-67115-0 6-21
3B6-67115-0 16-2
3B6-67116-1 6-23
3B9-52433-1 13-44
3B9-64081-1 ..... 11B-19-1
3B9-64082-1 ..... 11B-19-2
3B9-84398-0 6-75
3B9-84398-0 6-31
3B9-84398-0 9-32
3B9-84398-0 10-5
3B9-T02004-0 16-13
3B9-26832-0 16-27
3B9-26972-0 9-14
3B9-52396-1 12-18
3B9-52396-1 13-5
3B9-76085-0 16-26
3B9-76085-0 ..... 29-6x10
3E0-76079-0 1-2-28
3E0-76079-0 1-2-24
3E0-76079-0 8-24
3E0-76079-0 5-43
3A1-90233-0 ..... 11A-46
3A3-60835-0 22-9
3A3-62396-1 13-47
3A3-72560-0 22-5
3A3-72570-0 22-7
3A3-76037-0 8-28-1
3A3-76037-0 8-29-2
3A3-76037-0 9-10
3A3-76084-1 22-6
3A3-76115-1 22-11
BOLT 9-23
BOLT 6-44
BOLT 10-20
BOLT 10-26
BOLT 10-34
BOLT 10-35
BOLT 11A-6
BOLT 11A-27
BOLT 11A-35
BOLT 11A-38
BOLT 11A-39
BOLT 11B-8
BOLT 12-6
BOLT 12-19
BOLT 12-24
BOLT 12-31
BOLT 12-40
BOLT 12-46
BOLT 12-48
BOLT 12-50
BOLT 12-58
BOLT 12-63
BOLT 13-48
BOLT 13-6
BOLT 13-9
BOLT 13-19
BOLT 14-26
BOLT 14-32


C. Reference with “Parts name index”



INDEX

<A>
ADJUST SCREW 21-28
ADJUSTING NUT 3-9
ADJUSTING SCREW 5-8
ADJUSTING SCREW 11-12
AIR FILTER 5-40
AIR VENT ASSY 6-47
ALTERNATOR ASSY 6-2
ANODE 1-14
ANODE 1-2-3
ANODE 13-5
ANODE PLUG 1-2-1
APRON 10-28
ASSIST CORD (BLK) L=200 21-46-2
ASSIST CORD (BLU) L=200 21-46-1
ASSIST CORD (RED) L=200 21-46-3
ASSIST CORD (RED) L=200 21-46-5
<B>
BACK-UP RING 14-16
BALL 14-21
BALL 3/8 ..... 11B-20
BALL BEARING 6203 ..... 11B-5
BALL JOINT CONNECTOR 17-22
BAND 22-17
BAND 104 8-29
BAND 104 8-30
BAND 158 6-31
BAND 158 8-11
BOLT 9-23
BOLT 6-44
BOLT 10-20
BOLT 10-26
BOLT 10-34
BOLT 10-35
BOLT 11A-6
BOLT 11A-27
BOLT 11A-35
BOLT 11A-38
BOLT 11A-39
BOLT 11B-8
BOLT 12-6
BOLT 12-19
BOLT 12-24
BOLT 12-31
BOLT 12-40
BOLT 12-46
BOLT 12-48
BOLT 12-50
BOLT 12-58
BOLT 12-63
BOLT 13-48
BOLT 13-6
BOLT 13-9
BOLT 13-19
BOLT 14-26
BOLT 14-32

Part catalogue structure



Ref.No.		Part No.	Description	Q'ty		Remarks
				BRTANA	BRTANA	
E-2	1	HZV5-12155-000	METAL, ANODE	2	2	
E-2	2	HPJ1-12204-305	GUIDE, IN. VALVE(OS)	8	8	
E-2	3	HPJ1-12205-305	GUIDE, EX. VALVE(OS)	8	8	
E-2	4	HPZ1-12210-004	SEAL A, VALVE STEM(NOK)	8	8	
E-2	5	HZY9-12210-H002A	HEAD COMP., CYLINDER	1	1	•NH9• DARK GRAY
E-2	6	HPZ1-12211-004	SEAL B, VALVE STEM(NOK)	8	8	
E-2	7	HZW1-12211-010	BOLT, SEALING, 20MM	2	2	
E-2	8	HZY9-12251-013	GASKET COMP., CYLINDER HEAD	1	1	
E-2	9	HP2A-14820-013	MOTION COMP., LOST		4	
E-2	10	HZZD-15810-002A	VALVE ASSY., SPOOL		1	•NH9• DARK GRAY
E-2	11	HRAA-15815-A02	FILTER ASSY., SPOOL VALVE	1	1	
E-2	12	HZY9-15819-000	COVER ASSY., OIL PATH	1		
E-2	13	HZY9-16711-000	LIFTER, FUEL PUMP	1	1	
E-2	14	HZY9-16899-003	CLAMP B, FUEL TUBE	1	1	
E-2	15	HZY9-19300-003	THERMOSTAT ASSY.,	1	1	
E-2	16	HZW9-19315-000	COVER, THERMOSTAT	1	1	
E-2	17	HZW9-19317-000	O-RING, THERMOSTAT COVER	1	1	
E-2	18	HZY9-19361-010	COVER, WATER JACKET	1	1	
E-2	19	HZY9-19371-000	PACKING, EX. WATER JACKET	1	1	COVER
E-2	20	HZY9-31750-003	RECTIFIER ASSY., REGULATOR	1	1	
E-2	21	HZY9-31754-000	PACKING, REGULATOR	1	1	
E-2	22	HZY9-32114-000	BRACKET D, HARNESS CLIP	1	1	
E-2	23	HZY9-35685-H01	SENSOR, OXYGEN	1	1	
E-2	24	HZY3-35673-003	SENSOR ASSY., WATER	1	1	TEMPERATURE
E-2	25	HZY9-35699-003	SENSOR ASSY., TDC	1	1	
E-2	26	HPWA-60030-003	BOLT-WASHER, 8X155	10	10	
E-2	27	HZY9-60011-000	BOLT, FLANGE, 8X95	1	1	
E-2	28	HZY9-60016-000	BOLT, FLANGE, 8X110	1	1	
E-2	29	HZY3-60011-000	BOLT, FLANGE, 6X16	1	1	

① Fig. Number

② Fig. Title

③ Ref. Number

④ Parts Number

⑤ Parts Name

⑥ Q.ty

⑦ Remarks

⑧ Defferent specification


⑨ Direction Arrow

⑩ Parts enclosed within a doted line are sub assembly parts.

⑪ A solid arrow indicates the block No. the part in question is connected to.

How to check the part block and serial numbers

Part block	Engine parts E-1~	Frame parts F-2~
Numbers needed	Stamped engine number	Stamped frame number
Check point	①	②



Models, parts catalogue codes and applicable serial numbers

• Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Type	Parts catalogue type	Engine		Applicable engine serial No.	Applicable frame serial No.
			Model	Type		
BFT 80AK1	LRTU	LRTU	BF 80AK1	SE1	BEBLJ-1100001~	BBLJ-6000001~
	XRTU	XRTU				
BFT 100AK1	LRTU	LRTU	BF 100AK1		BEBMJ-1100001~	BBMJ-6000001~
	XRTU	XRTU				

Features of each type

• See the following table for the features of each type. (Items in brackets are optional)

Specifications \ Model		BFT 80AK1	
Specifications \ Type		LRTU	XRTU
Transom height	537 mm	●	
	664 mm		●
Remote control		(●)	(●)
Fuel tank		(●)	(●)

Specifications \ Model		BFT 100AK1	
Specifications \ Type		LRTU	XRTU
Transom height	537 mm	●	
	664 mm		●
Remote control		(●)	(●)
Fuel tank		(●)	(●)

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets ( ) underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name. (For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

Bulk part number of fuel hose, general purpose hose and vinyl hose.

Example: 95001-75001-50M

Bulk part number:
Refers to the bulk part.

Marking code (fuel hose and general purpose hose)
Change code (Vinyl hose)
Indicates number mark or change sequence, however, the code for the bulk part must be strictly 0 (zero).

Types of code:

- Fuel hose
  - 2: Red outside braid (3 mm inside dia. only)
  - 5: Black inside braid
  - 3: Red (3 mm inside dia. only)
  - 4: Ash gray with red stripe (3 mm inside dia. only)
  - 6: Black
- General hose
  - 1: Ash gray
  - 2: Ash gray
  - 3: Black
  - 5: Black
- Vinyl hose
  - 1: Clear
  - 2: Black
  - 3: Light red
  - 6: Light red
  - 7: Pale black

Lengths:
001: 1 m (standard)
003: 3 m
008: 8 m
} Application or specification of some parts is not settled.

I.D code: (fuel hose and general purpose hose)

30: 3.0 mm	35: 3.5 mm	45: 4.5 mm
50: 5.0 mm	55: 5.3 mm, 5.5 mm	65: 6.5 mm
70: 7.0 mm	75: 7.3 mm, 7.5 mm	80: 8.0 mm
11: 11 mm	91: 12 (outside dia. 15) mm	92: 12 (outside dia. 16) mm
12: 12 (outside dia. 17) mm	14: 14 mm	17: 17 mm

ID./OD. code: (vinyl hose)


01: ID. 2.9, OD. 6.8 mm	02: ID. 3.0, OD. 6.0 mm	03: ID. 3.5, OD. 6.5 mm
07: ID. 4.0, OD. 7.0 mm	08: ID. 4.5, OD. 6.5 mm	09: ID. 4.5, OD. 8.0 mm
12: ID. 5.0, OD. 7.0 mm	10: ID. 5.0, OD. 8.0 mm	11: ID. 5.0, OD. 9.0 mm
14: ID. 6.0, OD. 9.0 mm	17: ID. 7.0, OD. 9.0 mm	19: ID. 7.0, OD. 11.0 mm
21: ID. 8.0, OD. 9.0 mm	23: ID. 8.0, OD. 12.0 mm	25: ID. 9.0, OD. 11.0 mm
27: ID. 9.0, OD. 13.0 mm	33: ID. 10.0, OD. 14.0 mm	36: ID. 11.0, OD. 13.0 mm
37: ID. 11.0, OD. 15.0 mm	38: ID. 12.0, OD. 13.0 mm	39: ID. 12.0, OD. 14.0 mm
40: ID. 12.0, OD. 16.0 mm	43: ID. 13.0, OD. 15.0 mm	45: ID. 14.0, OD. 18.0 mm
50: ID. 16.0, OD. 19.0 mm	55: ID. 17.5, OD. 20.5 mm	60: ID. 22.0, OD. 27.0 mm

Hose type:
1: Fuel hose
3: Vinyl hose
5: General hose


CAUTION: It is DANGEROUS to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.


E-1 CYLINDER HEAD COVER




E-2 CYLINDER HEAD




E-3 CYLINDER BLOCK




E-5 OIL PUMP




E-6 OIL CASE




E-6-10 MOUNT CASE




E-7 CRANKSHAFT/PISTON/FLYWHEEL




E-9 CAMSHAFT/VALVE/BELT




E-9-10 CHAIN CASE/THARMOSTAT




E-14 INLET MANIFOLD/INJECTOR




E-15 SILENCER CASE/THROTTLE BODY




E-18 FUEL PUMP




E-18-10 WATER SEPARATOR




E-18-20 VAPOR SEPARATOR




E-19 A.C. GENERATOR




E-20 PLUG TOP COIL




E-20-10 ELECTRONIC CONTROL UNIT




E-21 STARTER MOTOR




F-2 SHIFT SHAFT




F-3 EXTENSION CASE




F-3-10 GEAR CASE




F-3-20 GEAR CASE ASSY.




F-4 WATER PUMP/VERTICAL SHAFT




F-5 PROPELLER SHAFT




F-6 FUEL TUBE




F-7 MAIN WIRE HARNESS




F-7-10 STARTER CABLE




F-8 ENGINE COVER/UNDER COVER




F-10 STERN BRACKET/SWIVEL CASE




F-11 POWER TRIM-TILT




F-12 LABEL




F-13 TOOL




F-15 REMOTE CONTROL (NHK MEC) (HANDLE CAP = CHROME)




F-15-1 REMOTE CONTROL (PANEL MOUNT)




FOP-3 IMPELLER PUMP KIT




FOP-4 REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT)




FOP-4-2 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)




FOP-4-4 REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)




FOP-6 SWITCH PANEL KIT (1)




FOP-6-1 SWITCH PANEL KIT (2)




FOP-6-2 SWITCH PANEL KIT (3)




FOP-6-3 SWITCH PANEL KIT (4)




FOP-6-4 SWITCH PANEL KIT (5)




FOP-7 METER




FOP-8 PROPELLER




FOP-9 BOLT KIT




FOP-10 STEERING HANDLE KIT




FOP-10-1 STEERING HANDLE KIT (MULTI-FUNCTION) (2)





FOP-11 INTERFACE CABLE KIT







FOP-12 TROLLING CONTROL SWITCH





FR.
4
E-15
2
1
5
3
F-3-30


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-1	1	HZY9-12310-010	COVER COMP., CYLINDER HEAD	1	1	
E-1	2	HZY9-12312-000	PACKING, HEAD COVER	1	1	
E-1	3	HZY9-15422-010	TUBE, OIL	1	1	
E-1	4	HZZ5-90030-M00	BOLT, FLANGE, 6X22	9	9	
E-1	5	HZW5-90606-030	CLAMP, TUBE(D29)	1	1	


FR.
8
41
41
34
35
22
10
33
5
13
23
38
2
4
14
38
11
3
1
39
1
39
6
11
12
40
7
26
9
37
29
28
36
25
27
24


18
15
42
17
16
31
32
43
32
45
21
30
19
32
20


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-2	1	HZV5-12155-000	METAL, ANODE	2	2	
E-2	2	HPJ7-12204-305	GUIDE, IN. VALVE(O.S.)	8	8	
E-2	3	HPJ7-12205-305	GUIDE, EX. VALVE(O.S.)	8	8	
E-2	4	HPZ1-12210-004	SEAL A, VALVE STEM(NOK)	8	8	
E-2	5	HZY9-12210-M00ZA	HEAD COMP., CYLINDER	1	1	*NH8* DARK GRAY
E-2	6	HPZ1-12211-004	SEAL B, VALVE STEM(NOK)	8	8	
E-2	7	HZY9-12217-M00	BOLT, SEALING, 20MM	2	2	
E-2	8	HZY9-12251-013	GASKET COMP., CYLINDER HEAD	1	1	
E-2	9	HPZA-14820-013	MOTION COMP., LOST		4	
E-2	10	HZZ0-15810-003ZA	VALVE ASSY., SPOOL		1	*NH8* DARK GRAY
E-2	11	HRAA-15815-A02	FILTER ASSY., SPOOL VALVE	1	1	
E-2	12	HZY9-15815-000	COVER ASSY., OIL PATH	1		
E-2	13	HZY9-16717-000	LIFTER, FUEL PUMP	1	1	
E-2	14	HZY9-16896-003	CLAMP B, FUEL TUBE	1	1	
E-2	15	HZY6-19300-003	THERMOSTAT ASSY.	1	1	
E-2	16	HZW9-19315-000	COVER, THERMOSTAT	1	1	
E-2	17	HZW9-19317-000	O-RING, THERMOSTAT COVER	1	1	
E-2	18	HZY9-19361-M00	COVER, WATER JACKET	1	1	
E-2	19	HZY9-19371-000	PACKING, EX. WATER JACKET COVER	1	1	
E-2	20	HZY9-31750-003	RECTIFIER ASSY., REGULATOR	1	1	
E-2	21	HZY9-31754-000	PACKING, REGULATOR	1	1	
E-2	22	HZY9-32114-000	BRACKET D, HARNESS CLIP	1	1	
E-2	23	HZY9-35655-H01	SENSOR, OXYGEN	1	1	
E-2	24	HZY3-35673-003	SENSOR ASSY., WATER TEMPERATURE	1	1	
E-2	25	HZY9-35695-003	SENSOR ASSY., TDC	1	1	
E-2	26	HPWA-90008-003	BOLT-WASHER, 9X155	10	10	
E-2	27	HZY9-90011-M00	BOLT, FLANGE, 8X95	1	1	
E-2	28	HZY9-90016-M00	BOLT, FLANGE, 8X110	1	1	
E-2	29	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	


FR.
8
41
41
34
35
22
10
33
5
13
23
38
2
4
14
38
11
3
1
39
6
1
39
11
12
40
7
26
9
37
29
28
36
25
27
24


18
15
42
17
16
31
32
43
32
45
21
30
19
32
20


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-2	30	HZZ5-90018-M00	BOLT, FLANGE, 6X20	4	4	
E-2	31	HZZ5-90019-M00	BOLT, FLANGE, 6X35	2	2	
E-2	32	HZZ5-90030-M00	BOLT, FLANGE, 6X22	13	13	
E-2	33	HZY9-90047-M00	BOLT, STUD, 8X32	2	2	
E-2	34	HZZ5-90047-M00	BOLT, FLANGE, 6X55	3	3	
E-2	35	HZB7-90691-003	CLIP, HARNESS	1	1	
E-2	36	HPNA-91307-003	O-RING, 9.5X1.9	1	1	
E-2	37	HPNA-91333-003	O-RING, 15X1.9	1	1	
E-2	38	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)	1	2	(145MM)
E-2	39	HCO-93500-06018-4J	SCREW, PAN, 6X18	2	2	
E-2	40	HCO-94109-20000	WASHER, DRAIN PLUG, 20MM	2	2	
E-2	41	HCO-94301-14200	DOWEL PIN, 14X20	2	2	
E-2	42	HZW9-19303-003	RUBBER, RING	1	1	
E-2	43	HZY9-19380-M01	COVER COMP., ANODE	1	1	
E-2	45	HZZ5-91302-M01	O RING, 33X2.4	1	1	

E-3 CYLINDER BLOCK




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-3	1	HPWA-11106-300	BOLT, SEALING, 24MM	2	2	
E-3	2	HPWA-11107-300	WASHER, SEALING, 24MM	2	2	
E-3	3	HZY9-11911-000	HANGER, ENGINE	2	2	
E-3	4	HZY9-12000-407ZA	BLOCK ASSY., CYLINDER	1	1	*NH8* DARK GRAY
E-3	5	HRTA-15400-004	CARTRIDGE, OIL FILTER	1	1	(TOYO ROKI)
E-3	6	HZY9-15600-M00	CAP ASSY., OIL FILLER	1	1	
E-3	7	HZY9-15612-000	PIPE, OIL	1	1	
E-3	8	HZY9-15631-000	EXTENSION, OIL FILLER	1	1	
E-3	9	HZW9-19300-003	THERMOSTAT ASSY.	1	1	
E-3	11	HZW9-19317-000	O-RING, THERMOSTAT COVER	1	1	
E-3	12	HRGA-30530-004	SENSOR COMP., KNOCK		1	
E-3	13	HZY3-35673-003	SENSOR ASSY., WATER TEMPERATURE	2	2	
E-3	14	HRNA-37260-A01	SENSOR, OIL PRESSURE	1	1	
E-3	15	HZY9-90008-003	BOLT-WASHER, 10X105	10	10	
E-3	16	HPH1-90015-013	HOLDER, OIL FILTER	1	1	
E-3	17	HZZ5-90014-M00	BOLT, FLANGE, 6X25	2	2	
E-3	18	HZY9-90026-M00	BOLT, FLANGE, 8X20	4	4	
E-3	20	HZZ5-90032-M00	BOLT, FLANGE, 6X32	12	12	
E-3	21	HZY9-90054-M00	BOLT, FLANGE, 8X35	1	1	
E-3	22	HHW1-90120-671	BOLT, FLANGE, 8X45	2	2	
E-3	23	HZY9-90201-M00	NUT, FLANGE CAP, 8MM	2	2	
E-3	24	HPD2-90701-000	DOWEL PIN, 12X14	10	10	
E-3	25	HPNA-91214-014	OIL SEAL, 80X98X10(ARAI)	1	1	
E-3	26	HMAL-91302-601	O-RING, 18.1X3.6	1	1	
E-3	27	HZY6-91305-003	O-RING, 6.5X1.5	1	1	
E-3	28	HPNA-91307-003	O-RING, 9.5X1.9	2	2	
E-3	29	HPR3-91319-003	O-RING, 13X1.5(ARAI)	1	1	
E-3	30	HPF4-91324-004	O-RING, 28.3X2.4(NOK)	1	1	
E-3	31	HCO-96300-06014-09	BOLT, FLANGE, 6X14	1	1	


E-3 CYLINDER BLOCK




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-3	32	HZW9-19303-003	RUBBER, RING	1	1	
E-3	33	HZW9-19315-000	COVER, THERMOSTAT	1	1	
E-3	34	HZY9-19330-M00	CASE, THERMOSTAT	1	1	
E-3	35	HZY9-19331-M00	PACKING, THERMOSTAT CASE	1	1	
E-3	36	HZY9-90020-M00	BOLT, FLANGE, 6X45	2	2	
E-3	37	HZZ5-90030-M00	BOLT, FLANGE, 6X22	2	2	


FR.
15
4
5
6
7
14
13
12
3
16
1
8
9
2
10
11


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-5	1	HZY9-15100-M00	PUMP ASSY., OIL	1	1	
E-5	2	HZY9-15121-000	COVER, OIL PUMP	1	1	
E-5	3	HZY9-15136-000	SHAFT, OIL PUMP	1	1	
E-5	4	HPE0-15231-000	VALVE, RELIEF	1	1	
E-5	5	HPG6-15232-000	SPRING, RELIEF VALVE	1	1	
E-5	6	HPC6-15234-000	WASHER, SEALING, 18MM	1	1	
E-5	7	HZY9-15236-M00	BOLT, SEALING, 18MM	1	1	
E-5	8	HZW1-15331-000	ROTOR, INNER	1	1	
E-5	9	HZW1-15341-000	ROTOR, OUTER	1	1	
E-5	10	HZZ5-90104-M00	BOLT, FLANGE, 6X18(CT200)	3	3	
E-5	11	HZY9-90027-M00	BOLT, FLANGE, 8X60	2	2	
E-5	12	HZZ5-90055-M00	BOLT, FLANGE, 8X40	2	2	
E-5	13	HMC7-90456-000	WASHER, THRUST, 13MM	1	1	
E-5	14	HZW1-91302-000	O-RING, PUMP COVER	1	1	
E-5	15	HZY9-91304-000	O-RING, OIL PUMP	1	1	
E-5	16	HCO-96220-50178	ROLLER, 5X17.8	1	1	


FR.
17
7
17
4
11
E-6-10
3
15
16
16
18
18
19
8
20
2
14
14
1
13
12
5
10
6
9
8
F-4


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-6	1	HZY9-11320-010ZA	CASE ASSY., OIL	1	1	*TGRAY* GRAY
E-6	2	HZY9-11381-003	PACKING, OIL PAN	1	1	
E-6	3	HZY9-15220-000	STRAINER COMP., OIL	1	1	
E-6	4	HZY9-15655-M00	GAUGE COMP., OIL LEVEL	1	1	
E-6	5	HZW1-19252-000	GROMMET, WATER TUBE	1	1	
E-6	6	HZY9-19254-000	PLATE, WATER TUBE	1	1	
E-6	7	HZY9-23172-003	GASKET, MOUNT CASE	1	1	
E-6	8	HZY3-90046-000	BOLT, FLANGE, 8X100	8	8	
E-6	9	HZW9-90102-000	BOLT, FLANGE, 6X12	1	1	
E-6	10	HHW1-90114-671	BOLT, FLANGE, 8X35	11	11	
E-6	11	HHW1-90120-671	BOLT, FLANGE, 8X45	4	4	
E-6	12	HZV5-90131-000	BOLT, DRAIN PLUG	1	1	
E-6	13	HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	1	1	
E-6	14	HZV5-90756-000	DOWEL PIN, 6X10	2	2	
E-6	15	HPC6-91310-004	O-RING, 15.5X2.7	1	1	
E-6	16	HZZ0-91601-M00	GROMMET, 1WAY	2	2	
E-6	17	HCO-94301-06100	DOWEL PIN, 6X10	2	2	
E-6	18	HCO-96300-06016-09	BOLT, FLANGE, 6X16	3	3	
E-6	19	HCO-96300-08100-09	BOLT, FLANGE, 8X100	4	4	
E-6	20	HCO-96300-08120-09	BOLT, FLANGE, 8X120	3	3	


E-18-20
20
4
15
9
12
7
E-6
E-1
2
24
20
11
13
16
21
21
E-18
E-18-20
16
17
1
23
E-6
FR.
19
19
25
6
8
10
22
3
5
18
F-8
14
F-10


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-6-10	1	HZY9-15665-000	PIPE COMP., OIL LEVEL	1	1	
E-6-10	2	HGHB-16163-600	CLIP, TUBE	1	1	
E-6-10	3	HZY9-17202-M00	COLLAR, DISTANCE, 6.5X11X7.5	1	1	
E-6-10	4	HZY9-19256-000	TUBE B, WATER	1	1	
E-6-10	5	HZY9-19277-M00	COVER, FLUSH VALVE	1	1	
E-6-10	6	HZW9-19279-010	SPRING, FLUSH VALVE	1	1	
E-6-10	7	HZY6-19290-003	VALVE ASSY., RELIEF	1	1	
E-6-10	8	HZW9-19291-000	VALVE, FLASH	1	1	
E-6-10	9	HZY9-19295-000	COVER, RELIEF VALVE	1	1	
E-6-10	10	HZW9-19297-000	PACKING, FLASH VALVE	1	1	
E-6-10	11	HZW4-19312-H00	JOINT, WATER TUBE	1	1	
E-6-10	12	HZW9-19317-000	O-RING, THERMOSTAT COVER	1	1	
E-6-10	13	HZY9-23170-010ZA	CASE COMP., MOUNT	1	1	*NH8* DARK GRAY
E-6-10	14	HZY9-63718-000	SEAL A, COVER UNDER	1	1	
E-6-10	15	HZZ5-90030-M00	BOLT, FLANGE, 6X22	2	2	
E-6-10	16	HZY9-90043-M00	BOLT, STUD, 8X28	2	2	
E-6-10	17	HZY9-90056-M00	BOLT, FLANGE, 6X12	1	1	
E-6-10	18	HZW9-90105-000	BOLT, FLANGE, 6X20	1	1	
E-6-10	19	HZY3-90601-030	CLAMP, TUBE(D10.5)	2	2	
E-6-10	20	HZV4-90603-000	CLIP, TUBE(B10)	3	3	
E-6-10	21	HZW5-91202-003	SEAL, WATER, 22X35X7	2	2	
E-6-10	22	H800-91303-000	O-RING, 16MM	1	1	
E-6-10	23	HPJ7-91309-010	O-RING, 11.5X3.5	1	1	
E-6-10	24	HZY9-91402-000	TUBE, WATER CHECK	1	1	
E-6-10	25	HCO-95005-70110-30	TUBE, 7X110	1	1	(HC-95005-70001-30M)


FR.
E-19
E-9-10
11
5
4
10
14
3
6
6
1
8
7
2
9
9
E-3
12
13


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-7	1	HZY9-13010-H00	RING SET, PISTON(STD.)	4	4	
E-7	1	HZY9-13011-010	RING SET, PISTON(0.25)	4	4	
E-7	2	HZY9-13101-H00	PISTON(STD.)	4	4	
E-7	2	HZZ0-13102-000	PISTON(0.25)	4	4	
E-7	3	HPWA-13111-000	PIN, PISTON	4	4	
E-7	4	HPWA-13204-003	BOLT, CONNECTING ROD	8	8	
E-7	5	HZY9-13210-010	ROD COMP., CONNECTING	4	4	
E-7	6	HPWA-13211-003	BEARING A, CONNECTING ROD(BLUE)	8	8	(DAIDO)
E-7	6	HPWA-13212-003	BEARING B, CONNECTING ROD(BLACK)	8	8	(DAIDO)
E-7	6	HPWA-13213-003	BEARING C, CONNECTING ROD(BROWN)	8	8	(DAIDO)
E-7	6	HPWA-13214-003	BEARING D, CONNECTING ROD(GREEN)	8	8	(DAIDO)
E-7	6	HPWA-13215-003	BEARING E, CONNECTING ROD(YELLOW)	8	8	(DAIDO)
E-7	6	HPWA-13216-003	BEARING F, CONNECTING ROD(PINK)	8	8	(DAIDO)
E-7	6	HPWA-13217-003	BEARING G, CONNECTING ROD(RED)	8	8	(DAIDO)
E-7	7	HZY9-13310-010	CRANKSHAFT COMP.	1	1	
E-7	8	HPWA-13322-003	BEARING B, MAIN UPPER(BLACK)	5	5	(DAIDO)
E-7	8	HPWA-13323-003	BEARING C, MAIN UPPER(BROWN)	5	5	(DAIDO)
E-7	8	HPWA-13324-003	BEARING D, MAIN UPPER(GREEN)	5	5	(DAIDO)
E-7	8	HPWA-13325-003	BEARING E, MAIN UPPER(YELLOW)	5	5	(DAIDO)
E-7	8	HPWA-13326-003	BEARING F, MAIN UPPER(PINK)	5	5	(DAIDO)
E-7	8	HPWA-13327-003	BEARING G, MAIN UPPER(RED)	5	5	(DAIDO)
E-7	8	HPWA-13328-003	BEARING H, MAIN UPPER(WHITE)	5	5	(DAIDO)
E-7	9	HZY9-13331-003	WASHER, THRUST	2	2	
E-7	10	HPWA-13342-003	BEARING B, MAIN LOWER(BLACK)	5	5	(DAIDO)
E-7	10	HPWA-13343-003	BEARING C, MAIN LOWER(BROWN)	5	5	(DAIDO)
E-7	10	HPWA-13344-003	BEARING D, MAIN LOWER(GREEN)	5	5	(DAIDO)
E-7	10	HPWA-13345-003	BEARING E, MAIN LOWER(YELLOW)	5	5	(DAIDO)
E-7	10	HPWA-13346-003	BEARING F, MAIN LOWER(PINK)	5	5	(DAIDO)
E-7	10	HPWA-13347-003	BEARING G, MAIN LOWER(RED)	5	5	(DAIDO)


FR.
E-19
E-9-10
11
5
4
10
14
3
6
6
1
8
7
2
9
9
E-3
12
13


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-7	10	HPWA-13348-003	BEARING H, MAIN LOWER(WHITE)	5	5	(DAIDO)
E-7	11	HZY9-13621-H01	SPROCKET, CAM CHAIN(23T)	1	1	
E-7	12	HZY9-31110-000ZB	FLYWHEEL COMP.	1	1	*TBLACK* BLAL
E-7	13	HZW1-90002-010	BOLT, 12MM	6	6	
E-7	14	HPH7-90704-000	KEY, SPECIAL	1	1	


FR.
30
12
31
24
10
11
5
26
2
28
6
18
18
27
29
14
25
9
27
18
15
13
27
18
7
14
3
4
27
18
8
14
23
21
19
22
16
23
22
17
20
21
23
23


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-9	1	HZY9-14110-000	CAMSHAFT COMP.	1		
E-9	1	HZZ0-14110-000	CAMSHAFT COMP.		1	
E-9	2	HRB0-14211-003	SPROCKET, CAM CHAIN DRIVEN	1	1	(46T)
E-9	3	HPWA-14221-003	PLATE, TDC PULSER	1	1	
E-9	4	HZY9-14222-000	BOLT, TDC PULSER PLATE	1	1	
E-9	5	HRB1-14401-003	CHAIN(132L)	1	1	
E-9	6	HZZ0-14420-000	ARM ASSY., ROCKER		4	
E-9	7	HZY9-14430-000	ARM COMP., IN. VALVE ROCKER	4		
E-9	8	HZY9-14441-000	ARM COMP., EX. ROCKER(A)	4		
E-9	9	HZY9-14442-000	ARM COMP., EX. ROCKER(B)	4		
E-9	10	HZY9-14510-003	TENSIONER COMP., CAM CHAIN	1	1	
E-9	11	HZY9-14512-000	SLIDER COMP., CAM CHAIN TENSIONER	1	1	
E-9	12	HRB1-14530-004	GUIDE COMP., CAM CHAIN	1	1	
E-9	13	HPWC-14631-010	SHAFT COMP., ROCKER ARM	1	1	
E-9	14	HPWA-14647-000	WASHER, THRUST	12		
E-9	15	HPY3-14647-000	WASHER, IN. WAVE	4		
E-9	16	HRB0-14711-000	VALVE, IN.	8	8	
E-9	17	HPWC-14721-010	VALVE, EX.	8	8	
E-9	18	HPM3-14744-000	SCREW, TAPPET ADJUSTING	16	16	
E-9	19	HZY9-14751-H01	SPRING, IN. VALVE	8	8	
E-9	20	HZY9-14752-003	SPRING, EX. VALVE	8	8	
E-9	21	HRGA-14765-000	RETAINER, VALVE SPRING	16	16	
E-9	22	HP08-14775-000	SEAT, VALVE SPRING	16	16	
E-9	23	HRGM-14781-A01	COTTER, VALVE(FUJI VALVE)	32	32	
E-9	24	HPNA-90003-000	BOLT, TENSIONER PIVOT	1	1	
E-9	25	HPWC-90006-003	BOLT, ROCKER ARM SHAFT	5	5	
E-9	26	HRNA-90031-A01	BOLT-WASHER, 10X30	1	1	
E-9	27	HPM3-90206-004	NUT, TAPPET ADJUSTING	16	8	(TOKAI TRW)
E-9	28	HPT0-90206-004	NUT, TAPPET ADJUSTING		8	


FR.
30
12
31
24
10
11
5
26
2
28
6
18
18
27
29
14
25
9
27
18
15
13
27
18
7
14
3
4
27
18
8
14
23
21
19
22
16
23
22
17
20
21
23
23


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-9	29	HCO-94301-07120	PIN A, DOWEL, 7X12	1	1	
E-9	30	HCO-96300-06014-09	BOLT, FLANGE, 6X14	2	2	
E-9	31	HCO-96300-06028-09	BOLT, FLANGE, 6X28	2	2	


FR.
7
3
7
4
7
8
2
11
12
13
6
1
10
5
14
9
6


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-9-10	1	HZY9-11411-415ZA	CASE COMP., CHAIN	1	1	*NH8* DARK GRAY
E-9-10	2	HZY9-32111-000	BRACKET A, HARNESS CLIP	1	1	
E-9-10	3	HZY9-32113-000	BRACKET C, HARNESS CLIP	1	1	
E-9-10	4	HZY9-32115-000	BRACKET E, HARNESS CLIP	1	1	
E-9-10	5	HPNB-37500-003	SENSOR ASSY., CRANK	1	1	
E-9-10	6	HZV5-40102-000	GROMMET, UNDER CASE	2	2	
E-9-10	7	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	4	4	
E-9-10	8	HZZ5-90016-M00	BOLT, FLANGE, 6X28	10	10	
E-9-10	9	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	
E-9-10	10	HZY6-90023-000	BOLT, SPECIAL, 6X31	2	2	
E-9-10	11	HZZ5-90030-M00	BOLT, FLANGE, 6X22	3	3	
E-9-10	12	HZZ5-90045-M00	BOLT, FLANGE, 6X40	1	1	
E-9-10	13	HPWA-91212-003	OIL SEAL, 40X55X7(NOK)	1	1	
E-9-10	14	HPNA-91333-003	O-RING, 15X1.9	1	1	


19
1
6
21
20
19
12
4
18
3
12
4
14
2
18
16
9
10
7
11
22
5
8
17
E-18-20
13
15


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-14	1	HZY9-16450-003	INJECTOR ASSY., FUEL	4	4	
E-14	2	HZY9-16451-000	CLIP, INJECTOR	2	2	
E-14	3	HZY9-16620-010	LINE COMP., FUEL	1	1	
E-14	4	HPH3-16638-S00	INSULATOR, FUEL PIPE	2	2	
E-14	5	HZY9-16733-000	GROMMET, VAPOR SEPARATOR	2	2	
E-14	6	HZY3-16752-A00	JOINT, FUEL PIPE	1	1	
E-14	7	HPWA-17105-007	PACKING, INTAKE MANIFOLD	4	4	
E-14	8	HZY6-17109-000	PACKING, THROTTLE BODY	1	1	
E-14	9	HZY9-17110-003	MANIFOLD COMP., INLET	1	1	
E-14	10	HZY9-36550-003	VALVE ASSY., ELECTRONIC AIR CONTROL	1	1	
E-14	11	HZY6-36551-003	PACKING, ELECTRONIC AIR CONTROL VALVE	1	1	
E-14	12	HZY9-90004-M00	BOLT, STUD, 6X40	2	2	
E-14	13	HZY9-90014-M00	BOLT-WASHER, 8X35	2	2	
E-14	14	HZY9-90042-M00	BOLT, FLANGE, 6X10	4	4	
E-14	15	HZY9-90054-M00	BOLT, FLANGE, 8X35	3	3	
E-14	16	HZZ5-90026-M00	BOLT, FLANGE, 8X45	2	2	
E-14	17	HZY9-90205-M00	NUT, FLANGE, 8MM	2	2	
E-14	18	HZZ5-90201-M00	NUT, FLANGE, 6MM	2	2	
E-14	19	HMJ0-91301-003	O-RING, 7.8X1.9(ARAI)	2	2	
E-14	20	HPLC-91301-000	O-RING, 7.47X3.6	4	4	
E-14	21	HPNA-91302-003	O-RING, 7.45X3.61(NOK)	4	4	
E-14	22	HZY9-91504-M00	COLLAR, 8.5X14.5	2	2	


4
21
23
1
22
5
E-1
15
19
20
9
24
7
14
13
F-7
8
25
26
16
10
11
12
18
3
2
FR.


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-15	1	HZY9-15171-000	PIPE, BREATHER	1	1	
E-15	2	HZY6-16016-003	SCREW SET	1	1	
E-15	3	HZY9-16400-H01	THROTTLE BODY ASSY.	1	1	
E-15	4	HZY9-16896-003	CLAMP B, FUEL TUBE	1	1	
E-15	5	HMR5-16966-000	JOINT, FUEL TUBE	1	1	
E-15	7	HZY9-17371-000	CASE COMP., SILENCER	1		
E-15	7	HZY9-17371-H00	CASE COMP., SILENCER		1	
E-15	8	HZY9-17374-000	GROMMET, SILENCER	1	1	
E-15	9	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	2	2	
E-15	10	HZY3-32128-000	BRACKET, SENSOR CORD	1	1	
E-15	11	HRNA-37830-A01	SENSOR ASSY., MAP	1	1	
E-15	12	HPGK-37835-A01	O-RING	1	1	
E-15	13	HPLC-37880-004	SENSOR ASSY., AIR TEMP	1		(MATSUSHITA DENSHI)
E-15	13	HRE1-37880-Z01	SENSOR ASSY., AIR TEMPERATURE		1	
E-15	14	HP2A-37881-000	GROMMET, TA SENSOR	1	1	
E-15	15	HZZ5-90003-M00	BOLT-WASHER, 6X27(CT200)	2	2	
E-15	16	HZY6-90006-000	SCREW, PAN, 5X18	1	1	
E-15	18	HZY9-90027-M00	BOLT, FLANGE, 8X60	4	4	
E-15	19	HZY9-90069-M00	BOLT, FLANGE, 6X25	1	1	
E-15	20	HZZ5-90508-M00	WASHER, PLAIN, 6MM	1	1	
E-15	21	HZY9-91403-000	TUBE A, BREATHER	1	1	
E-15	22	HZY9-91404-000	TUBE B, BREATHER	1	1	
E-15	23	HZY9-91405-000	TUBE C, BREATHER	1	1	
E-15	24	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	2	2	
E-15	25	HCO-95003-07019-31	TUBE, VINYL, 4X7X190	1	1	(HCO-95003-07001-60M)
E-15	26	HZY9-17315-M00	BAND, AIR FLOW	1	1	


FR.
E-18-10
22
12
22
19
13
22
11
22
1
23
7
22
3
13
17
20
14
10
2
20
6
16
5
4
15
14
14
14
E-6-10
E-18-20
21
E-14
18
14
8
9
21


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-18	1	HZY9-06167-000	PUMP ASSY KIT, FUEL	1	1	
E-18	2	HZY9-16195-000	TUBE A, CHECK VALVE	1	1	
E-18	3	HZY9-16196-000	TUBE B, CHECK VALVE	1	1	
E-18	4	HZY9-16197-000	TUBE A, AIR VENT	1	1	
E-18	5	HZY9-16198-000	TUBE B, AIR VENT	1	1	
E-18	6	HZY9-16199-000	TUBE C, AIR VENT	1	1	
E-18	7	HZY9-16700-013	PUMP ASSY., FUEL	1	1	
E-18	8	HZY9-16755-003	HOSE COMP., FUEL	1	1	
E-18	9	HZY9-16756-000	GROMMET, FUEL HOSE	1	1	
E-18	10	HZY9-16816-000	BRACKET, FUEL TUBE CLAMP	1	1	
E-18	11	HZY9-16881-010	TUBE D, FUEL	1	1	
E-18	12	HZY9-16891-000	TUBE E, FUEL	1	1	
E-18	13	HZY9-16895-003	CLAMP A, FUEL TUBE	2	2	
E-18	14	HZY9-16896-003	CLAMP B, FUEL TUBE	7	7	
E-18	15	HZV4-16910-015	STRAINER COMP., FUEL	1	1	
E-18	16	HZY6-19269-000	T-JOINT	1	1	
E-18	17	HZY6-36135-003	VALVE, CHECK	1	1	
E-18	18	HP3F-36533-A01	CLAMP, OXYGEN SENSOR	1	1	
E-18	19	HZY9-90003-M00	BOLT, FLANGE, 6X22	2	2	
E-18	20	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	2	2	
E-18	21	HZZ5-90014-M00	BOLT, FLANGE, 6X25	2	2	
E-18	22	HZV0-90604-000	CLIP, TUBE(B12)	4	4	
E-18	23	HZW9-91303-000	O-RING, 31.2X2.4	1	1	


FR.
19
13
13
14
7
16
9
17
10
15
E-18
16
6
19
18
1
18
19
4
2
11
3
12
8
10
5


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-18-10	1	HRMA-16723-E00	JOINT, FUEL FEED HOSE	1	1	
E-18-10	2	HZY9-16800-003	SEPARATOR ASSY., WATER	1	1	
E-18-10	3	HZY9-16805-003	CUP, WATER SEPARATOR	1	1	
E-18-10	4	HZY3-16807-003	BUFFER, PLATE	1	1	
E-18-10	5	HZY9-16850-000	TUBE COMP. A, FUEL	1	1	
E-18-10	6	HZY9-16860-000	TUBE COMP. B, FUEL	1	1	
E-18-10	7	HZY9-16871-000	TUBE C, FUEL	1	1	
E-18-10	8	HZY3-16904-003	SCREW, PAN, 5X12	3	3	
E-18-10	9	HZY9-16910-004	STRAINER COMP., FUEL	1	1	
E-18-10	10	HZY3-16915-010	SUSPENSION, STRAINER	2	2	
E-18-10	11	HZY3-16918-003	O-RING	1	1	
E-18-10	12	HZY3-16919-003	PLATE	1	1	
E-18-10	13	HPY3-17439-A01	CLAMP, TUBE(7.5-11.5)(BLACK)	2	2	
E-18-10	14	HPN4-19526-000	CLAMP, TUBE	1	1	
E-18-10	15	HZY9-32112-000	BRACKET B, HARNESS CLIP	1	1	
E-18-10	16	HSE0-53740-953	CLIP, SENSOR HOSE	2	2	
E-18-10	17	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	2	2	
E-18-10	18	HZW5-90602-030	CLAMP, TUBE(D12)	2	2	
E-18-10	19	HZV0-90604-000	CLIP, TUBE(B12)	3	3	


FR.
20
21
22
50
46
26
45
41
7
44
54
3
40
52
37
52
17
E-14
15
27
39
35
9
36
51
51
34
29
42
49
47
30
14
24
38
8
28
25
6
48
31
33
12
E-14
55
53
32
17
E-18
5
11
E-18
1
2
47
19
19
16
4
16
23
32
43
38
13
23
53
E-6-10
10
18
E-6-10


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-18-20	1	HZY3-16011-A01	VALVE SET, FLOAT	1	1	
E-18-20	2	HZY9-16013-000	FLOAT SET	1	1	
E-18-20	3	HZY9-16017-M00	PUMP UNIT, FUEL(A)	1	1	
E-18-20	4	HZY9-16019-003	BODY	1	1	
E-18-20	5	HZY9-16020-013	COVER COMP.	1	1	
E-18-20	6	HZY3-16024-000	SCREW SET, DRAIN	1	1	
E-18-20	7	HZY3-16026-000	JOINT SET	1	1	
E-18-20	8	HZY6-16036-003	PUMP UNIT, FUEL(B)	1	1	
E-18-20	9	HZY9-16042-013	HOLDER	1	1	
E-18-20	10	HZY9-16061-003	COVER, WATER JACKET	1	1	
E-18-20	11	HZY9-16071-003	O-RING	1	1	
E-18-20	12	HZY3-16072-000	O-RING	1	1	
E-18-20	13	HZY9-16072-003	PACKING	1	1	
E-18-20	14	HZY3-16073-000	O-RING	1	1	
E-18-20	15	HZY9-16073-003	O-RING	1	1	
E-18-20	16	HZY3-16077-000	O-RING	2	2	
E-18-20	17	HZW5-16081-010	SCREW-WASHER	9	9	
E-18-20	18	HZY9-16081-003	SCREW-WASHER	5	5	
E-18-20	19	HZY3-16082-000	SCREW, PAN	2	2	
E-18-20	20	HZY9-16082-003	SCREW-WASHER	3	3	
E-18-20	21	HZY3-16083-000	SCREW, WASHER	1	1	
E-18-20	22	HZY3-16087-000	WASHER, PLAIN	1	1	
E-18-20	23	HGHB-16163-610	CLIP, TUBE	2	2	
E-18-20	24	HZY3-16193-A00	CLAMP, CHECK VALVE	1	1	
E-18-20	25	HZY9-16701-003	CASE, PUMP	1	1	
E-18-20	26	HZY9-16708-003	COVER, PUMP(B)	1	1	
E-18-20	27	HZY9-16715-013	COVER, PUMP(A)	1	1	
E-18-20	28	HZY6-16718-013	INSULATOR COMP.	1	1	
E-18-20	29	HZY9-16721-003	INSULATOR	1	1	


FR.
20
26
41
40
21
22
45
44
17
15
27
50
46
7
52
37
52
3
54
E-14
39
35
36
9
51
29
42
51
49
47
34
30
28
12
14
24
38
48
31
33
8
25
6
53
32
E-14
55
17
E-18
5
11
E-18
1
2
47
19
19
16
4
16
23
43
23
E-6-10
38
32
13
10
18
53
E-6-10


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-18-20	30	HZY6-16723-003	RING	1	1	
E-18-20	31	HZY9-16730-M01	SEPARATOR ASSY., VAPOR	1	1	
E-18-20	32	HZY9-16733-000	GROMMET, VAPOR SEPARATOR	3	3	
E-18-20	33	HZY9-16734-010	STAY, FUEL TUBE	1	1	
E-18-20	34	HZW5-16735-003	PUMP UNIT, FUEL	1	1	
E-18-20	35	HZY9-16740-003	REGULATOR ASSY., PRESSURE	1	1	
E-18-20	36	HPG7-16741-005	O-RING, PRESSURE REGULATOR	1	1	
E-18-20	37	HZY3-16752-000	JOINT, FUEL PIPE	1	1	
E-18-20	38	HZY9-16896-003	CLAMP B, FUEL TUBE	2	2	
E-18-20	39	HZY9-16898-003	CLAMP D, FUEL TUBE	1	1	
E-18-20	40	HZY3-16911-010	SCREEN COMP., FUEL STRAINER	1	1	
E-18-20	41	HZY9-16913-003	SPRING, COMPRESSION	1	1	
E-18-20	42	HZY9-17723-F00	HOSE, PRESSURE REGULATOR RETURN	1	1	
E-18-20	43	HZY9-19255-000	TUBE A, WATER	1	1	
E-18-20	44	HZY9-32166-013	HARNESS COMP.	1	1	
E-18-20	45	HZW5-32168-003	BAND	1	1	
E-18-20	46	HPP4-90009-E01	BOLT, SEALING, 6MM	1	1	
E-18-20	47	HZY9-90014-M00	BOLT-WASHER, 8X35	3	3	
E-18-20	48	HZZ5-90014-M00	BOLT, FLANGE, 6X25	3	3	
E-18-20	49	HZZ5-90021-M00	BOLT, FLANGE, 6X14	2	2	
E-18-20	50	HPD6-90430-003	WASHER, SEALING, 6MM	1	1	
E-18-20	51	HZW5-90601-030	CLAMP, TUBE(D10.7)	2	2	
E-18-20	52	HMJ0-91301-003	O-RING, 7.8X1.9(ARAI)	2	2	
E-18-20	53	HZY9-91504-M00	COLLAR, 8.5X14.5	3	3	
E-18-20	54	HCO-95001-35120-40	TUBE, FUEL, 3.5X120	1	1	(HCO-95001-35001-60M)
E-18-20	55	HCO-95003-11024-31	TUBE, VINYL, 5X9X240	1	1	(HCO-95003-11001-60M)


1
5
FR.
9
6
3
7
4
2
8
E-2


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-19	1	HZY9-31145-M00	COVER ASSY., A.C. GENERATOR	1	1	
E-19	2	HZY9-31630-H01	GENERATOR ASSY., A.C.	1	1	
E-19	3	HZY9-31631-H01	ROTOR	1	1	
E-19	4	HZY9-31632-003	STATOR	1	1	
E-19	5	HZV5-40102-000	GROMMET, UNDER CASE	1	1	
E-19	6	HPWA-90017-G02	BOLT-WASHER, 14X36	1	1	
E-19	7	HZY9-90023-M00	BOLT, FLANGE, 6X32(CT200)	3	3	
E-19	8	HS0A-91540-003	CLIP, HARNESS BAND(NATURAL)	1	1	(96.9MM)
E-19	9	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	1	1	


FR.
E-2
2
1
3


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-20	1	HPWC-30520-S01	COIL ASSY., PLUG TOP	4	4	
E-20	2	HZY9-31916-H01	PLUG, SPARK(ZFR6K-9E)	4	4	(NGK)
E-20	2	HCO-9807B-5617C	PLUG, SPARK(IZFR6K-11E)	4	4	(NGK)
E-20	3	HZZ5-90014-M00	BOLT, FLANGE, 6X25	4	4	


FR.
8
2
1
5
7
4
3
6
6


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-20-10	1	HZZ0-30416-M00	CASE, ELECTRONIC PARTS	1	1	
E-20-10	2	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	4	4	
E-20-10	3	HZY9-34750-M41	CONTROL UNIT, ELECTRONIC	1		
E-20-10	3	HZZ0-34750-M41	CONTROL UNIT, ELECTRONIC		1	
E-20-10	4	HZY9-34754-H00	BRACKET, ELECTRONIC CONTROL UNIT	1	1	
E-20-10	5	HZZ5-90003-M00	BOLT-WASHER, 6X27(CT200)	4	4	
E-20-10	6	HZZ0-90102-M00	BOLT, TORX(M6X20)	2	2	
E-20-10	7	H763-90681-A01	CLIP, WIRE HARNESS	1	1	
E-20-10	8	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	4	4	


FR.
18
20
12
1
5
4
8
10
17
3
3
3
6
14
15
13
16
21
19
2
9
11
7
22


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
E-21	1	HZY9-31200-H01	MOTOR ASSY., STARTER	1	1	
E-21	2	HZY9-31207-H01	CLUTCH COMP., OVERRUNNING	1	1	
E-21	3	HPY3-31215-004	GEAR ASSY., PLANETARY	3	3	
E-21	4	HZY9-31216-003	YOKE COMP.	1	1	
E-21	5	HZW1-31217-004	ROTOR COMP.	1	1	
E-21	6	HPY3-31218-004	BALL, STEEL	1	1	
E-21	7	HZY9-31226-H01	SCREW, PAN, 6X22	2	2	
E-21	8	HZY9-31227-H01	BRUSH SET	1	1	
E-21	9	HZY9-31229-H01	STOPPER SET, SLEEVE	1	1	
E-21	10	HZY9-31231-H01	HOLDER COMP., BRUSH	1	1	
E-21	11	HZY6-31235-003	BRACKET, FR.	1	1	
E-21	12	HZY6-31236-003	BRACKET, RR.	1	1	
E-21	13	HZY9-31240-003	SWITCH ASSY., MAGNET	1	1	
E-21	14	HZY9-31242-H01	SHAFT ASSY., CLUTCH	1	1	
E-21	15	HZY9-31246-H01	SHAFT ASSY., GEAR	1	1	
E-21	16	HZW1-31250-004	LEVER SET	1	1	
E-21	17	HZY9-31251-H01	GEAR ASSY., INTERNAL	1	1	
E-21	18	HZW1-31261-004	BOLT A, THROUGH	2	2	
E-21	19	HZY9-90013-M00	BOLT, FLANGE, 10X75	1	1	
E-21	20	HZW1-90107-004	SCREW, PAN, 5X8	2	2	
E-21	21	HZY9-90059-M00	BOLT, FLANGE, 10X35	1	1	
E-21	22	HZY3-91303-000	O-RING, 59.4X3.1	1	1	


25
10
9
25
6
25
5
42
21
28
23
20
19
FR.
1
4
43
2
31
27
8
7
15
3
13
44
22
24
37
15
12
44
13
16
44
22
34
45
14
38
39
36
40
26
11
17
41
29
46
18
30
40
32
33
35


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-2	1	HZV5-17838-000	LINKAGE, PIVOT	1	1	
F-2	2	HZY9-17840-000	ROD COMP., THROTTLE	1	1	
F-2	3	HZY6-17845-000	LINK, THROTTLE	1	1	
F-2	4	HZY9-17860-000	PLATE COMP., THROTTLE	1	1	
F-2	5	HZY9-17877-000	PLATE, REMOTE CONTROL CABLE	1	1	
F-2	6	HZY9-17878-000	COVER, REMOTE CONTROL CABLE	1	1	
F-2	7	HZY6-17931-000	ARM, THROTTLE	1	1	
F-2	8	H921-17936-000	WASHER, PIVOT	1	1	
F-2	9	HZW1-24210-010	SPRING COMP., CLICK	1	1	
F-2	10	HZY9-24221-000	SPRING, CLICK ASSIST	1	1	
F-2	11	HZY9-24612-000	ARM, SHIFT	1	1	
F-2	12	HZY9-24614-000	PLATE, SHIFT PIVOT	1	1	
F-2	13	HZY3-24618-000	PIVOT, SHIFT	2	2	
F-2	14	HZY9-24618-000	PIVOT, SHIFT SLIDE	1	1	
F-2	15	HZY3-24619-000	PLATE, LOCK	2	2	
F-2	16	HZY9-24628-000	BRACKET, SHIFT LINK	1	1	
F-2	17	HZW1-24629-000	HOLDER, SEAL	1	1	
F-2	18	HZY9-24630-000	SHAFT COMP., SHIFT	1	1	
F-2	19	HZY9-35470-023	SWITCH ASSY., NEUTRAL	1	1	
F-2	20	HZY9-35475-010	BRACKET, NEUTRAL SWITCH	1	1	
F-2	21	HVM0-46391-003	CLIP, BRAKE PIPE(A)	1	1	
F-2	22	HZY3-63205-000	BUSH A, COVER LOCK	2	2	
F-2	23	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	1	1	
F-2	24	HZZ5-90104-M00	BOLT, FLANGE, 6X18(CT200)	2	2	
F-2	25	HZY3-90017-000	BOLT, FLANGE, 6X16	3	3	
F-2	26	HZZ0-90101-M00	BOLT, FLANGE, 6X11	2	2	
F-2	27	HZY3-90056-000	BOLT, FLANGE, 6X12	1	1	
F-2	28	HZV5-90302-003	NUT, HEX., 20MM	1	1	
F-2	29	HGET-90429-000	WASHER, SIDE, 14MM	1	1	


25
10
9
25
6
25
5
42
21
28
23
20
19
FR.
1
4
43
2
31
27
15
8
7
3
13
44
37
22
24
15
12
44
13
16
44
22
34
45
14
38
39
36
11
40
26
17
41
29
46
18
30
40
32
33
35


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-2	30	HZW5-90501-000	WASHER, SHIFT SHAFT	1	1	
F-2	31	HZZ5-90508-M00	WASHER, PLAIN, 6MM	1	1	
F-2	32	HZY9-90508-000	WASHER, 14MM	1	1	
F-2	33	HZY9-90509-000	WASHER, 13MM	1	1	
F-2	34	H921-90518-000	WASHER, PLAIN, 8MM	1	1	
F-2	35	HZY9-90651-000	CIRCLIP, EXTERNAL, 12	1	1	
F-2	36	HSD2-90705-931	PIN, SNAP, 6MM	1	1	
F-2	37	HZY3-90751-000	PIN, LINK	1	1	
F-2	38	HZY6-90752-000	PIN, SHIFT LINK	1	1	
F-2	39	HZY6-90753-000	PIN, LINK	1	1	
F-2	40	HZV4-91255-651	WATER SEAL, 14X26X6	2	2	
F-2	41	HKF0-91305-003	O-RING, 27X2(ARAI)	1	1	
F-2	42	HSTK-91540-003	CLIP, HARNESS BAND(BLACK)	1	1	(155.3MM)
F-2	43	HCO-94001-05490-0S	NUT, HEX., 5MM	1	1	
F-2	44	HCO-94540-04029	E-RING, 4MM	3	3	
F-2	45	HCO-94540-06029	E-RING, 6MM	1	1	
F-2	46	HCO-94540-12029	E-RING, 12MM	1	1	


4
8
33
31
26
6
44
7
9
43
6
25
10
47
45
24
41
42
42
27
32
11
17
28
40
14
32
17
F-4
1
39
3
36
3
46
16
3
23
2
35
22
5
35
22
3
15
20
18
19
34
37
21
38
29
13
30
FR.


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-3	1	HZY9-06411-010	TUBE KIT, SPEED SENSOR	1	1	
F-3	2	HGE1-17357-670	JOINT A, BREATHER	1	1	
F-3	3	HKM3-32161-003	BAND, WIRE	4	4	
F-3	4	HMG9-35701-950	BAND(BLACK 3.5X140)	1	1	
F-3	5	HZY6-36104-003	TUBE, SPIRAL	1	1	
F-3	6	HZV5-40102-000	GROMMET, UNDER CASE	3	3	
F-3	7	HZY9-40105-000	GROMMET, REMOTE CONTROL CABLE	1	1	
F-3	8	HZW1-40107-700	GROMMET, UNDER CASE(C)	1	1	
F-3	9	HZY3-40119-003	BAND, UNDER CASE GROMMET	1	1	
F-3	10	HZY9-40154-000ZC	BRACKET, FR. UNDER COVER	1	1	*T107* BAY BLUE
F-3	11	HZY9-40201-020ZC	CASE, EXTENSION	1	1	*T107* BAY BLUE
F-3	13	HZY6-40219-023	WIRE, LEAD(1.5X137MM)	1	1	
F-3	14	HZV5-41172-000	NIPPLE, SENSOR	1	1	
F-3	15	HZV5-41172-000	NIPPLE, SENSOR	1	1	
F-3	16	HZY9-41173-000	TUBE, SPEED SENSOR	1	1	
F-3	17	HZY9-50111-000ZC	HOUSING, LOWER MOUNTING	2	2	*T107* BAY BLUE
F-3	18	HZZ0-50155-000	MOUNT COMP., LOWER RUBBER	2	2	
F-3	19	HZZ0-50156-C00	COLLAR, LOWER MOUNTING	2	2	
F-3	20	HZY9-50157-000	STOPPER, LOWER MOUNT	2	2	
F-3	21	HZW1-50161-020ZC	HOUSING, LOWER CENTER MOUNTING	1	1	*T107* BAY BLUE
F-3	22	HZY6-50209-000	PLATE, SPEED SENSOR TUBE	2	2	
F-3	23	HZY6-56118-000	BUSH, MOTOR CODE	1	1	
F-3	24	HZY9-63232-010	LEVER, FASTENER	1	1	
F-3	25	HZY9-63237-000	WIRE, FASTENER	1	1	
F-3	26	HZC0-63515-700	CAP, L. SIDE COVER	1	1	
F-3	27	HZY9-63719-000	SEAL B, COVER UNDER	1	1	
F-3	28	HZY6-90002-000	BOLT, FLANGE, 10X40	8	8	
F-3	29	HZY9-90102-000	BOLT, HEX., 12X186	2	2	
F-3	30	HZW9-90103-010	BOLT, FLANGE, 6X12	1	1	


4
8
33
31
26
6
44
7
9
43
6
25
10
47
45
24
41
42
42
27
32
11
17
28
40
14
32
17
F-4
1
39
3
36
3
46
16
3
23
2
35
22
5
35
22
3
15
20
18
19
34
37
21
38
29
13
30
FR.


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-3	31	HZY9-90104-000	BOLT-WASHER, 6X95	1	1	
F-3	32	HZY6-90105-000	BOLT-WASHER, 8X30	6	6	
F-3	33	HZY9-90105-000	BOLT-WASHER, 6X27	2	2	
F-3	34	HZV5-90119-000	SCREW, PAN, 6X8	1	1	
F-3	35	HZV5-90119-000	SCREW, PAN, 6X8	2	2	
F-3	36	HZV5-90127-003	SCREW, RIVET, 5X10	1	1	
F-3	37	HZW5-90302-003	NUT, FLANGE, 12MM	2	2	
F-3	38	HZW1-90559-000	WASHER, PLAIN, 12MM	2	2	
F-3	39	H750-90628-000	CLIP(14MM)	1	1	
F-3	40	HZZ3-90651-003	CLIP, 7MM	1	1	
F-3	41	HZY9-90754-000	PIN, 5X44.5	1	1	
F-3	42	HZV5-90756-000	DOWEL PIN, 6X10	2	2	
F-3	43	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	2	2	
F-3	44	HZY9-91553-000	COLLAR, FR. BRACKET	1	1	
F-3	45	HCO-94540-04029	E-RING, 4MM	1	1	
F-3	46	HCO-95005-50950-30	TUBE, 5X950	1	1	(HCO-95005-50001-30M)
F-3	47	HZZ0-40160-M00ZA	BRACKET ASSY., FR. UNDER COVER	1	1	*T107* BAY BLUE


28
25
3
29
29
2
19
27
24
FR.
22
11
5
1
29
7
15
26
8
23
12
30
29
10
11
21
4
18
27
17
9
14
27
24
31
6
13
16
30
20


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-3-10	1	HZW1-19286-B00	PLATE, RUBBER SETTING	1	1	
F-3-10	2	HZY9-40202-H50ZB	SEPARATOR, EXTENSION(XL)	1	1	*T107* BAY BLUE XRTU
F-3-10	3	HZW1-40210-710	BUSH COMP., VERTICAL SHAFT	1	1	XRTU
F-3-10	4	HZY9-41101-H00ZB	CASE, GEAR	1	1	*T107* BAY BLUE
F-3-10	5	HZW1-41102-B00	GROMMET, GEAR CASE	1	1	
F-3-10	6	HZZ0-41102-000	COVER B, GEAR CASE	1	1	
F-3-10	7	HZZ0-41103-000	GROMMET, GEAR CASE	1	1	
F-3-10	8	HZZ0-41104-010	SCREEN, R. WATER	1	1	
F-3-10	9	HZZ0-41105-010	SCREEN, L. WATER	1	1	
F-3-10	10	HZZ0-41107-000ZD	TAB, TRIM	1	1	*T107* BAY BLUE
F-3-10	11	HZW1-41109-B00	METAL COMP., ANODE	2	2	
F-3-10	12	HZW9-90101-003	BOLT, OIL CHECK	1	1	
F-3-10	13	HZZ0-90101-000	SCREW, FLAT, 5X55	1	1	
F-3-10	14	HZW1-90104-900	BOLT, HEX., 10X80	1	1	LRTU
F-3-10	15	HZV5-90115-000	BOLT, HEX., 8X25	1	1	
F-3-10	16	HZY3-90120-000	BOLT, DRAIN PLUG	1	1	
F-3-10	17	HZY6-90123-000	BOLT-WASHER, 10X40	4	4	LRTU
F-3-10	18	HZW1-90124-910	BOLT, STUD(10X202)	1	1	XRTU
F-3-10	19	HZW1-90125-910	BOLT, STUD(10X164)	4	4	XRTU
F-3-10	20	HZY3-90133-000	BOLT, SOCKET, 6X16	1	1	
F-3-10	21	HZY1-90205-000	NUT, SELF-LOCK, 6MM	1	1	
F-3-10	22	HHW1-90225-670	BOLT, FLANGE, 6X35	1	1	
F-3-10	23	HZV4-90302-000	NUT, SELF-LOCK, 5MM	1	1	
F-3-10	24	HZV5-90306-003	NUT, SELF-LOCK, 10MM	5	5	XRTU
F-3-10	25	HZW1-90501-710	WASHER, 26MM	1	1	XRTU
F-3-10	26	HZV4-90507-000	WASHER, PLAIN, 8MM	1	1	
F-3-10	27	HZV5-90563-000	WASHER, PLAIN, 10MM	1	1	LRTU
F-3-10	27	HZV5-90563-000	WASHER, PLAIN, 10MM	5	5	XRTU
F-3-10	28	HZW1-90651-710	CIRCLIP, INTERNAL, 40	1	1	XRTU


28
25
3
29
29
2
19
27
24
FR.
22
11
5
1
29
7
15
26
8
23
12
30
29
10
11
21
4
18
27
17
9
14
27
24
31
6
13
16
30
20


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-3-10	29	HZV5-90756-000	DOWEL PIN, 6X10	2	2	LRTU
F-3-10	29	HZV5-90756-000	DOWEL PIN, 6X10	4	4	XRTU
F-3-10	30	HZW4-91301-003	O-RING, 6.9X1.45	2	2	
F-3-10	31	HZY3-91556-000	COLLAR, DISTANCE, 6.5X9X3	1	1	


1
FR.


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-3-20	1	HZY9-41100-H01ZB	CASE ASSY., GEAR(L)	1	1	*T107* BAY BLUE LRTU
F-3-20	1	HZY9-41100-H51ZB	CASE ASSY., GEAR(XL)	1	1	*T107* BAY BLUE XRTU


19
9
25
36
2
3
34
1
27
28
28
4
5
6
7
35
31
31
E-6
8
15
16
13
20
32
32
24
14
33
11
23
37
12
10
21
30
26
17
29
18
22
FR.


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-4	1	HZY9-19210-H01	IMPELLER, PUMP	1	1	
F-4	2	HZY9-19221-H01	HOUSING, IMPELLER	1	1	
F-4	3	HZY9-19223-H00	LINER, PUMP	1	1	
F-4	4	HZY9-19231-H01	COVER, IMPELLER	1	1	
F-4	5	HZW1-19234-B00	GASKET B, IMPELLER	1	1	
F-4	6	HZZ0-19241-000	HOUSING, WATER PUMP	1	1	
F-4	7	HZW1-19242-B00	GASKET, WATER PUMP	1	1	
F-4	8	HZY9-19251-000	TUBE, WATER(L)	1	1	LRTU
F-4	8	HZY9-19251-610	TUBE, WATER(XL)	1	1	XRTU
F-4	9	HZW1-19253-B01	RING, WATER TUBE SEAL	1	1	
F-4	10	HZZ0-24310-000	ROD COMP., SHIFT(L)	1	1	
F-4	11	HZY3-24318-000	SPRING, SHIFT ROD	1	1	
F-4	12	HZW1-24320-B00	ROD A COMP., SHIFT(L)	1	1	LRTU
F-4	12	HZY9-24320-610	ROD A COMP., SHIFT(XL)	1	1	XRTU
F-4	13	HZW1-24327-000	RING, STOPPER	1	1	
F-4	14	HZY9-24343-H00	HOLDER, SHIFT ROD	1	1	
F-4	15	HZW1-40204-000	GROMMET, EXTENSION CASE	1	1	
F-4	16	HZW1-41112-B03	SHAFT, VERTICAL(L)	1	1	LRTU
F-4	16	HZW1-41112-B33	SHAFT, VERTICAL(UL)	1	1	XRTU
F-4	17	HZW1-41116-B00	SLINGER, OIL	1	1	
F-4	18	HZW1-41131-B01	GEAR, PINION(12T)	1	1	
F-4	19	HZV5-90010-000	BOLT, HEX., 8X55	4	4	
F-4	20	HZW9-90102-000	BOLT, FLANGE, 6X12	1	1	
F-4	21	HZW1-90242-000	NUT, LOCK, 64MM	1	1	
F-4	22	HZW1-90303-B03	NUT, HEX., 16MM	1	1	
F-4	23	H723-90472-000	WASHER, PLAIN, 12MM	1	1	
F-4	24	HZV4-90511-000	WASHER, PLAIN, 6MM	1	1	
F-4	25	H921-90514-000	WASHER, 8MM	4	4	
F-4	26	HZW1-90518-B00	SHIM A, GEAR(0.10)	1	1	


19
9
25
36
2
3
34
1
27
28
28
4
5
6
7
35
31
31
E-6
8
15
16
13
20
32
32
24
14
33
11
23
37
12
10
21
30
26
17
29
18
22
FR.

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-4	26	HZW1-90519-B00	SHIM B, GEAR(0.15)	1	1	
F-4	26	HZW1-90520-B00	SHIM C, GEAR(0.30)	1	1	
F-4	26	HZW1-90521-B00	SHIM D, GEAR(0.50)	1	1	
F-4	27	HZW1-90752-B02	KEY, WOODRUFF	1	1	
F-4	28	HZV5-90756-000	DOWEL PIN, 6X10	2	2	
F-4	29	HZW1-91052-B02	BEARING, NEEDLE	1	1	(1-1/8X1-1/2X1-1/4)
F-4	30	HZW1-91054-B31	BEARING, TAPER ROLLER, 30X62X40	1	1	
F-4	31	HZZ3-91253-003	SEAL, WATER, 23X36X6	2	2	
F-4	32	HZY3-91254-003	SEAL, WATER, 12X21X6	2	2	
F-4	33	HMJ0-91308-003	O-RING	1	1	
F-4	34	HZW1-91356-B00	O-RING, WATER PUMP	1	1	
F-4	35	HMB0-91359-000	O-RING, 58.5X3.5	1	1	
F-4	36	HZY6-91552-000	COLLAR, DISTANCE	4	4	
F-4	37	HC0-94540-10019	E-RING, 10MM	1	1	



10
11
2
27
3
1
28
22
7
6
28
6
5
27
25
4
8
17
20
19
12
24
26
13
FR.
21
18
14
16
9
21
FOP-8
15
23
23

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-5	1	HZZ0-24101-010	SHIFTER, CLUTCH	1	1	
F-5	2	HZW1-24102-B00	PIN, SHIFTER, 8X47	1	1	
F-5	3	HZW1-24103-B00	RING, CROSS PIN	1	1	
F-5	4	HZZ0-24113-000	SLIDER COMP., SHIFT	1	1	
F-5	5	HZZ0-24122-000	SLIDER, SHIFT	1	1	
F-5	6	HZZ0-24123-000	SPRING, SHIFT	2	2	
F-5	7	HZZ0-24124-000	PLATE, SHIFT	1	1	
F-5	8	HZZ0-41140-010	GEAR COMP., FR. BEVEL	1	1	
F-5	9	HZY9-41151-H00	GEAR, RR. BEVEL	1	1	
F-5	10	HZZ0-41160-010	SHAFT ASSY., PROPELLER	1	1	
F-5	11	HZZ0-41161-000	SHAFT, PROPELLER	1	1	
F-5	12	HZW1-41201-B02ZD	HOLDER, PROPELLER SHAFT	1	1	*T107* BAY BLUE
F-5	13	HZY6-90123-000	BOLT-WASHER, 10X40	2	2	
F-5	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	
F-5	15	HZZ0-90506-C00	WASHER, PROPELLER THRUST	1	1	
F-5	16	HZW1-90508-B00	WASHER, PLAIN, 18.5MM	1	1	
F-5	17	HZW1-90528-B00	SHIM A, BEVEL(FR.)(0.10)	1	1	
F-5	17	HZW1-90529-B00	SHIM B, BEVEL(FR.)(0.15)	1	1	
F-5	17	HZW1-90530-B00	SHIM C, BEVEL(FR.)(0.30)	1	1	
F-5	17	HZW1-90531-B00	SHIM D, BEVEL(FR.)(0.50)	1	1	
F-5	18	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	
F-5	19	HMY5-91005-601	BEARING, NEEDLE, 30X37X26	1	1	
F-5	20	HZW1-91051-B02	BEARING, TAPERED ROLLER	1	1	(50X82X21.5)
F-5	21	HZW5-91054-003	BEARING, BALL(28X38X3)	2	2	
F-5	22	HZW1-91101-003	ROLLER, 3X12.8	1	1	
F-5	23	HZZ3-91252-003	SEAL, WATER, 30X45X7	2	2	
F-5	24	HZW1-91351-B02	O-RING, 94X4.1	1	1	
F-5	25	HCO-94510-14000	CIRCLIP, EXTERNAL, 14MM	1	1	
F-5	26	HCO-96100-62080-00	BEARING, RADIAL BALL, 6208	1	1	



10
11
2
27
3
1
28
22
7
6
28
6
5
27
25
4
8
17
20
19
12
24
26
13
FR.
21
18
14
16
9
21
FOP-8
15
23
23

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-5	27	HCO-96211-07000	BALL, STEEL, #7(7/32)	2	2	
F-5	28	HCO-96211-11000	BALL, STEEL, #11(11/32)	2	2	


F-6 FUEL TUBE




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-6	1	3T1-70200-1	PRIMER BULB ASSY	1	1	
F-6	2	3C7-70220-1	*JOINT ASSY(INLET)	1	1	
F-6	3	3C7-70224-1	*JOINT ASSY(OUTLET)	1	1	
F-6	4	3C7-70211-1	*PRIMER BULB	1	1	
F-6	5	3C7-70217-0	*CLANP	2	2	
F-6	6	98AB-70-700	*HOSE	1	1	
F-6	7	98AB-701600	*HOSE	1	1	
F-6	8	332-70201-0	*CLANP	2	2	


F-12
FR.


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-7	1	HZY9-32100-M00	HARNESS ASSY., MAIN WIRE	1		
F-7	1	HZZ0-32100-M00	HARNESS ASSY., MAIN WIRE		1	
F-7	2	HZZ0-32101-M00	BRACKET A, COUPLER	1	1	
F-7	3	HZY9-32103-000	BRACKET C, COUPLER	1	1	
F-7	4	HZY9-32104-H00	BRACKET, COUPLER	1	1	
F-7	5	HZZ3-32127-000	SUSPENSION, COUPLER	1	1	
F-7	6	HZY9-38201-003	FUSE(70A)	2	2	
F-7	7	HZY9-38216-003	COVER ASSY., FUSE(70A)	1	1	
F-7	8	HZY9-38233-000	PACKING, FUSE BOX COVER	1	1	
F-7	9	HZW1-38551-000	GROMMET, RELAY	2	2	
F-7	10	HZZ5-90003-M00	BOLT-WASHER, 6X27(CT200)	2	2	
F-7	11	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	2	2	
F-7	12	HZZ5-90105-M00	BOLT, FLANGE, 6X12	3	3	
F-7	13	HZZ0-90103-M00	BOLT, FLANGE, 6X10	1	1	
F-7	14	HZW5-90105-003	SCREW-WASHER, 3X7	2	2	
F-7	15	HZW5-90106-000	BOLT-WASHER, 5X9	2	2	
F-7	16	HSB2-90153-003	SCREW-WASHER, 5X10	2	2	
F-7	17	HZW1-90203-000	NUT-WASHER, 8MM	1	1	
F-7	18	HZY9-90652-003	BAND, WIRE HARNESS	1	1	
F-7	19	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)	31	31	(145MM)
F-7	20	HSW5-91551-003	CLIP, HARNESS BAND(BROWN)	1	1	(151MM)
F-7	21	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	2	2	
F-7	22	HSJ6-91558-003	STRAP, HARNESS(30)(BLACK)	3	3	(107.5MM)
F-7	23	HCO-98200-41000	FUSE, MINI(10A)	4	4	
F-7	24	HCO-98200-41500	FUSE, MINI(15A)	3	3	
F-7	25	HCO-98200-43000	FUSE, MINI(30A)	2	2	
F-7	26	HZY9-38210-003	BOX ASSY., FUSE(70A)	1	1	


FR.
18
20
25
27
8
12
15
13
16
20
24
17
26
F-7
14
4
11
2
6
10
23
5
1
22
19
21


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-7-10	1	HZV5-17202-310	COLLAR, DISTANCE, 6.5X11X7.5	2	2	
F-7-10	2	HKV6-90651-003	BAND, WIRE, 165MM(BLACK)	1	1	
F-7-10	4	HZY9-32410-000	CABLE ASSY., STARTER	1	1	
F-7-10	5	HZY3-32411-003	COVER, STARTER TERMINAL	1	1	
F-7-10	6	HZY9-32418-000	HOLDER COMP., STARTER CABLE	1	1	
F-7-10	8	HMJ6-32660-710	CLAMPER, CORD	1	1	
F-7-10	10	HZY3-38216-003	CLIP, COUPLER HOLDER(B)	1	1	
F-7-10	11	HZY9-38217-000	BRACKET, FUSE BOX	1	1	
F-7-10	12	HZY9-38550-003	RELAY ASSY., POWER TILT	1	1	
F-7-10	13	HZY9-38552-000	BRACKET, RELAY	1	1	
F-7-10	14	HZY9-38553-003	GROMMET, RELAY BRACKET	4	4	
F-7-10	15	HZY9-38580-023	RELAY ASSY., MAIN	1	1	
F-7-10	16	HZZ5-90003-M00	BOLT-WASHER, 6X27(CT200)	4	4	
F-7-10	17	HZZ5-90011-M00	BOLT, FLANGE, 6X14(CT200)	2	2	
F-7-10	18	HZZ5-90105-M00	BOLT, FLANGE, 6X12	1	1	
F-7-10	19	HZZ5-90018-M00	BOLT, FLANGE, 6X20	2	2	
F-7-10	20	HZZ5-90021-M00	BOLT, FLANGE, 6X14	4	4	
F-7-10	21	HZY3-90107-000	BOLT, FLANGE, 8X18	1	1	
F-7-10	22	HZW1-90203-000	NUT-WASHER, 8MM	1	1	
F-7-10	23	HZY3-90405-000	WASHER, PLAIN, 8MM	1	1	
F-7-10	24	HSA0-90683-003	CLIP, WIRE HARNESS, 25MM	1	1	
F-7-10	25	HSZ5-91531-003	CLIP, TUBE, 3.5	1	1	
F-7-10	26	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	4	4	
F-7-10	27	HZZ0-91555-M00	COLLAR, P.T.T. RELAY	2	2	


13
14
E-6-10
31
41
9
27
30
36
43
4
5
3
2
6
21
27
31
41
17
32
7
18
33
11
20
40
8
24
25
E-18
12
42
8
20
11
40
24
29
35
42
19
27
12
25
44
1
16
15
38
37
10
32
40
39
23
22
28
34
26
21
11
8
20
40
24
FR.


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-8	1	HZY9-18211-000	PORT, IDLE EXHAUST	1	1	
F-8	2	HZY3-19270-000	NUT, WATER MOUTH	1	1	
F-8	3	HZY3-19271-000	JOINT, WATER HOSE	1	1	
F-8	4	HZY3-19272-000	SEAT, WATER MOUTH	1	1	
F-8	5	HZY6-19289-000	CAP, WATER JOINT	1	1	
F-8	6	HZY9-35640-003	SWITCH ASSY., POWER TILT	1	1	
F-8	7	HZY9-35645-000	STAY, POWER TILT SWITCH	1	1	
F-8	8	HZV5-40102-000	GROMMET, UNDER CASE	5	5	
F-8	9	HZY9-40151-000ZD	COVER, SEPARATE FRONT	1	1	*T107* BAY BLUE
F-8	10	HZZ0-40155-M00	BRACKET, UNDER COVER	1	1	
F-8	11	HZZ0-40165-M00	STOPPER ASSY., ENGINE SIDE	3	3	
F-8	12	HMB6-61102-631	RUBBER, FENDER MOUNTING	6	6	
F-8	13	HZZ0-63100-M30ZA	COVER COMP., ENGINE	1	1	*T107* BAY BLUE
F-8	14	HZZ0-63102-M00	SEAL, ENGINE COVER	1	1	
F-8	15	HZY9-63232-010	LEVER, FASTENER	1	1	
F-8	16	HZY9-63237-000	WIRE, FASTENER	1	1	
F-8	17	HZZ0-63347-M00ZA	COVER, PLUG MAINTENANCE	1	1	*T107* BAY BLUE
F-8	18	HZZ0-63711-M00ZA	COVER COMP., R. ENGINE UNDER	1	1	*T107* BAY BLUE
F-8	19	HZZ0-63716-M00ZA	COVER COMP., L. ENGINE UNDER	1	1	*T107* BAY BLUE
F-8	20	H965-77212-000	RUBBER, SEAT SIDE	3	3	
F-8	21	HGJ5-80103-000	GROMMET, ENGINE COVER	3	3	
F-8	22	HZY9-82873-000	GROMMET, WATER CHECK	1	1	
F-8	23	HZY9-82874-000	SEAL, WATER CHECK GROMMET	1	1	
F-8	24	HZZ5-90003-M00	BOLT-WASHER, 6X27(CT200)	3	3	
F-8	25	HZY9-90103-000	BOLT-WASHER, 6X22	6	6	
F-8	26	HZZ0-90106-M00	BOLT, FLANGE, 6X55	2	2	
F-8	27	HZY3-90111-000	BOLT, SPECIAL, 6X17	6	6	
F-8	28	HZY9-90113-003	BOLT, RR. BRACKET	1	1	
F-8	29	HZV5-90127-003	SCREW, RIVET, 5X10	1	1	


13
14
E-6-10
31
41
9
27
30
36
43
4
5
3
2
6
21
27
31
41
17
32
7
18
33
11
20
40
8
24
25
E-18
12
42
8
20
11
40
24
29
35
42
12
25
19
27
44
1
16
15
38
37
10
32
40
39
23
22
28
34
26
21
21
27
8
20
40
24
FR.


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-8	30	HZY3-90132-000	BOLT, SPECIAL, 6X37	1	1	
F-8	31	HZW4-90168-000	BOLT, FLANGE, 6X20	2	2	
F-8	32	HZY6-90301-000	NUT, CLIP	3	3	
F-8	33	H921-90302-000	NUT, HEX., 16MM	1	1	
F-8	34	HZZ5-90508-M00	WASHER, PLAIN, 6MM	2	2	
F-8	35	HSB0-90602-003	CLIP, 10.7MM	1	1	
F-8	36	HZY6-90651-000	CLIP B1, TUBE	1	1	
F-8	37	HZY9-90751-000	PIN, SPRING, 2.0X12	1	1	
F-8	38	HZY9-90755-000	PIN, 5X59	1	1	
F-8	39	HZZ0-91552-M00	COLLAR, DISTANCE(6.5X11X27)	2	2	
F-8	40	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	5	5	
F-8	41	HZY6-91553-000	COLLAR, DISTANCE, 6.5X9X11.5	2	2	
F-8	42	HZY9-91554-000	COLLAR, DISTANCE, 6.2X7.5	6	6	
F-8	43	HCO-95001-80300-40	TUBE, FUEL, 8X300	1	1	(HCO-95001-80001-60M)
F-8	44	HZZ0-40161-M00	BRACKET ASSY., RR. UNDER COVER	1	1	


FR.
24
30
48
36
23
61
35
44
39
10
48
48
11
44
7
9
8
29
6
47
33
4
41
46
59
3
55
18
13
56
56
28
28
14
21
16
22
57
5
31
20
57
32
14
43
46
26
53
42
52
20
22
62
62
1
27
F-11
57
25
51
50
51
40
60
13
19
12
15
2
58
34
17
38
45
54
37
49
43


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-10	1	HZW1-06411-020	METAL KIT, ANODE	1	1	
F-10	2	HZY9-06534-000	PLATE KIT, SPLASH	1	1	
F-10	3	HZV1-24210-010	SPRING COMP., CLICK	1	1	
F-10	4	HZV4-24221-010	SPRING, CLICK ASSIST	1	1	
F-10	5	HZY9-35660-003	SENSOR ASSY., TRIM ANGLE	1	1	
F-10	6	HZY9-50100-020	FRAME COMP., MOUNTING	1	1	
F-10	7	HZZ0-50151-000	MOUNT COMP., UPPER RUBBER	2	2	
F-10	8	HZY9-50153-000	RUBBER, UPPER MOUNT STOPPER	2	2	
F-10	9	HZY9-50158-000	STOPPER, UPPER MOUNT	2	2	
F-10	10	HZY9-50166-010	COVER, UPPER MOUNT	1	1	
F-10	11	HZY9-50168-000	SEAL, UPPER MOUNT COVER	1	1	
F-10	12	HZY9-50201-020ZC	CASE, SWIVEL	1	1	*T107* BAY BLUE
F-10	13	HZZ5-50211-000	LINER, SWIVEL CASE	2	2	
F-10	14	HZW1-50214-000	BUSH, SWIVEL CASE	2	2	
F-10	15	HZY9-50301-020ZC	BRACKET, R. STERN	1	1	*T107* BAY BLUE
F-10	16	HZY9-50311-020ZC	BRACKET, L. STERN	1	1	*T107* BAY BLUE
F-10	17	HZW5-50341-010	ROD, ADJUSTING	1	1	
F-10	18	HZY9-50381-000	SHAFT, TILTING	1	1	
F-10	19	HZY9-50412-000	PLATE COMP., SPLASH	1	1	
F-10	20	HZV5-50522-000	BUSH, TILT ARM	2	2	
F-10	21	HZW1-50527-000	BRACKET, TILTING	1	1	
F-10	22	HZW1-50529-000	STOPPER, TILT	2	2	
F-10	23	HZW1-53234-010	PLATE, STEERING	1	1	
F-10	24	HZW1-53238-010	ROD, STEERING	1	1	
F-10	25	HZW1-56516-000	RECEIVER, THRUST	2	2	
F-10	26	HZZ0-56539-C00	COLLAR, LOWER CYLINDER	1	1	
F-10	27	HZW9-90009-000	BOLT, FLANGE, 6X23	2	2	
F-10	28	HZW1-90102-000	BOLT, 1/4-28UNF	2	2	
F-10	29	HZY9-90102-000	BOLT, HEX., 12X186	2	2	


FR.
24
30
48
36
23
61
35
44
39
10
48
48
11
44
7
9
8
29
6
47
33
4
41
46
59
3
55
18
13
56
56
28
28
14
21
16
22
57
5
31
20
57
32
14
43
46
26
53
62
62
42
52
20
22
1
27
F-11
57
25
51
50
51
40
60
13
19
12
15
2
58
34
17
38
45
37
54
49
43


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-10	30	HZW1-90105-000	BOLT, 3/8-24UNF	1	1	
F-10	31	HZW9-90105-000	BOLT, FLANGE, 6X20	2	2	
F-10	32	HZW1-90108-000	BOLT, HEX., 10X235	1	1	
F-10	33	H881-90110-000	BOLT, HEX., 6X14	1	1	
F-10	34	HZZ3-90129-000	BOLT, HEX., 12X119	4	4	
F-10	35	HZZ0-90151-M00	BOLT, FLANGE, 8X25	8	8	
F-10	36	HZW9-90154-000	BOLT, FLANGE, 10X25	2	2	
F-10	37	HHW1-90214-671	BOLT, FLANGE, 6X25(SUS-D)	2	2	
F-10	38	HHW1-90215-671	BOLT, FLANGE, 6X16	2	2	
F-10	39	HZW5-90302-003	NUT, FLANGE, 12MM	2	2	
F-10	40	HZV5-90304-013	NUT, SELF-LOCK(7/8-14UNF)	1	1	
F-10	41	HZW1-90304-013	NUT, SELF-LOCK(25X2.0)	1	1	
F-10	42	HZW5-90304-000	NUT, ADJUSTER ROD	1	1	
F-10	43	HZW4-90306-003	NUT, FLANGE, 10MM	3	3	
F-10	44	HZV5-90307-003	NUT, SELF-LOCK(3/8-24UNF)	2	2	
F-10	45	HZV5-90501-000	WASHER, WAVE, 40MM	1	1	
F-10	46	HZV5-90502-000	WASHER, WAVE, 26MM	2	2	
F-10	47	HZV5-90504-000	WASHER, THRUST, 34MM	1	1	
F-10	48	HZV4-90514-000	WASHER, 10MM	3	3	
F-10	49	H921-90511-000	WASHER, PLAIN, 10MM	1	1	
F-10	50	HZV5-90552-000	WASHER, PLAIN, 12MM	4	4	
F-10	51	HZV5-90559-000	WASHER, PLAIN, 12MM	8	8	
F-10	52	HZV5-90559-000	WASHER, PLAIN, 12MM	1	1	
F-10	53	HZV5-90563-000	WASHER, PLAIN, 10MM	2	2	
F-10	54	HZW4-90651-000	CIRCLIP, EXTERNAL, 39MM	1	1	
F-10	55	H763-90681-A01	CLIP, WIRE HARNESS	1	1	
F-10	56	HZW6-90752-000	PIN, SPRING, 2.5X20	2	2	
F-10	57	HZV7-90951-010	NIPPLE, GREASE	3	3	
F-10	58	HZV5-91256-003	OIL SEAL, 39.5X52X6(ARAI)	1	1	


FR.
24
30
48
36
23
61
35
44
39
10
48
48
11
44
7
9
8
29
6
47
33
4
41
46
59
3
55
18
13
56
56
28
28
14
21
16
22
57
5
31
20
57
32
14
43
46
26
53
42
52
20
22
62
62
1
27
F-11
57
25
51
50
51
40
60
13
19
12
15
2
58
34
17
38
45
54
37
49
43


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-10	59	HZV5-91352-000	O-RING, 15.54X2.62	1	1	
F-10	60	HZY9-91557-000	COLLAR, SPLASH PLATE	2	2	
F-10	61	HZV5-91560-000	COLLAR, STEERING ROD	1	1	
F-10	62	HCO-94001-12490-0S	NUT, HEX., 12MM	8	8	


FR.
18
3
30
30
30
45
23
7
6
34
23
24
45
4
5
8
2
1
8
33
32
21
14
35
44
37
37
37
22
16
37
37
47
28
29
12
40
36
29
11
20
17
36
10
25
37
26
38
27
9
31
F-10
10
42
43
46
39
42
43
46
39
13
13
41
41


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-11	1	HZX2-30280-003	BREAKER ASSY.	1	1	
F-11	2	HZX2-31106-003	BRUSH ASSY.	1	1	
F-11	3	HZY9-36104-003	TUBE, SPIRAL(12X14.6)	1	1	
F-11	4	HZY9-36120-013	MOTOR ASSY., POWER TILT	1	1	
F-11	5	HZX2-36122-003	BRACKET ASSY.	1	1	
F-11	6	HZW1-36123-013	ARMATURE COMP.	1	1	
F-11	7	HZY9-36129-003	YOKE ASSY.	1	1	
F-11	8	HZV5-36136-821	SPRING, MOTOR	2	2	
F-11	9	HZY3-40219-013	WIRE, LEAD(1.5X116MM)	1	1	
F-11	10	HZV5-50214-003	BUSH, SWIVEL CASE	2	2	
F-11	11	HZY9-56000-033	TRIM-TILT ASSY., POWER	1	1	
F-11	12	HZY9-56100-013	PUMP ASSY.	1	1	
F-11	13	HZW1-56110-701	ROD COMP., PISTON(B)	2	2	
F-11	14	HZW1-56113-701	JOINT, DRIVE	1	1	
F-11	16	HZW1-56116-701	FILTER B	1	1	
F-11	17	HZV5-56117-821	RING, BACK UP	1	1	
F-11	18	HZV5-56118-820	BUSH, MOTOR CODE	1	1	
F-11	20	HZW1-56130-702	PISTON COMP., FREE	1	1	
F-11	21	HZY9-56170-003	VALVE COMP., MANUAL	1	1	
F-11	22	HZW1-56180-701	VALVE COMP., RESERVOIR	1	1	
F-11	23	HZV5-56513-000	BUSH, LOWER CYLINDER	2	2	
F-11	24	HZZ0-56532-C00	PIN, UPPER CYLINDER	1	1	
F-11	25	HZW1-56851-703	TANK, OIL	1	1	
F-11	26	HZW1-56860-701	CAP COMP., OIL TANK	1	1	
F-11	27	HZW1-90113-702	BOLT, RECESSED	3	3	
F-11	28	HZW1-90114-702	BOLT, SOCKET(A)	1	1	
F-11	29	HZW1-90115-702	BOLT, SOCKET(B)	2	2	
F-11	30	HZW1-90116-702	BOLT, HEX.	4	4	
F-11	31	HZV5-90119-000	SCREW, PAN, 6X8	1	1	


FR.
18
3
30
30
30
45
23
7
6
34
23
24
45
4
5
8
2
1
8
33
32
21
14
35
44
37
37
37
22
16
37
37
47
28
29
12
40
36
29
11
20
17
36
10
25
37
26
38
27
9
31
F-10
10
42
43
46
39
42
43
46
39
13
13
41
41

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-11	32	HZW1-90652-702	CIRCLIP, INTERNAL	1	1	
F-11	33	HZV5-91203-821	OIL SEAL	1	1	
F-11	34	HZW1-91207-013	O-RING, 2.0X70.5	1	1	
F-11	35	HZV5-91302-821	O-RING, 1.8X69.6	1	1	
F-11	36	HZV5-91316-821	O-RING, 3.5X38.7	2	2	
F-11	37	HZX2-91352-003	O-RING, 1.67X7.25	6	6	
F-11	38	HZW1-91353-703	O-RING, 1.9X11	1	1	
F-11	39	HZW1-91354-701	O-RING, 3.5X35.7	2	2	
F-11	40	HZW1-91355-701	O-RING, 3.5X41.7	1	1	
F-11	41	HZW1-91357-701	O-RING SET, 3.5X31.7	2	2	
F-11	42	HZX2-91358-003	SEAL, WATER	2	2	
F-11	43	HZW1-91361-701	PACKING	2	2	
F-11	44	HZW1-91557-701	COLLAR, ORIFICE	1	1	
F-11	45	HCO-94540-15029	E-RING, 15MM	2	2	
F-11	46	HZY9-56115-023	GUIDE COMP., ROD	2	2	
F-11	47	HZY9-56120-013	ROD COMP., PISTON	1	1	



2
TOHATSU
80
3
TOHATSU
100
1
4
TOHATSU
8
4
TOHATSU
5
80
6
100
9
7

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-12	1	HZY9-87117-000	LABEL, FUSE	1	1	
F-12	2	HZY9-87121-T80	MARK, RR.(BFT80)	1		～6000004
F-12	2	HZY9-87121-T81	MARK, RR.(BFT80)	1		6000005～
F-12	3	HZZ0-87121-T80	MARK, RR.(BFT100)		1	～6000006
F-12	3	HZZ0-87121-T81	MARK, RR.(BFT100)		1	6000007～
F-12	4	HZX1-87132-R00	MARK, R. SIDE STRIPE	1	1	BFT80AK1:～6000004 BFT100AK1:～6000006
F-12	4	HZX1-87133-R00	MARK, L. SIDE STRIPE	1	1	BFT80AK1:～6000004 BFT100AK1:～6000006
F-12	4	HZY6-87132-R00	MARK, SIDE STRIPE	2	2	BFT80AK1:6000005～ BFT100AK1:6000007～
F-12	5	HZZ3-87301-R00	MARK, FR. EMBLEM(TOHATSU)	1		～6000004
F-12	5	HZY9-87301-T80	MARK, FR.(BFT80)	1		6000005～
F-12	6	HZZ3-87301-R00	MARK, FR. EMBLEM(TOHATSU)		1	～6000006
F-12	6	HZZ0-87301-T80	MARK, FR.(BFT100)		1	6000007～
F-12	7	HZZ0-87531-M90	LABEL, OIL CAUTION	1	1	(ENGLISH/FRENCH)
F-12	8	HZY9-87538-U80	LABEL, WARNING OPERATOR(EU)	1	1	
F-12	9	HZY9-87546-U80	MARK, EMERGENCY START(EU)	1	1	


1
2
START
4
5
6
7
8
9
10


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-13	1	HZH8-28461-013	KNOB, RECOIL STARTER	1	1	
F-13	2	HZW9-28462-003	ROPE, RECOIL STARTER(1300MM)	1	1	
F-13	4	HS04-38235-003	PULLER, MINI FUSE(SUMITOMO)	1	1	
F-13	5	HVF9-89203-003	SPANNER, 8X10	1	1	
F-13	6	HSF4-89216-000	WRENCH, PLUG	1	1	
F-13	7	HCO-99003-10000	DRIVER 1, PLUS SCREW(NO.2)	1	1	
F-13	8	HCO-99003-50000	GRIP, SCREW DRIVER	1	1	
F-13	9	HCO-99004-18190	WRENCH, BOX(P18X19)	1	1	
F-13	10	HCO-99008-02000	BAG, TOOL, 200MM	1	1	

F-15 REMOTE CONTROL
(NHK MEC) (HANDLE CAP = CHROME)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-15	1	HZZ3-24800-P02	BOX ASSY., REMOTE CONTROL	1	1	(NHK MEC)
F-15	2	HZZ5-24810-D01	PLATE ASSY.	1	1	
F-15	3	HZZ5-24811-D01	LEVER, HAND	1	1	
F-15	4	HZZ5-24812-D01	ARM, NEUTRAL LOCK	1	1	
F-15	5	HZZ5-24813-D01	GRIP	1	1	
F-15	6	HZZ5-24814-D01	COVER, LEVER	1	1	
F-15	7	HZZ5-24815-D01	ARM ASSY., BRAKE	1	1	
F-15	8	HZZ5-24816-D01	SPRING(2)	1	1	
F-15	9	HZZ5-24817-D01	CLIP, DETENT	1	1	
F-15	10	HZZ5-24818-D01	SPACER(1)(LOOSE PARTS)	1	1	
F-15	11	HZZ5-24819-D01	BRACKET	1	1	
F-15	12	HZZ5-24821-D01	HOUSING, FR.	1	1	
F-15	13	HZZ5-24822-D01	HOUSING, RR.	1	1	
F-15	14	HZZ5-24823-D01	PANEL, BACK	1	1	
F-15	15	HZZ5-24824-D01	BRACKET, WIRE CLAMP	1	1	
F-15	16	HZZ5-24826-D01	CAP, RUBBER	1	1	
F-15	17	HZZ5-24827-D01	ADJUSTER	1	1	
F-15	18	HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	1	1	
F-15	19	HZZ5-24829-D01	SEAL, RUBBER	1	1	
F-15	20	HZZ5-24831-D01	HOLDER, NEUTRAL LOCK	1	1	
F-15	21	HZZ5-24832-D01	GROMMET, WIRE(14)	1	1	
F-15	22	HZZ5-24833-D01	CAP, TROLLING CONTROL SWITCH BLANK	1	1	
F-15	23	HZZ5-24845-D01	GEAR ASSY., SHIFT	1	1	
F-15	24	HZZ5-24850-D01	GEAR, DRIVE	1	1	
F-15	25	HZZ5-24855-D01	TERMINAL, CABLE (LOOSE PARTS)	2	2	
F-15	26	HZZ5-24875-D01	DRUM ASSY., FREE THROTTLE	1	1	
F-15	27	HZZ5-24876-D01	SPRING(1)	1	1	
F-15	28	HZZ5-24878-D01	LEVER, FREE THROTTLE	1	1	
F-15	29	HZZ5-24883-D01	SPRING, DETENT	5	5	

F-15 REMOTE CONTROL
(NHK MEC) (HANDLE CAP = CHROME)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-15	30	HZZ5-32530-D01	CABLE ASSY., REMOTE CONTROL(B)	1	1	
F-15	31	HZV5-32823-003	PLUG, INNER CONNECTOR	7	7	
F-15	32	HZV5-32824-003	PLUG, OUTER CONNECTOR	1	1	
F-15	33	HZZ3-35100-R11	SWITCH ASSY., COMBINATION	1	1	
F-15	35	HZZ5-35370-D02	SWITCH ASSY., POWER TRIM-TILT	1	1	
F-15	36	HZZ3-35645-A41	PLATE, SWITCH	1	1	
F-15	37	HZZ5-35701-D01	BAND, WIRE	1	1	
F-15	38	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	
F-15	39	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	
F-15	40	HZZ5-37210-D01	LAMP ASSY., INDICATION	1	1	
F-15	41	H341-38403-672	PLATE, WINKER BUZZER	1	1	
F-15	42	HZV5-38410-003	BUZZER COMP., WARNING	1	1	
F-15	43	HZZ5-87701-D00	MARK, FAST IDLE	1	1	
F-15	44	HZZ5-87702-D00	MARK, EMERGENCY STOP	1	1	
F-15	46	HZZ5-87702-D00	MARK, EMERGENCY STOP(LOOSE PARTS)	1	1	
F-15	47	HZZ5-87703-P00	MARK, EMBLEM	1	1	
F-15	48	HZZ5-87704-D01	LABEL, SIGP	1	1	
F-15	49	HZZ5-90101-D01	SCREW, 5X18	7	7	
F-15	50	HZZ5-90102-D01	SCREW, 4X6	2	2	
F-15	51	HZZ5-90103-D01	SCREW, 5X10	1	1	
F-15	52	HZZ5-90104-D01	SCREW, 4X10	2	2	
F-15	53	HZZ5-90106-D01	SCREW, 5X12	2	2	
F-15	54	HZZ5-90107-D01	SCREW, 6X90(LOOSE PARTS)	3	3	
F-15	55	HZZ5-90108-D01	BOLT, 8X50	1	1	
F-15	56	HZZ5-90109-D01	BOLT, 5X25	1	1	
F-15	57	HZZ5-90301-D01	NUT, 6MM(LOOSE PARTS)	3	3	
F-15	58	H921-90302-000	NUT, HEX., 16MM	1	1	
F-15	59	HZZ5-90302-D01	NUT, 5MM	1	1	
F-15	60	HZZ5-90501-D01	BEARING(1)	1	1	

F-15 REMOTE CONTROL
(NHK MEC) (HANDLE CAP = CHROME)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-15	61	HZZ5-90502-D01	WASHER(3)	1	1	
F-15	62	HZZ5-90503-D01	WASHER(4)	2	2	
F-15	63	HZZ5-90504-D01	WASHER(5)	1	1	
F-15	64	HZZ5-90506-D01	WASHER, 8MM	1	1	
F-15	65	HZZ5-90507-D01	WASHER(7)(LOOSE PARTS)	3	3	
F-15	66	HZZ5-90508-D01	WASHER, WAVE	1	1	
F-15	67	HZZ5-90509-D01	SPACER(2)(LOOSE PARTS)	3	3	
F-15	68	HZZ5-90651-D01	E-RING, 6MM(LOOSE PARTS)	2	2	
F-15	69	HZZ5-91151-D01	ROLLER, DRIVE GEAR CAM	1	1	
F-15	70	HZZ5-91152-D01	ROLLER	1	1	
F-15	71	HZZ5-91153-D01	BEARING(2)	1	1	
F-15	72	HZZ5-91154-D01	BEARING(3)	2	2	
F-15	73	HZZ5-91156-D01	ROLLER, FREE THROTTLE	1	1	
F-15	74	HZZ5-91157-D01	CLIP, ROLLER	1	1	
F-15	75	HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	1	1	(LOOSE PARTS)
F-15	76	HZW1-17736-000	TUBE, CORRUGATE(28MM)	1	1	
F-15	77	HMG9-91058-681	BAND, SELF LOCK	2	2	
F-15	78	HZZ5-87701-790	PLATE, REMOTE CONTROL(REVERSE)	1	1	

F-15-1 REMOTE CONTROL
(PANEL MOUNT)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-15-1	1	HZW1-24800-V21	BOX ASSY., REMOTE CONTROL	1	1	(PANEL MOUNT)
F-15-1	2	HZW1-24811-V21	HANDLE, REMOTE CONTROL	1	1	
F-15-1	3	HZW1-24812-V21	LEVER, HANDLE LOCK	1	1	
F-15-1	4	HZW1-24813-V21	GRIP, REMOTE CONTROL HANDLE	1	1	
F-15-1	5	HZW1-24816-V21	SPRING, REMOTE CONTROL HANDLE	1	1	
F-15-1	6	HZW1-24819-V21	COVER, GRIP	1	1	
F-15-1	7	HZW1-24820-V21	HOUSING ASSY., REMOTE CONTROL BOX(A)	1	1	
F-15-1	8	HZW1-24821-003	BUSHING	1	1	
F-15-1	9	HZW1-24822-V21	BUTTON, THROTTLE	1	1	
F-15-1	10	HZW1-24825-V01	FRAME ASSY., REMOTE CONTROL BOX	1	1	
F-15-1	11	HZW1-24829-003	BAND, CABLE(B)	1	1	
F-15-1	12	HZW1-24830-V21	HOUSING, REMOTE CONTROL BOX(B)	1	1	
F-15-1	13	HZW1-24834-003	RETAINER	1	1	
F-15-1	14	HZW1-24836-V21	HOUSING, REMOTE CONTROL BOX(C)	1	1	
F-15-1	15	HZW1-24839-V01	GROMMET	2	2	
F-15-1	16	HZW1-24841-V01	WHEEL, CONTROL	1	1	
F-15-1	17	HZW1-24843-V01	SHAFT, HANDLE	1	1	
F-15-1	18	HZW1-24845-V01	ARM ASSY., SHIFT LINK	1	1	
F-15-1	19	HZW1-24847-V01	SHAFT, GEAR SHIFT	1	1	
F-15-1	20	HZW1-24848-V01	SPRING, GEAR SHIFT	1	1	
F-15-1	21	HZW1-24865-V01	ARM ASSY., THROTTLE LINK	1	1	
F-15-1	22	HZW1-24870-V21	HOUSING ASSY., INNER	1	1	(PANEL MOUNT)
F-15-1	23	HZW1-24873-V01	BUSH	1	1	
F-15-1	24	HZW1-24883-V01	SPRING, SHIFT CLICK	5	5	
F-15-1	27	HZW5-32167-650	HARNESS ASSY., POWER TRIM-TILT	1	1	
F-15-1	28	HZW1-35180-003	SWITCH ASSY., EMERGENCY STOP	1	1	
F-15-1	29	HZW1-35182-003	CORD COMP., EMERGENCY	1	1	
F-15-1	30	HZW1-35370-V01	SWITCH ASSY., POWER TRIM-TILT (A)	1	1	
F-15-1	31	HZW1-87705-003	MARK, REMOTE CONTROL(A)(PANEL)	1	1	

F-15-1 REMOTE CONTROL
(PANEL MOUNT)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
F-15-1	32	HZW1-87706-003	MARK, REMOTE CONTROL(B)	1	1	(FOR STARBOARD)
F-15-1	32	HZW1-87707-003	MARK, REMOTE CONTROL(C)	1	1	(FOR PORT)
F-15-1	33	HZW1-90136-003	SCREW A	1	1	
F-15-1	34	HZW1-90137-003	SCREW B	3	3	
F-15-1	35	HZW1-90138-003	SCREW C	3	3	
F-15-1	36	HZW1-90139-003	SCREW, FRICTION	1	1	
F-15-1	37	HZW1-90140-003	BOLT	1	1	
F-15-1	38	HZW1-90142-003	SCREW(8-32X3/8)	2	2	
F-15-1	39	HZW1-90143-003	SCREW(10-32X3/8)	4	4	
F-15-1	40	HZW1-90145-003	SCREW(10-32X5/8)	3	3	
F-15-1	41	HZW1-90314-003	NUT(1/4X20)	3	3	
F-15-1	42	HZW1-90551-003	WASHER	3	3	
F-15-1	43	HZW1-90552-003	WASHER	1	1	
F-15-1	44	HZW1-90653-003	CIRCLIP, EXTERNAL	1	1	
F-15-1	45	HZW1-90753-003	PIN, GEARSHIFT	1	1	
F-15-1	46	HZW1-90953-003	BALL, STEEL	2	2	
F-15-1	47	HZW1-91553-003	ROLLER, SHIFT CLICK	1	1	


9
8
10
13
3
4
12
1
2
14
11
5
6
7


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-3	1	HZY9-06193-H01	PUMP KIT, IMPELLER	1	1	
FOP-3	2	HZY9-19210-H01	IMPELLER, PUMP	1	1	
FOP-3	3	HZY9-19221-H01	HOUSING, IMPELLER	1	1	
FOP-3	4	HZY9-19223-H00	LINER, PUMP	1	1	
FOP-3	5	HZY9-19231-H01	COVER, IMPELLER	1	1	
FOP-3	6	HZW1-19234-B00	GASKET B, IMPELLER	1	1	
FOP-3	7	HZW1-19242-B00	GASKET, WATER PUMP	1	1	
FOP-3	8	HZW1-19253-B01	RING, WATER TUBE SEAL	1	1	
FOP-3	9	HZV5-90010-000	BOLT, HEX., 8X55	4	4	
FOP-3	10	H921-90514-000	WASHER, 8MM	4	4	
FOP-3	11	HZW1-90752-B02	KEY, WOODRUFF	1	1	
FOP-3	12	HZW1-91356-B00	O-RING, WATER PUMP	1	1	
FOP-3	13	HZY6-91552-000	COLLAR, DISTANCE	4	4	
FOP-3	14	HZY9-06192-H00	PUMP KIT, IMPELLER	1	1	

FOP-4 **REMOTE CONTROL**
(TOP MOUNT SINGLE TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-4	1	HZZ3-06240-R30	BOX KIT, REMOTE CONTROL	1	1	(TOP MOUNT SINGLE)(R.)
FOP-4	2	HZW5-06241-U00	SPACER KIT, REMOTE CONTROL BOX	1	1	(TOP MOUNT SINGLE)
FOP-4	3	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	(TOP MOUNT)
FOP-4	4	HZW5-24811-U01	HANDLE, REMOTE CONTROL	1	1	
FOP-4	5	HZW5-24812-U01	COVER, L. GRIP	1	1	
FOP-4	6	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	1	1	
FOP-4	7	HZW5-24814-U01	CAP, GRIP	1	1	
FOP-4	8	HZW5-24815-U01	CAP, SWITCH	1	1	
FOP-4	9	HZW5-24816-U01	BUTTON, THROTTLE	1	1	
FOP-4	10	HZW5-24817-U01	PLATE, HANDLE	1	1	
FOP-4	11	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	
FOP-4	12	HZW5-24819-U01	BRACKET, REMOTE CONTROL HOUSING	2	2	
FOP-4	13	HZZ3-24820-R11	HOUSING COMP., REMOTE CONTROL BOX	1	1	
FOP-4	14	HZW5-24825-U01	HOUSING, LEAD	1	1	
FOP-4	15	HZW5-24826-U01	PLATE, DWELL	1	1	
FOP-4	16	HZW5-24831-U01	TERMINAL, CABLE	2	2	
FOP-4	17	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	
FOP-4	18	HZW5-24834-U01	PACKING, SINGLE	1	1	
FOP-4	19	HZW7-32530-U00	SUB HARNESS ASSY., POWER TRIM-TILT(A)	1	1	
FOP-4	20	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT (A)	1	1	
FOP-4	21	HZZ3-87703-R81	MARK, REMOTE CONTROL(SINGLE)	1	1	
FOP-4	22	HZW5-90101-U00	SCREW, PAN, 5X16	2	2	
FOP-4	23	HZW5-90102-U00	SCREW, PAN, 5X10	1	1	
FOP-4	24	HZW5-90103-U01	SCREW, PAN, 5X20	2	2	
FOP-4	25	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	
FOP-4	26	HZW5-90105-U01	SCREW, PAN, 4X10	2	2	
FOP-4	27	HZW5-90106-U00	SCREW, PAN, 6X18	2	2	
FOP-4	28	HZW5-90107-U00	SCREW, PAN, 5X40	4	4	
FOP-4	29	HZW5-90301-U00	NUT, HEX., 5MM	4	4	

FOP-4 **REMOTE CONTROL**
(TOP MOUNT SINGLE TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-4	30	HZW5-90501-U00	WASHER, LOCK, 5MM	4	4	
FOP-4	31	HZV4-90502-000	WASHER, PLAIN, 5MM	4	4	
FOP-4	32	HZW5-90502-U00	WASHER, LOCK, 6MM	2	2	
FOP-4	33	HZW5-90503-U00	WASHER, PLAIN, 5MM	4	4	
FOP-4	34	HCO-93500-05065-4J	SCREW, PAN, 5X65	4	4	
FOP-4	35	HCO-94001-05490-0S	NUT, HEX., 5MM	4	4	
FOP-4	36	HCO-94540-06029	E-RING, 6MM	2	2	

FOP-4-2 **REMOTE CONTROL**
(TOP MOUNT DUAL TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-4-2	1	HZZ3-06240-R60	BOX KIT, REMOTE CONTROL	1	1	(TOP MOUNT DUAL)(R.)
FOP-4-2	2	HZW5-06241-U10	SPACER KIT, REMOTE CONTROL BOX	1	1	(TOP MOUNT DUAL)
FOP-4-2	3	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	(TOP MOUNT)
FOP-4-2	4	HZW5-24810-U01	HOUSING ASSY., R. INNER	1	1	(TOP MOUNT)
FOP-4-2	5	HZW5-24811-U01	HANDLE, REMOTE CONTROL	2	2	
FOP-4-2	6	HZW5-24812-U01	COVER, L. GRIP	1	1	
FOP-4-2	7	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	2	2	
FOP-4-2	8	HZW5-24813-U21	COVER, DUAL GRIP	1	1	
FOP-4-2	9	HZW5-24814-U01	CAP, GRIP	2	2	
FOP-4-2	10	HZW5-24816-U01	BUTTON, THROTTLE	2	2	
FOP-4-2	11	HZW5-24817-U01	PLATE, HANDLE	2	2	
FOP-4-2	12	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	
FOP-4-2	13	HZW5-24819-U01	BRACKET, REMOTE CONTROL HOUSING	2	2	
FOP-4-2	14	HZZ3-24820-R21	HOUSING COMP., REMOTE CONTROL BOX(DUAL)	1	1	
FOP-4-2	15	HZW5-24825-U01	HOUSING, LEAD	2	2	
FOP-4-2	16	HZW5-24826-U01	PLATE, DWELL	2	2	
FOP-4-2	17	HZW5-24831-U01	TERMINAL, CABLE	4	4	
FOP-4-2	18	HZW5-24832-U01	SPACER, CABLE CLAMP	2	2	
FOP-4-2	19	HZW5-24834-U21	PACKING, DUAL	1	1	
FOP-4-2	20	HZW7-32530-U00	SUB HARNESS ASSY., POWER TRIM-TILT(A)	1	1	
FOP-4-2	21	HZW7-32530-U10	SUB HARNESS ASSY., POWER TRIM-TILT(B)	1	1	
FOP-4-2	22	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT(A)	1	1	
FOP-4-2	23	HZW5-35370-U12	SWITCH ASSY., POWER TRIM-TILT(B)	1	1	
FOP-4-2	24	HZZ3-87703-R01	MARK, REMOTE CONTROL(DUAL)	1	1	
FOP-4-2	25	HZW5-90101-U00	SCREW, PAN, 5X16	3	3	
FOP-4-2	26	HZW5-90102-U00	SCREW, PAN, 5X10	2	2	
FOP-4-2	27	HZW5-90103-U01	SCREW, PAN, 5X20	4	4	
FOP-4-2	28	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	
FOP-4-2	29	HZW5-90105-U01	SCREW, PAN, 4X10	4	4	

FOP-4-2 **REMOTE CONTROL**
(TOP MOUNT DUAL TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-4-2	30	HZW5-90106-U00	SCREW, PAN, 6X18	4	4	
FOP-4-2	31	HZW5-90107-U00	SCREW, PAN, 5X40	4	4	
FOP-4-2	32	HZW5-90108-U00	SCREW, PAN, 5X55	3	3	
FOP-4-2	33	HZW5-90301-U00	NUT, HEX., 5MM	4	4	
FOP-4-2	34	HZW5-90302-U21	NUT, HEX., 5MM	1	1	
FOP-4-2	35	HZW5-90501-U00	WASHER, LOCK, 5MM	8	8	
FOP-4-2	36	HZV4-90502-000	WASHER, PLAIN, 5MM	4	4	
FOP-4-2	37	HZW5-90502-U00	WASHER, LOCK, 6MM	4	4	
FOP-4-2	38	HZW5-90503-U00	WASHER, PLAIN, 5MM	4	4	
FOP-4-2	39	HCO-93500-05065-4J	SCREW, PAN, 5X65	4	4	
FOP-4-2	40	HCO-94001-05490-0S	NUT, HEX., 5MM	4	4	
FOP-4-2	41	HCO-94540-06029	E-RING, 6MM	4	4	


FOP-4-4 REMOTE CONTROL
(FLUSH MOUNT TYPE) (RIGHT)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-4-4	1	HZZ3-06240-R40	BOX KIT, REMOTE CONTROL	1	1	(FLUSH MOUNT)(R.)
FOP-4-4	2	HZW7-24810-U01	HOUSING ASSY., R. INNER	1	1	(FLUSH MOUNT)
FOP-4-4	3	HZW7-24811-U01	HANDLE, REMOTE CONTROL	1	1	
FOP-4-4	4	HZW7-24812-U01	COVER, GRIP	1	1	
FOP-4-4	5	HZW7-24813-U01	ARM, NEUTRAL LOCK	1	1	
FOP-4-4	6	HZW7-24814-U01	COVER, LOCK ARM	1	1	
FOP-4-4	7	HZW7-24815-U01	SPRING, NEUTRAL LOCK ARM	1	1	
FOP-4-4	8	HZW5-24816-U01	BUTTON, THROTTLE	1	1	
FOP-4-4	9	HZW7-24817-U01	SHAFT, THROTTLE BUTTON	1	1	
FOP-4-4	10	HZW5-24826-U01	PLATE, DWELL	1	1	
FOP-4-4	11	HZZ3-24830-R41	COVER ASSY.	1	1	
FOP-4-4	12	HZW5-24831-U01	TERMINAL, CABLE	2	2	
FOP-4-4	13	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	
FOP-4-4	14	HZW7-24832-U01	HOLDER, NEUTRAL LOCK	1	1	
FOP-4-4	15	HZW7-24833-U01	BASE	1	1	
FOP-4-4	16	HZW7-32530-U20	SUB HARNESS ASSY., POWER TRIM-TILT(C)	1	1	
FOP-4-4	17	HZW7-35370-U02	SWITCH ASSY., POWER TRIM-TILT(C)	1	1	
FOP-4-4	18	HZZ3-87701-R40	MARK, HANDLE FLUSH MOUNT	1	1	
FOP-4-4	19	HZW7-87703-U00	MARK, FLUSH MOUNT	1	1	
FOP-4-4	20	HZW5-90101-U00	SCREW, PAN, 5X16	1	1	
FOP-4-4	21	HZW7-90101-U01	SCREW, TRUSS, 4X12	1	1	
FOP-4-4	22	HZW7-90102-U01	SCREW, PAN, 5X30	4	4	
FOP-4-4	23	HZW7-90103-U01	SCREW, PAN, 6X35	3	3	
FOP-4-4	24	HZW7-90104-U01	SCREW, TAPPING, 6X30	3	3	
FOP-4-4	25	HZW7-90301-U01	NUT, HEX., 6MM	3	3	
FOP-4-4	26	HZW5-90501-U00	WASHER, LOCK, 5MM	4	4	
FOP-4-4	27	HZW7-90502-U00	WASHER, PLAIN, 6MM	3	3	
FOP-4-4	28	HCO-94540-06029	E-RING, 6MM	2	2	


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-6	1	HZZ3-06323-R00	PANEL KIT, SWITCH(B)(4-LED)	1	1	
FOP-6	2	HZZ5-06325-600	CABLE SET, PANEL INDICATOR(20FT)	1	1	
FOP-6	2	HZZ5-06325-700	CABLE SET, PANEL INDICATOR(25FT)	1	1	
FOP-6	2	HZZ5-06325-800	CABLE SET, PANEL INDICATOR(30FT)	1	1	
FOP-6	3	HMT8-18334-770	NUT, FLANGE, 5MM	8	8	
FOP-6	4	HZZ5-32185-600	CORD ASSY., INDICATOR(20FT)	1	1	
FOP-6	4	HZZ5-32185-700	CORD ASSY., INDICATOR(25FT)	1	1	
FOP-6	4	HZZ5-32185-800	CORD ASSY., INDICATOR(30FT)	1	1	
FOP-6	5	HZZ3-32341-R01	PANEL ASSY., SWITCH	1	1	
FOP-6	6	HZZ3-32346-R01	PANEL, CONTROL	1	1	
FOP-6	7	HZZ3-32347-R01	PANEL, CONTROL	1	1	
FOP-6	8	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	
FOP-6	9	HZZ5-32580-D01	CABLE ASSY., SWITCH PANEL(20FT)	1	1	(NHK MEC)
FOP-6	9	HZZ5-32580-D11	CABLE ASSY., SWITCH PANEL(25FT)	1	1	(NHK MEC)
FOP-6	9	HZZ5-32580-D21	CABLE ASSY., SWITCH PANEL(30FT)	1	1	(NHK MEC)
FOP-6	10	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	
FOP-6	11	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	
FOP-6	12	H952-32901-770	TIE, CABLE(NATURAL)(2.4X92)	6	6	
FOP-6	13	HZZ3-35100-R11	SWITCH ASSY., COMBINATION	1	1	
FOP-6	14	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	
FOP-6	15	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	
FOP-6	16	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	
FOP-6	17	HZZ3-37205-R01	PANEL ASSY., INDICATOR(4-LED)	1	1	
FOP-6	18	HZZ5-37210-762	LAMP ASSY., INDICATION(4-LED)	1	1	
FOP-6	19	H341-38403-672	PLATE, WINKER BUZZER	1	1	
FOP-6	20	HZV5-38410-003	BUZZER COMP., WARNING	1	1	
FOP-6	21	HZZ5-38414-003	BRACKET, BUZZER	1	1	
FOP-6	22	HZW5-90109-000	SCREW, PAN, 5X40	8	8	
FOP-6	23	H921-90302-000	NUT, HEX., 16MM	1	1	


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-6	24	HSC2-90649-003	BAND, WIRE HARNESS(NATURAL)	1	1	(150MM)
FOP-6	25	HCO-94103-05400	WASHER, PLAIN, 5MM	8	8	
FOP-6	26	HCO-94111-05400	WASHER, SPRING, 5MM	8	8	


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-6-1	1	HZZ3-06323-R10	PANEL KIT, SWITCH(4-LED)	1	1	
FOP-6-1	2	HMT8-18334-770	NUT, FLANGE, 5MM	4	4	
FOP-6-1	3	HZZ3-32346-R11	PANEL, CONTROL	1	1	
FOP-6-1	4	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	
FOP-6-1	5	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	
FOP-6-1	6	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	
FOP-6-1	7	HZZ3-35100-R11	SWITCH ASSY., COMBINATION	1	1	
FOP-6-1	8	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	
FOP-6-1	9	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	
FOP-6-1	10	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	
FOP-6-1	11	HZZ5-37210-712	LAMP ASSY., INDICATION(4-LED)	1	1	
FOP-6-1	12	H341-38403-672	PLATE, WINKER BUZZER	1	1	
FOP-6-1	13	HZV5-38410-003	BUZZER COMP., WARNING	1	1	
FOP-6-1	14	HZZ5-38414-003	BRACKET, BUZZER	1	1	
FOP-6-1	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	
FOP-6-1	16	H921-90302-000	NUT, HEX., 16MM	1	1	
FOP-6-1	17	HSC2-90649-003	BAND, WIRE HARNESS(NATURAL)	1	1	(150MM)
FOP-6-1	18	HCO-94103-05400	WASHER, PLAIN, 5MM	4	4	
FOP-6-1	19	HCO-94111-05400	WASHER, SPRING, 5MM	4	4	


7
6
4
8
2
13
11
9
12
15
3
14
17
16
10
18
19
5
1


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-6-2	1	HZY6-06323-R80	PANEL KIT, SWITCH(SINGLE)	1	1	
FOP-6-2	2	HZY6-32340-R81	PANEL ASSY, CONTROL(SINGLE)	1	1	
FOP-6-2	3	HZY6-32346-R81	PANEL, CONTROL(SINGLE)	1	1	
FOP-6-2	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	1	1	
FOP-6-2	5	HZY6-32606-000	DUMMY, WATER PROOF(GREEN)	1	1	
FOP-6-2	6	HZV5-32823-003	PLUG, INNER CONNECTOR	9	9	
FOP-6-2	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	7	7	
FOP-6-2	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	1	1	
FOP-6-2	9	HZY6-36180-003	SWITCH ASSY., EMERGENCY STOP (SINGLE)	1	1	
FOP-6-2	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	
FOP-6-2	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	
FOP-6-2	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	1	1	
FOP-6-2	13	HZY9-38410-A01	BUZZER COMP., WARNING	1	1	
FOP-6-2	14	HZY6-38414-003	BRACKET	1	1	
FOP-6-2	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	
FOP-6-2	16	HZZ5-90301-M00	NUT, FLANGE, 5MM	4	4	
FOP-6-2	17	HZY6-90302-003	NUT	1	1	
FOP-6-2	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	4	4	
FOP-6-2	19	HZZ5-90502-M00	WASHER, SPRING, 5MM	4	4	



7
6
4
8
2
9
13
11
17
3
12
15
16
14
10
18
5
19
1


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-6-3	1	HZY6-06323-R90	PANEL KIT, SWITCH(TWIN)	1	1	
FOP-6-3	2	HZY6-32340-R91	PANEL ASSY., CONTROL(TWIN)	1	1	
FOP-6-3	3	HZY6-32346-R91	PANEL, CONTROL(TWIN)	1	1	
FOP-6-3	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	2	2	
FOP-6-3	5	HZY6-32606-000	DUMMY, WATER PROOF(GREEN)	2	2	
FOP-6-3	6	HZV5-32823-003	PLUG, INNER CONNECTOR	18	18	
FOP-6-3	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	14	14	
FOP-6-3	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	2	2	
FOP-6-3	9	HZY6-36180-712	SWITCH ASSY., EMERGENCY STOP (TWIN)	1	1	
FOP-6-3	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	
FOP-6-3	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	
FOP-6-3	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	2	2	
FOP-6-3	13	HZY9-38410-A01	BUZZER COMP., WARNING	2	2	
FOP-6-3	14	HZY6-38414-003	BRACKET	2	2	
FOP-6-3	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	
FOP-6-3	16	HZZ5-90301-M00	NUT, FLANGE, 5MM	4	4	
FOP-6-3	17	HZY6-90302-003	NUT	1	1	
FOP-6-3	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	4	4	
FOP-6-3	19	HZZ5-90502-M00	WASHER, SPRING, 5MM	4	4	


7
6
4
2
8
9
13
11
3
12
17
15
16
14
10
18
5
19
1


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-6-4	1	HZY6-06323-R30	PANEL KIT, SWITCH(TRIPLE)	1	1	
FOP-6-4	2	HZY6-32340-R31	PANEL ASSY., CONTROL(TRIPLE)	1	1	
FOP-6-4	3	HZY6-32346-R31	PANEL, CONTROL(TRIPLE)	1	1	
FOP-6-4	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	3	3	
FOP-6-4	5	HZY6-32606-000	DUMMY, WATER PROOF(GREEN)	3	3	
FOP-6-4	6	HZV5-32823-003	PLUG, INNER CONNECTOR	27	27	
FOP-6-4	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	21	21	
FOP-6-4	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	3	3	
FOP-6-4	9	HZY6-36180-612	SWITCH ASSY., EMERGENCY STOP(TRIPLE)	1	1	
FOP-6-4	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	
FOP-6-4	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	
FOP-6-4	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	3	3	
FOP-6-4	13	HZY9-38410-A01	BUZZER COMP., WARNING	3	3	
FOP-6-4	14	HZY6-38414-003	BRACKET	3	3	
FOP-6-4	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	
FOP-6-4	16	HZZ5-90301-M00	NUT, FLANGE, 5MM	4	4	
FOP-6-4	17	HZY6-90302-003	NUT	1	1	
FOP-6-4	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	4	4	
FOP-6-4	19	HZZ5-90502-M00	WASHER, SPRING, 5MM	4	4	


1
TOHATSU



2
TOHATSU
RPM
X1000


3


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-7	1	3PU-72571-0	TRIM METER ASSY	1	1	White
FOP-7	1	3PV-72571-0	TRIM METER ASSY	1	1	Black
FOP-7	2	3PU-72637-0	TACHOMETER HOUR METER	1	1	White
FOP-7	2	3PV-72637-0	TACHOMETER HOUR METER	1	1	Black
FOP-7	3	3PU-72537-0	METER LEAD WIRE	1	1	


1


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-8	1	HZW1-58130-V03	PROPELLER COMP., THREE BLADES	1	1	(13X19)(SUS)
FOP-8	1	HZW1-58130-V13	PROPELLER COMP., THREE BLADES	1	1	(13X21)(SUS)
FOP-8	1	HZW1-58130-W03ZA	PROPELLER COMP., THREE BLADES	1	1	(14X11)(AL) *NH283* STIN GRAY
FOP-8	1	HZW1-58130-W13ZA	PROPELLER COMP., THREE BLADES	1	1	(13-3/4X13)(AL) *NH283* STIN GRAY
FOP-8	1	HZW1-58130-W24ZA	PROPELLER COMP., THREE BLADES	1	1	(13-1/2X15)(AL) *NH283* STIN GRAY
FOP-8	1	HZW1-58130-W33ZA	PROPELLER COMP., THREE BLADES	1	1	(13-1/4X17)(AL) *NH* STIN GRAY
FOP-8	1	HZW1-58130-W43ZB	PROPELLER COMP., THREE BLADES	1	1	(13X21)(AL) *NH283* STIN GEAY
FOP-8	1	HZW1-58130-W64ZA	PROPELLER COMP., THREE BLADES	1	1	(13X19)(AL) *NH283* STIN GRAY
FOP-8	1	HZW1-58130-W93	PROPELLER COMP., THREE BLADES	1	1	(13-1/4X17)(SUS)
FOP-8	1	HZW7-58130-U02	PROPELLER COMP., THREE BLADES	1	1	(13-1/4X15)(SUS/HAC)
FOP-8	1	HZW7-58130-U12	PROPELLER COMP., THREE BLADES	1	1	(13-1/4X17)(SUS/HAC)
FOP-8	1	HZW7-58130-U22	PROPELLER COMP., THREE BLADES	1	1	(13-1/4X19)(SUS/HAC)
FOP-8	1	HZW7-58130-U32	PROPELLER COMP., THREE BLADES	1	1	(13-1/4X21)(SUS/HAC)
FOP-8	1	HZY9-58130-H01ZA	PROPELLER COMP., THREE BLADES	1	1	(13-1/2X14) *NH283* STIN GRAY
FOP-8	1	HZZ0-58130-D81ZB	PROPELLER COMP., THREE BLADES	1	1	(13-1/5X19) *NH283* STIN GRAY
FOP-8	1	HZZ0-58130-D91ZB	PROPELLER COMP., THREE BLADES	1	1	(13-1/5X21) *NH283* STIN GRAY


2
3
4
1


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-9	1	HZW5-06900-U00	BOLT KIT, SIDE REMOTE CONTROL	1	1	
FOP-9	2	HZW5-90021-U00	BOLT, SPECIAL, 6X220	3	3	
FOP-9	3	HZW5-90511-U00	COLLAR, DISTANCE(A)	3	3	
FOP-9	4	HZW5-90512-U00	COLLAR, DISTANCE(B)	3	3	


1
10
62
16
12
12
83
54
2
70
53
66
81
5
27
74
23
75
72
56
21
22
93
80
73
9
57
75
74
91
55
31
94
86
95
6
7
39
40
24
41
88
68
38
35
89
43
79
90
85
68
44
87
45
84
69
78
4
60
28
42
58
18
16
19
85
78
42
82
33
13
61
14
30
71
47
32
34
59
13
15
15
3
46
11
68
77
65
37
11
51
20
36
64
52
50
8
49
76
92
11
29
48
63
17
68
67
25
26


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-10	1	HZZ0-06533-R50ZA	HANDLE KIT, STEERING	1	1	*T107* BAY BLUE
FOP-10	2	HZY9-17910-701	CABLE COMP., THROTTLE	1	1	
FOP-10	3	HZW9-17917-000	PIVOT, THROTTLE CABLE	1	1	
FOP-10	4	HZW4-17931-H02	ARM, THROTTLE	1	1	
FOP-10	5	HZY9-24590-701	CABLE COMP., SHIFT	1	1	
FOP-10	6	HZW4-24614-H03	LEVER, SHIFT	1	1	
FOP-10	7	HZW4-24615-H03	FRAME ASSY., SHIFT	1	1	
FOP-10	8	HZW4-32533-H01	TUBE(38.1X40)	1	1	
FOP-10	9	HZY9-32534-A01	TUBE	1	1	
FOP-10	10	HZY9-32538-A01	CABLE ASSY., LONG HANDLE(A)	1	1	
FOP-10	11	HZW4-32543-H01	BAND(CONVEX CV-150)	3	3	
FOP-10	12	HZW4-32544-H01	BAND(CONVEX CV-200)	2	2	
FOP-10	13	HZW4-32547-H01	BAND(CONVEX)	2	2	
FOP-10	14	HZW4-32548-H01	COVER, WIRE	1	1	
FOP-10	15	HZW4-32549-H01	SCREW	2	2	
FOP-10	16	HZV5-32823-003	PLUG, INNER CONNECTOR	13	13	
FOP-10	17	HZZ3-35100-R01	SWITCH ASSY., COMBINATION	1	1	
FOP-10	18	HZW4-35640-H11	SWITCH ASSY., POWER TILT	1	1	
FOP-10	19	HZW4-35643-H02	GROMMET	1	1	
FOP-10	20	HZW4-35645-H02	HOLDER, SWITCH	1	1	
FOP-10	21	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	
FOP-10	22	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	
FOP-10	23	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	
FOP-10	24	HZY9-37210-A02	LAMP ASSY., INDICATOR	1	1	
FOP-10	25	HZY9-38400-A00	BUZZER ASSY., WARNING	1	1	
FOP-10	26	HZY9-38402-A00	SUSPENSION, WARNING BUZZER	1	1	
FOP-10	27	HZY9-40105-A00	GROMMET, STEERING HANDLE CABLE	1	1	
FOP-10	28	HZY9-53101-A02ZD	HOUSING	1	1	*T107* BAY BLUE
FOP-10	29	HZY9-53102-A02	COVER, STEERING HANDLE UNDER	1	1	


1
10
62
16
12
12
83
54
2
70
53
81
66
5
27
74
23
75
72
56
21
22
93
80
73
9
57
75
74
91
55
31
94
86
95
6
7
41
39
40
24
88
68
89
38
35
90
85
68
44
87
45
84
43
79
69
78
4
60
28
42
58
18
16
19
85
78
42
82
33
13
61
14
30
71
47
32
34
59
13
15
15
3
46
11
68
77
65
37
11
51
20
36
64
52
50
49
76
92
68
11
8
29
48
63
17
68
67
26
25

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-10	30	HZW9-53103-000	PIN, THROTTLE CABLE	1	1	
FOP-10	31	HZV3-53104-000	BOLT, FRICTION	1	1	
FOP-10	32	HZW4-53104-H02	BRACKET, CABLE	1	1	
FOP-10	33	HZY9-53105-A01	PLATE ASSY., LOCK	1	1	
FOP-10	34	HZW4-53106-H01	STOPPER	1	1	
FOP-10	35	HZW4-53107-H02	PLATE, GUIDE	1	1	
FOP-10	36	HZY9-53108-A00	GROMMET	1	1	
FOP-10	37	HZW4-53109-H02	CAP	1	1	
FOP-10	38	HZW4-53112-H02	GUIDE, SPRING	1	1	
FOP-10	39	HZW4-53113-H01	ACTUATOR	1	1	
FOP-10	40	HZW4-53114-H01	SPRING, COIL	1	1	
FOP-10	41	HZW4-53116-H01	ROLLER	1	1	
FOP-10	42	HZW4-53116-H11	BUSH, STEERING HANDLE	2	2	
FOP-10	43	HZW4-53117-H01	SCREW(M5X14)	4	4	
FOP-10	44	HZW4-53118-H03	GEAR, SHIFT	1	1	
FOP-10	45	HZW4-53119-H02	PLATE, BALL GUIDE	1	1	
FOP-10	46	HZW4-53121-H02	BRACKET	1	1	
FOP-10	47	HZW4-53122-H01	ROD, GROMMET	1	1	
FOP-10	48	HZW4-53123-H01	CLAMP, BRACKET	1	1	
FOP-10	49	HZW9-53130-000	GRIP ASSY., THROTTLE FRICTION	1	1	
FOP-10	50	HZW9-53133-000	PAD, THROTTLE FRICTION	1	1	
FOP-10	51	HZW4-53141-H00	PIPE, GRIP	1	1	
FOP-10	52	HZW9-53165-000	RUBBER, GRIP	1	1	
FOP-10	53	HZY9-53232-A00	BLOCK, HEIGHT ADJUSTER	1	1	
FOP-10	54	HZY9-53233-A00ZD	BRACKET B, STEERING	1	1	*T107* BAY BLUE
FOP-10	55	HZW1-53236-700	BLOCK, STEERING FRICTION	1	1	
FOP-10	56	HZW1-53238-700	ROD, STEERING FRICTION	1	1	
FOP-10	57	HZW1-53239-701	SHAFT, STEERING FRICTION	1	1	
FOP-10	58	HZW6-87124-U80	MARK, EMERGENCY SWITCH INDICATION(EU)	1	1	



1
10
62
16
12
12
83
54
2
70
53
81
66
5
27
74
23
75
72
56
21
22
93
80
73
9
57
75
74
91
55
31
94
86
95
6
7
41
39
40
24
88
68
89
38
35
90
85
68
44
87
45
84
43
79
69
78
4
60
28
42
58
18
16
19
85
78
42
82
33
13
61
14
30
71
47
32
34
59
13
15
15
3
46
11
68
77
65
37
11
51
20
36
64
52
50
49
76
92
68
11
8
29
48
63
17
68
67
26
25

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-10	59	HZZ0-87125-R00	MARK, START	1	1	
FOP-10	60	HZW9-87511-620	MARK, CHANGE	1	1	
FOP-10	61	HZW9-87532-620	MARK, THROTTLE(ENGLISH/FRENCH)	1	1	
FOP-10	62	HZW4-90101-H00	BOLT, HEX., 12X80	1	1	
FOP-10	63	HZW4-90102-H01	BOLT(M5X8)	1	1	
FOP-10	64	HZW9-90102-000	BOLT, FLANGE, 6X12	1	1	
FOP-10	65	HZW4-90103-H02	BOLT(M8X50)	1	1	
FOP-10	66	HZY3-90103-000	BOLT, HEX., 10X32	2	2	
FOP-10	67	HZW4-90104-H01	BOLT(M5X12)	6	6	
FOP-10	68	HZW4-90105-H02	BOLT(M6X12)	5	5	
FOP-10	69	HZW4-90106-H01	BOLT(M5X12)	3	3	
FOP-10	70	HHW1-90118-671	BOLT, FLANGE, 8X28	1	1	
FOP-10	71	HZW4-90301-H01	NUT, HEX., 5MM	1	1	
FOP-10	72	H921-90302-000	NUT, HEX., 16MM	1	1	
FOP-10	73	HZW4-90303-H00	NUT, HEX., 12MM	1	1	
FOP-10	74	HZV4-90305-000	NUT, SELF-LOCK, 8MM	2	2	
FOP-10	75	HZW1-90401-000	WASHER, PLAIN, 8MM	2	2	
FOP-10	76	HZW4-90501-H01	WASHER, 5MM	1	1	
FOP-10	77	HZW4-90502-H02	WASHER, 8MM	1	1	
FOP-10	78	HZW4-90503-H01	WASHER, 10MM	2	2	
FOP-10	79	HZW4-90504-H01	WASHER, 5MM	3	3	
FOP-10	80	HZV1-90506-000	WASHER, WAVE, 14MM	1	1	
FOP-10	81	HZV4-90514-000	WASHER, 10MM	2	2	
FOP-10	82	HZV5-90552-000	WASHER, PLAIN, 12MM	1	1	
FOP-10	83	HZV5-90559-000	WASHER, PLAIN, 12MM	1	1	
FOP-10	84	HZW4-90651-H01	E-RING	1	1	
FOP-10	85	HZW4-90652-H01	E-RING	2	2	
FOP-10	86	HZV1-90759-000	PIN, SPLIT, 2.0	1	1	
FOP-10	87	HZY9-90951-A01	BALL, STEEL	1	1	


1
10
62
16
12
12
83
54
2
70
53
81
66
5
27
74
23
75
72
56
21
22
93
80
73
9
57
75
74
91
55
31
94
86
95
6
7
39
40
24
41
88
68
38
35
89
90
85
68
87
84
43
79
42
58
44
45
78
69
60
28
18
16
4
85
19
78
42
82
33
13
61
30
14
71
47
32
34
59
13
15
15
3
46
11
68
77
65
37
11
51
20
36
64
52
50
8
49
76
92
11
29
48
63
17
68
67
26
25


Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-10	88	HZW4-91051-H02	BEARING	1	1	
FOP-10	89	HZW4-91052-H01	BEARING	1	1	
FOP-10	90	HHP5-91304-601	O-RING, 20.6X1.9	1	1	
FOP-10	91	HZV5-91352-000	O-RING, 15.54X2.62	1	1	
FOP-10	92	HZY9-91451-A00	TUBE, CORD, 40MM	1	1	
FOP-10	93	HZW4-91552-H00	COLLAR, DISTANCE, 12.2X23X16	1	1	
FOP-10	94	HCO-94002-06490-0S	NUT, HEX., 6MM	1	1	
FOP-10	95	HCO-94002-12490-0S	NUT, HEX., 12MM	1	1	

FOP-10-1 STEERING HANDLE KIT (MULTI-FUNCTION) (2)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-10-1	1	HZZ0-06533-T80ZA	HANDLE KIT, STEERING(EF)	1	1	*T107* BAY BLUE
FOP-10-1	2	HZY9-17910-H01	CABLE, THROTTLE	1	1	
FOP-10-1	3	HZZ3-17931-A41	ARM ASSY., THROTTLE	1	1	
FOP-10-1	4	HZY9-24590-H01	CABLE, SHIFT	1	1	
FOP-10-1	5	HZZ3-24614-A41	LEVER, SHIFT	1	1	
FOP-10-1	6	HZZ3-24615-A41	FRAME ASSY., SHIFT	1	1	
FOP-10-1	7	HZY9-32538-H01	CABLE ASSY., LONG HANDLE(A)	1	1	
FOP-10-1	8	HZW4-32543-H01	BAND(CONVEX CV-150)	1	1	
FOP-10-1	9	HZZ3-35100-R01	SWITCH ASSY., COMBINATION	1	1	
FOP-10-1	10	HZZ3-35180-A42	SWITCH ASSY., EMERGENCY STOP	1	1	
FOP-10-1	11	HZZ3-35340-A42	SWITCH ASSY., TROLLING CONTROL	1	1	
FOP-10-1	12	HZZ3-35640-A41	SWITCH ASSY., POWER TILT	1	1	
FOP-10-1	13	HZZ3-35645-A41	PLATE, SWITCH	2	2	
FOP-10-1	14	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	
FOP-10-1	15	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	
FOP-10-1	16	HZY9-37210-A02	LAMP ASSY., INDICATOR	1	1	
FOP-10-1	17	HZY9-38400-A00	BUZZER ASSY., WARNING	1	1	
FOP-10-1	18	HZY9-38402-A00	SUSPENSION, WARNING BUZZER	1	1	
FOP-10-1	19	HZY9-40105-H00	GROMMET, STEERING HANDLE CABLE	1	1	
FOP-10-1	20	HZZ3-53101-A41ZD	HOUSING	1	1	*T107* BAY BLUE
FOP-10-1	21	HZZ3-53102-A41	COVER, UNDER	1	1	
FOP-10-1	22	HZZ3-53103-A41	CLAMP, SHIFT CABLE	1	1	
FOP-10-1	23	HZV3-53104-000	BOLT, FRICTION	1	1	
FOP-10-1	24	HZZ3-53104-A41	CLAMP, THROTTLE CABLE	1	1	
FOP-10-1	25	HZZ3-53105-A41	PLATE, LOCK	1	1	
FOP-10-1	26	HZZ3-53106-A41	STOPPER, SHIFT	1	1	
FOP-10-1	27	HZZ3-53108-A41	GROMMET	1	1	
FOP-10-1	28	HZZ3-53109-A41	SPACER	4	4	
FOP-10-1	29	HZZ3-53110-A41	SHAFT ASSY., THROTTLE	1	1	

FOP-10-1 STEERING HANDLE KIT (MULTI-FUNCTION) (2)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-10-1	30	HZZ3-53111-A41	FRAME, THROTTLE	1	1	
FOP-10-1	31	HZZ3-53112-A41	GUIDE, SPRING	1	1	
FOP-10-1	32	HZW4-53113-H01	ACTUATOR	1	1	
FOP-10-1	33	HZZ3-53113-A41	CAP	1	1	
FOP-10-1	34	HZZ3-53114-A41	SPRING	1	1	
FOP-10-1	35	HZW4-53115-H02	GROMMET, POWER TILT SWITCH	1	1	
FOP-10-1	36	HZZ3-53115-A41	GROMMET, POWER TILT SWITCH	1	1	
FOP-10-1	37	HZW4-53116-H01	ROLLER	1	1	
FOP-10-1	38	HZW4-53116-H11	BUSH, STEERING HANDLE	2	2	
FOP-10-1	39	HZZ3-53117-A41	PIN, SLIDE	1	1	
FOP-10-1	40	HZZ3-53118-A41	GEAR, SHIFT	1	1	
FOP-10-1	41	HZZ3-53119-A41	PLATE, BALL GUIDE	1	1	
FOP-10-1	42	HZZ3-53120-A41	GUIDE, THROTTLE HARNESS	1	1	
FOP-10-1	43	HZZ3-53121-A41	FRAME ASSY., THROTTLE SUB	1	1	
FOP-10-1	44	HZZ3-53122-A41	ROLLER, PLATE	2	2	
FOP-10-1	45	HZZ3-53123-A41	ROLLER, CAM	1	1	
FOP-10-1	46	HZZ3-53124-A41	STAY	1	1	
FOP-10-1	47	HZZ3-53125-A41	PLATE, SHIFT CLAMP	2	2	
FOP-10-1	48	HZZ3-53126-A41	GROMMET, SIDE	1	1	
FOP-10-1	49	HZZ3-53127-A41	GUIDE, HARNESS	1	1	
FOP-10-1	50	HZZ3-53128-A41	BOX ASSY., POWER TILT SWITCH-1	1	1	
FOP-10-1	51	HZZ3-53129-A41	BOX ASSY., POWER TILT SWITCH-2	1	1	
FOP-10-1	52	HZW9-53130-000	GRIP ASSY., THROTTLE FRICTION	1	1	
FOP-10-1	53	HZZ3-53130-A41	BUSH, THROTTLE SHAFT	1	1	
FOP-10-1	54	HZZ3-53131-A41	HOLDER, SWITCH	1	1	
FOP-10-1	55	HZZ3-53132-A41	PLATE, HARNESS	1	1	
FOP-10-1	56	HZW9-53133-000	PAD, THROTTLE FRICTION	1	1	
FOP-10-1	57	HZZ3-53141-A41	PIPE, THROTTLE GRIP	1	1	
FOP-10-1	58	HZZ3-53142-A41	CAP, GRIP	1	1	

FOP-10-1 STEERING HANDLE KIT (MULTI-FUNCTION) (2)





Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-10-1	59	HZZ3-53165-000	RUBBER, GRIP	1	1	
FOP-10-1	60	HZY9-53232-A00	BLOCK, HEIGHT ADJUSTER	1	1	
FOP-10-1	61	HZY9-53233-A00ZD	BRACKET B, STEERING	1	1	*T107* BAY BLUE
FOP-10-1	62	HZW1-53236-700	BLOCK, STEERING FRICTION	1	1	
FOP-10-1	63	HZW1-53238-700	ROD, STEERING FRICTION	1	1	
FOP-10-1	64	HZW1-53239-701	SHAFT, STEERING FRICTION	1	1	
FOP-10-1	65	HZW6-87124-U80	MARK, EMERGENCY SWITCH INDICATION(EU)	1	1	
FOP-10-1	66	HZZ3-87125-R00	MARK, STARTER(ENGLISH)	1	1	
FOP-10-1	67	HZW9-87511-620	MARK, CHANGE	1	1	
FOP-10-1	68	HZW4-90101-H00	BOLT, HEX., 12X80	1	1	
FOP-10-1	69	HZY3-90103-000	BOLT, HEX., 10X32	2	2	
FOP-10-1	70	HZZ3-90103-A41	BOLT, SOCKET, 8X70	1	1	
FOP-10-1	71	HZW4-90104-H01	BOLT(M5X12)	8	8	
FOP-10-1	72	HZZ3-90111-A41	SCREW, FLAT, 5X14	7	7	
FOP-10-1	73	HZZ3-90112-A41	BOLT, 5X12	11	11	
FOP-10-1	74	HZZ3-90113-A41	BOLT, 5X20	2	2	
FOP-10-1	75	HZZ3-90114-A41	BOLT, 6X15	7	7	
FOP-10-1	76	HHW1-90118-671	BOLT, FLANGE, 8X28	1	1	
FOP-10-1	77	H921-90302-000	NUT, HEX., 16MM	1	1	
FOP-10-1	78	HZW4-90303-H00	NUT, HEX., 12MM	1	1	
FOP-10-1	79	HZV4-90305-000	NUT, SELF-LOCK, 8MM	2	2	
FOP-10-1	80	HZZ3-90305-A41	NUT, NYLON, 5MM	1	1	
FOP-10-1	81	HZW1-90401-000	WASHER, PLAIN, 8MM	2	2	
FOP-10-1	82	HZZ3-90501-A41	WASHER	2	2	
FOP-10-1	83	HZW4-90502-H02	WASHER, 8MM	2	2	
FOP-10-1	84	HZZ3-90502-A41	WASHER	3	3	
FOP-10-1	85	HZZ3-90503-A41	WASHER, PLATE	1	1	
FOP-10-1	86	HZW4-90504-H01	WASHER, 5MM	1	1	
FOP-10-1	87	HZV1-90506-000	WASHER, WAVE, 14MM	1	1	

FOP-10-1 STEERING HANDLE KIT (MULTI-FUNCTION) (2)




Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-10-1	88	HZV4-90514-000	WASHER, 10MM	2	2	
FOP-10-1	89	HZV5-90552-000	WASHER, PLAIN, 12MM	1	1	
FOP-10-1	90	HZV5-90559-000	WASHER, PLAIN, 12MM	1	1	
FOP-10-1	91	HZV1-90759-000	PIN, SPLIT, 2.0	1	1	
FOP-10-1	92	HZY9-90951-A01	BALL, STEEL	1	1	
FOP-10-1	93	HZW4-91051-H02	BEARING	2	2	
FOP-10-1	94	HZW4-91052-H01	BEARING	1	1	
FOP-10-1	95	HHP5-91304-601	O-RING, 20.6X1.9	1	1	
FOP-10-1	96	HZV5-91352-000	O-RING, 15.54X2.62	1	1	
FOP-10-1	97	HZJ1-91408-810	TUBE, CORD, 30MM	1	1	
FOP-10-1	98	HZW4-91552-H00	COLLAR, DISTANCE, 12.2X23X16	1	1	
FOP-10-1	99	HCO-93500-05014-4J	SCREW, PAN, 5X14	3	3	
FOP-10-1	100	HCO-94002-06490-0S	NUT, HEX., 6MM	1	1	
FOP-10-1	101	HCO-94002-12490-0S	NUT, HEX., 12MM	1	1	
FOP-10-1	102	HCO-94540-04029	E-RING, 4MM	2	2	
FOP-10-1	103	HCO-94540-07029	E-RING, 7MM	1	1	
FOP-10-1	104	HZW9-87532-620	MARK, THROTTLE(ENGLISH/FRENCH)	1	1	


2
3
4


1
5
6

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-11	1	HZZ3-06328-763	KIT, CABLE(NMEA)(6FT)	1	1	
FOP-11	2	HZZ3-32186-000	HARNESS ASSY., REMOTE CONTROL SUB	1	1	
FOP-11	3	HZV5-32823-003	PLUG, INNER CONNECTOR	2	2	
FOP-11	4	HZV5-32824-003	PLUG, OUTER CONNECTOR	1	1	
FOP-11	5	HZY1-90650-003	TIE, CABLE	2	2	
FOP-11	6	HSTK-91540-003	CLIP, HARNESS BAND(BLACK)	2	2	(155.3MM)


6
3
1
2
7
5
4
8
9
8
9

Ref.No.		Part No.	Description	Q'ty		Remarks
				BFT80AK1	BFT100AK1	
FOP-12	1	HZZ3-35340-741	SWITCH ASSY., TROLLING CONTROL	1	1	
FOP-12	2	HZZ3-35341-740	RUBBER, TROLLING CONTROL SWITCH PANEL	1	1	
FOP-12	3	HZZ3-35342-740	BODY, TROLLING CONTROL SWITCH PANEL	1	1	
FOP-12	4	HZZ3-35343-740	BRACKET, TROLLING CONTROL SWITCH PANEL	1	1	
FOP-12	5	HZZ3-35344-740	HARNESS, TROLLING CONTROL SWITCH PANEL	1	1	
FOP-12	6	HZZ3-35345-741	PANEL ASSY., TROLLING CONTROL	1	1	
FOP-12	7	HCO-92101-04020-4J	BOLT, HEX., 4X20	2	2	
FOP-12	8	HCO-94001-04490-0S	NUT, HEX., 4MM	4	4	
FOP-12	9	HCO-94111-04500	WASHER, SPRING, 4MM	4	4	

INDEX

<A>
ACTUATOR FOP-10-39
ACTUATOR FOP-10-1-32
ADJUSTER F-15-17
ARM ASSY., BRAKE F-15-7
ARM ASSY., ROCKER E-9-6
ARM ASSY., SHIFT LINK F-15-1-18
ARM ASSY., THROTTLE FOP-10-1-3
ARM ASSY., THROTTLE LINK F-15-1-21
ARM COMP., EX. ROCKER(A) E-9-8
ARM COMP., EX. ROCKER(B) E-9-9
ARM COMP., IN. VALVE ROCKER E-9-7
ARM, NEUTRAL LOCK F-15-4
ARM, NEUTRAL LOCK FOP-4-4-5
ARM, SHIFT F-2-11
ARM, THROTTLE F-2-7
ARM, THROTTLE FOP-10-4
ARMATURE COMP. F-11-6
<B>
BAG, TOOL, 200MM F-13-10
BALL, STEEL E-21-6
BALL, STEEL F-15-1-46
BALL, STEEL FOP-10-87
BALL, STEEL FOP-10-1-92
BALL, STEEL, #11(11/32) F-5-28
BALL, STEEL, #7(7/32) F-5-27
BAND E-18-20-45
BAND(BLACK 3.5X140) F-3-4
BAND(CONVEX CV-150) FOP-10-11
BAND(CONVEX CV-150) FOP-10-1-8
BAND(CONVEX CV-200) FOP-10-12
BAND(CONVEX) FOP-10-13
BAND, AIR FLOW E-15-26
BAND, CABLE(B) F-15-1-11
BAND, SELF LOCK F-15-77
BAND, UNDER CASE GROMMET F-3-9
BAND, WIRE F-3-3
BAND, WIRE F-15-37
BAND, WIRE HARNESS F-7-18
BAND, WIRE HARNESS(NATURAL) FOP-6-24
BAND, WIRE HARNESS(NATURAL) FOP-6-1-17
BAND, WIRE, 165MM(BLACK) F-7-10-2
BASE FOP-4-4-15
BEARING FOP-10-88
BEARING FOP-10-89
BEARING FOP-10-1-93
BEARING FOP-10-1-94
BEARING A, CONNECTING ROD(BLUE) . E-7-6
BEARING B, CONNECTING ROD(BLACK) E-7-6
BEARING B, MAIN LOWER(BLACK) E-7-10
BEARING B, MAIN UPPER(BLACK) E-7-8
BEARING C, CONNECTING ROD(BROWN) E-7-6
BEARING C, MAIN LOWER(BROWN) E-7-10
BEARING C, MAIN UPPER(BROWN) E-7-8
BEARING D, CONNECTING ROD(GREEN) E-7-6
BEARING D, MAIN LOWER(GREEN) E-7-10
BEARING D, MAIN UPPER(GREEN) E-7-8
BEARING E, CONNECTING ROD(YELLOW) E-7-6
BEARING E, MAIN LOWER(YELLOW) ... E-7-10
BEARING E, MAIN UPPER(YELLOW) E-7-8
BEARING F, CONNECTING ROD(PINK) .. E-7-6
BEARING F, MAIN LOWER(PINK) E-7-10
BEARING F, MAIN UPPER(PINK) E-7-8
BEARING G, CONNECTING ROD(RED) .. E-7-6
BEARING G, MAIN LOWER(RED) E-7-10
BEARING G, MAIN UPPER(RED) E-7-8
BEARING H, MAIN LOWER(WHITE) E-7-10
BEARING H, MAIN UPPER(WHITE) E-7-8
BEARING(1) F-15-60
BEARING(2) F-15-71
BEARING(3) F-15-72
BEARING, BALL(28X38X3) F-5-21
BEARING, NEEDLE F-4-29
BEARING, NEEDLE, 30X37X26 ..... F-5-19
BEARING, RADIAL BALL, 6208 ..... F-5-26
BEARING, TAPER ROLLER, 30X62X40 ... F-4-30
BEARING, TAPERED ROLLER F-5-20
BLOCK ASSY., CYLINDER E-3-4
BLOCK, HEIGHT ADJUSTER FOP-10-53
BLOCK, HEIGHT ADJUSTER FOP-10-1-60
BLOCK, STEERING FRICTION FOP-10-55
BLOCK, STEERING FRICTION FOP-10-1-62
BODY E-18-20-4
BODY, TROLLING CONTROL SWITCH PANEL FOP-12-3
BOLT F-15-1-37
BOLT A, THROUGH E-21-18
BOLT KIT, SIDE REMOTE CONTROL FOP-9-1
BOLT(M5X12) FOP-10-67
BOLT(M5X12) FOP-10-69
BOLT(M5X12) FOP-10-1-71
BOLT(M5X8) FOP-10-63
BOLT(M6X12) FOP-10-68
BOLT(M8X50) FOP-10-65
BOLT, 1/4-28UNF F-10-28
BOLT, 12MM E-7-13
BOLT, 3/8-24UNF F-10-30
BOLT, 5X12 ..... FOP-10-1-73
BOLT, 5X20 ..... FOP-10-1-74
BOLT, 5X25 ..... F-15-56
BOLT, 6X15 ..... FOP-10-1-75
BOLT, 8X50 ..... F-15-55
BOLT, CONNECTING ROD E-7-4
BOLT, DRAIN PLUG E-6-12
BOLT, DRAIN PLUG F-3-10-16
BOLT, FLANGE, 10X25 ..... F-10-36
BOLT, FLANGE, 10X35 ..... E-21-21
BOLT, FLANGE, 10X40 ..... F-3-28
BOLT, FLANGE, 10X75 ..... E-21-19
BOLT, FLANGE, 6X10 ..... E-14-14
BOLT, FLANGE, 6X10 ..... F-7-13
BOLT, FLANGE, 6X11 ..... F-2-26
BOLT, FLANGE, 6X12 ..... E-6-9
BOLT, FLANGE, 6X12 ..... E-6-10-17
BOLT, FLANGE, 6X12 ..... F-2-27
BOLT, FLANGE, 6X12 ..... F-3-30
BOLT, FLANGE, 6X12 ..... F-4-20
BOLT, FLANGE, 6X12 ..... F-7-12
BOLT, FLANGE, 6X12 ..... F-7-10-18
BOLT, FLANGE, 6X12 ..... FOP-10-64
BOLT, FLANGE, 6X14 ..... E-3-31
BOLT, FLANGE, 6X14 ..... E-9-30
BOLT, FLANGE, 6X14 ..... E-18-20-49
BOLT, FLANGE, 6X14 ..... F-7-10-20
BOLT, FLANGE, 6X14(CT200) E-9-10-7
BOLT, FLANGE, 6X14(CT200) E-18-20
BOLT, FLANGE, 6X14(CT200) E-18-10-17
BOLT, FLANGE, 6X14(CT200) F-2-23
BOLT, FLANGE, 6X14(CT200) F-7-11
BOLT, FLANGE, 6X14(CT200) F-7-10-17
BOLT, FLANGE, 6X16 ..... E-2-29
BOLT, FLANGE, 6X16 ..... E-6-18
BOLT, FLANGE, 6X16 ..... E-9-10-9
BOLT, FLANGE, 6X16 ..... F-2-25
BOLT, FLANGE, 6X16 ..... F-10-38
BOLT, FLANGE, 6X18(CT200) E-5-10
BOLT, FLANGE, 6X18(CT200) F-2-24
BOLT, FLANGE, 6X20 ..... E-2-30
BOLT, FLANGE, 6X20 ..... E-6-10-18
BOLT, FLANGE, 6X20 ..... F-7-10-19
BOLT, FLANGE, 6X20 ..... F-8-31
BOLT, FLANGE, 6X20 ..... F-10-31
BOLT, FLANGE, 6X22 ..... E-1-4
BOLT, FLANGE, 6X22 ..... E-2-32
BOLT, FLANGE, 6X22 ..... E-3-37
BOLT, FLANGE, 6X22 ..... E-6-10-15
BOLT, FLANGE, 6X22 ..... E-9-10-11
BOLT, FLANGE, 6X22 ..... E-18-19
BOLT, FLANGE, 6X23 ..... F-10-27
BOLT, FLANGE, 6X25 ..... E-3-17
BOLT, FLANGE, 6X25 ..... E-15-19
BOLT, FLANGE, 6X25 ..... E-18-21
BOLT, FLANGE, 6X25 ..... E-18-20-48
BOLT, FLANGE, 6X25 ..... E-20-3
BOLT, FLANGE, 6X25(SUS-D) F-10-37
BOLT, FLANGE, 6X28 ..... E-9-31
BOLT, FLANGE, 6X28 ..... E-9-10-8
BOLT, FLANGE, 6X32 ..... E-3-20
BOLT, FLANGE, 6X32(CT200) E-19-7
BOLT, FLANGE, 6X35 ..... E-2-31
BOLT, FLANGE, 6X35 ..... F-3-10-22
BOLT, FLANGE, 6X40 ..... E-9-10-12
BOLT, FLANGE, 6X45 ..... E-3-36
BOLT, FLANGE, 6X55 ..... E-2-34
BOLT, FLANGE, 6X55 ..... F-8-26
BOLT, FLANGE, 8X100 ..... E-6-8
BOLT, FLANGE, 8X100 ..... E-6-19
BOLT, FLANGE, 8X110 ..... E-2-28
BOLT, FLANGE, 8X120 ..... E-6-20
BOLT, FLANGE, 8X18 ..... F-7-10-21
BOLT, FLANGE, 8X20 ..... E-3-18
BOLT, FLANGE, 8X25 ..... F-10-35
BOLT, FLANGE, 8X28 ..... FOP-10-70
BOLT, FLANGE, 8X28 ..... FOP-10-1-76
BOLT, FLANGE, 8X35 ..... E-3-21
BOLT, FLANGE, 8X35 ..... E-6-10
BOLT, FLANGE, 8X35 ..... E-14-15
BOLT, FLANGE, 8X40 ..... E-5-12
BOLT, FLANGE, 8X45 ..... E-3-22
BOLT, FLANGE, 8X45 ..... E-6-11
BOLT, FLANGE, 8X45 ..... E-14-16
BOLT, FLANGE, 8X60 ..... E-5-11
BOLT, FLANGE, 8X60 ..... E-15-18
BOLT, FLANGE, 8X95 ..... E-2-27
BOLT, FRICTION FOP-10-31
BOLT, FRICTION FOP-10-1-23
BOLT, HEX. F-11-30
BOLT, HEX., 10X235 ..... F-10-32
BOLT, HEX., 10X32 ..... FOP-10-66
BOLT, HEX., 10X32 ..... FOP-10-1-69
BOLT, HEX., 10X80 ..... F-3-10-14
BOLT, HEX., 12X119 ..... F-10-34
BOLT, HEX., 12X186 ..... F-3-29
BOLT, HEX., 12X186 ..... F-10-29
BOLT, HEX., 12X80 ..... FOP-10-62
BOLT, HEX., 12X80 ..... FOP-10-1-68
BOLT, HEX., 4X20 ..... FOP-12-7
BOLT, HEX., 6X14 ..... F-10-33
BOLT, HEX., 8X25 ..... F-3-10-15
BOLT, HEX., 8X55 ..... F-4-19
BOLT, HEX., 8X55 ..... FOP-3-9
BOLT, OIL CHECK F-3-10-12
BOLT, RECESSED F-11-27
BOLT, ROCKER ARM SHAFT E-9-25
BOLT, RR. BRACKET F-8-28
BOLT, SEALING, 18MM E-5-7
BOLT, SEALING, 20MM E-2-7
BOLT, SEALING, 24MM E-3-1
BOLT, SEALING, 6MM E-18-20-46
BOLT, SOCKET(A) F-11-28
BOLT, SOCKET(B) F-11-29
BOLT, SOCKET, 6X16 ..... F-3-10-20
BOLT, SOCKET, 8X70 ..... FOP-10-1-70
BOLT, SPECIAL, 6X17 ..... F-8-27
BOLT, SPECIAL, 6X220 ..... FOP-9-2
BOLT, SPECIAL, 6X31 ..... E-9-10-10
BOLT, SPECIAL, 6X37 ..... F-8-30
BOLT, STUD(10X164) F-3-10-19
BOLT, STUD(10X202) F-3-10-18
BOLT, STUD, 6X40 ..... E-14-12
BOLT, STUD, 8X28 ..... E-6-10-16
BOLT, STUD, 8X32 ..... E-2-33
BOLT, TDC PULSER PLATE E-9-4
BOLT, TENSIONER PIVOT E-9-24
BOLT, TORX(M6X20) E-20-10-6
BOLT-WASHER, 10X105 ..... E-3-15
BOLT-WASHER, 10X30 ..... E-9-26
BOLT-WASHER, 10X40 ..... F-3-10-17
BOLT-WASHER, 10X40 ..... F-5-13
BOLT-WASHER, 14X36 ..... E-19-6
BOLT-WASHER, 5X9 ..... F-7-15
BOLT-WASHER, 6X22 ..... F-8-25
BOLT-WASHER, 6X27 ..... F-3-33
BOLT-WASHER, 6X27(CT200) E-15-15
BOLT-WASHER, 6X27(CT200) E-20-10-5
BOLT-WASHER, 6X27(CT200) F-7-10
BOLT-WASHER, 6X27(CT200) F-7-10-16
BOLT-WASHER, 6X27(CT200) F-8-24
BOLT-WASHER, 6X95 ..... F-3-31
BOLT-WASHER, 8X30 ..... F-3-32
BOLT-WASHER, 8X35 ..... E-14-13
BOLT-WASHER, 8X35 ..... E-18-20-47
BOLT-WASHER, 9X155 ..... E-2-26
BOX ASSY., FUSE(70A) F-7-26

BOX ASSY., POWER TILT SWITCH-1..... FOP-10-1-50
BOX ASSY., POWER TILT SWITCH-2..... FOP-10-1-51
BOX ASSY., REMOTE CONTROL F-15-1
BOX ASSY., REMOTE CONTROL F-15-1-1
BOX KIT, REMOTE CONTROL..... FOP-4-1
BOX KIT, REMOTE CONTROL..... FOP-4-2-1
BOX KIT, REMOTE CONTROL..... FOP-4-4-1
BRACKET F-15-11
BRACKET FOP-6-2-14
BRACKET FOP-6-3-14
BRACKET FOP-6-4-14
BRACKET FOP-10-46
BRACKET A, COUPLER..... F-7-2
BRACKET A, HARNESS CLIP..... E-9-10-2
BRACKET ASSY..... F-11-5
BRACKET ASSY., FR. UNDER COVER F-3-47
BRACKET ASSY., RR. UNDER COVER F-8-44
BRACKET B, HARNESS CLIP E-18-10-15
BRACKET B, STEERING..... FOP-10-54
BRACKET B, STEERING..... FOP-10-1-61
BRACKET C, COUPLER..... F-7-3
BRACKET C, HARNESS CLIP..... E-9-10-3
BRACKET D, HARNESS CLIP..... E-2-22
BRACKET E, HARNESS CLIP E-9-10-4
BRACKET, BUZZER FOP-6-21
BRACKET, BUZZER FOP-6-1-14
BRACKET, CABLE..... FOP-10-32
BRACKET, COUPLER..... F-7-4
BRACKET, ELECTRONIC CONTROL UNIT E-20-10-4
BRACKET, FR..... E-21-11
BRACKET, FR. UNDER COVER F-3-10
BRACKET, FUEL TUBE CLAMP..... E-18-10
BRACKET, FUSE BOX F-7-10-11
BRACKET, L. STERN..... F-10-16
BRACKET, NEUTRAL SWITCH F-2-20
BRACKET, R. STERN F-10-15
BRACKET, RELAY..... F-7-10-13
BRACKET, REMOTE CONTROL HOUSINGFOP-4-12
BRACKET, REMOTE CONTROL HOUSINGFOP-4-2-13
BRACKET, RR..... E-21-12
BRACKET, SENSOR CORD..... E-15-10
BRACKET, SHIFT LINK F-2-16
BRACKET, TILTING F-10-21
BRACKET, TROLLING CONTROL SWITCH PANEL
..... FOP-12-4
BRACKET, UNDER COVER..... F-8-10
BRACKET, WIRE CLAMP F-15-15
BREAKER ASSY..... F-11-1
BRUSH ASSY..... F-11-2
BRUSH SET E-21-8
BUFFER, PLATE E-18-10-4
BUSH..... F-15-1-23
BUSH A, COVER LOCK..... F-2-22
BUSH COMP., VERTICAL SHAFT..... F-3-10-3
BUSH, LOWER CYLINDER..... F-11-23
BUSH, MOTOR CODE..... F-3-23
BUSH, MOTOR CODE..... F-11-18
BUSH, STEERING HANDLE..... FOP-10-42
BUSH, STEERING HANDLE..... FOP-10-1-38
BUSH, SWIVEL CASE F-10-14
BUSH, SWIVEL CASE F-11-10
BUSH, THROTTLE SHAFT FOP-10-1-53
BUSH, TILT ARM F-10-20
BUSHING..... F-15-1-8
BUTTON, THROTTLE F-15-1-9
BUTTON, THROTTLE FOP-4-9
BUTTON, THROTTLE FOP-4-2-10
BUTTON, THROTTLE FOP-4-4-8
BUZZER ASSY., WARNING FOP-10-25
BUZZER ASSY., WARNING FOP-10-1-17
BUZZER COMP., WARNING F-15-42
BUZZER COMP., WARNING FOP-6-20
BUZZER COMP., WARNING FOP-6-1-13
BUZZER COMP., WARNING FOP-6-2-13
BUZZER COMP., WARNING FOP-6-3-13
BUZZER COMP., WARNING FOP-6-4-13
<C>
CABLE ASSY., LONG HANDLE(A)..... FOP-10-10
CABLE ASSY., LONG HANDLE(A)..... FOP-10-1-7
CABLE ASSY., REMOTE CONTROL(B) ... F-15-30
CABLE ASSY., STARTER..... F-7-10-4
CABLE ASSY., SWITCH PANEL(20FT) ... FOP-6-9
CABLE ASSY., SWITCH PANEL(25FT) ... FOP-6-9
CABLE ASSY., SWITCH PANEL(30FT) ... FOP-6-9
CABLE COMP., SHIFT..... FOP-10-5
CABLE COMP., THROTTLE FOP-10-2
CABLE SET, PANEL INDICATOR(20FT) .. FOP-6-2
CABLE SET, PANEL INDICATOR(25FT) .. FOP-6-2
CABLE SET, PANEL INDICATOR(30FT) .. FOP-6-2
CABLE, SHIFT..... FOP-10-1-4
CABLE, THROTTLE FOP-10-1-2
CAMSHAFT COMP..... E-9-1
CAMSHAFT COMP..... E-9-1
CAP..... FOP-10-37
CAP..... FOP-10-1-33
CAP ASSY., OIL FILLER..... E-3-6
CAP COMP., OIL TANK..... F-11-26
CAP, GRIP FOP-4-7
CAP, GRIP FOP-4-2-9
CAP, GRIP FOP-10-1-58
CAP, L. SIDE COVER F-3-26
CAP, RUBBER F-15-16
CAP, SWITCH FOP-4-8
CAP, TROLLING CONTROL SWITCH BLANK
..... F-15-22
CAP, WATER JOINT..... F-8-5
CARTRIDGE, OIL FILTER E-3-5
CASE ASSY., GEAR(L)..... F-3-20-1
CASE ASSY., GEAR(XL)..... F-3-20-1
CASE ASSY., OIL..... E-6-1
CASE COMP., CHAIN E-9-10-1
CASE COMP., MOUNT..... E-6-10-13
CASE COMP., SILENCER E-15-7
CASE COMP., SILENCER E-15-7
CASE, ELECTRONIC PARTS..... E-20-10-1
CASE, EXTENSION..... F-3-11
CASE, GEAR F-3-10-4
CASE, PUMP..... E-18-20-25
CASE, SWIVEL..... F-10-12
CASE, THERMOSTAT E-3-34
CHAIN(132L) E-9-5
CIRCLIP, EXTERNAL F-15-1-44
CIRCLIP, EXTERNAL, 12..... F-2-35
CIRCLIP, EXTERNAL, 14MM F-5-25
CIRCLIP, EXTERNAL, 39MM F-10-54
CIRCLIP, INTERNAL..... F-11-32
CIRCLIP, INTERNAL, 40 ..... F-3-10-28
CLAMP A, FUEL TUBE E-18-13
CLAMP B, FUEL TUBE E-2-14
CLAMP B, FUEL TUBE E-15-4
CLAMP B, FUEL TUBE E-18-14
CLAMP B, FUEL TUBE E-18-20-38
CLAMP D, FUEL TUBE E-18-20-39
CLAMP, BRACKET..... FOP-10-48
CLAMP, CHECK VALVE E-18-20-24
CLAMP, OXYGEN SENSOR..... E-18-18
CLAMP, SHIFT CABLE..... FOP-10-1-22
CLAMP, THROTTLE CABLE..... FOP-10-1-24
CLAMP, TUBE..... E-18-10-14
CLAMP, TUBE(7.5-11.5)(BLACK)..... E-18-10-13
CLAMP, TUBE(D10.5)..... E-6-10-19
CLAMP, TUBE(D10.7)..... E-18-20-51
CLAMP, TUBE(D12) E-18-10-18
CLAMP, TUBE(D29) E-1-5
CLAMPER, CORD..... F-7-10-8
CLANP F-6-5
CLANP F-6-8
CLIP B1, TUBE..... F-8-36
CLIP(14MM) F-3-39
CLIP, 10.7MM..... F-8-35
CLIP, 7MM..... F-3-40
CLIP, BRAKE PIPE(A)..... F-2-21
CLIP, COUPLER HOLDER(B)..... F-7-10-10
CLIP, DETENT..... F-15-9
CLIP, EMERGENCY LOCK FOP-6-16
CLIP, EMERGENCY LOCK FOP-6-1-10
CLIP, EMERGENCY LOCK FOP-6-2-11
CLIP, EMERGENCY LOCK FOP-6-3-11
CLIP, EMERGENCY LOCK FOP-6-4-11
CLIP, EMERGENCY LOCK FOP-10-23
CLIP, EMERGENCY LOCK FOP-10-1-15
CLIP, HARNESS..... E-2-35
CLIP, HARNESS BAND(BLACK) E-2-38
CLIP, HARNESS BAND(BLACK) F-2-42
CLIP, HARNESS BAND(BLACK) F-7-19
CLIP, HARNESS BAND(BLACK) FOP-11-6
CLIP, HARNESS BAND(BROWN) F-7-20
CLIP, HARNESS BAND(NATURAL) E-19-8
CLIP, INJECTOR E-14-2
CLIP, ROLLER F-15-74
CLIP, SENSOR HOSE..... E-18-10-16
CLIP, TUBE..... E-6-10-2
CLIP, TUBE..... E-18-20-23
CLIP, TUBE(B10)..... E-6-10-20
CLIP, TUBE(B12)..... E-18-22
CLIP, TUBE(B12)..... E-18-10-19
CLIP, TUBE, 3.5..... F-7-10-25
CLIP, WIRE HARNESS E-20-10-7
CLIP, WIRE HARNESS F-10-55
CLIP, WIRE HARNESS, 25MM..... F-7-10-24
CLUTCH COMP., OVERRUNNING..... E-21-2
COIL ASSY., PLUG TOP E-20-1
COLLAR, 8.5X14.5..... E-14-22
COLLAR, 8.5X14.5..... E-18-20-53
COLLAR, C.D.I. UNIT CASE E-15-24
COLLAR, C.D.I. UNIT CASE E-19-9
COLLAR, C.D.I. UNIT CASE E-20-10-8
COLLAR, C.D.I. UNIT CASE F-3-43
COLLAR, C.D.I. UNIT CASE F-7-21
COLLAR, C.D.I. UNIT CASE F-7-10-26
COLLAR, C.D.I. UNIT CASE F-8-40
COLLAR, DISTANCE..... F-4-36
COLLAR, DISTANCE FOP-3-13
COLLAR, DISTANCE(6.5X11X27) F-8-39
COLLAR, DISTANCE(A) FOP-9-3
COLLAR, DISTANCE(B) FOP-9-4
COLLAR, DISTANCE, 12.2X23X16 ..... FOP-10-93
COLLAR, DISTANCE, 12.2X23X16 ..... FOP-10-1-98
COLLAR, DISTANCE, 6.2X7.5..... F-8-42
COLLAR, DISTANCE, 6.5X11X7.5 ..... E-6-10-3
COLLAR, DISTANCE, 6.5X11X7.5 ..... F-7-10-1
COLLAR, DISTANCE, 6.5X9X11.5 ..... F-8-41
COLLAR, DISTANCE, 6.5X9X3..... F-3-10-31
COLLAR, FR. BRACKET..... F-3-44
COLLAR, LOWER CYLINDER F-10-26
COLLAR, LOWER MOUNTING..... F-3-19
COLLAR, ORIFICE F-11-44
COLLAR, P.T.T. RELAY F-7-10-27
COLLAR, SPLASH PLATE..... F-10-60
COLLAR, STEERING ROD F-10-61
CONTROL UNIT, ELECTRONIC..... E-20-10-3
CONTROL UNIT, ELECTRONIC..... E-20-10-3
CORD ASSY., INDICATOR(20FT)..... FOP-6-4
CORD ASSY., INDICATOR(25FT)..... FOP-6-4
CORD ASSY., INDICATOR(30FT)..... FOP-6-4
CORD COMP., EMERGENCY..... F-15-39
CORD COMP., EMERGENCY..... F-15-1-29
CORD COMP., EMERGENCY..... FOP-6-15
CORD COMP., EMERGENCY..... FOP-6-1-9
CORD COMP., EMERGENCY..... FOP-6-2-10
CORD COMP., EMERGENCY..... FOP-6-3-10
CORD COMP., EMERGENCY..... FOP-6-4-10
CORD COMP., EMERGENCY..... FOP-10-22
CORD COMP., EMERGENCY..... FOP-10-1-14
COTTER, VALVE(FUJI VALVE)..... E-9-23
COVER ASSY..... FOP-4-4-11
COVER ASSY., A.C. GENERATOR..... E-19-1
COVER ASSY., FUSE(70A)..... F-7-7
COVER ASSY., OIL PATH E-2-12
COVER B, GEAR CASE F-3-10-6
COVER COMP..... E-18-20-5
COVER COMP., ANODE..... E-2-43
COVER COMP., CYLINDER HEAD E-1-1
COVER COMP., ENGINE..... F-8-13
COVER COMP., L. ENGINE UNDER..... F-8-19
COVER COMP., R. ENGINE UNDER..... F-8-18
COVER, DUAL GRIP FOP-4-2-8
COVER, FLUSH VALVE..... E-6-10-5
COVER, GRIP..... F-15-1-6
COVER, GRIP..... FOP-4-4-4
COVER, IMPELLER..... F-4-4
COVER, IMPELLER..... FOP-3-5
COVER, L. GRIP..... FOP-4-5
COVER, L. GRIP..... FOP-4-2-6
COVER, LEVER F-15-6
COVER, LOCK ARM..... FOP-4-4-6
COVER, OIL PUMP E-5-2
COVER, PLUG MAINTENANCE F-8-17
COVER, POWER TRIM-TILT WIRE F-15-18
COVER, POWER TRIM-TILT WIRE F-15-75
COVER, PUMP(A) E-18-20-27
COVER, PUMP(B)..... E-18-20-26
COVER, RELIEF VALVE E-6-10-9
COVER, REMOTE CONTROL CABLE..... F-2-6
COVER, SEPARATE FRONT..... F-8-9
COVER, STARTER TERMINAL..... F-7-10-5
COVER, STEERING HANDLE UNDER FOP-10-29
COVER, THERMOSTAT..... E-2-16

COVER, THERMOSTAT E-3-33
COVER, UNDER FOP-10-1-21
COVER, UPPER MOUNT F-10-10
COVER, WATER JACKET E-2-18
COVER, WATER JACKET E-18-20-10
COVER, WIRE FOP-10-14
CRANKSHAFT COMP. E-7-7
CUP, WATER SEPARATOR E-18-10-3
<D>
DOWEL PIN, 12X14 ..... E-3-24
DOWEL PIN, 14X20 ..... E-2-41
DOWEL PIN, 6X10 ..... E-6-14
DOWEL PIN, 6X10 ..... E-6-17
DOWEL PIN, 6X10 ..... F-3-42
DOWEL PIN, 6X10 ..... F-3-10-29
DOWEL PIN, 6X10 ..... F-3-10-29
DOWEL PIN, 6X10 ..... F-4-28
DRIVER 1, PLUS SCREW(NO.2) F-13-7
DRUM ASSY., FREE THROTTLE F-15-26
DUMMY, WATER PROOF (GREEN) FOP-6-2-5
DUMMY, WATER PROOF (GREEN) FOP-6-3-5
DUMMY, WATER PROOF (GREEN) FOP-6-4-5
<E>
E-RING FOP-10-84
E-RING FOP-10-85
E-RING, 10MM F-4-37
E-RING, 12MM F-2-46
E-RING, 15MM F-11-45
E-RING, 4MM F-2-44
E-RING, 4MM F-3-45
E-RING, 4MM FOP-10-1-102
E-RING, 6MM F-2-45
E-RING, 6MM FOP-4-36
E-RING, 6MM FOP-4-2-41
E-RING, 6MM FOP-4-4-28
E-RING, 6MM(LOOSE PARTS) F-15-68
E-RING, 7MM FOP-10-1-103
EXTENSION, OIL FILLER E-3-8
<F>
FILTER ASSY., SPOOL VALVE E-2-11
FILTER B F-11-16
FLOAT SET E-18-20-2
FLYWHEEL COMP. E-7-12
FRAME ASSY., REMOTE CONTROL BOX F-15-1-10
FRAME ASSY., SHIFT FOP-10-7
FRAME ASSY., SHIFT FOP-10-1-6
FRAME ASSY., THROTTLE SUB FOP-10-1-43
FRAME COMP., MOUNTING F-10-6
FRAME, THROTTLE FOP-10-1-30
FUSE(70A) F-7-6
FUSE, MINI(10A) F-7-23
FUSE, MINI(15A) F-7-24
FUSE, MINI(30A) F-7-25
<G>
GASKET B, IMPELLER F-4-5
GASKET B, IMPELLER FOP-3-6
GASKET COMP., CYLINDER HEAD E-2-8
GASKET, MOUNT CASE E-6-7
GASKET, WATER PUMP F-4-7
GASKET, WATER PUMP FOP-3-7
GAUGE COMP., OIL LEVEL E-6-4
GEAR ASSY., INTERNAL E-21-17
GEAR ASSY., PLANETARY E-21-3
GEAR ASSY., SHIFT F-15-23
GEAR COMP., FR. BEVEL F-5-8
GEAR, DRIVE F-15-24
GEAR, PINION(12T) F-4-18
GEAR, RR. BEVEL F-5-9
GEAR, SHIFT FOP-10-44
GEAR, SHIFT FOP-10-1-40
GENERATOR ASSY., A.C. E-19-2
GRIP F-15-5
GRIP ASSY., THROTTLE FRICTION FOP-10-49
GRIP ASSY., THROTTLE FRICTION FOP-10-1-52
GRIP, REMOTE CONTROL HANDLE F-15-1-4
GRIP, REMOTE CONTROL HANDLE FOP-4-6
GRIP, REMOTE CONTROL HANDLE FOP-4-2-7
GRIP, SCREW DRIVER F-13-8
GROMMET F-15-1-15
GROMMET FOP-10-19
GROMMET FOP-10-36
GROMMET FOP-10-1-27
GROMMET, 1WAY E-6-16
GROMMET, ELECTRONIC PARTS CASE E-15-9
GROMMET, ELECTRONIC PARTS CASE E-20-10-2
GROMMET, ENGINE COVER F-8-21
GROMMET, EXTENSION CASE F-4-15
GROMMET, FUEL HOSE E-18-9
GROMMET, GEAR CASE F-3-10-5
GROMMET, GEAR CASE F-3-10-7
GROMMET, POWER TILT SWITCH FOP-10-1-35
GROMMET, POWER TILT SWITCH FOP-10-1-36
GROMMET, RELAY F-7-9
GROMMET, RELAY BRACKET F-7-10-14
GROMMET, REMOTE CONTROL CABLE F-3-7
GROMMET, SIDE FOP-10-1-48
GROMMET, SILENCER E-15-8
GROMMET, STEERING HANDLE CABLE FOP-10-27
GROMMET, STEERING HANDLE CABLE FOP-10-1-19
GROMMET, TA SENSOR E-15-14
GROMMET, UNDER CASE E-9-10-6
GROMMET, UNDER CASE E-19-5
GROMMET, UNDER CASE F-3-6
GROMMET, UNDER CASE F-8-8
GROMMET, UNDER CASE(C) F-3-8
GROMMET, VAPOR SEPARATOR E-14-5
GROMMET, VAPOR SEPARATOR E-18-20-32
GROMMET, WATER CHECK F-8-22
GROMMET, WATER TUBE E-6-5
GROMMET, WIRE(14) F-15-21
GUIDE COMP., CAM CHAIN E-9-12
GUIDE COMP., ROD F-11-46
GUIDE, EX. VALVE(O.S.) E-2-3
GUIDE, HARNESS FOP-10-1-49
GUIDE, IN. VALVE(O.S.) E-2-2
GUIDE, SPRING FOP-10-38
GUIDE, SPRING FOP-10-1-31
GUIDE, THROTTLE HARNESS FOP-10-1-42
<H>
HANDLE KIT, STEERING FOP-10-1
HANDLE KIT, STEERING(EF) FOP-10-1-1
HANDLE, REMOTE CONTROL F-15-1-2
HANDLE, REMOTE CONTROL FOP-4-4
HANDLE, REMOTE CONTROL FOP-4-2-5
HANDLE, REMOTE CONTROL FOP-4-4-3
HANGER, ENGINE E-3-3
HARNESS ASSY., MAIN WIRE F-7-1
HARNESS ASSY., MAIN WIRE F-7-1
HARNESS ASSY., POWER TRIM-TILT F-15-1-27
HARNESS ASSY., REMOTE CONTROL SUB FOP-11-2
HARNESS ASSY., SWITCH PANEL FOP-6-8
HARNESS ASSY., SWITCH PANEL FOP-6-1-4
HARNESS ASSY., SWITCH PANEL FOP-6-2-4
HARNESS ASSY., SWITCH PANEL FOP-6-3-4
HARNESS ASSY., SWITCH PANEL FOP-6-4-4
HARNESS COMP. E-18-20-44
HARNESS, TROLLING CONTROL SWITCH PANEL FOP-12-5
HEAD COMP., CYLINDER E-2-5
HOLDER E-18-20-9
HOLDER COMP., BRUSH E-21-10
HOLDER COMP., STARTER CABLE F-7-10-6
HOLDER, NEUTRAL LOCK F-15-20
HOLDER, NEUTRAL LOCK FOP-4-4-14
HOLDER, OIL FILTER E-3-16
HOLDER, PROPELLER SHAFT F-5-12
HOLDER, SEAL F-2-17
HOLDER, SHIFT ROD F-4-14
HOLDER, SWITCH FOP-10-20
HOLDER, SWITCH FOP-10-1-54
HOSE F-6-6
HOSE F-6-7
HOSE COMP., FUEL E-18-8
HOSE, PRESSURE REGULATOR RETURN E-18-20-42
HOUSING FOP-10-28
HOUSING FOP-10-1-20
HOUSING ASSY., INNER F-15-1-22
HOUSING ASSY., L. INNER FOP-4-3
HOUSING ASSY., L. INNER FOP-4-2-3
HOUSING ASSY., R. INNER FOP-4-2-4
HOUSING ASSY., R. INNER FOP-4-4-2
HOUSING ASSY., REMOTE CONTROL BOX(A) F-15-1-7
HOUSING COMP., REMOTE CONTROL BOX FOP-4-13
HOUSING COMP., REMOTE CONTROL BOX(DUAL) FOP-4-2-14
HOUSING, FR. F-15-12
HOUSING, IMPELLER F-4-2
HOUSING, IMPELLER FOP-3-3
HOUSING, LEAD FOP-4-14
HOUSING, LEAD FOP-4-2-15
HOUSING, LOWER CENTER MOUNTING F-3-21
HOUSING, LOWER MOUNTING F-3-17
HOUSING, REMOTE CONTROL BOX(B) F-15-1-12
HOUSING, REMOTE CONTROL BOX(C) F-15-1-14
HOUSING, RR. F-15-13
HOUSING, WATER PUMP F-4-6
<I>
IMPELLER, PUMP F-4-1
IMPELLER, PUMP FOP-3-2
INJECTOR ASSY., FUEL E-14-1
INSULATOR E-18-20-29
INSULATOR COMP. E-18-20-28
INSULATOR, FUEL PIPE E-14-4
<J>
JOINT A, BREATHER F-3-2
JOINT ASSY(INLET) F-6-2
JOINT ASSY(OUTLET) F-6-3
JOINT SET E-18-20-7
JOINT, DRIVE F-11-14
JOINT, FUEL FEED HOSE E-18-10-1
JOINT, FUEL PIPE E-14-6
JOINT, FUEL PIPE E-18-20-37
JOINT, FUEL TUBE E-15-5
JOINT, WATER HOSE F-8-3
JOINT, WATER TUBE E-6-10-11
<K>
KEY, SPECIAL E-7-14
KEY, WOODRUFF F-4-27
KEY, WOODRUFF FOP-3-11
KIT, CABLE(NMEA)(6FT) FOP-11-1
KNOB, RECOIL STARTER F-13-1
<L>
LABEL, FUSE F-12-1
LABEL, OIL CAUTION F-12-7
LABEL, SIGP F-15-48
LABEL, WARNING OPERATOR(EU) F-12-8
LAMP ASSY., INDICATION F-15-40
LAMP ASSY., INDICATION(4-LED) FOP-6-18
LAMP ASSY., INDICATION(4-LED) FOP-6-1-11
LAMP ASSY., INDICATOR FOP-10-24
LAMP ASSY., INDICATOR FOP-10-1-16
LEVER SET E-21-16
LEVER, FASTENER F-3-24
LEVER, FASTENER F-8-15
LEVER, FREE THROTTLE F-15-28
LEVER, HAND F-15-3
LEVER, HANDLE LOCK F-15-1-3
LEVER, SHIFT FOP-10-6
LEVER, SHIFT FOP-10-1-5
LIFTER, FUEL PUMP E-2-13
LINE COMP., FUEL E-14-3
LINER, PUMP F-4-3
LINER, PUMP FOP-3-4
LINER, SWIVEL CASE F-10-13
LINK, THROTTLE F-2-3
LINKAGE, PIVOT F-2-1
<M>
MANIFOLD COMP., INLET E-14-9
MARK, CHANGE FOP-10-60
MARK, CHANGE FOP-10-1-67
MARK, EMBLEM F-15-47
MARK, EMERGENCY START(EU) F-12-9
MARK, EMERGENCY STOP F-15-44
MARK, EMERGENCY STOP(LOOSE PARTS) F-15-46
MARK, EMERGENCY SWITCH INDICATION(EU) FOP-10-58
MARK, EMERGENCY SWITCH INDICATION(EU) FOP-10-1-65
MARK, FAST IDLE F-15-43
MARK, FLUSH MOUNT FOP-4-4-19
MARK, FR. EMBLEM(TOHATSU) F-12-5
MARK, FR. EMBLEM(TOHATSU) F-12-6
MARK, FR.(BFT100) F-12-6
MARK, FR.(BFT80) F-12-5
MARK, HANDLE FLUSH MOUNT FOP-4-4-18
MARK, L. SIDE STRIPE F-12-4
MARK, R. SIDE STRIPE F-12-4
MARK, REMOTE CONTROL(A)(PANEL) F-15-1-31
MARK, REMOTE CONTROL(B) F-15-1-32
MARK, REMOTE CONTROL(C) F-15-1-32
MARK, REMOTE CONTROL(DUAL) FOP-4-2-24
MARK, REMOTE CONTROL(SINGLE) FOP-4-21
MARK, RR.(BFT100) F-12-3
MARK, RR.(BFT100) F-12-3

MARK, RR.(BFT80) F-12-2
MARK, RR.(BFT80) F-12-2
MARK, SIDE STRIPE F-12-4
MARK, START FOP-10-59
MARK, STARTER(ENGLISH) FOP-10-1-66
MARK, THROTTLE(ENGLISH/FRENCH) .. FOP-10-61
MARK, THROTTLE(ENGLISH/FRENCH) .. FOP-10-1-104
METAL COMP., ANODE F-3-10-11
METAL KIT, ANODE F-10-1
METAL, ANODE E-2-1
METER LEAD WIRE FOP-7-3
MOTION COMP., LOST E-2-9
MOTOR ASSY., POWER TILT F-11-4
MOTOR ASSY., STARTER E-21-1
MOUNT COMP., LOWER RUBBER F-3-18
MOUNT COMP., UPPER RUBBER F-10-7
<N>
NIPPLE, GREASE F-10-57
NIPPLE, SENSOR F-3-14
NIPPLE, SENSOR F-3-15
NUT FOP-6-2-17
NUT FOP-6-3-17
NUT FOP-6-4-17
NUT(1/4X20) F-15-1-41
NUT, 5MM F-15-59
NUT, 6MM(LOOSE PARTS) F-15-57
NUT, ADJUSTER ROD F-10-42
NUT, CASTLE, 18MM F-5-14
NUT, CLIP F-8-32
NUT, FLANGE CAP, 8MM E-3-23
NUT, FLANGE, 10MM F-10-43
NUT, FLANGE, 12MM F-3-37
NUT, FLANGE, 12MM F-10-39
NUT, FLANGE, 5MM FOP-6-3
NUT, FLANGE, 5MM FOP-6-1-2
NUT, FLANGE, 5MM FOP-6-2-16
NUT, FLANGE, 5MM FOP-6-3-16
NUT, FLANGE, 5MM FOP-6-4-16
NUT, FLANGE, 6MM E-14-18
NUT, FLANGE, 8MM E-14-17
NUT, HEX., 12MM F-10-62
NUT, HEX., 12MM FOP-10-73
NUT, HEX., 12MM FOP-10-95
NUT, HEX., 12MM FOP-10-1-78
NUT, HEX., 12MM FOP-10-1-101
NUT, HEX., 16MM F-4-22
NUT, HEX., 16MM F-8-33
NUT, HEX., 16MM F-15-58
NUT, HEX., 16MM FOP-6-23
NUT, HEX., 16MM FOP-6-1-16
NUT, HEX., 16MM FOP-10-72
NUT, HEX., 16MM FOP-10-1-77
NUT, HEX., 20MM F-2-28
NUT, HEX., 4MM FOP-12-8
NUT, HEX., 5MM F-2-43
NUT, HEX., 5MM FOP-4-29
NUT, HEX., 5MM FOP-4-35
NUT, HEX., 5MM FOP-4-2-33
NUT, HEX., 5MM FOP-4-2-34
NUT, HEX., 5MM FOP-4-2-40
NUT, HEX., 5MM FOP-10-71
NUT, HEX., 6MM FOP-4-4-25
NUT, HEX., 6MM FOP-10-94
NUT, HEX., 6MM FOP-10-1-100
NUT, LOCK, 64MM F-4-21
NUT, NYLON, 5MM FOP-10-1-80
NUT, SELF-LOCK(25X2.0) F-10-41
NUT, SELF-LOCK(3/8-24UNF) F-10-44
NUT, SELF-LOCK(7/8-14UNF) F-10-40
NUT, SELF-LOCK, 10MM F-3-10-24
NUT, SELF-LOCK, 5MM F-3-10-23
NUT, SELF-LOCK, 6MM F-3-10-21
NUT, SELF-LOCK, 8MM FOP-10-74
NUT, SELF-LOCK, 8MM FOP-10-1-79
NUT, TAPPET ADJUSTING E-9-27
NUT, TAPPET ADJUSTING E-9-28
NUT, WATER MOUTH F-8-2
NUT-WASHER, 8MM F-7-17
NUT-WASHER, 8MM F-7-10-22
<O>
O RING, 33X2.4 ..... E-2-45
OIL SEAL F-11-33
OIL SEAL, 39.5X52X6(ARAI) F-10-58
OIL SEAL, 40X55X7(NOK) E-9-10-13
OIL SEAL, 80X98X10(ARAI) E-3-25
O-RING E-15-12
O-RING E-18-10-11
O-RING E-18-20-11
O-RING E-18-20-12
O-RING E-18-20-14
O-RING E-18-20-15
O-RING E-18-20-16
O-RING F-4-33
O-RING SET, 3.5X31.7 ..... F-11-41
O-RING, 1.67X7.25 ..... F-11-37
O-RING, 1.8X69.6 ..... F-11-35
O-RING, 1.9X11 ..... F-11-38
O-RING, 11.5X3.5 ..... E-6-10-23
O-RING, 13X1.5(ARAI) E-3-29
O-RING, 15.54X2.62 ..... F-10-59
O-RING, 15.54X2.62 ..... FOP-10-91
O-RING, 15.54X2.62 ..... FOP-10-1-96
O-RING, 15.5X2.7 ..... E-6-15
O-RING, 15X1.9 ..... E-2-37
O-RING, 15X1.9 ..... E-9-10-14
O-RING, 16MM E-6-10-22
O-RING, 18.1X3.6 ..... E-3-26
O-RING, 2.0X70.5 ..... F-11-34
O-RING, 20.6X1.9 ..... FOP-10-90
O-RING, 20.6X1.9 ..... FOP-10-1-95
O-RING, 27X2(ARAI) F-2-41
O-RING, 28.3X2.4(NOK) E-3-30
O-RING, 3.5X35.7 ..... F-11-39
O-RING, 3.5X38.7 ..... F-11-36
O-RING, 3.5X41.7 ..... F-11-40
O-RING, 31.2X2.4 ..... E-18-23
O-RING, 58.5X3.5 ..... F-4-35
O-RING, 59.4X3.1 ..... E-21-22
O-RING, 6.5X1.5 ..... E-3-27
O-RING, 6.9X1.45 ..... F-3-10-30
O-RING, 7.45X3.61(NOK) E-14-21
O-RING, 7.47X3.6 ..... E-14-20
O-RING, 7.8X1.9(ARAI) E-14-19
O-RING, 7.8X1.9(ARAI) E-18-20-52
O-RING, 9.5X1.9 ..... E-2-36
O-RING, 9.5X1.9 ..... E-3-28
O-RING, 94X4.1 ..... F-5-24
O-RING, OIL PUMP E-5-15
O-RING, PRESSURE REGULATOR E-18-20-36
O-RING, PUMP COVER E-5-14
O-RING, THERMOSTAT COVER E-2-17
O-RING, THERMOSTAT COVER E-3-11
O-RING, THERMOSTAT COVER E-6-10-12
O-RING, WATER PUMP F-4-34
O-RING, WATER PUMP FOP-3-12
<P>
PACKING E-18-20-13
PACKING F-11-43
PACKING, DUAL FOP-4-2-19
PACKING, ELECTRONIC AIR CONTROL VALVE E-14-11
PACKING, EX. WATER JACKET COVER .. E-2-19
PACKING, FLASH VALVE E-6-10-10
PACKING, FUSE BOX COVER F-7-8
PACKING, HEAD COVER E-1-2
PACKING, INTAKE MANIFOLD E-14-7
PACKING, OIL PAN E-6-2
PACKING, REGULATOR E-2-21
PACKING, SINGLE FOP-4-18
PACKING, THERMOSTAT CASE E-3-35
PACKING, THROTTLE BODY E-14-8
PAD, THROTTLE FRICTION FOP-10-50
PAD, THROTTLE FRICTION FOP-10-1-56
PANEL ASSY, CONTROL(SINGLE) FOP-6-2-2
PANEL ASSY., CONTROL(TRIPLE) FOP-6-4-2
PANEL ASSY., CONTROL(TWIN) FOP-6-3-2
PANEL ASSY., INDICATOR(4-LED) FOP-6-17
PANEL ASSY., SWITCH FOP-6-5
PANEL ASSY., TROLLING CONTROL FOP-12-6
PANEL KIT, SWITCH(4-LED) FOP-6-1-1
PANEL KIT, SWITCH(B)(4-LED) FOP-6-1
PANEL KIT, SWITCH(SINGLE) FOP-6-2-1
PANEL KIT, SWITCH(TRIPLE) FOP-6-4-1
PANEL KIT, SWITCH(TWIN) FOP-6-3-1
PANEL, BACK F-15-14
PANEL, CONTROL FOP-6-6
PANEL, CONTROL FOP-6-7
PANEL, CONTROL FOP-6-1-3
PANEL, CONTROL(SINGLE) FOP-6-2-3
PANEL, CONTROL(TRIPLE) FOP-6-4-3
PANEL, CONTROL(TWIN) FOP-6-3-3
PIN A, DOWEL, 7X12 ..... E-9-29
PIN, 5X44.5 ..... F-3-41
PIN, 5X59 ..... F-8-38
PIN, GEARSHIFT F-15-1-45
PIN, LINK F-2-37
PIN, LINK F-2-39
PIN, PISTON E-7-3
PIN, SHIFT LINK F-2-38
PIN, SHIFTER, 8X47 ..... F-5-2
PIN, SLIDE FOP-10-1-39
PIN, SNAP, 6MM F-2-36
PIN, SPLIT, 2.0 ..... FOP-10-86
PIN, SPLIT, 2.0 ..... FOP-10-1-91
PIN, SPLIT, 4.0 ..... F-5-18
PIN, SPRING, 2.0X12 ..... F-8-37
PIN, SPRING, 2.5X20 ..... F-10-56
PIN, THROTTLE CABLE FOP-10-30
PIN, UPPER CYLINDER F-11-24
PIPE COMP., OIL LEVEL E-6-10-1
PIPE, BREATHER E-15-1
PIPE, GRIP FOP-10-51
PIPE, OIL E-3-7
PIPE, THROTTLE GRIP FOP-10-1-57
PISTON COMP., FREE F-11-20
PISTON(0.25) E-7-2
PISTON(STD.) E-7-2
PIVOT, SHIFT F-2-13
PIVOT, SHIFT SLIDE F-2-14
PIVOT, THROTTLE CABLE FOP-10-3
PLATE E-18-10-12
PLATE ASSY. F-15-2
PLATE ASSY., LOCK FOP-10-33
PLATE COMP., SPLASH F-10-19
PLATE COMP., THROTTLE F-2-4
PLATE KIT, SPLASH F-10-2
PLATE, BALL GUIDE FOP-10-45
PLATE, BALL GUIDE FOP-10-1-41
PLATE, CABLE CLAMP FOP-4-11
PLATE, CABLE CLAMP FOP-4-2-12
PLATE, DWELL FOP-4-15
PLATE, DWELL FOP-4-2-16
PLATE, DWELL FOP-4-4-10
PLATE, GUIDE FOP-10-35
PLATE, HANDLE FOP-4-10
PLATE, HANDLE FOP-4-2-11
PLATE, HARNESS FOP-10-1-55
PLATE, LOCK F-2-15
PLATE, LOCK FOP-10-1-25
PLATE, REMOTE CONTROL CABLE F-2-5
PLATE, REMOTE CONTROL(REVERSE) .. F-15-78
PLATE, RUBBER SETTING F-3-10-1
PLATE, SHIFT F-5-7
PLATE, SHIFT CLAMP FOP-10-1-47
PLATE, SHIFT PIVOT F-2-12
PLATE, SPEED SENSOR TUBE F-3-22
PLATE, STEERING F-10-23
PLATE, SWITCH F-15-36
PLATE, SWITCH FOP-10-1-13
PLATE, TDC PULSER E-9-3
PLATE, WATER TUBE E-6-6
PLATE, WINKER BUZZER F-15-41
PLATE, WINKER BUZZER FOP-6-19
PLATE, WINKER BUZZER FOP-6-1-12
PLUG, INNER CONNECTOR F-15-31
PLUG, INNER CONNECTOR FOP-6-10
PLUG, INNER CONNECTOR FOP-6-1-5
PLUG, INNER CONNECTOR FOP-6-2-6
PLUG, INNER CONNECTOR FOP-6-3-6
PLUG, INNER CONNECTOR FOP-6-4-6
PLUG, INNER CONNECTOR FOP-10-16
PLUG, INNER CONNECTOR FOP-11-3
PLUG, OUTER CONNECTOR F-15-32
PLUG, OUTER CONNECTOR FOP-6-11
PLUG, OUTER CONNECTOR FOP-6-1-6
PLUG, OUTER CONNECTOR FOP-6-2-7
PLUG, OUTER CONNECTOR FOP-6-3-7
PLUG, OUTER CONNECTOR FOP-6-4-7
PLUG, OUTER CONNECTOR FOP-11-4
PLUG, SPARK(IZFR6K-11E) E-20-2
PLUG, SPARK(ZFR6K-9E) E-20-2
PORT, IDLE EXHAUST F-8-1
PRIMER BULB F-6-4
PRIMER BULB ASSY F-6-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1

PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PROPELLER COMP., THREE BLADES FOP-8-1
PULLER, MINI FUSE(SUMITOMO) F-13-4
PUMP ASSY KIT, FUEL E-18-1
PUMP ASSY. F-11-12
PUMP ASSY., FUEL E-18-7
PUMP ASSY., OIL E-5-1
PUMP KIT, IMPELLER FOP-3-1
PUMP KIT, IMPELLER FOP-3-14
PUMP UNIT, FUEL E-18-20-34
PUMP UNIT, FUEL(A) E-18-20-3
PUMP UNIT, FUEL(B) E-18-20-8
<R>
RECEIVER, THRUST F-10-25
RECTIFIER ASSY., REGULATOR E-2-20
REGULATOR ASSY., PRESSURE E-18-20-35
RELAY ASSY., MAIN F-7-10-15
RELAY ASSY., POWER TILT F-7-10-12
RETAINER F-15-1-13
RETAINER, VALVE SPRING E-9-21
RING E-18-20-30
RING SET, PISTON(0.25) E-7-1
RING SET, PISTON(STD.) E-7-1
RING, BACK UP F-11-17
RING, CROSS PIN F-5-3
RING, STOPPER F-4-13
RING, WATER TUBE SEAL F-4-9
RING, WATER TUBE SEAL FOP-3-8
ROD A COMP., SHIFT(L) F-4-12
ROD A COMP., SHIFT(XL) F-4-12
ROD COMP., CONNECTING E-7-5
ROD COMP., PISTON F-11-47
ROD COMP., PISTON(B) F-11-13
ROD COMP., SHIFT(L) F-4-10
ROD COMP., THROTTLE F-2-2
ROD, ADJUSTING F-10-17
ROD, GROMMET FOP-10-47
ROD, STEERING F-10-24
ROD, STEERING FRICTION FOP-10-56
ROD, STEERING FRICTION FOP-10-1-63
ROLLER F-15-70
ROLLER FOP-10-41
ROLLER FOP-10-1-37
ROLLER, 3X12.8 ..... F-5-22
ROLLER, 5X17.8 ..... E-5-16
ROLLER, CAM FOP-10-1-45
ROLLER, DRIVE GEAR CAM F-15-69
ROLLER, FREE THROTTLE F-15-73
ROLLER, PLATE FOP-10-1-44
ROLLER, SHIFT CLICK F-15-1-47
ROPE, RECOIL STARTER(1300MM) F-13-2
ROTOR E-19-3
ROTOR COMP. E-21-5
ROTOR, INNER E-5-8
ROTOR, OUTER E-5-9
RUBBER, FENDER MOUNTING F-8-12
RUBBER, GRIP FOP-10-52
RUBBER, GRIP FOP-10-1-59
RUBBER, RING E-2-42
RUBBER, RING E-3-32
RUBBER, SEAT SIDE F-8-20
RUBBER, TROLLING CONTROL SWITCH PANEL FOP-12-2
RUBBER, UPPER MOUNT STOPPER F-10-8
<S>
SCREEN COMP., FUEL STRAINER E-18-20-40
SCREEN, L. WATER F-3-10-9
SCREEN, R. WATER F-3-10-8
SCREW FOP-10-15
SCREW A F-15-1-33
SCREW B F-15-1-34
SCREW C F-15-1-35
SCREW SET E-15-2
SCREW SET, DRAIN E-18-20-6
SCREW(10-32X3/8) F-15-1-39
SCREW(10-32X5/8) F-15-1-40
SCREW(8-32X3/8) F-15-1-38
SCREW(M5X14) FOP-10-43
SCREW, 4X10 ..... F-15-52
SCREW, 4X6 ..... F-15-50
SCREW, 5X10 ..... F-15-51
SCREW, 5X12 ..... F-15-53
SCREW, 5X18 ..... F-15-49
SCREW, 6X90(LOOSE PARTS) F-15-54
SCREW, FLAT, 5X14 ..... FOP-10-1-72
SCREW, FLAT, 5X55 ..... F-3-10-13
SCREW, FRICTION F-15-1-36
SCREW, PAN E-18-20-19
SCREW, PAN, 4X10 ..... FOP-4-26
SCREW, PAN, 4X10 ..... FOP-4-2-29
SCREW, PAN, 5X10 ..... FOP-4-23
SCREW, PAN, 5X10 ..... FOP-4-2-26
SCREW, PAN, 5X12 ..... E-18-10-8
SCREW, PAN, 5X14 ..... FOP-10-1-99
SCREW, PAN, 5X16 ..... FOP-4-22
SCREW, PAN, 5X16 ..... FOP-4-2-25
SCREW, PAN, 5X16 ..... FOP-4-4-20
SCREW, PAN, 5X18 ..... E-15-16
SCREW, PAN, 5X18 ..... FOP-4-25
SCREW, PAN, 5X18 ..... FOP-4-2-28
SCREW, PAN, 5X20 ..... FOP-4-24
SCREW, PAN, 5X20 ..... FOP-4-2-27
SCREW, PAN, 5X30 ..... FOP-4-4-22
SCREW, PAN, 5X40 ..... FOP-4-28
SCREW, PAN, 5X40 ..... FOP-4-2-31
SCREW, PAN, 5X40 ..... FOP-6-22
SCREW, PAN, 5X40 ..... FOP-6-1-15
SCREW, PAN, 5X40 ..... FOP-6-2-15
SCREW, PAN, 5X40 ..... FOP-6-3-15
SCREW, PAN, 5X40 ..... FOP-6-4-15
SCREW, PAN, 5X55 ..... FOP-4-2-32
SCREW, PAN, 5X65 ..... FOP-4-34
SCREW, PAN, 5X65 ..... FOP-4-2-39
SCREW, PAN, 5X8 ..... E-21-20
SCREW, PAN, 6X18 ..... E-2-39
SCREW, PAN, 6X18 ..... FOP-4-27
SCREW, PAN, 6X18 ..... FOP-4-2-30
SCREW, PAN, 6X22 ..... E-21-7
SCREW, PAN, 6X35 ..... FOP-4-4-23
SCREW, PAN, 6X8 ..... F-3-34
SCREW, PAN, 6X8 ..... F-3-35
SCREW, PAN, 6X8 ..... F-11-31
SCREW, RIVET, 5X10 ..... F-3-36
SCREW, RIVET, 5X10 ..... F-8-29
SCREW, TAPPET ADJUSTING E-9-18
SCREW, TAPPING, 6X30 ..... FOP-4-4-24
SCREW, TRUSS, 4X12 ..... FOP-4-4-21
SCREW, WASHER E-18-20-21
SCREW-WASHER E-18-20-17
SCREW-WASHER E-18-20-18
SCREW-WASHER E-18-20-20
SCREW-WASHER, 3X7 ..... F-7-14
SCREW-WASHER, 5X10 ..... F-7-16
SEAL A, COVER UNDER E-6-10-14
SEAL A, VALVE STEM(NOK) E-2-4
SEAL B, COVER UNDER F-3-27
SEAL B, VALVE STEM(NOK) E-2-6
SEAL, ENGINE COVER F-8-14
SEAL, RUBBER F-15-19
SEAL, UPPER MOUNT COVER F-10-11
SEAL, WATER F-11-42
SEAL, WATER CHECK GROMMET F-8-23
SEAL, WATER, 12X21X6 ..... F-4-32
SEAL, WATER, 22X35X7 ..... E-6-10-21
SEAL, WATER, 23X36X6 ..... F-4-31
SEAL, WATER, 30X45X7 ..... F-5-23
SEAT, VALVE SPRING E-9-22
SEAT, WATER MOUTH F-8-4
SENSOR ASSY., AIR TEMP E-15-13
SENSOR ASSY., AIR TEMPERATURE E-15-13
SENSOR ASSY., CRANK E-9-10-5
SENSOR ASSY., MAP E-15-11
SENSOR ASSY., TDC E-2-25
SENSOR ASSY., TRIM ANGLE F-10-5
SENSOR ASSY., WATER TEMPERATURE . E-2-24
SENSOR ASSY., WATER TEMPERATURE . E-3-13
SENSOR COMP., KNOCK E-3-12
SENSOR, OIL PRESSURE E-3-14
SENSOR, OXYGEN E-2-23
SEPARATOR ASSY., VAPOR E-18-20-31
SEPARATOR ASSY., WATER E-18-10-2
SEPARATOR, EXTENSION(XL) F-3-10-2
SHAFT ASSY., CLUTCH E-21-14
SHAFT ASSY., GEAR E-21-15
SHAFT ASSY., PROPELLER F-5-10
SHAFT ASSY., THROTTLE FOP-10-1-29
SHAFT COMP., ROCKER ARM E-9-13
SHAFT COMP., SHIFT F-2-18
SHAFT, GEAR SHIFT F-15-1-19
SHAFT, HANDLE F-15-1-17
SHAFT, OIL PUMP E-5-3
SHAFT, PROPELLER F-5-11
SHAFT, STEERING FRICTION FOP-10-57
SHAFT, STEERING FRICTION FOP-10-1-64
SHAFT, THROTTLE BUTTON FOP-4-4-9
SHAFT, TILTING F-10-18
SHAFT, VERTICAL(L) F-4-16
SHAFT, VERTICAL(UL) F-4-16
SHIFTER, CLUTCH F-5-1
SHIM A, BEVEL(FR.)(0.10) F-5-17
SHIM A, GEAR(0.10) F-4-26
SHIM B, BEVEL(FR.)(0.15) F-5-17
SHIM B, GEAR(0.15) F-4-26
SHIM C, BEVEL(FR.)(0.30) F-5-17
SHIM C, GEAR(0.30) F-4-26
SHIM D, BEVEL(FR.)(0.50) F-5-17
SHIM D, GEAR(0.50) F-4-26
SLIDER COMP., CAM CHAIN TENSIONER E-9-11
SLIDER COMP., SHIFT F-5-4
SLIDER, SHIFT F-5-5
SLINGER, OIL F-4-17
SPACER FOP-10-1-28
SPACER KIT, REMOTE CONTROL BOX .. FOP-4-2
SPACER KIT, REMOTE CONTROL BOX .. FOP-4-2-2
SPACER(1)(LOOSE PARTS) F-15-10
SPACER(2)(LOOSE PARTS) F-15-67
SPACER, CABLE CLAMP FOP-4-17
SPACER, CABLE CLAMP FOP-4-2-18
SPACER, CABLE CLAMP FOP-4-4-13
SPANNER, 8X10 ..... F-13-5
SPRING FOP-10-1-34
SPRING COMP., CLICK F-2-9
SPRING COMP., CLICK F-10-3
SPRING(1) F-15-27
SPRING(2) F-15-8
SPRING, CLICK ASSIST F-2-10
SPRING, CLICK ASSIST F-10-4
SPRING, COIL FOP-10-40
SPRING, COMPRESSION E-18-20-41
SPRING, DETENT F-15-29
SPRING, EX. VALVE E-9-20
SPRING, FLUSH VALVE E-6-10-6
SPRING, GEAR SHIFT F-15-1-20
SPRING, IN. VALVE E-9-19
SPRING, MOTOR F-11-8
SPRING, NEUTRAL LOCK ARM FOP-4-4-7
SPRING, RELIEF VALVE E-5-5
SPRING, REMOTE CONTROL HANDLE .. F-15-1-5
SPRING, SHIFT F-5-6
SPRING, SHIFT CLICK F-15-1-24
SPRING, SHIFT ROD F-4-11
SPROCKET, CAM CHAIN DRIVEN E-9-2
SPROCKET, CAM CHAIN(23T) E-7-11
STATOR E-19-4
STAY FOP-10-1-46
STAY, FUEL TUBE E-18-20-33
STAY, POWER TILT SWITCH F-8-7
STOPPER FOP-10-34
STOPPER ASSY., ENGINE SIDE F-8-11
STOPPER SET, SLEEVE E-21-9
STOPPER, LOWER MOUNT F-3-20
STOPPER, SHIFT FOP-10-1-26
STOPPER, TILT F-10-22
STOPPER, UPPER MOUNT F-10-9
STRAINER COMP., FUEL E-18-15
STRAINER COMP., FUEL E-18-10-9
STRAINER COMP., OIL E-6-3
STRAP, HARNESS(30)(BLACK) F-7-22
SUB HARNESS ASSY., POWER TRIM-TILT(A) FOP-4-19
SUB HARNESS ASSY., POWER TRIM-TILT(A) FOP-4-2-20
SUB HARNESS ASSY., POWER TRIM-TILT(B) FOP-4-2-21
SUB HARNESS ASSY., POWER TRIM-TILT(C) FOP-4-4-16
SUSPENSION, AUDIBLE PILOT FOP-6-2-12
SUSPENSION, AUDIBLE PILOT FOP-6-3-12

SUSPENSION, AUDIBLE PILOT FOP-6-4-12
SUSPENSION, COUPLER F-7-5
SUSPENSION, STRAINER E-18-10-10
SUSPENSION, WARNING BUZZER FOP-10-26
SUSPENSION, WARNING BUZZER FOP-10-1-18
SWITCH ASSY., COMBINATION F-15-33
SWITCH ASSY., COMBINATION FOP-6-13
SWITCH ASSY., COMBINATION FOP-6-1-7
SWITCH ASSY., COMBINATION FOP-6-2-8
SWITCH ASSY., COMBINATION FOP-6-3-8
SWITCH ASSY., COMBINATION FOP-6-4-8
SWITCH ASSY., COMBINATION FOP-10-17
SWITCH ASSY., COMBINATION FOP-10-1-9
SWITCH ASSY., EMERGENCY STOP F-15-38
SWITCH ASSY., EMERGENCY STOP F-15-1-28
SWITCH ASSY., EMERGENCY STOP FOP-6-14
SWITCH ASSY., EMERGENCY STOP FOP-6-1-8
SWITCH ASSY., EMERGENCY STOP FOP-10-21
SWITCH ASSY., EMERGENCY STOP FOP-10-1-10
SWITCH ASSY., EMERGENCY STOP (TWIN) FOP-6-3-9
SWITCH ASSY., EMERGENCY STOP (SINGLE) FOP-6-2-9
SWITCH ASSY., EMERGENCY STOP(TRIPLE) FOP-6-4-9
SWITCH ASSY., MAGNET E-21-13
SWITCH ASSY., NEUTRAL F-2-19
SWITCH ASSY., POWER TILT F-8-6
SWITCH ASSY., POWER TILT FOP-10-18
SWITCH ASSY., POWER TILT FOP-10-1-12
SWITCH ASSY., POWER TRIM-TILT F-15-35
SWITCH ASSY., POWER TRIM-TILT (A) .. F-15-1-30
SWITCH ASSY., POWER TRIM-TILT (A) .. FOP-4-20
SWITCH ASSY., POWER TRIM-TILT(A) ... FOP-4-2-22
SWITCH ASSY., POWER TRIM-TILT(B) ... FOP-4-2-23
SWITCH ASSY., POWER TRIM-TILT(C) ... FOP-4-4-17
SWITCH ASSY., TROLLING CONTROL ... FOP-10-1-11
SWITCH ASSY., TROLLING CONTROL ... FOP-12-1
<T>
TAB, TRIM F-3-10-10
TACHOMETER HOUR METER FOP-7-2
TACHOMETER HOUR METER FOP-7-2
TANK, OIL F-11-25
TENSIONER COMP., CAM CHAIN E-9-10
TERMINAL, CABLE FOP-4-16
TERMINAL, CABLE FOP-4-2-17
TERMINAL, CABLE FOP-4-4-12
TERMINAL, CABLE (LOOSE PARTS) F-15-25
THERMOSTAT ASSY. E-2-15
THERMOSTAT ASSY. E-3-9
THROTTLE BODY ASSY. E-15-3
TIE, CABLE FOP-11-5
TIE, CABLE(NATURAL)(2.4X92) FOP-6-12
T-JOINT E-18-16
TRIM METER ASSY FOP-7-1
TRIM METER ASSY FOP-7-1
TRIM-TILT ASSY., POWER F-11-11
TUBE FOP-10-9
TUBE A, AIR VENT E-18-4
TUBE A, BREATHER E-15-21
TUBE A, CHECK VALVE E-18-2
TUBE A, WATER E-18-20-43
TUBE B, AIR VENT E-18-5
TUBE B, BREATHER E-15-22
TUBE B, CHECK VALVE E-18-3
TUBE B, WATER E-6-10-4
TUBE C, AIR VENT E-18-6
TUBE C, BREATHER E-15-23
TUBE C, FUEL E-18-10-7
TUBE COMP. A, FUEL E-18-10-5
TUBE COMP. B, FUEL E-18-10-6
TUBE D, FUEL E-18-11
TUBE E, FUEL E-18-12
TUBE KIT, SPEED SENSOR F-3-1
TUBE(38.1X40) FOP-10-8
TUBE, 5X950 ..... F-3-46
TUBE, 7X110 ..... E-6-10-25
TUBE, CORD, 30MM FOP-10-1-97
TUBE, CORD, 40MM FOP-10-92
TUBE, CORRUGATE(28MM) F-15-76
TUBE, FUEL, 3.5X120 ..... E-18-20-54
TUBE, FUEL, 8X300 ..... F-8-43
TUBE, OIL E-1-3
TUBE, SPEED SENSOR F-3-16
TUBE, SPIRAL F-3-5
TUBE, SPIRAL(12X14.6) F-11-3
TUBE, VINYL, 4X7X190 ..... E-15-25
TUBE, VINYL, 5X9X240 ..... E-18-20-55
TUBE, WATER CHECK E-6-10-24
TUBE, WATER(L) F-4-8
TUBE, WATER(XL) F-4-8
<V>
VALVE ASSY., ELECTRONIC AIR CONTROL E-14-10
VALVE ASSY., RELIEF E-6-10-7
VALVE ASSY., SPOOL E-2-10
VALVE COMP., MANUAL F-11-21
VALVE COMP., RESERVOIR F-11-22
VALVE SET, FLOAT E-18-20-1
VALVE, CHECK E-18-17
VALVE, EX E-9-17
VALVE, FLASH E-6-10-8
VALVE, IN E-9-16
VALVE, RELIEF E-5-4
<W>
WASHER F-15-1-42
WASHER F-15-1-43
WASHER FOP-10-1-82
WASHER FOP-10-1-84
WASHER(3) F-15-61
WASHER(4) F-15-62
WASHER(5) F-15-63
WASHER(7)(LOOSE PARTS) F-15-65
WASHER, 10MM F-10-48
WASHER, 10MM FOP-10-78
WASHER, 10MM FOP-10-81
WASHER, 10MM FOP-10-1-88
WASHER, 13MM F-2-33
WASHER, 14MM F-2-32
WASHER, 26MM F-3-10-25
WASHER, 5MM FOP-10-76
WASHER, 5MM FOP-10-79
WASHER, 5MM FOP-10-1-86
WASHER, 8MM F-4-25
WASHER, 8MM F-15-64
WASHER, 8MM FOP-3-10
WASHER, 8MM FOP-10-77
WASHER, 8MM FOP-10-1-83
WASHER, DRAIN PLUG, 12MM E-6-13
WASHER, DRAIN PLUG, 20MM E-2-40
WASHER, IN. WAVE E-9-15
WASHER, LOCK, 5MM FOP-4-30
WASHER, LOCK, 5MM FOP-4-2-35
WASHER, LOCK, 5MM FOP-4-4-26
WASHER, LOCK, 6MM FOP-4-32
WASHER, LOCK, 6MM FOP-4-2-37
WASHER, PIVOT F-2-8
WASHER, PLAIN E-18-20-22
WASHER, PLAIN, 10MM F-3-10-27
WASHER, PLAIN, 10MM F-3-10-27
WASHER, PLAIN, 10MM F-10-49
WASHER, PLAIN, 10MM F-10-53
WASHER, PLAIN, 12MM F-3-38
WASHER, PLAIN, 12MM F-4-23
WASHER, PLAIN, 12MM F-10-50
WASHER, PLAIN, 12MM F-10-51
WASHER, PLAIN, 12MM F-10-52
WASHER, PLAIN, 12MM FOP-10-82
WASHER, PLAIN, 12MM FOP-10-83
WASHER, PLAIN, 12MM FOP-10-1-89
WASHER, PLAIN, 12MM FOP-10-1-90
WASHER, PLAIN, 18.5MM F-5-16
WASHER, PLAIN, 5MM FOP-4-31
WASHER, PLAIN, 5MM FOP-4-33
WASHER, PLAIN, 5MM FOP-4-2-36
WASHER, PLAIN, 5MM FOP-4-2-38
WASHER, PLAIN, 5MM FOP-6-25
WASHER, PLAIN, 5MM FOP-6-1-18
WASHER, PLAIN, 5MM FOP-6-2-18
WASHER, PLAIN, 5MM FOP-6-3-18
WASHER, PLAIN, 5MM FOP-6-4-18
WASHER, PLAIN, 6MM E-15-20
WASHER, PLAIN, 6MM F-2-31
WASHER, PLAIN, 6MM F-4-24
WASHER, PLAIN, 6MM F-8-34
WASHER, PLAIN, 6MM FOP-4-4-27
WASHER, PLAIN, 8MM F-2-34
WASHER, PLAIN, 8MM F-3-10-26
WASHER, PLAIN, 8MM F-7-10-23
WASHER, PLAIN, 8MM FOP-10-75
WASHER, PLAIN, 8MM FOP-10-1-81
WASHER, PLATE FOP-10-1-85
WASHER, PROPELLER THRUST F-5-15
WASHER, SEALING, 18MM E-5-6
WASHER, SEALING, 24MM E-3-2
WASHER, SEALING, 6MM E-18-20-50
WASHER, SHIFT SHAFT F-2-30
WASHER, SIDE, 14MM F-2-29
WASHER, SPRING, 4MM FOP-12-9
WASHER, SPRING, 5MM FOP-6-26
WASHER, SPRING, 5MM FOP-6-1-19
WASHER, SPRING, 5MM FOP-6-2-19
WASHER, SPRING, 5MM FOP-6-3-19
WASHER, SPRING, 5MM FOP-6-4-19
WASHER, THRUST E-7-9
WASHER, THRUST E-9-14
WASHER, THRUST, 13MM E-5-13
WASHER, THRUST, 34MM F-10-47
WASHER, WAVE F-15-66
WASHER, WAVE, 14MM FOP-10-80
WASHER, WAVE, 14MM FOP-10-1-87
WASHER, WAVE, 26MM F-10-46
WASHER, WAVE, 40MM F-10-45
WATER SEAL, 14X26X6 ..... F-2-40
WHEEL, CONTROL F-15-1-16
WIRE, FASTENER F-3-25
WIRE, FASTENER F-8-16
WIRE, LEAD(1.5X116MM) F-11-9
WIRE, LEAD(1.5X137MM) F-3-13
WRENCH, BOX(P18X19) F-13-9
WRENCH, PLUG F-13-6
<Y>
YOKE ASSY. F-11-7
YOKE COMP. E-21-4

INDEX (Parts Number)

332-70201-0 . . . . . .F-6-8
3C7-70211-1 . . . . . .F-6-4
3C7-70217-0 . . . . . .F-6-5
3C7-70220-1 . . . . . .F-6-2
3C7-70224-1 . . . . . .F-6-3
3PU-72537-0 . . . . . .FOP-7-3
3PU-72571-0 . . . . . .FOP-7-1
3PU-72637-0 . . . . . .FOP-7-2
3PV-72571-0 . . . . . .FOP-7-1
3PV-72637-0 . . . . . .FOP-7-2
3T1-70200-1 . . . . . .F-6-1
98AB-701600. . . . . .F-6-7
98AB-70-700 . . . . . .F-6-6
H341-38403-672. . . . . .F-15-41
H341-38403-672. . . . . .FOP-6-19
H341-38403-672. . . . . .FOP-6-1-12
H723-90472-000. . . . . .F-4-23
H750-90628-000. . . . . .F-3-39
H763-90681-A01 . . . . .E-20-10-7
H763-90681-A01 . . . . .F-10-55
H800-91303-000. . . . . .E-6-10-22
H881-90110-000. . . . . .F-10-33
H921-17936-000. . . . . .F-2-8
H921-90302-000. . . . . .F-8-33
H921-90302-000. . . . . .F-15-58
H921-90302-000. . . . . .FOP-6-23
H921-90302-000. . . . . .FOP-6-1-16
H921-90302-000. . . . . .FOP-10-72
H921-90302-000. . . . . .FOP-10-1-77
H921-90511-000. . . . . .F-10-49
H921-90514-000. . . . . .F-4-25
H921-90514-000. . . . . .FOP-3-10
H921-90518-000. . . . . .F-2-34
H952-32901-770. . . . . .FOP-6-12
H965-77212-000. . . . . .F-8-20
HCO-92101-04020-4J. . .FOP-12-7
HCO-93500-05014-4J. . .FOP-10-1-99
HCO-93500-05065-4J. . .FOP-4-34
HCO-93500-05065-4J. . .FOP-4-2-39
HCO-93500-06018-4J. . .E-2-39
HCO-94001-04490-0S . .FOP-12-8
HCO-94001-05490-0S . .F-2-43
HCO-94001-05490-0S . .FOP-4-35
HCO-94001-05490-0S . .FOP-4-2-40
HCO-94001-12490-0S . .F-10-62
HCO-94002-06490-0S . .FOP-10-94
HCO-94002-06490-0S . .FOP-10-1-100
HCO-94002-12490-0S . .FOP-10-95
HCO-94002-12490-0S . .FOP-10-1-101
HCO-94103-05400 . . . .FOP-6-25
HCO-94103-05400 . . . .FOP-6-1-18
HCO-94109-20000 . . . .E-2-40
HCO-94111-04500 . . . .FOP-12-9
HCO-94111-05400 . . . .FOP-6-26
HCO-94111-05400 . . . .FOP-6-1-19
HCO-94301-06100 . . . .E-6-17
HCO-94301-07120 . . . .E-9-29
HCO-94301-14200 . . . .E-2-41
HCO-94510-14000 . . . .F-5-25
HCO-94540-04029 . . . .F-2-44
HCO-94540-04029 . . . .F-3-45
HCO-94540-04029 . . . .FOP-10-1-102
HCO-94540-06029 . . . .F-2-45
HCO-94540-06029 . . . .FOP-4-36
HCO-94540-06029 . . . .FOP-4-2-41
HCO-94540-06029 . . . .FOP-4-4-28
HCO-94540-07029 . . . .FOP-10-1-103
HCO-94540-10019 . . . .F-4-37
HCO-94540-12029 . . . .F-2-46
HCO-94540-15029 . . . .F-11-45
HCO-95001-35120-40 . .E-18-20-54
HCO-95001-80300-40 . .F-8-43
HCO-95003-07019-31 . .E-15-25
HCO-95003-11024-31 . .E-18-20-55
HCO-95005-50950-30 . .F-3-46
HCO-95005-70110-30 . .E-6-10-25
HCO-96100-62080-00 . .F-5-26
HCO-96211-07000 . . . .F-5-27
HCO-96211-11000 . . . .F-5-28
HCO-96220-50178 . . . .E-5-16
HCO-96300-06014-09 . .E-3-31
HCO-96300-06014-09 . .E-9-30
HCO-96300-06016-09 . .E-6-18
HCO-96300-06028-09 . .E-9-31
HCO-96300-08100-09 . .E-6-19
HCO-96300-08120-09 . .E-6-20
HCO-9807B-5617C E-20-2
HCO-98200-41000 . . . .F-7-23
HCO-98200-41500 . . . .F-7-24
HCO-98200-43000 . . . .F-7-25
HCO-99003-10000 . . . .F-13-7
HCO-99003-50000 . . . .F-13-8
HCO-99004-18190 . . . .F-13-9
HCO-99008-02000 . . . .F-13-10
HGC1-38402-000 . . . . .FOP-6-2-12
HGC1-38402-000 . . . . .FOP-6-3-12
HGC1-38402-000 . . . . .FOP-6-4-12
HGE1-17357-670 . . . . .F-3-2
HGET-90429-000. . . . . .F-2-29
HGHB-16163-600 . . . . .E-6-10-2
HGHB-16163-610 . . . . .E-18-20-23
HGJ5-80103-000. . . . . .F-8-21
HHP5-91304-601 . . . . .FOP-10-90
HHP5-91304-601 . . . . .FOP-10-1-95
HHW1-90114-671 . . . . .E-6-10
HHW1-90118-671 . . . . .FOP-10-70
HHW1-90118-671 . . . . .FOP-10-1-76
HHW1-90120-671 . . . . .E-3-22
HHW1-90120-671 . . . . .E-6-11
HHW1-90214-671 . . . . .F-10-37
HHW1-90215-671 . . . . .F-10-38
HHW1-90225-670 . . . . .F-3-10-22
HKF0-91305-003. . . . . .F-2-41
HKM3-32161-003 . . . . .F-3-3
HKV6-90651-003. . . . . .F-7-10-2
HMAL-91302-601 . . . . .E-3-26
HMB0-91359-000 . . . . .F-4-35
HMB6-61102-631 . . . . .F-8-12
HMC7-90456-000 . . . . .E-5-13
HMG9-35701-950 . . . . .F-3-4
HMG9-91058-681 . . . . .F-15-77
HMJ0-91301-003 . . . . .E-14-19
HMJ0-91301-003 . . . . .E-18-20-52
HMJ0-91308-003 . . . . .F-4-33
HMJ6-32660-710 . . . . .F-7-10-8
HMR5-16966-000 . . . . .E-15-5
HMT8-18334-770 . . . . .FOP-6-3
HMT8-18334-770 . . . . .FOP-6-1-2
HMY5-91005-601 . . . . .F-5-19
HP08-14775-000. . . . . .E-9-22
HP2A-37881-000 . . . . .E-15-14
HP3F-36533-A01. . . . . .E-18-18
HPC6-15234-000. . . . . .E-5-6
HPC6-91310-004. . . . . .E-6-15
HPD2-90701-000 . . . . .E-3-24
HPD6-90430-003 . . . . .E-18-20-50
HPE0-15231-000. . . . . .E-5-4
HPF4-91324-004. . . . . .E-3-30
HPG6-15232-000 . . . . .E-5-5
HPG7-16741-005 . . . . .E-18-20-36
HPGK-37835-A01 . . . . .E-15-12
HPH1-90015-013 . . . . .E-3-16
HPH3-16638-S00 . . . . .E-14-4
HPH7-90704-000 . . . . .E-7-14
HPJ7-12204-305 . . . . .E-2-2
HPJ7-12205-305 . . . . .E-2-3
HPJ7-91309-010 . . . . .E-6-10-23
HPLC-37880-004. . . . . .E-15-13
HPLC-91301-000. . . . . .E-14-20
HPM3-14744-000 . . . . .E-9-18
HPM3-90206-004 . . . . .E-9-27
HPN4-19526-000 . . . . .E-18-10-14
HPNA-90003-000 . . . . .E-9-24
HPNA-91214-014 . . . . .E-3-25
HPNA-91302-003 . . . . .E-14-21
HPNA-91307-003 . . . . .E-2-36
HPNA-91307-003 . . . . .E-3-28
HPNA-91333-003 . . . . .E-2-37
HPNA-91333-003 . . . . .E-9-10-14
HPNB-37500-003 . . . . .E-9-10-5
HPP4-90009-E01. . . . . .E-18-20-46
HPR3-91319-003. . . . . .E-3-29
HPT0-90206-004. . . . . .E-9-28
HPWA-11106-300 . . . . .E-3-1
HPWA-11107-300 . . . . .E-3-2
HPWA-13111-000 . . . . .E-7-3
HPWA-13204-003 . . . . .E-7-4
HPWA-13211-003 . . . . .E-7-6
HPWA-13212-003 . . . . .E-7-6
HPWA-13213-003 . . . . .E-7-6
HPWA-13214-003 . . . . .E-7-6
HPWA-13215-003 . . . . .E-7-6
HPWA-13216-003 . . . . .E-7-6
HPWA-13217-003 . . . . .E-7-6
HPWA-13322-003 . . . . .E-7-8
HPWA-13323-003 . . . . .E-7-8
HPWA-13324-003 . . . . .E-7-8
HPWA-13325-003 . . . . .E-7-8
HPWA-13326-003 . . . . .E-7-8
HPWA-13327-003 . . . . .E-7-8
HPWA-13328-003 . . . . .E-7-8
HPWA-13342-003 . . . . .E-7-10
HPWA-13343-003 . . . . .E-7-10
HPWA-13344-003 . . . . .E-7-10
HPWA-13345-003 . . . . .E-7-10
HPWA-13346-003 . . . . .E-7-10
HPWA-13347-003 . . . . .E-7-10
HPWA-13348-003 . . . . .E-7-10
HPWA-14221-003 . . . . .E-9-3
HPWA-14647-000 . . . . .E-9-14
HPWA-17105-007 . . . . .E-14-7
HPWA-90008-003 . . . . .E-2-26
HPWA-90017-G02. . . . . .E-19-6
HPWA-91212-003 . . . . .E-9-10-13
HPWC-14631-010 . . . . .E-9-13
HPWC-14721-010 . . . . .E-9-17
HPWC-30520-S01 . . . . .E-20-1
HPWC-90006-003 . . . . .E-9-25
HPY3-14647-000. . . . . .E-9-15
HPY3-17439-A01 . . . . .E-18-10-13
HPY3-31215-004. . . . . .E-21-3
HPY3-31218-004. . . . . .E-21-6
HPZ1-12210-004. . . . . .E-2-4
HPZ1-12211-004. . . . . .E-2-6
HPZA-14820-013 . . . . .E-2-9
HRAA-15815-A02 . . . . .E-2-11
HRB0-14211-003. . . . . .E-9-2
HRB0-14711-000. . . . . .E-9-16
HRB1-14401-003. . . . . .E-9-5
HRB1-14530-004. . . . . .E-9-12
HRE1-37880-Z01. . . . . .E-15-13
HRGA-14765-000 . . . . .E-9-21
HRGA-30530-004 . . . . .E-3-12
HRGM-14781-A01 . . . . .E-9-23
HRMA-16723-E00 . . . . .E-18-10-1
HRNA-37260-A01 . . . . .E-3-14
HRNA-37830-A01 . . . . .E-15-11
HRNA-90031-A01 . . . . .E-9-26
HRTA-15400-004. . . . . .E-3-5
HS04-38235-003. . . . . .F-13-4
HS0A-91540-003. . . . . .E-19-8
HS0A-91541-003. . . . . .E-2-38
HS0A-91541-003. . . . . .F-7-19
HSA0-90683-003. . . . . .F-7-10-24
HSB0-90602-003. . . . . .F-8-35
HSB2-90153-003. . . . . .F-7-16
HSC2-90649-003. . . . . .FOP-6-24
HSC2-90649-003. . . . . .FOP-6-1-17
HSD2-90705-931 . . . . .F-2-36
HSE0-53740-953. . . . . .E-18-10-16
HSF4-89216-000. . . . . .F-13-6
HSJ6-91558-003 . . . . . .F-7-22
HSTK-91540-003. . . . . .F-2-42
HSTK-91540-003. . . . . .FOP-11-6
HSW5-91551-003 . . . . .F-7-20
HSZ5-91531-003. . . . . .F-7-10-25
HVF9-89203-003. . . . . .F-13-5
HVM0-46391-003 . . . . .F-2-21
HZB7-90691-003. . . . . .E-2-35
HZC0-63515-700 . . . . .F-3-26
HZE2-90601-000. . . . . .E-6-13
HZH8-28461-013 . . . . .F-13-1
HZJ1-91408-810 . . . . .FOP-10-1-97
HZV0-90604-000. . . . . .E-18-22
HZV0-90604-000. . . . . .E-18-10-19
HZV1-24210-010. . . . . .F-10-3
HZV1-90506-000. . . . . .FOP-10-80
HZV1-90506-000. . . . . .FOP-10-1-87
HZV1-90759-000. . . . . .FOP-10-86
HZV1-90759-000. . . . . .FOP-10-1-91
HZV3-53104-000. . . . . .FOP-10-31
HZV3-53104-000. . . . . .FOP-10-1-23
HZV4-16910-015. . . . . .E-18-15
HZV4-24221-010. . . . . .F-10-4
HZV4-36182-651. . . . . .F-15-39
HZV4-36182-651. . . . . .FOP-6-15
HZV4-36182-651. . . . . .FOP-6-1-9
HZV4-36182-651. . . . . .FOP-10-22
HZV4-36182-651. . . . . .FOP-10-1-14
HZV4-36187-652. . . . . .FOP-6-16
HZV4-36187-652. . . . . .FOP-6-1-10
HZV4-36187-652. . . . . .FOP-10-23
HZV4-36187-652. . . . . .FOP-10-1-15
HZV4-90302-000. . . . . .F-3-10-23
HZV4-90305-000. . . . . .FOP-10-74
HZV4-90305-000. . . . . .FOP-10-1-79
HZV4-90502-000. . . . . .FOP-4-31
HZV4-90502-000. . . . . .FOP-4-2-36
HZV4-90507-000. . . . . .F-3-10-26
HZV4-90511-000. . . . . .F-4-24
HZV4-90514-000. . . . . .F-10-48
HZV4-90514-000. . . . . .FOP-10-81
HZV4-90514-000. . . . . .FOP-10-1-88
HZV4-90603-000. . . . . .E-6-10-20
HZV4-91255-651. . . . . .F-2-40
HZV5-12155-000. . . . . .E-2-1
HZV5-17202-310. . . . . .F-7-10-1
HZV5-17838-000. . . . . .F-2-1
HZV5-32823-003. . . . . .F-15-31
HZV5-32823-003. . . . . .FOP-6-10
HZV5-32823-003. . . . . .FOP-6-1-5
HZV5-32823-003. . . . . .FOP-6-2-6
HZV5-32823-003. . . . . .FOP-6-3-6
HZV5-32823-003. . . . . .FOP-6-4-6
HZV5-32823-003. . . . . .FOP-10-16
HZV5-32823-003. . . . . .FOP-11-3
HZV5-32824-003. . . . . .F-15-32
HZV5-32824-003. . . . . .FOP-6-11
HZV5-32824-003. . . . . .FOP-6-1-6
HZV5-32824-003. . . . . .FOP-6-2-7
HZV5-32824-003. . . . . .FOP-6-3-7
HZV5-32824-003. . . . . .FOP-6-4-7
HZV5-32824-003. . . . . .FOP-11-4
HZV5-36136-821. . . . . .F-11-8
HZV5-36180-033. . . . . .F-15-38
HZV5-36180-033. . . . . .FOP-6-14
HZV5-36180-033. . . . . .FOP-6-1-8
HZV5-36180-033. . . . . .FOP-10-21
HZV5-38410-003. . . . . .F-15-42
HZV5-38410-003. . . . . .FOP-6-20
HZV5-38410-003. . . . . .FOP-6-1-13
HZV5-40102-000. . . . . .E-9-10-6
HZV5-40102-000. . . . . .E-19-5
HZV5-40102-000. . . . . .F-3-6
HZV5-40102-000. . . . . .F-8-8
HZV5-41172-000. . . . . .F-3-14
HZV5-41172-000. . . . . .F-3-15
HZV5-50214-003. . . . . .F-11-10
HZV5-50522-000. . . . . .F-10-20
HZV5-56117-821. . . . . .F-11-17
HZV5-56118-820. . . . . .F-11-18
HZV5-56513-000. . . . . .F-11-23
HZV5-90010-000. . . . . .F-4-19
HZV5-90010-000. . . . . .FOP-3-9
HZV5-90115-000. . . . . .F-3-10-15
HZV5-90119-000. . . . . .F-3-34

HZV5-90119-000. . . . . F-3-35
HZV5-90119-000. . . . . F-11-31
HZV5-90127-003. . . . . F-3-36
HZV5-90127-003. . . . . F-8-29
HZV5-90131-000. . . . . E-6-12
HZV5-90302-003. . . . . F-2-28
HZV5-90304-013. . . . . F-10-40
HZV5-90306-003. . . . . F-3-10-24
HZV5-90307-003. . . . . F-10-44
HZV5-90501-000. . . . . F-10-45
HZV5-90502-000. . . . . F-10-46
HZV5-90504-000. . . . . F-10-47
HZV5-90552-000. . . . . F-10-50
HZV5-90552-000. . . . . FOP-10-82
HZV5-90552-000. . . . . FOP-10-1-89
HZV5-90559-000. . . . . F-10-51
HZV5-90559-000. . . . . F-10-52
HZV5-90559-000. . . . . FOP-10-83
HZV5-90559-000. . . . . FOP-10-1-90
HZV5-90563-000. . . . . F-3-10-27
HZV5-90563-000. . . . . F-3-10-27
HZV5-90563-000. . . . . F-10-53
HZV5-90756-000. . . . . E-6-14
HZV5-90756-000. . . . . F-3-42
HZV5-90756-000. . . . . F-3-10-29
HZV5-90756-000. . . . . F-3-10-29
HZV5-90756-000. . . . . F-4-28
HZV5-91203-821. . . . . F-11-33
HZV5-91256-003. . . . . F-10-58
HZV5-91302-821. . . . . F-11-35
HZV5-91316-821. . . . . F-11-36
HZV5-91352-000. . . . . F-10-59
HZV5-91352-000. . . . . FOP-10-91
HZV5-91352-000. . . . . FOP-10-1-96
HZV5-91560-000. . . . . F-10-61
HZV7-90951-010. . . . . F-10-57
HZW1-06411-020 . . . . . F-10-1
HZW1-15331-000 . . . . . E-5-8
HZW1-15341-000 . . . . . E-5-9
HZW1-17736-000 . . . . . F-15-76
HZW1-19234-B00 . . . . . F-4-5
HZW1-19234-B00 . . . . . FOP-3-6
HZW1-19242-B00 . . . . . F-4-7
HZW1-19242-B00 . . . . . FOP-3-7
HZW1-19252-000 . . . . . E-6-5
HZW1-19253-B01 . . . . . F-4-9
HZW1-19253-B01 . . . . . FOP-3-8
HZW1-19286-B00 . . . . . F-3-10-1
HZW1-24102-B00 . . . . . F-5-2
HZW1-24103-B00 . . . . . F-5-3
HZW1-24210-010 . . . . . F-2-9
HZW1-24320-B00 . . . . . F-4-12
HZW1-24327-000 . . . . . F-4-13
HZW1-24629-000 . . . . . F-2-17
HZW1-24800-V21 . . . . . F-15-1-1
HZW1-24811-V21 . . . . . F-15-1-2
HZW1-24812-V21 . . . . . F-15-1-3
HZW1-24813-V21 . . . . . F-15-1-4
HZW1-24816-V21 . . . . . F-15-1-5
HZW1-24819-V21 . . . . . F-15-1-6
HZW1-24820-V21 . . . . . F-15-1-7
HZW1-24821-003 . . . . . F-15-1-8
HZW1-24822-V21 . . . . . F-15-1-9
HZW1-24825-V01 . . . . . F-15-1-10
HZW1-24829-003 . . . . . F-15-1-11
HZW1-24830-V21 . . . . . F-15-1-12
HZW1-24834-003 . . . . . F-15-1-13
HZW1-24836-V21 . . . . . F-15-1-14
HZW1-24839-V01 . . . . . F-15-1-15
HZW1-24841-V01 . . . . . F-15-1-16
HZW1-24843-V01 . . . . . F-15-1-17
HZW1-24845-V01 . . . . . F-15-1-18
HZW1-24847-V01 . . . . . F-15-1-19
HZW1-24848-V01 . . . . . F-15-1-20
HZW1-24865-V01 . . . . . F-15-1-21
HZW1-24870-V21 . . . . . F-15-1-22
HZW1-24873-V01 . . . . . F-15-1-23
HZW1-24883-V01 . . . . . F-15-1-24
HZW1-31217-004 . . . . . E-21-5
HZW1-31250-004 . . . . . E-21-16
HZW1-31261-004 . . . . . E-21-18
HZW1-35180-003 . . . . . F-15-1-28
HZW1-35182-003 . . . . . F-15-1-29
HZW1-35370-V01 . . . . . F-15-1-30
HZW1-36123-013 . . . . . F-11-6
HZW1-38551-000 . . . . . F-7-9
HZW1-40107-700 . . . . . F-3-8
HZW1-40204-000 . . . . . F-4-15
HZW1-40210-710 . . . . . F-3-10-3
HZW1-41102-B00 . . . . . F-3-10-5
HZW1-41109-B00 . . . . . F-3-10-11
HZW1-41112-B03 . . . . . F-4-16
HZW1-41112-B33 . . . . . F-4-16
HZW1-41116-B00 . . . . . F-4-17
HZW1-41131-B01 . . . . . F-4-18
HZW1-41201-B02ZD . . . F-5-12
HZW1-50161-020ZC . . . F-3-21
HZW1-50214-000 . . . . . F-10-14
HZW1-50527-000 . . . . . F-10-21
HZW1-50529-000 . . . . . F-10-22
HZW1-53234-010 . . . . . F-10-23
HZW1-53236-700 . . . . . FOP-10-55
HZW1-53236-700 . . . . . FOP-10-1-62
HZW1-53238-010 . . . . . F-10-24
HZW1-53238-700 . . . . . FOP-10-56
HZW1-53238-700 . . . . . FOP-10-1-63
HZW1-53239-701 . . . . . FOP-10-57
HZW1-53239-701 . . . . . FOP-10-1-64
HZW1-56110-701 . . . . . F-11-13
HZW1-56113-701 . . . . . F-11-14
HZW1-56116-701 . . . . . F-11-16
HZW1-56130-702 . . . . . F-11-20
HZW1-56180-701 . . . . . F-11-22
HZW1-56516-000 . . . . . F-10-25
HZW1-56851-703 . . . . . F-11-25
HZW1-56860-701 . . . . . F-11-26
HZW1-58130-V03 . . . . . FOP-8-1
HZW1-58130-V13 . . . . . FOP-8-1
HZW1-58130-W03ZA. . . FOP-8-1
HZW1-58130-W13ZA. . . FOP-8-1
HZW1-58130-W24ZA. . . FOP-8-1
HZW1-58130-W33ZA. . . FOP-8-1
HZW1-58130-W43ZB. . . FOP-8-1
HZW1-58130-W64ZA. . . FOP-8-1
HZW1-58130-W93. . . . . FOP-8-1
HZW1-87705-003 . . . . . F-15-1-31
HZW1-87706-003 . . . . . F-15-1-32
HZW1-87707-003 . . . . . F-15-1-32
HZW1-90002-010 . . . . . E-7-13
HZW1-90102-000 . . . . . F-10-28
HZW1-90104-900 . . . . . F-3-10-14
HZW1-90105-000 . . . . . F-10-30
HZW1-90107-004 . . . . . E-21-20
HZW1-90108-000 . . . . . F-10-32
HZW1-90113-702 . . . . . F-11-27
HZW1-90114-702 . . . . . F-11-28
HZW1-90115-702 . . . . . F-11-29
HZW1-90116-702 . . . . . F-11-30
HZW1-90124-910 . . . . . F-3-10-18
HZW1-90125-910 . . . . . F-3-10-19
HZW1-90136-003 . . . . . F-15-1-33
HZW1-90137-003 . . . . . F-15-1-34
HZW1-90138-003 . . . . . F-15-1-35
HZW1-90139-003 . . . . . F-15-1-36
HZW1-90140-003 . . . . . F-15-1-37
HZW1-90142-003 . . . . . F-15-1-38
HZW1-90143-003 . . . . . F-15-1-39
HZW1-90145-003 . . . . . F-15-1-40
HZW1-90203-000 . . . . . F-7-17
HZW1-90203-000 . . . . . F-7-10-22
HZW1-90242-000 . . . . . F-4-21
HZW1-90301-B00 . . . . . F-5-14
HZW1-90303-B03 . . . . . F-4-22
HZW1-90304-013 . . . . . F-10-41
HZW1-90314-003 . . . . . F-15-1-41
HZW1-90401-000 . . . . . FOP-10-75
HZW1-90401-000 . . . . . FOP-10-1-81
HZW1-90501-710 . . . . . F-3-10-25
HZW1-90508-B00 . . . . . F-5-16
HZW1-90518-B00 . . . . . F-4-26
HZW1-90519-B00 . . . . . F-4-26
HZW1-90520-B00 . . . . . F-4-26
HZW1-90521-B00 . . . . . F-4-26
HZW1-90528-B00 . . . . . F-5-17
HZW1-90529-B00 . . . . . F-5-17
HZW1-90530-B00 . . . . . F-5-17
HZW1-90531-B00 . . . . . F-5-17
HZW1-90551-003 . . . . . F-15-1-42
HZW1-90552-003 . . . . . F-15-1-43
HZW1-90559-000 . . . . . F-3-38
HZW1-90651-710 . . . . . F-3-10-28
HZW1-90652-702 . . . . . F-11-32
HZW1-90653-003 . . . . . F-15-1-44
HZW1-90752-B02 . . . . . F-4-27
HZW1-90752-B02 . . . . . FOP-3-11
HZW1-90753-003 . . . . . F-15-1-45
HZW1-90758-B00 . . . . . F-5-18
HZW1-90953-003 . . . . . F-15-1-46
HZW1-91051-B02 . . . . . F-5-20
HZW1-91052-B02 . . . . . F-4-29
HZW1-91054-B31 . . . . . F-4-30
HZW1-91101-003 . . . . . F-5-22
HZW1-91207-013 . . . . . F-11-34
HZW1-91302-000 . . . . . E-5-14
HZW1-91351-B02 . . . . . F-5-24
HZW1-91353-703 . . . . . F-11-38
HZW1-91354-701 . . . . . F-11-39
HZW1-91355-701 . . . . . F-11-40
HZW1-91356-B00 . . . . . F-4-34
HZW1-91356-B00 . . . . . FOP-3-12
HZW1-91357-701 . . . . . F-11-41
HZW1-91361-701 . . . . . F-11-43
HZW1-91553-003 . . . . . F-15-1-47
HZW1-91557-701 . . . . . F-11-44
HZW4-17931-H02 . . . . . FOP-10-4
HZW4-19312-H00 . . . . . E-6-10-11
HZW4-24614-H03 . . . . . FOP-10-6
HZW4-24615-H03 . . . . . FOP-10-7
HZW4-32533-H01 . . . . . FOP-10-8
HZW4-32543-H01 . . . . . FOP-10-11
HZW4-32543-H01 . . . . . FOP-10-1-8
HZW4-32544-H01 . . . . . FOP-10-12
HZW4-32547-H01 . . . . . FOP-10-13
HZW4-32548-H01 . . . . . FOP-10-14
HZW4-32549-H01 . . . . . FOP-10-15
HZW4-35640-H11 . . . . . FOP-10-18
HZW4-35643-H02 . . . . . FOP-10-19
HZW4-35645-H02 . . . . . FOP-10-20
HZW4-53104-H02 . . . . . FOP-10-32
HZW4-53106-H01 . . . . . FOP-10-34
HZW4-53107-H02 . . . . . FOP-10-35
HZW4-53109-H02 . . . . . FOP-10-37
HZW4-53112-H02 . . . . . FOP-10-38
HZW4-53113-H01 . . . . . FOP-10-39
HZW4-53113-H01 . . . . . FOP-10-1-32
HZW4-53114-H01 . . . . . FOP-10-40
HZW4-53115-H02 . . . . . FOP-10-1-35
HZW4-53116-H01 . . . . . FOP-10-41
HZW4-53116-H01 . . . . . FOP-10-1-37
HZW4-53116-H11 . . . . . FOP-10-42
HZW4-53116-H11 . . . . . FOP-10-1-38
HZW4-53117-H01 . . . . . FOP-10-43
HZW4-53118-H03 . . . . . FOP-10-44
HZW4-53119-H02 . . . . . FOP-10-45
HZW4-53121-H02 . . . . . FOP-10-46
HZW4-53122-H01 . . . . . FOP-10-47
HZW4-53123-H01 . . . . . FOP-10-48
HZW4-53141-H00 . . . . . FOP-10-51
HZW4-90101-H00 . . . . . FOP-10-62
HZW4-90101-H00 . . . . . FOP-10-1-68
HZW4-90102-H01 . . . . . FOP-10-63
HZW4-90103-H02 . . . . . FOP-10-65
HZW4-90104-H01 . . . . . FOP-10-67
HZW4-90104-H01 . . . . . FOP-10-1-71
HZW4-90105-H02 . . . . . FOP-10-68
HZW4-90106-H01 . . . . . FOP-10-69
HZW4-90168-000 . . . . . F-8-31
HZW4-90301-H01 . . . . . FOP-10-71
HZW4-90303-H00 . . . . . FOP-10-73
HZW4-90303-H00 . . . . . FOP-10-1-78
HZW4-90306-003 . . . . . F-10-43
HZW4-90501-H01 . . . . . FOP-10-76
HZW4-90502-H02 . . . . . FOP-10-77
HZW4-90502-H02 . . . . . FOP-10-1-83
HZW4-90503-H01 . . . . . FOP-10-78
HZW4-90504-H01 . . . . . FOP-10-79
HZW4-90504-H01 . . . . . FOP-10-1-86
HZW4-90651-000 . . . . . F-10-54
HZW4-90651-H01 . . . . . FOP-10-84
HZW4-90652-H01 . . . . . FOP-10-85
HZW4-91051-H02 . . . . . FOP-10-88
HZW4-91051-H02 . . . . . FOP-10-1-93
HZW4-91052-H01 . . . . . FOP-10-89
HZW4-91052-H01 . . . . . FOP-10-1-94
HZW4-91301-003 . . . . . F-3-10-30
HZW4-91552-H00 . . . . . FOP-10-93
HZW4-91552-H00 . . . . . FOP-10-1-98
HZW5-06241-U00 . . . . . FOP-4-2
HZW5-06241-U10 . . . . . FOP-4-2-2
HZW5-06900-U00 . . . . . FOP-9-1
HZW5-16081-010 . . . . . E-18-20-17
HZW5-16735-003 . . . . . E-18-20-34
HZW5-24810-U01 . . . . . FOP-4-3
HZW5-24810-U01 . . . . . FOP-4-2-3
HZW5-24810-U01 . . . . . FOP-4-2-4
HZW5-24811-U01 . . . . . FOP-4-4
HZW5-24811-U01 . . . . . FOP-4-2-5
HZW5-24812-U01 . . . . . FOP-4-5
HZW5-24812-U01 . . . . . FOP-4-2-6
HZW5-24813-U01 . . . . . FOP-4-6
HZW5-24813-U01 . . . . . FOP-4-2-7
HZW5-24813-U21 . . . . . FOP-4-2-8
HZW5-24814-U01 . . . . . FOP-4-7
HZW5-24814-U01 . . . . . FOP-4-2-9
HZW5-24815-U01 . . . . . FOP-4-8
HZW5-24816-U01 . . . . . FOP-4-9
HZW5-24816-U01 . . . . . FOP-4-2-10
HZW5-24816-U01 . . . . . FOP-4-4-8
HZW5-24817-U01 . . . . . FOP-4-10
HZW5-24817-U01 . . . . . FOP-4-2-11
HZW5-24818-U01 . . . . . FOP-4-11
HZW5-24818-U01 . . . . . FOP-4-2-12
HZW5-24819-U01 . . . . . FOP-4-12
HZW5-24819-U01 . . . . . FOP-4-2-13
HZW5-24825-U01 . . . . . FOP-4-14
HZW5-24825-U01 . . . . . FOP-4-2-15
HZW5-24826-U01 . . . . . FOP-4-15
HZW5-24826-U01 . . . . . FOP-4-2-16
HZW5-24826-U01 . . . . . FOP-4-4-10
HZW5-24831-U01 . . . . . FOP-4-16
HZW5-24831-U01 . . . . . FOP-4-2-17
HZW5-24831-U01 . . . . . FOP-4-4-12
HZW5-24832-U01 . . . . . FOP-4-17
HZW5-24832-U01 . . . . . FOP-4-2-18
HZW5-24832-U01 . . . . . FOP-4-4-13
HZW5-24834-U01 . . . . . FOP-4-18
HZW5-24834-U21 . . . . . FOP-4-2-19
HZW5-32167-650 . . . . . F-15-1-27
HZW5-32168-003 . . . . . E-18-20-45
HZW5-35370-U02 . . . . . FOP-4-20
HZW5-35370-U02 . . . . . FOP-4-2-22
HZW5-35370-U12 . . . . . FOP-4-2-23
HZW5-50341-010 . . . . . F-10-17
HZW5-90021-U00 . . . . . FOP-9-2
HZW5-90101-U00 . . . . . FOP-4-22
HZW5-90101-U00 . . . . . FOP-4-2-25
HZW5-90101-U00 . . . . . FOP-4-4-20
HZW5-90102-U00 . . . . . FOP-4-23
HZW5-90102-U00 . . . . . FOP-4-2-26
HZW5-90103-U01 . . . . . FOP-4-24
HZW5-90103-U01 . . . . . FOP-4-2-27
HZW5-90104-U00 . . . . . FOP-4-25
HZW5-90104-U00 . . . . . FOP-4-2-28
HZW5-90105-003 . . . . . F-7-14
HZW5-90105-U01 . . . . . FOP-4-26
HZW5-90105-U01 . . . . . FOP-4-2-29
HZW5-90106-000 . . . . . F-7-15
HZW5-90106-U00 . . . . . FOP-4-27
HZW5-90106-U00 . . . . . FOP-4-2-30
HZW5-90107-U00 . . . . . FOP-4-28
HZW5-90107-U00 . . . . . FOP-4-2-31
HZW5-90108-U00 . . . . . FOP-4-2-32
HZW5-90109-000 . . . . . FOP-6-22
HZW5-90109-000 . . . . . FOP-6-1-15
HZW5-90109-000 . . . . . FOP-6-2-15
HZW5-90109-000 . . . . . FOP-6-3-15
HZW5-90109-000 . . . . . FOP-6-4-15
HZW5-90301-U00 . . . . . FOP-4-29
HZW5-90301-U00 . . . . . FOP-4-2-33
HZW5-90302-003 . . . . . F-3-37
HZW5-90302-003 . . . . . F-10-39
HZW5-90302-U21 . . . . . FOP-4-2-34

HZW5-90304-000 . . . . .F-10-42
HZW5-90501-000 . . . . .F-2-30
HZW5-90501-U00 . . . . .FOP-4-30
HZW5-90501-U00 . . . . .FOP-4-2-35
HZW5-90501-U00 . . . . .FOP-4-4-26
HZW5-90502-U00 . . . . .FOP-4-32
HZW5-90502-U00 . . . . .FOP-4-2-37
HZW5-90503-U00 . . . . .FOP-4-33
HZW5-90503-U00 . . . . .FOP-4-2-38
HZW5-90511-U00 . . . . .FOP-9-3
HZW5-90512-U00 . . . . .FOP-9-4
HZW5-90601-030 . . . . .E-18-20-51
HZW5-90602-030 . . . . .E-18-10-18
HZW5-90606-030 . . . . .E-1-5
HZW5-91054-003 . . . . .F-5-21
HZW5-91202-003 . . . . .E-6-10-21
HZW6-87124-U80 . . . . .FOP-10-58
HZW6-87124-U80 . . . . .FOP-10-1-65
HZW6-90752-000 . . . . .F-10-56
HZW7-24810-U01 . . . . .FOP-4-4-2
HZW7-24811-U01 . . . . .FOP-4-4-3
HZW7-24812-U01 . . . . .FOP-4-4-4
HZW7-24813-U01 . . . . .FOP-4-4-5
HZW7-24814-U01 . . . . .FOP-4-4-6
HZW7-24815-U01 . . . . .FOP-4-4-7
HZW7-24817-U01 . . . . .FOP-4-4-9
HZW7-24832-U01 . . . . .FOP-4-4-14
HZW7-24833-U01 . . . . .FOP-4-4-15
HZW7-32530-U00 . . . . .FOP-4-19
HZW7-32530-U00 . . . . .FOP-4-2-20
HZW7-32530-U10 . . . . .FOP-4-2-21
HZW7-32530-U20 . . . . .FOP-4-4-16
HZW7-35370-U02 . . . . .FOP-4-4-17
HZW7-58130-U02 . . . . .FOP-8-1
HZW7-58130-U12 . . . . .FOP-8-1
HZW7-58130-U22 . . . . .FOP-8-1
HZW7-58130-U32 . . . . .FOP-8-1
HZW7-87703-U00 . . . . .FOP-4-4-19
HZW7-90101-U01 . . . . .FOP-4-4-21
HZW7-90102-U01 . . . . .FOP-4-4-22
HZW7-90103-U01 . . . . .FOP-4-4-23
HZW7-90104-U01 . . . . .FOP-4-4-24
HZW7-90301-U01 . . . . .FOP-4-4-25
HZW7-90502-U00 . . . . .FOP-4-4-27
HZW9-17917-000 . . . . .FOP-10-3
HZW9-19279-010 . . . . .E-6-10-6
HZW9-19291-000 . . . . .E-6-10-8
HZW9-19297-000 . . . . .E-6-10-10
HZW9-19300-003 . . . . .E-3-9
HZW9-19303-003 . . . . .E-2-42
HZW9-19303-003 . . . . .E-3-32
HZW9-19315-000 . . . . .E-2-16
HZW9-19315-000 . . . . .E-3-33
HZW9-19317-000 . . . . .E-2-17
HZW9-19317-000 . . . . .E-3-11
HZW9-19317-000 . . . . .E-6-10-12
HZW9-28462-003 . . . . .F-13-2
HZW9-53103-000 . . . . .FOP-10-30
HZW9-53130-000 . . . . .FOP-10-49
HZW9-53130-000 . . . . .FOP-10-1-52
HZW9-53133-000 . . . . .FOP-10-50
HZW9-53133-000 . . . . .FOP-10-1-56
HZW9-53165-000 . . . . .FOP-10-52
HZW9-87511-620 . . . . .FOP-10-60
HZW9-87511-620 . . . . .FOP-10-1-67
HZW9-87532-620 . . . . .FOP-10-61
HZW9-87532-620 . . . . .FOP-10-1-104
HZW9-90009-000 . . . . .F-10-27
HZW9-90101-003 . . . . .F-3-10-12
HZW9-90102-000 . . . . .E-6-9
HZW9-90102-000 . . . . .F-4-20
HZW9-90102-000 . . . . .FOP-10-64
HZW9-90103-010 . . . . .F-3-30
HZW9-90105-000 . . . . .E-6-10-18
HZW9-90105-000 . . . . .F-10-31
HZW9-90154-000 . . . . .F-10-36
HZW9-91303-000 . . . . .E-18-23
HZX1-87132-R00 . . . . .F-12-4
HZX1-87133-R00 . . . . .F-12-4
HZX2-30280-003 . . . . .F-11-1
HZX2-31106-003 . . . . .F-11-2
HZX2-36122-003 . . . . .F-11-5
HZX2-91352-003 . . . . .F-11-37
HZX2-91358-003 . . . . .F-11-42
HZY1-90205-000. . . . . .F-3-10-21
HZY1-90650-003. . . . . .FOP-11-5
HZY3-16011-A01 . . . . .E-18-20-1
HZY3-16024-000. . . . . .E-18-20-6
HZY3-16026-000. . . . . .E-18-20-7
HZY3-16072-000. . . . . .E-18-20-12
HZY3-16073-000. . . . . .E-18-20-14
HZY3-16077-000. . . . . .E-18-20-16
HZY3-16082-000. . . . . .E-18-20-19
HZY3-16083-000. . . . . .E-18-20-21
HZY3-16087-000. . . . . .E-18-20-22
HZY3-16193-A00 . . . . .E-18-20-24
HZY3-16752-000. . . . . .E-18-20-37
HZY3-16752-A00 . . . . .E-14-6
HZY3-16807-003. . . . . .E-18-10-4
HZY3-16904-003. . . . . .E-18-10-8
HZY3-16911-010. . . . . .E-18-20-40
HZY3-16915-010. . . . . .E-18-10-10
HZY3-16918-003. . . . . .E-18-10-11
HZY3-16919-003. . . . . .E-18-10-12
HZY3-19270-000. . . . . .F-8-2
HZY3-19271-000. . . . . .F-8-3
HZY3-19272-000. . . . . .F-8-4
HZY3-24318-000. . . . . .F-4-11
HZY3-24618-000. . . . . .F-2-13
HZY3-24619-000. . . . . .F-2-15
HZY3-32128-000. . . . . .E-15-10
HZY3-32411-003. . . . . .F-7-10-5
HZY3-35673-003. . . . . .E-2-24
HZY3-35673-003. . . . . .E-3-13
HZY3-38216-003. . . . . .F-7-10-10
HZY3-40119-003. . . . . .F-3-9
HZY3-40219-013. . . . . .F-11-9
HZY3-63205-000. . . . . .F-2-22
HZY3-90017-000. . . . . .F-2-25
HZY3-90046-000. . . . . .E-6-8
HZY3-90056-000. . . . . .F-2-27
HZY3-90103-000. . . . . .FOP-10-66
HZY3-90103-000. . . . . .FOP-10-1-69
HZY3-90107-000. . . . . .F-7-10-21
HZY3-90111-000. . . . . .F-8-27
HZY3-90120-000. . . . . .F-3-10-16
HZY3-90132-000. . . . . .F-8-30
HZY3-90133-000. . . . . .F-3-10-20
HZY3-90405-000. . . . . .F-7-10-23
HZY3-90601-030. . . . . .E-6-10-19
HZY3-90751-000. . . . . .F-2-37
HZY3-91254-003. . . . . .F-4-32
HZY3-91303-000. . . . . .E-21-22
HZY3-91556-000. . . . . .F-3-10-31
HZY6-06323-R30. . . . . .FOP-6-4-1
HZY6-06323-R80. . . . . .FOP-6-2-1
HZY6-06323-R90. . . . . .FOP-6-3-1
HZY6-16016-003. . . . . .E-15-2
HZY6-16036-003. . . . . .E-18-20-8
HZY6-16718-013. . . . . .E-18-20-28
HZY6-16723-003. . . . . .E-18-20-30
HZY6-17109-000. . . . . .E-14-8
HZY6-17845-000. . . . . .F-2-3
HZY6-17931-000. . . . . .F-2-7
HZY6-19269-000. . . . . .E-18-16
HZY6-19289-000. . . . . .F-8-5
HZY6-19290-003. . . . . .E-6-10-7
HZY6-19300-003. . . . . .E-2-15
HZY6-31235-003. . . . . .E-21-11
HZY6-31236-003. . . . . .E-21-12
HZY6-32340-R31. . . . . .FOP-6-4-2
HZY6-32340-R81. . . . . .FOP-6-2-2
HZY6-32340-R91. . . . . .FOP-6-3-2
HZY6-32346-R31. . . . . .FOP-6-4-3
HZY6-32346-R81. . . . . .FOP-6-2-3
HZY6-32346-R91. . . . . .FOP-6-3-3
HZY6-32545-003. . . . . .FOP-6-2-4
HZY6-32545-003. . . . . .FOP-6-3-4
HZY6-32545-003. . . . . .FOP-6-4-4
HZY6-32606-000. . . . . .FOP-6-2-5
HZY6-32606-000. . . . . .FOP-6-3-5
HZY6-32606-000. . . . . .FOP-6-4-5
HZY6-35100-R01. . . . . .FOP-6-2-8
HZY6-35100-R01. . . . . .FOP-6-3-8
HZY6-35100-R01. . . . . .FOP-6-4-8
HZY6-36104-003. . . . . .F-3-5
HZY6-36135-003. . . . . .E-18-17
HZY6-36180-003. . . . . .FOP-6-2-9
HZY6-36180-612. . . . . .FOP-6-4-9
HZY6-36180-712. . . . . .FOP-6-3-9
HZY6-36182-003. . . . . .FOP-6-2-10
HZY6-36182-003. . . . . .FOP-6-3-10
HZY6-36182-003. . . . . .FOP-6-4-10
HZY6-36187-003. . . . . .FOP-6-2-11
HZY6-36187-003. . . . . .FOP-6-3-11
HZY6-36187-003. . . . . .FOP-6-4-11
HZY6-36551-003. . . . . .E-14-11
HZY6-38414-003. . . . . .FOP-6-2-14
HZY6-38414-003. . . . . .FOP-6-3-14
HZY6-38414-003. . . . . .FOP-6-4-14
HZY6-40219-023. . . . . .F-3-13
HZY6-50209-000. . . . . .F-3-22
HZY6-56118-000. . . . . .F-3-23
HZY6-87132-R00. . . . . .F-12-4
HZY6-90002-000. . . . . .F-3-28
HZY6-90006-000. . . . . .E-15-16
HZY6-90023-000. . . . . .E-9-10-10
HZY6-90105-000. . . . . .F-3-32
HZY6-90123-000. . . . . .F-3-10-17
HZY6-90123-000. . . . . .F-5-13
HZY6-90301-000. . . . . .F-8-32
HZY6-90302-003. . . . . .FOP-6-2-17
HZY6-90302-003. . . . . .FOP-6-3-17
HZY6-90302-003. . . . . .FOP-6-4-17
HZY6-90651-000. . . . . .F-8-36
HZY6-90752-000. . . . . .F-2-38
HZY6-90753-000. . . . . .F-2-39
HZY6-91305-003. . . . . .E-3-27
HZY6-91552-000. . . . . .F-4-36
HZY6-91552-000. . . . . .FOP-3-13
HZY6-91553-000. . . . . .F-8-41
HZY9-06167-000. . . . . .E-18-1
HZY9-06192-H00 . . . . .FOP-3-14
HZY9-06193-H01 . . . . .FOP-3-1
HZY9-06411-010. . . . . .F-3-1
HZY9-06534-000. . . . . .F-10-2
HZY9-11320-010ZA. . . .E-6-1
HZY9-11381-003. . . . . .E-6-2
HZY9-11411-415ZA. . . .E-9-10-1
HZY9-11911-000. . . . . .E-3-3
HZY9-12000-407ZA. . . .E-3-4
HZY9-12210-M00ZA . . .E-2-5
HZY9-12217-M00 . . . . .E-2-7
HZY9-12251-013. . . . . .E-2-8
HZY9-12310-010. . . . . .E-1-1
HZY9-12312-000. . . . . .E-1-2
HZY9-13010-H00 . . . . .E-7-1
HZY9-13011-010. . . . . .E-7-1
HZY9-13101-H00 . . . . .E-7-2
HZY9-13210-010. . . . . .E-7-5
HZY9-13310-010. . . . . .E-7-7
HZY9-13331-003. . . . . .E-7-9
HZY9-13621-H01 . . . . .E-7-11
HZY9-14110-000. . . . . .E-9-1
HZY9-14222-000. . . . . .E-9-4
HZY9-14430-000. . . . . .E-9-7
HZY9-14441-000. . . . . .E-9-8
HZY9-14442-000. . . . . .E-9-9
HZY9-14510-003. . . . . .E-9-10
HZY9-14512-000. . . . . .E-9-11
HZY9-14751-H01 . . . . .E-9-19
HZY9-14752-003. . . . . .E-9-20
HZY9-15100-M00 . . . . .E-5-1
HZY9-15121-000. . . . . .E-5-2
HZY9-15136-000. . . . . .E-5-3
HZY9-15171-000. . . . . .E-15-1
HZY9-15220-000. . . . . .E-6-3
HZY9-15236-M00 . . . . .E-5-7
HZY9-15422-010. . . . . .E-1-3
HZY9-15600-M00 . . . . .E-3-6
HZY9-15612-000. . . . . .E-3-7
HZY9-15631-000. . . . . .E-3-8
HZY9-15655-M00 . . . . .E-6-4
HZY9-15665-000. . . . . .E-6-10-1
HZY9-15815-000. . . . . .E-2-12
HZY9-16013-000. . . . . .E-18-20-2
HZY9-16017-M00 . . . . .E-18-20-3
HZY9-16019-003. . . . . .E-18-20-4
HZY9-16020-013. . . . . .E-18-20-5
HZY9-16042-013. . . . . .E-18-20-9
HZY9-16061-003. . . . . .E-18-20-10
HZY9-16071-003. . . . . .E-18-20-11
HZY9-16072-003. . . . . .E-18-20-13
HZY9-16073-003. . . . . .E-18-20-15
HZY9-16081-003. . . . . .E-18-20-18
HZY9-16082-003. . . . . .E-18-20-20
HZY9-16195-000. . . . . .E-18-2
HZY9-16196-000. . . . . .E-18-3
HZY9-16197-000. . . . . .E-18-4
HZY9-16198-000. . . . . .E-18-5
HZY9-16199-000. . . . . .E-18-6
HZY9-16400-H01 . . . . .E-15-3
HZY9-16450-003. . . . . .E-14-1
HZY9-16451-000. . . . . .E-14-2
HZY9-16620-010. . . . . .E-14-3
HZY9-16700-013. . . . . .E-18-7
HZY9-16701-003. . . . . .E-18-20-25
HZY9-16708-003. . . . . .E-18-20-26
HZY9-16715-013. . . . . .E-18-20-27
HZY9-16717-000. . . . . .E-2-13
HZY9-16721-003. . . . . .E-18-20-29
HZY9-16730-M01 . . . . .E-18-20-31
HZY9-16733-000. . . . . .E-14-5
HZY9-16733-000. . . . . .E-18-20-32
HZY9-16734-010. . . . . .E-18-20-33
HZY9-16740-003. . . . . .E-18-20-35
HZY9-16755-003. . . . . .E-18-8
HZY9-16756-000. . . . . .E-18-9
HZY9-16800-003. . . . . .E-18-10-2
HZY9-16805-003. . . . . .E-18-10-3
HZY9-16816-000. . . . . .E-18-10
HZY9-16850-000. . . . . .E-18-10-5
HZY9-16860-000. . . . . .E-18-10-6
HZY9-16871-000. . . . . .E-18-10-7
HZY9-16881-010. . . . . .E-18-11
HZY9-16891-000. . . . . .E-18-12
HZY9-16895-003. . . . . .E-18-13
HZY9-16896-003. . . . . .E-2-14
HZY9-16896-003. . . . . .E-15-4
HZY9-16896-003. . . . . .E-18-14
HZY9-16896-003. . . . . .E-18-20-38
HZY9-16898-003. . . . . .E-18-20-39
HZY9-16910-004. . . . . .E-18-10-9
HZY9-16913-003. . . . . .E-18-20-41
HZY9-17110-003. . . . . .E-14-9
HZY9-17202-M00 . . . . .E-6-10-3
HZY9-17315-M00 . . . . .E-15-26
HZY9-17371-000. . . . . .E-15-7
HZY9-17371-H00 . . . . .E-15-7
HZY9-17374-000. . . . . .E-15-8
HZY9-17723-F00. . . . . .E-18-20-42
HZY9-17840-000. . . . . .F-2-2
HZY9-17860-000. . . . . .F-2-4
HZY9-17877-000. . . . . .F-2-5
HZY9-17878-000. . . . . .F-2-6
HZY9-17910-701. . . . . .FOP-10-2
HZY9-17910-H01 . . . . .FOP-10-1-2
HZY9-18211-000. . . . . .F-8-1
HZY9-19210-H01 . . . . .F-4-1
HZY9-19210-H01 . . . . .FOP-3-2
HZY9-19221-H01 . . . . .F-4-2
HZY9-19221-H01 . . . . .FOP-3-3
HZY9-19223-H00 . . . . .F-4-3
HZY9-19223-H00 . . . . .FOP-3-4
HZY9-19231-H01 . . . . .F-4-4
HZY9-19231-H01 . . . . .FOP-3-5
HZY9-19251-000. . . . . .F-4-8
HZY9-19251-610. . . . . .F-4-8
HZY9-19254-000. . . . . .E-6-6
HZY9-19255-000. . . . . .E-18-20-43
HZY9-19256-000. . . . . .E-6-10-4
HZY9-19277-M00 . . . . .E-6-10-5
HZY9-19295-000. . . . . .E-6-10-9
HZY9-19330-M00 . . . . .E-3-34
HZY9-19331-M00 . . . . .E-3-35
HZY9-19361-M00 . . . . .E-2-18
HZY9-19371-000. . . . . .E-2-19
HZY9-19380-M01 . . . . .E-2-43
HZY9-23170-010ZA. . . .E-6-10-13
HZY9-23172-003. . . . . .E-6-7
HZY9-24221-000. . . . . .F-2-10
HZY9-24320-610. . . . . .F-4-12

HZY9-24343-H00 . . . . .F-4-14
HZY9-24590-701. . . . .FOP-10-5
HZY9-24590-H01 . . . . .FOP-10-1-4
HZY9-24612-000. . . . . .F-2-11
HZY9-24614-000. . . . . .F-2-12
HZY9-24618-000. . . . . .F-2-14
HZY9-24628-000. . . . . .F-2-16
HZY9-24630-000. . . . . .F-2-18
HZY9-30419-003. . . . . .E-15-9
HZY9-30419-003. . . . . .E-20-10-2
HZY9-31110-000ZB. . . .E-7-12
HZY9-31145-M00 . . . . .E-19-1
HZY9-31200-H01 . . . . .E-21-1
HZY9-31207-H01 . . . . .E-21-2
HZY9-31216-003. . . . . .E-21-4
HZY9-31226-H01 . . . . .E-21-7
HZY9-31227-H01 . . . . .E-21-8
HZY9-31229-H01 . . . . .E-21-9
HZY9-31231-H01 . . . . .E-21-10
HZY9-31240-003. . . . . .E-21-13
HZY9-31242-H01 . . . . .E-21-14
HZY9-31246-H01 . . . . .E-21-15
HZY9-31251-H01 . . . . .E-21-17
HZY9-31630-H01 . . . . .E-19-2
HZY9-31631-H01 . . . . .E-19-3
HZY9-31632-003. . . . . .E-19-4
HZY9-31750-003. . . . . .E-2-20
HZY9-31754-000. . . . . .E-2-21
HZY9-31916-H01 . . . . .E-20-2
HZY9-32100-M00 . . . . .F-7-1
HZY9-32103-000. . . . . .F-7-3
HZY9-32104-H00 . . . . .F-7-4
HZY9-32111-000. . . . . .E-9-10-2
HZY9-32112-000. . . . . .E-18-10-15
HZY9-32113-000. . . . . .E-9-10-3
HZY9-32114-000. . . . . .E-2-22
HZY9-32115-000. . . . . .E-9-10-4
HZY9-32166-013. . . . . .E-18-20-44
HZY9-32410-000. . . . . .F-7-10-4
HZY9-32418-000. . . . . .F-7-10-6
HZY9-32534-A01 . . . . .FOP-10-9
HZY9-32538-A01 . . . . .FOP-10-10
HZY9-32538-H01 . . . . .FOP-10-1-7
HZY9-34750-M41 . . . . .E-20-10-3
HZY9-34754-H00 . . . . .E-20-10-4
HZY9-35470-023. . . . . .F-2-19
HZY9-35475-010. . . . . .F-2-20
HZY9-35640-003. . . . . .F-8-6
HZY9-35645-000. . . . . .F-8-7
HZY9-35655-H01 . . . . .E-2-23
HZY9-35660-003. . . . . .F-10-5
HZY9-35695-003. . . . . .E-2-25
HZY9-36104-003. . . . . .F-11-3
HZY9-36120-013. . . . . .F-11-4
HZY9-36129-003. . . . . .F-11-7
HZY9-36550-003. . . . . .E-14-10
HZY9-37210-A02 . . . . .FOP-10-24
HZY9-37210-A02 . . . . .FOP-10-1-16
HZY9-38201-003. . . . . .F-7-6
HZY9-38210-003. . . . . .F-7-26
HZY9-38216-003. . . . . .F-7-7
HZY9-38217-000. . . . . .F-7-10-11
HZY9-38233-000. . . . . .F-7-8
HZY9-38400-A00 . . . . .FOP-10-25
HZY9-38400-A00 . . . . .FOP-10-1-17
HZY9-38402-A00 . . . . .FOP-10-26
HZY9-38402-A00 . . . . .FOP-10-1-18
HZY9-38410-A01 . . . . .FOP-6-2-13
HZY9-38410-A01 . . . . .FOP-6-3-13
HZY9-38410-A01 . . . . .FOP-6-4-13
HZY9-38550-003. . . . . .F-7-10-12
HZY9-38552-000. . . . . .F-7-10-13
HZY9-38553-003. . . . . .F-7-10-14
HZY9-38580-023. . . . . .F-7-10-15
HZY9-40105-000. . . . . .F-3-7
HZY9-40105-A00 . . . . .FOP-10-27
HZY9-40105-H00 . . . . .FOP-10-1-19
HZY9-40151-000ZD. . . .F-8-9
HZY9-40154-000ZC. . . .F-3-10
HZY9-40201-020ZC. . . .F-3-11
HZY9-40202-H50ZB. . . .F-3-10-2
HZY9-41100-H01ZB. . . .F-3-20-1
HZY9-41100-H51ZB. . . .F-3-20-1
HZY9-41101-H00ZB. . . .F-3-10-4
HZY9-41151-H00 . . . . .F-5-9
HZY9-41173-000. . . . . .F-3-16
HZY9-50100-020. . . . . .F-10-6
HZY9-50111-000ZC. . . .F-3-17
HZY9-50153-000. . . . . .F-10-8
HZY9-50157-000. . . . . .F-3-20
HZY9-50158-000. . . . . .F-10-9
HZY9-50166-010. . . . . .F-10-10
HZY9-50168-000. . . . . .F-10-11
HZY9-50201-020ZC. . . .F-10-12
HZY9-50301-020ZC. . . .F-10-15
HZY9-50311-020ZC. . . .F-10-16
HZY9-50381-000. . . . . .F-10-18
HZY9-50412-000. . . . . .F-10-19
HZY9-53101-A02ZD . . .FOP-10-28
HZY9-53102-A02 . . . . .FOP-10-29
HZY9-53105-A01 . . . . .FOP-10-33
HZY9-53108-A00 . . . . .FOP-10-36
HZY9-53232-A00 . . . . .FOP-10-53
HZY9-53232-A00 . . . . .FOP-10-1-60
HZY9-53233-A00ZD . . .FOP-10-54
HZY9-53233-A00ZD . . .FOP-10-1-61
HZY9-56000-033. . . . . .F-11-11
HZY9-56100-013. . . . . .F-11-12
HZY9-56115-023. . . . . .F-11-46
HZY9-56120-013. . . . . .F-11-47
HZY9-56170-003. . . . . .F-11-21
HZY9-58130-H01ZA. . . .FOP-8-1
HZY9-63232-010. . . . . .F-3-24
HZY9-63232-010. . . . . .F-8-15
HZY9-63237-000. . . . . .F-3-25
HZY9-63237-000. . . . . .F-8-16
HZY9-63718-000. . . . . .E-6-10-14
HZY9-63719-000. . . . . .F-3-27
HZY9-82873-000. . . . . .F-8-22
HZY9-82874-000. . . . . .F-8-23
HZY9-87117-000. . . . . .F-12-1
HZY9-87121-T80. . . . . .F-12-2
HZY9-87121-T81. . . . . .F-12-2
HZY9-87301-T80. . . . . .F-12-5
HZY9-87538-U80 . . . . .F-12-8
HZY9-87546-U80 . . . . .F-12-9
HZY9-90003-M00 . . . . .E-18-19
HZY9-90004-M00 . . . . .E-14-12
HZY9-90008-003. . . . . .E-3-15
HZY9-90011-M00 . . . . .E-2-27
HZY9-90013-M00 . . . . .E-21-19
HZY9-90014-M00 . . . . .E-14-13
HZY9-90014-M00 . . . . .E-18-20-47
HZY9-90016-M00 . . . . .E-2-28
HZY9-90020-M00 . . . . .E-3-36
HZY9-90023-M00 . . . . .E-19-7
HZY9-90026-M00 . . . . .E-3-18
HZY9-90027-M00 . . . . .E-5-11
HZY9-90027-M00 . . . . .E-15-18
HZY9-90042-M00 . . . . .E-14-14
HZY9-90043-M00 . . . . .E-6-10-16
HZY9-90047-M00 . . . . .E-2-33
HZY9-90054-M00 . . . . .E-3-21
HZY9-90054-M00 . . . . .E-14-15
HZY9-90056-M00 . . . . .E-6-10-17
HZY9-90059-M00 . . . . .E-21-21
HZY9-90069-M00 . . . . .E-15-19
HZY9-90102-000. . . . . .F-3-29
HZY9-90102-000. . . . . .F-10-29
HZY9-90103-000. . . . . .F-8-25
HZY9-90104-000. . . . . .F-3-31
HZY9-90105-000. . . . . .F-3-33
HZY9-90113-003. . . . . .F-8-28
HZY9-90201-M00 . . . . .E-3-23
HZY9-90205-M00 . . . . .E-14-17
HZY9-90508-000. . . . . .F-2-32
HZY9-90509-000. . . . . .F-2-33
HZY9-90651-000. . . . . .F-2-35
HZY9-90652-003. . . . . .F-7-18
HZY9-90751-000. . . . . .F-8-37
HZY9-90754-000. . . . . .F-3-41
HZY9-90755-000. . . . . .F-8-38
HZY9-90951-A01 . . . . .FOP-10-87
HZY9-90951-A01 . . . . .FOP-10-1-92
HZY9-91304-000. . . . . .E-5-15
HZY9-91402-000. . . . . .E-6-10-24
HZY9-91403-000. . . . . .E-15-21
HZY9-91404-000. . . . . .E-15-22
HZY9-91405-000. . . . . .E-15-23
HZY9-91451-A00 . . . . .FOP-10-92
HZY9-91503-M00 . . . . .E-15-24
HZY9-91503-M00 . . . . .E-19-9
HZY9-91503-M00 . . . . .E-20-10-8
HZY9-91503-M00 . . . . .F-3-43
HZY9-91503-M00 . . . . .F-7-21
HZY9-91503-M00 . . . . .F-7-10-26
HZY9-91503-M00 . . . . .F-8-40
HZY9-91504-M00 . . . . .E-14-22
HZY9-91504-M00 . . . . .E-18-20-53
HZY9-91553-000. . . . . .F-3-44
HZY9-91554-000. . . . . .F-8-42
HZY9-91557-000. . . . . .F-10-60
HZZ0-06533-R50ZA. . . .FOP-10-1
HZZ0-06533-T80ZA. . . .FOP-10-1-1
HZZ0-13102-000. . . . . .E-7-2
HZZ0-14110-000. . . . . .E-9-1
HZZ0-14420-000. . . . . .E-9-6
HZZ0-15810-003ZA. . . .E-2-10
HZZ0-19241-000. . . . . .F-4-6
HZZ0-24101-010. . . . . .F-5-1
HZZ0-24113-000. . . . . .F-5-4
HZZ0-24122-000. . . . . .F-5-5
HZZ0-24123-000. . . . . .F-5-6
HZZ0-24124-000. . . . . .F-5-7
HZZ0-24310-000. . . . . .F-4-10
HZZ0-30416-M00 . . . . .E-20-10-1
HZZ0-32100-M00 . . . . .F-7-1
HZZ0-32101-M00 . . . . .F-7-2
HZZ0-34750-M41 . . . . .E-20-10-3
HZZ0-40155-M00 . . . . .F-8-10
HZZ0-40160-M00ZA . . .F-3-47
HZZ0-40161-M00 . . . . .F-8-44
HZZ0-40165-M00 . . . . .F-8-11
HZZ0-41102-000. . . . . .F-3-10-6
HZZ0-41103-000. . . . . .F-3-10-7
HZZ0-41104-010. . . . . .F-3-10-8
HZZ0-41105-010. . . . . .F-3-10-9
HZZ0-41107-000ZD. . . .F-3-10-10
HZZ0-41140-010. . . . . .F-5-8
HZZ0-41160-010. . . . . .F-5-10
HZZ0-41161-000. . . . . .F-5-11
HZZ0-50151-000. . . . . .F-10-7
HZZ0-50155-000. . . . . .F-3-18
HZZ0-50156-C00 . . . . .F-3-19
HZZ0-56532-C00 . . . . .F-11-24
HZZ0-56539-C00 . . . . .F-10-26
HZZ0-58130-D81ZB. . . .FOP-8-1
HZZ0-58130-D91ZB. . . .FOP-8-1
HZZ0-63100-M30ZA . . .F-8-13
HZZ0-63102-M00 . . . . .F-8-14
HZZ0-63347-M00ZA . . .F-8-17
HZZ0-63711-M00ZA . . .F-8-18
HZZ0-63716-M00ZA . . .F-8-19
HZZ0-87121-T80. . . . . .F-12-3
HZZ0-87121-T81. . . . . .F-12-3
HZZ0-87125-R00 . . . . .FOP-10-59
HZZ0-87301-T80. . . . . .F-12-6
HZZ0-87531-M90 . . . . .F-12-7
HZZ0-90101-000. . . . . .F-3-10-13
HZZ0-90101-M00 . . . . .F-2-26
HZZ0-90102-M00 . . . . .E-20-10-6
HZZ0-90103-M00 . . . . .F-7-13
HZZ0-90106-M00 . . . . .F-8-26
HZZ0-90151-M00 . . . . .F-10-35
HZZ0-90506-C00 . . . . .F-5-15
HZZ0-91552-M00 . . . . .F-8-39
HZZ0-91555-M00 . . . . .F-7-10-27
HZZ0-91601-M00 . . . . .E-6-16
HZZ3-06240-R30 . . . . .FOP-4-1
HZZ3-06240-R40 . . . . .FOP-4-4-1
HZZ3-06240-R60 . . . . .FOP-4-2-1
HZZ3-06323-R00 . . . . .FOP-6-1
HZZ3-06323-R10 . . . . .FOP-6-1-1
HZZ3-06328-763. . . . . .FOP-11-1
HZZ3-17931-A41 . . . . .FOP-10-1-3
HZZ3-24614-A41 . . . . .FOP-10-1-5
HZZ3-24615-A41 . . . . .FOP-10-1-6
HZZ3-24800-P02. . . . . .F-15-1
HZZ3-24820-R11 . . . . .FOP-4-13
HZZ3-24820-R21 . . . . .FOP-4-2-14
HZZ3-24830-R41 . . . . .FOP-4-4-11
HZZ3-32127-000. . . . . .F-7-5
HZZ3-32186-000. . . . . .FOP-11-2
HZZ3-32341-R01 . . . . .FOP-6-5
HZZ3-32346-R01 . . . . .FOP-6-6
HZZ3-32346-R11 . . . . .FOP-6-1-3
HZZ3-32347-R01 . . . . .FOP-6-7
HZZ3-35100-R01 . . . . .FOP-10-17
HZZ3-35100-R01 . . . . .FOP-10-1-9
HZZ3-35100-R11 . . . . .F-15-33
HZZ3-35100-R11 . . . . .FOP-6-13
HZZ3-35100-R11 . . . . .FOP-6-1-7
HZZ3-35180-A42 . . . . .FOP-10-1-10
HZZ3-35340-741. . . . . .FOP-12-1
HZZ3-35340-A42 . . . . .FOP-10-1-11
HZZ3-35341-740. . . . . .FOP-12-2
HZZ3-35342-740. . . . . .FOP-12-3
HZZ3-35343-740. . . . . .FOP-12-4
HZZ3-35344-740. . . . . .FOP-12-5
HZZ3-35345-741. . . . . .FOP-12-6
HZZ3-35640-A41 . . . . .FOP-10-1-12
HZZ3-35645-A41 . . . . .F-15-36
HZZ3-35645-A41 . . . . .FOP-10-1-13
HZZ3-37205-R01 . . . . .FOP-6-17
HZZ3-53101-A41ZD . . .FOP-10-1-20
HZZ3-53102-A41 . . . . .FOP-10-1-21
HZZ3-53103-A41 . . . . .FOP-10-1-22
HZZ3-53104-A41 . . . . .FOP-10-1-24
HZZ3-53105-A41 . . . . .FOP-10-1-25
HZZ3-53106-A41 . . . . .FOP-10-1-26
HZZ3-53108-A41 . . . . .FOP-10-1-27
HZZ3-53109-A41 . . . . .FOP-10-1-28
HZZ3-53110-A41 . . . . .FOP-10-1-29
HZZ3-53111-A41 . . . . .FOP-10-1-30
HZZ3-53112-A41 . . . . .FOP-10-1-31
HZZ3-53113-A41 . . . . .FOP-10-1-33
HZZ3-53114-A41 . . . . .FOP-10-1-34
HZZ3-53115-A41 . . . . .FOP-10-1-36
HZZ3-53117-A41 . . . . .FOP-10-1-39
HZZ3-53118-A41 . . . . .FOP-10-1-40
HZZ3-53119-A41 . . . . .FOP-10-1-41
HZZ3-53120-A41 . . . . .FOP-10-1-42
HZZ3-53121-A41 . . . . .FOP-10-1-43
HZZ3-53122-A41 . . . . .FOP-10-1-44
HZZ3-53123-A41 . . . . .FOP-10-1-45
HZZ3-53124-A41 . . . . .FOP-10-1-46
HZZ3-53125-A41 . . . . .FOP-10-1-47
HZZ3-53126-A41 . . . . .FOP-10-1-48
HZZ3-53127-A41 . . . . .FOP-10-1-49
HZZ3-53128-A41 . . . . .FOP-10-1-50
HZZ3-53129-A41 . . . . .FOP-10-1-51
HZZ3-53130-A41 . . . . .FOP-10-1-53
HZZ3-53131-A41 . . . . .FOP-10-1-54
HZZ3-53132-A41 . . . . .FOP-10-1-55
HZZ3-53141-A41 . . . . .FOP-10-1-57
HZZ3-53142-A41 . . . . .FOP-10-1-58
HZZ3-53165-000. . . . . .FOP-10-1-59
HZZ3-87125-R00 . . . . .FOP-10-1-66
HZZ3-87301-R00 . . . . .F-12-5
HZZ3-87301-R00 . . . . .F-12-6
HZZ3-87701-R40 . . . . .FOP-4-4-18
HZZ3-87703-R01 . . . . .FOP-4-2-24
HZZ3-87703-R81 . . . . .FOP-4-21
HZZ3-90103-A41 . . . . .FOP-10-1-70
HZZ3-90111-A41 . . . . .FOP-10-1-72
HZZ3-90112-A41 . . . . .FOP-10-1-73
HZZ3-90113-A41 . . . . .FOP-10-1-74
HZZ3-90114-A41 . . . . .FOP-10-1-75
HZZ3-90129-000. . . . . .F-10-34
HZZ3-90305-A41 . . . . .FOP-10-1-80
HZZ3-90501-A41 . . . . .FOP-10-1-82
HZZ3-90502-A41 . . . . .FOP-10-1-84
HZZ3-90503-A41 . . . . .FOP-10-1-85
HZZ3-90651-003. . . . . .F-3-40
HZZ3-91252-003. . . . . .F-5-23
HZZ3-91253-003. . . . . .F-4-31
HZZ5-06325-600. . . . . .FOP-6-2
HZZ5-06325-700. . . . . .FOP-6-2
HZZ5-06325-800. . . . . .FOP-6-2
HZZ5-24810-D01 . . . . .F-15-2
HZZ5-24811-D01 . . . . .F-15-3
HZZ5-24812-D01 . . . . .F-15-4


HZZ5-24813-D01 . . . . . F-15-5
HZZ5-24814-D01 . . . . . F-15-6
HZZ5-24815-D01 . . . . . F-15-7
HZZ5-24816-D01 . . . . . F-15-8
HZZ5-24817-D01 . . . . . F-15-9
HZZ5-24818-D01 . . . . . F-15-10
HZZ5-24819-D01 . . . . . F-15-11
HZZ5-24821-D01 . . . . . F-15-12
HZZ5-24822-D01 . . . . . F-15-13
HZZ5-24823-D01 . . . . . F-15-14
HZZ5-24824-D01 . . . . . F-15-15
HZZ5-24826-D01 . . . . . F-15-16
HZZ5-24827-D01 . . . . . F-15-17
HZZ5-24828-D01 . . . . . F-15-18
HZZ5-24828-D01 . . . . . F-15-75
HZZ5-24829-D01 . . . . . F-15-19
HZZ5-24831-D01 . . . . . F-15-20
HZZ5-24832-D01 . . . . . F-15-21
HZZ5-24833-D01 . . . . . F-15-22
HZZ5-24845-D01 . . . . . F-15-23
HZZ5-24850-D01 . . . . . F-15-24
HZZ5-24855-D01 . . . . . F-15-25
HZZ5-24875-D01 . . . . . F-15-26
HZZ5-24876-D01 . . . . . F-15-27
HZZ5-24878-D01 . . . . . F-15-28
HZZ5-24883-D01 . . . . . F-15-29
HZZ5-32185-600. . . . . FOP-6-4
HZZ5-32185-700. . . . . FOP-6-4
HZZ5-32185-800. . . . . FOP-6-4
HZZ5-32530-D01 . . . . . F-15-30
HZZ5-32545-000. . . . . FOP-6-8
HZZ5-32545-000. . . . . FOP-6-1-4
HZZ5-32580-D01 . . . . . FOP-6-9
HZZ5-32580-D11 . . . . . FOP-6-9
HZZ5-32580-D21 . . . . . FOP-6-9
HZZ5-35370-D02 . . . . . F-15-35
HZZ5-35701-D01 . . . . . F-15-37
HZZ5-37210-712. . . . . FOP-6-1-11
HZZ5-37210-762. . . . . FOP-6-18
HZZ5-37210-D01 . . . . . F-15-40
HZZ5-38414-003. . . . . FOP-6-21
HZZ5-38414-003. . . . . FOP-6-1-14
HZZ5-50211-000. . . . . F-10-13
HZZ5-87701-790. . . . . F-15-78
HZZ5-87701-D00 . . . . . F-15-43
HZZ5-87702-D00 . . . . . F-15-44
HZZ5-87702-D00 . . . . . F-15-46
HZZ5-87703-P00. . . . . F-15-47
HZZ5-87704-D01 . . . . . F-15-48
HZZ5-90003-M00 . . . . . E-15-15
HZZ5-90003-M00 . . . . . E-20-10-5
HZZ5-90003-M00 . . . . . F-7-10
HZZ5-90003-M00 . . . . . F-7-10-16
HZZ5-90003-M00 . . . . . F-8-24
HZZ5-90011-M00 . . . . . E-9-10-7
HZZ5-90011-M00 . . . . . E-18-20
HZZ5-90011-M00 . . . . . E-18-10-17
HZZ5-90011-M00 . . . . . F-2-23
HZZ5-90011-M00 . . . . . F-7-11
HZZ5-90011-M00 . . . . . F-7-10-17
HZZ5-90014-M00 . . . . . E-3-17
HZZ5-90014-M00 . . . . . E-18-21
HZZ5-90014-M00 . . . . . E-18-20-48
HZZ5-90014-M00 . . . . . E-20-3
HZZ5-90016-M00 . . . . . E-9-10-8
HZZ5-90017-M00 . . . . . E-2-29
HZZ5-90017-M00 . . . . . E-9-10-9
HZZ5-90018-M00 . . . . . E-2-30
HZZ5-90018-M00 . . . . . F-7-10-19
HZZ5-90019-M00 . . . . . E-2-31
HZZ5-90021-M00 . . . . . E-18-20-49
HZZ5-90021-M00 . . . . . F-7-10-20
HZZ5-90026-M00 . . . . . E-14-16
HZZ5-90030-M00 . . . . . E-1-4
HZZ5-90030-M00 . . . . . E-2-32
HZZ5-90030-M00 . . . . . E-3-37
HZZ5-90030-M00 . . . . . E-6-10-15
HZZ5-90030-M00 . . . . . E-9-10-11
HZZ5-90032-M00 . . . . . E-3-20
HZZ5-90045-M00 . . . . . E-9-10-12
HZZ5-90047-M00 . . . . . E-2-34
HZZ5-90055-M00 . . . . . E-5-12
HZZ5-90101-D01 . . . . . F-15-49
HZZ5-90102-D01 . . . . . F-15-50
HZZ5-90103-D01 . . . . . F-15-51
HZZ5-90104-D01 . . . . . F-15-52
HZZ5-90104-M00 . . . . . E-5-10
HZZ5-90104-M00 . . . . . F-2-24
HZZ5-90105-M00 . . . . . F-7-12
HZZ5-90105-M00 . . . . . F-7-10-18
HZZ5-90106-D01 . . . . . F-15-53
HZZ5-90107-D01 . . . . . F-15-54
HZZ5-90108-D01 . . . . . F-15-55
HZZ5-90109-D01 . . . . . F-15-56
HZZ5-90201-M00 . . . . . E-14-18
HZZ5-90301-D01 . . . . . F-15-57
HZZ5-90301-M00 . . . . . FOP-6-2-16
HZZ5-90301-M00 . . . . . FOP-6-3-16
HZZ5-90301-M00 . . . . . FOP-6-4-16
HZZ5-90302-D01 . . . . . F-15-59
HZZ5-90501-D01 . . . . . F-15-60
HZZ5-90501-M00 . . . . . FOP-6-2-18
HZZ5-90501-M00 . . . . . FOP-6-3-18
HZZ5-90501-M00 . . . . . FOP-6-4-18
HZZ5-90502-D01 . . . . . F-15-61
HZZ5-90502-M00 . . . . . FOP-6-2-19
HZZ5-90502-M00 . . . . . FOP-6-3-19
HZZ5-90502-M00 . . . . . FOP-6-4-19
HZZ5-90503-D01 . . . . . F-15-62
HZZ5-90504-D01 . . . . . F-15-63
HZZ5-90506-D01 . . . . . F-15-64
HZZ5-90507-D01 . . . . . F-15-65
HZZ5-90508-D01 . . . . . F-15-66
HZZ5-90508-M00 . . . . . E-15-20
HZZ5-90508-M00 . . . . . F-2-31
HZZ5-90508-M00 . . . . . F-8-34
HZZ5-90509-D01 . . . . . F-15-67
HZZ5-90651-D01 . . . . . F-15-68
HZZ5-91151-D01 . . . . . F-15-69
HZZ5-91152-D01 . . . . . F-15-70
HZZ5-91153-D01 . . . . . F-15-71
HZZ5-91154-D01 . . . . . F-15-72
HZZ5-91156-D01 . . . . . F-15-73
HZZ5-91157-D01 . . . . . F-15-74
HZZ5-91302-M01 . . . . . E-2-45

Copyright © 2019 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means without the express written permission of Tohatsu Corporation.

2019 PARTS CATALOG

BFT 80AK1
BFT 100AK1
Models

OB No.002-13ZZ0-0AK 1812 EU/EX



TOHATSU CORPORATION

5-4, Azusawa 3-Chome, Itabashi-Ku
Tokyo 174-0051, Japan
Tel: +81-3-3966-3117 Fax: +81-3-3966-2951
www.tohatsu.com