
2023 PARTS CATALOG

トーハツ船外機 パーツカタログ

TOHATSU
Feel the Wind™

MX 15E2
MX 18E2
Models

Serial Number 000001BC～
OB NO.002-21043X0BC 350X 2301



BACKS YOU UP™

TOHATSU CORPORATION

パーツカタログのご使用について


1. このパーツカタログは 2023 年 1 月現在で編集しております。

2. 新設、廃止または変更が生じた場合は、パーツブルテンまたはサービスブルテンにてお知らせ致します。

3. イラストは部品検索の目安として表現していますので、必ずしも現品と形状が一致するわけではありません。

4. 部品をご注文する際は、以下の点に注意し正確にご注文ください。
   ・モデル、製造番号、年式
   ・部品番号、部品名、数量、長さ、色

5. イラストが一つに対して複数の部品番号がある場合は見出番号の枝番、適用モデル、備考をご確認のうえご注文願います。



6. アッセンブリまたはキットでの販売部品は、その構成する部品名の頭に（＊）印をつけて表しています。

7. 本文中に記載されている記号は、次の様になっています。

STD	：スタンダード	OPT	：オプション
O/S	：オーバーサイズ	ASSY	：アッセンブリ
DO	：日本国内向け	EX	：海外輸出向け
A	：必要に応じて選択	US	：米国、カナダ向け
		EU	：EU 加盟国、およびその他の国向け

8. オーダー上の注意
   塗装部品の注文に当っては、以下に従ってください。
   パーツナンバーの 4 桁目が大文字アルファベットのものは塗装されています。
   ［カラーコード］
   B：ブラック
   Q：アクアマリンブルー
   W：ホワイト
   J ：グレー
   H：シルバー

   [例示]

エンジンショートブロックキット	ロワユニットアッシ (L)
3B2B87090-7	3B2Q87302-6
B: ブラック	Q: アクアマリンブルー

9. 標準部品のボルト・ナット・ワッシャのサイズ記号に付いて

ボルト　916129 - 0675
- 首下長さ
- 径
- (5) 平座付き、(0,1,2) 座金無し、(6) ばね座付き

ナット・ワッシャ　940121 - 0600
- 径

10. 標準部品のホースのサイズ記号について


ホース　98AL - 40 - 120
- 長さ
- 径

標準部品のホース、パイプは、1 メートル単位で販売しています。必要な長さにカットしてご使用ください。
標準ホース、パイプは異なる用途、位置に使用しないでください。
部品番号、数量は注文時に置き換えられます。パーツカタログの備考を参照ください。

11. 船外機仕様説明

MFS	25	D	E	F	T	L
エンジン形式	馬力	世代	始動方法	操舵方法	チルト方式	シャフト長さ
MFS: 4ストローク M: 2ストローク MX: 2ストローク Everrun	2~140	A~	M: マニュアル E: 電動	F: ティラーハンドル P: リモートコントロール H: マルチティラーハンドル	T: パワートリム&チルト G: ガスアシスト 空白: マニュアルチルト	S：ショート L：ロング UL：ウルトラロング

12. 製造番号表示位置



HOW TO USE THIS PARTS CATALOG


1. This Parts Catalog provides information available as of the end of January, 2023.

2. Please keep the Parts Catalog updated each time when receiving the Parts/Service Bulletin describing the addition, discontinuation and/or change of parts.

3. Actual shapes of parts may be different from the illustrations shown in this Parts Catalog because they are described only as a guide for searching parts.

4. When ordering spare parts, pay attention to the following points and order correctly.
   · model, serial number, production year
   · part number, part name, quantity, length, color

5. One illustration is given more than one article number. Please confirm the sub-number, applicable model and remarks before ordering parts.



6. Given mark in (＊) to head of part name shows components of assembly or kit parts.

7. Abbreviation used in this Parts Catalog.

STD	: Standard	OPT	: Optional Parts
O/S	: Over size	ASSY	: Assembly
DO	: Domestic model (Japanese model)	EX	: Export model
A	: As required	US	: USA and Canada model
		EU	: EU and other countries model

8. Attention to order
   Please order painted parts in accordance with following.
   Capital letter of the 4th digit indicates color code.
   [Color code]
   B : Black
   Q : Aquamarine Blue
   W : White
   J : Gray
   H : Silver

   [Example]

ENGINE SHORT BLOCK KIT	LOWER UNIT ASSY (L)
3B2B87090-7	3B2Q87302-6
B: Black	Q: Aquamarine Blue

9. Size identification of standard bolt, nut and washer.

BOLT 916129 - 0675

- 0675: Length (not including the head)
- 06: Diameter
- 7: (5) with flat washer, (0,1,2) no washer, (6) with spring washer

NUTS & WASHERS 940121 - 0600

- 06: Diameter

10. Dimensional identification of hose and pipe.

HOSE 98AL - 40 - 120

- 120: Length
- 40: Diameter

Standard hose and pipe are sold by meter.
When replacing the hose or pipe, cut and use at the specified length.


Never use the standard hose and pipe into other purpose or place.

Part number and quantity will be superseded when ordering the parts. Refer to remark in this Parts Catalog.

11. Model description

MFS	25	D	E	F	T	L
Engine type	Horse power	Product generation	Starting system	Steering system	Tilt system	Shaft length
MFS: 4 stroke M: 2 stroke MX: 2 stroke Everrun	2 to 140	A and up	M: Manual E: Electric	F: Tiller handle P: Remote control H: Multi-function tiller handle	T: Power trim & tilt G: Gas assist Blank: Manual tilt	S: Short L: Long UL: Ultra long

12. Serial number location



CONTENTS
目　　次

Fig. 1 CYLINDER・CRANK CASE ····· 1
シリンダ・クランクケース

Fig. 2 PISTON・CRANK SHAFT ····· 7
ピストン・クランクシャフト

Fig. 3 INTAKE MANIFOLD ····· 11
インテークマニホールド

Fig. 4 CARBURETOR ····· 15
キャブレタ

Fig. 5 RECOIL STARTER ····· 19
リコイルスタータ

Fig. 6 MAGNETO・ELECTRIC PARTS ····· 23
マグネト・エレクトリックパーツ

Fig. 8 DRIVE SHAFT HOUSING ····· 27
ドライブシャフトハウジング

Fig. 9 GEAR CASE ····· 29
ギヤケース

Fig. 10 BRACKET ····· 35
ブラケット

Fig. 11 TILLER HANDLE ····· 41
ティラハンドル

Fig. 12 BOTTOM COWL ····· 43
ボトムカウル

Fig. 13 SHIFT ····· 47
シフト

Fig. 15 TOP COWL ····· 49
トップカウル

Fig. 16 FUEL TANK ····· 51
フュエルタンク

Fig. 19 OPTIONAL PARTS・ACCESSORIES ····· 53
オプショナルパーツ・アクセサリ

Fig. 20 ASSEMBLY・KIT PARTS ····· 55
アッセンブリ・キットパーツ

索引 ····· 63

INDEX ····· 67

INDEX (Parts Number) ····· 70

Fig. 1 CYLINDER・CRANK CASE
シリンダ・クランクケース





Fig. 2 PISTON・CRANK SHAFT
ピストン・クランクシャフト



(REMARKS) CRANK SHAFT ASSY ..... Very difficult to assemble. The component parts to be purchased as an assy basically.

Fig. 3 INTAKE MANIFOLD
インテークマニホールド




Fig. 4 CARBURETOR
キャブレタ




Fig. 5 RECOIL STARTER
リコイルスタータ




Fig. 6 MAGNETO・ELECTRIC PARTS
マグネト・エレクトリックパーツ




Fig. 8 DRIVE SHAFT HOUSING
ドライブシャフトハウジング




Fig. 9 GEAR CASE
ギヤケース




Fig. 10 BRACKET
ブラケット




Fig. 11 TILLER HANDLE
ティラハンドル




Fig. 12 BOTTOM COWL
ボトムカウル




Fig. 13 SHIFT
シフト




Fig. 15 TOP COWL
トップカウル




Fig. 16 FUEL TANK
フュエルタンク




Fig. 19 OPTIONAL PARTS・ACCESSORIES
オプショナルパーツ・アクセサリ




Fig. 20 ASSEMBLY・KIT PARTS
アッセンブリ・キットパーツ






Fig. 1 **CYLINDER・CRANK CASE**
シリンダ・クランクケース




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
1-1	3	3LDJ01100-3	CYL BLOCK & CRANKCASE ASSY ｼﾘﾝﾀﾞﾌﾞﾛｯｸ＆ｸﾗﾝｸｹｰｽｱｯｼ	1	1	Gray
1-5		338-01131-1	* NIPPLE 4.8-5 *ﾆｯﾌﾟﾙ 4.8-5	1	1	
1-6		393-01131-0	* NIPPLE 5.5-5 *ﾆｯﾌﾟﾙ 5.5-5	1	1	
1-7		393-01137-0	* NIPPLE 5-4-5 *ﾆｯﾌﾟﾙ L	1	1	
1-8	2	3KK-01012-0	* CYLINDER HEAD BOLT *ｼﾘﾝﾀﾞﾍｯﾄﾞﾎﾞﾙﾄ	10	10	
1-9	2	940103-0800	* WASHER *ﾜｯｼｬ	10	10	
1-10		345-01111-0	* DOWEL PIN 6-12 *ﾀﾞｳｪﾙﾋﾟﾝ 6-12	2	2	
1-11	3	3LDJ01001-0	CYLINDER HEAD ASSY ｼﾘﾝﾀﾞﾍｯﾄﾞｱｯｼ	1	1	Gray
1-12		350-01093-0	* WELCH PLUG *ｳｪﾙﾁﾌﾟﾗｸﾞ	1	1	
1-13	2	3M4-01005-0	CYLINDER HEAD GASKET ｼﾘﾝﾀﾞﾍｯﾄﾞｶﾞｽｹｯﾄ	1	1	
1-14	2	3LD-01012-0	CYLINDER HEAD BOLT ｼﾘﾝﾀﾞﾍｯﾄﾞﾎﾞﾙﾄ	10	10	
1-15		940103-0800	WASHER ﾜｯｼｬ	10	10	
1-16		350-01030-1	THERMOSTAT ｻｰﾓｽﾀｯﾄ	1	1	Mark 52C PRV
1-17	2	3H6J01031-0	THERMOSTAT CAP ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟ	1	1	Gray
1-18		346-01032-0	THERMOSTAT CAP GASKET ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	
1-19	2	9101E3-5630	BOLT ﾎﾞﾙﾄ	2	2	
1-22	2	350J02300-1	EXHAUST COVER ASSY ｴｷｿﾞｰｽﾄｶﾊﾞｰｱｯｼ	1	1	Gray
1-23		9106E3-0808	* BOLT *ﾎﾞﾙﾄ	1	1	
1-24		332-60006-1	* GASKET 8.1-15-1 *ｶﾞｽｹｯﾄ	1	1	
1-25	2	350J02302-1	EXHAUST COVER (INNER) ｴｷｿﾞｰｽﾄｶﾊﾞｰ (ｲﾝﾅ)	1	1	Gray
1-26		350-02305-2	EXHAUST COVER GASKET ｴｷｿﾞｰｽﾄｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	Exhaust Cover Side
1-27		350-02306-2	EXHAUST COVER GASKET ｴｷｿﾞｰｽﾄｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	Cylinder Side
1-28		3NT-02319-0	BOLT 25mm ﾎﾞﾙﾄ 25mm	11	11	
1-29		940103-0600	WASHER ﾜｯｼｬ	11	11	
1-32		98AL-40-030	HOSE ﾎｰｽ	1	1	98AL-401000
1-33		98AL-40-220	HOSE ﾎｰｽ	1	1	98AL-401000
1-34		3LC-01160-0	CHECK VALVE ﾁｪｯｸﾊﾞﾙﾌﾞ	1	1	
1-35		3T5-01133-0	CLIP φ8 ｸﾘｯﾌﾟ φ8	1	1	
1-36		338-01133-0	CLIP φ7 ｸﾘｯﾌﾟ φ7	1	1	

Fig. 1 **CYLINDER・CRANK CASE**
シリンダ・クランクケース




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
1-37		3T5-84398-0	BAND 104 ﾊﾞﾝﾄﾞ	2	2	
1-38		98AB-30-270	HOSE ﾎｰｽ	1	1	Intake Manifold-Cylinder 98AB-301000
1-39		338-01133-0	CLIP φ7 ｸﾘｯﾌﾟ φ7	2	2	
1-40		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	Ground Cable
1-41		350-05211-0	THROTTLE LIMITER ARM ｽﾛｯﾄﾙﾘﾐｯﾀｱｰﾑ	1	1	
1-42	2	350-05227-2	THROTTLE LIMITER SHAFT ｽﾛｯﾄﾙﾘﾐｯﾀｼｬﾌﾄ	1	1	
1-43		941403-0800	WAVE WASHER d=8 ｳｪｰﾌﾞﾜｯｼｬ d=8	1	1	
1-44		350-05222-0	STARTER LOCK ROD ｽﾀｰﾀﾛｯｸﾛｯﾄﾞ	1	1	
1-45		345-05223-1	ROD SNAP 3.5-2 ﾛｯﾄﾞｽﾅｯﾌﾟ 3.5-2	2	2	
1-46		350-63711-2	ADVANCER ARM ｱﾄﾞﾊﾞﾝｻｱｰﾑ	1	1	
1-47		3B7-63733-0	ROD SNAP 5-2.5 ﾛｯﾄﾞｽﾅｯﾌﾟ 5-2.5	1	1	
1-48	2	3KK-63104-0	STUD ｽﾀｯﾄﾞ	1	1	
1-49		345-63713-0	BUSHING 8-14-4 ﾌﾞｯｼﾝｸﾞ 8-14-4	2	2	
1-50		930403-0800	NYLON NUT 8-P1.25 ﾅｲﾛﾝﾅｯﾄ 8-P1.25	1	1	
1-51		940203-0800	WASHER 8.4-15.5-1.6 ﾜｯｼｬ	1	1	
1-52		921503-0525	SCREW ｽｸﾘｭ	2	2	
1-53		930103-0500	NUT ﾅｯﾄ	2	2	
1-54		398-63717-1	ROD 5-65L ﾛｯﾄﾞ 5-65L	1	1	for MX18E2/MX15D2 ℓ=78 M9.9D2 ℓ=75
1-55		930103-0500	NUT ﾅｯﾄ	1	1	for MF/EF Type
1-56		346-05234-0	ROD JOINT φ5 ﾛｯﾄﾞｼﾞｮｲﾝﾄ φ5	1	1	for MF/EF Type
1-57		3B7-63733-0	ROD SNAP 5-2.5 ﾛｯﾄﾞｽﾅｯﾌﾟ 5-2.5	1	1	
1-58		353-83728-1	PIN ﾋﾟﾝ ｹｰﾌﾞﾙ	1	1	for MF/EF Type
1-59		3AA-83719-0	WASHER 8.5-18-1.6 ﾜｯｼｬ 8.5-18-1.6	1	1	for MF/EF Type
1-60		951603-0800	SNAP PIN d=8 ｽﾅｯﾌﾟﾋﾟﾝ d=8	1	1	for MF/EF Type
1-61		930103-0600	NUT ﾅｯﾄ	1	1	for MF/EF Type
1-62		350-63715-1	ROD 5-60L ﾛｯﾄﾞ ｱﾄﾞﾊﾞﾝｻﾘﾝｸ B 5-60L	1	1	ℓ=73
1-63		930103-0500	NUT ﾅｯﾄ	1	1	
1-64		3B7-05243-0	BALL JOINT CONNECTOR ﾎﾞｰﾙｼﾞｮｲﾝﾄｺﾈｸﾀ	1	1	
1-65		398-06972-1	CLAMP 6.5-67P ｸﾗﾝﾌﾟ	1	1	

Fig. 1 **CYLINDER・CRANK CASE**
シリンダ・クランクケース



Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
1-66		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	
1-67		398-06972-1	CLAMP 6.5-67P ｸﾗﾝﾌﾟ	1	1	
1-68	2	9701-1-1010	SPARK PLUG(BP7HS-10) ｽﾊﾟｰｸﾌﾟﾗｸﾞ (BP7HS-10)	2	2	
1-69		3M3-01303-0	ENGINE BASEMENT GASKET ｴﾝｼﾞﾝﾍﾞｰｽｶﾞｽｹｯﾄ	1	1	
1-70		3KK-01012-0	CYLINDER HEAD BOLT ｼﾘﾝﾀﾞﾍｯﾄﾞﾎﾞﾙﾄ	4	4	Engine Basement
1-71		9401E3-0800	WASHER ﾜｯｼｬ	4	4	
1-72		3B7-76142-1	GROUND CABLE L=120 ｸﾞﾗﾝﾄﾞｹｰﾌﾞﾙ (AV2) L=120	1	1	Cylinder Head-Cylinder
1-73		910103-5612	BOLT ﾎﾞﾙﾄ	1	1	Grund Cable
1-74		3KM-01142-0	ANODE PLUG ASSY ｱﾉｰﾄﾞﾌﾟﾗｸﾞｱｯｼ	1	1	
1-75		3P0-01143-0	* ANODE PLUG *ｱﾉｰﾄﾞﾌﾟﾗｸﾞ	1	1	
1-76		3T5-10046-0	* O-RING 1.9-13 *Oﾘﾝｸﾞ 1.9-13	1	1	
1-77		921503-0530	* SCREW *ｽｸﾘｭ	1	1	
1-78		3P0-60218-0	* ANODE *ｱﾉｰﾄﾞ	1	1	


Fig. 2 **PISTON・CRANK SHAFT**
ピストン・クランクシャフト



(REMARKS) CRANK SHAFT ASSY ..... Very difficult to assemble. The component parts to be purchased as an assy basically.

Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
2-1	2	350-00115-0	THRUST PLATE ｽﾗｽﾄﾌﾟﾚｰﾄ ｸﾗﾝｸｼｬﾌﾄ	2	2	
2-2		350-00107-0	THRUST PLATE ｽﾗｽﾄﾌﾟﾚｰﾄ	1	1	
2-6		3LD-00046-1	SMALL END BEARING WASHER ｽﾓｰﾙｴﾝﾄﾞﾍﾞｱﾘﾝｸﾞﾜｯｼｬ	4	4	
2-7	2	3LD-00069-0	CRANKSHAFT SUB-ASSY ｸﾗﾝｸｼｬﾌﾄｻﾌﾞｱｯｼ	1	1	
2-8		350-00040-0	* CONNECTING ROD *ｺﾝﾛｯﾄﾞ	2	2	
2-9		3G4-00043-0	* ROLLER BEARING 20-26-16 *ﾛｰﾗﾍﾞｱﾘﾝｸﾞ 20-26-16	2	2	Big End
2-10		3M2-00031-1	* CRANKSHAFT A *ｸﾗﾝｸｼｬﾌﾄ A	1	1	
2-11	2	3LD-00032-0	* CRANKSHAFT B *ｸﾗﾝｸｼｬﾌﾄ B	1	1	
2-12		350-00051-1	* LABYRINTH PACKING *ﾗﾋﾞﾘﾝｽﾊﾟｯｷﾝ	1	1	
2-13		951407-0308	* SPRING PIN 3-8 *ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-8	1	1	
2-14	2	3LD-00033-0	* CRANKSHAFT C *ｸﾗﾝｸｼｬﾌﾄ C	1	1	
2-15		350-00034-2	* CRANKSHAFT D *ｸﾗﾝｸｼｬﾌﾄ D	1	1	
2-16		350-00062-0	* SEALING PLUG *ｼｰﾘﾝｸﾞﾌﾟﾗｸﾞ	1	1	Crankshaft D
2-17		350-00061-1	* CRANK PIN *ｸﾗﾝｸﾋﾟﾝ	2	2	
2-18		9603-3-6305	* BALL BEARING *ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ	1	1	Center
2-19		9603-3-6305	BALL BEARING ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ	2	2	Upper, Lower
2-20		346-00116-0	SPACER 25.2-34-1.6 ｽﾍﾟｰｻ 25.2-34-1.6	1	1	
2-21		945102-2500	C-RING Cﾘﾝｸﾞ	1	1	
2-22		3LD-01291-0	CRANKCASE HEAD ｸﾗﾝｸｹｰｽﾍｯﾄﾞ	1	1	
2-23		3LD-00121-0	OIL SEAL 25-47-6 ｵｲﾙｼｰﾙ 25-47-6	1	1	
2-24		350-01215-1	OIL SEAL 12.8-25-7 ｵｲﾙｼｰﾙ 12.8-25-7	1	1	
2-25		338-01403-0	O-RING 2-55.5 Oﾘﾝｸﾞ 2-55.5	1	1	
2-31	1	3LD-87123-1	PISTON RING SET ﾋﾟｽﾄﾝﾘﾝｸﾞｾｯﾄ	2	2	STD
2-31	2	3LD-87124-1	PISTON RING SET (0.5 O/S) ﾋﾟｽﾄﾝﾘﾝｸﾞｾｯﾄ (0.5 O/S)	2	2	OPT
2-32	1	3LD-00011-0	* PISTON RING *ﾋﾟｽﾄﾝﾘﾝｸﾞ	1	1	STD 1st Keystone Ring
2-32	2	3LD-00014-0	* PISTON RING (0.5 O/S) *ﾋﾟｽﾄﾝﾘﾝｸﾞ (0.5 O/S)	1	1	OPT 1st Keystone Ring
2-33	1	350-00011-0	* PISTON RING *ﾋﾟｽﾄﾝﾘﾝｸﾞ	1	1	STD 2nd
2-33	2	350-00014-0	* PISTON RING (0.5 O/S) *ﾋﾟｽﾄﾝﾘﾝｸﾞ (0.5 O/S)	1	1	OPT 2nd
2-42	1	3LD-87130-0	PISTON REPAIR KIT ﾋﾟｽﾄﾝﾘﾍﾟｱｷｯﾄ	2	2	STD


Fig. 2 **PISTON・CRANK SHAFT**
ピストン・クランクシャフト



(REMARKS) CRANK SHAFT ASSY ..... Very difficult to assemble. The component parts to be purchased as an assy basically.


Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
2-42	2	3LD-87131-0	PISTON REPAIR KIT (0.5 O/S) ﾋﾟｽﾄﾝﾘﾍﾟｱｷｯﾄ (0.5 O/S)	2	2	OPT
2-43	1	3LD-00001-0	* PISTON *ﾋﾟｽﾄﾝ	1	1	STD
2-43	2	3LD-00004-0	* PISTON (0.5 O/S) *ﾋﾟｽﾄﾝ (0.5 O/S)	1	1	OPT
2-44		350-00021-1	* PISTON PIN *ﾋﾟｽﾄﾝﾋﾟﾝ	1	1	
2-45		350-00024-1	* PISTON PIN CLIP *ﾋﾟｽﾄﾝﾋﾟﾝｸﾘｯﾌﾟ	2	2	
2-46		3LD-00090-0	NEEDLE ROLLER SET ﾆｰﾄﾞﾙﾛｰﾗｾｯﾄ	2	2	Roller x25

Fig. 3 INTAKE MANIFOLD
インテークマニホールド




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
3-1	2	3M2J02010-1	INTAKE MANIFOLD ASSY ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｱｯｼ	1	1	Gray
3-2		338-01131-1	* NIPPLE 4.8-5 * ﾆｯﾌﾟﾙ 4.8-5	1	1	
3-3		350-02104-2	INTAKE MANIFOLD GASKET ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｶﾞｽｹｯﾄ A	1	1	Intake Manifold Side
3-4		350-02105-3	INTAKE MANIFOLD GASKET ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｶﾞｽｹｯﾄ B	1	1	Crankcase Side
3-5	2	3LD-02095-0	BOLT ﾎﾞﾙﾄ	4	4	
3-6	2	3NT-02095-0	BOLT 35mm ﾎﾞﾙﾄ 35mm	1	1	
3-7	2	3LD-63104-0	STUD ｽﾀｯﾄﾞ	1	1	
3-8	2	930103-0600	NUT ﾅｯﾄ	2	2	
3-9	2	3MY-63104-0	STUD ｽﾀｯﾄﾞ	1	1	
3-10	2	940103-0600	WASHER ﾜｯｼｬ	7	7	
3-11		3M2-03167-0	THROTTLE LEVER ASSY ｽﾛｯﾄﾙﾚﾊﾞｰｱｯｼ	1	1	
3-12		3M2-03171-0	* THROTTLE ROLLER * ｽﾛｯﾄﾙﾛｰﾗ	1	1	
3-13		350-03176-0	THROTTLE LEVER END ｽﾛｯﾄﾙﾚﾊﾞｰｴﾝﾄﾞ	1	1	
3-14		910903-0506	BOLT ﾎﾞﾙﾄ	1	1	
3-15		350-03174-0	ROD ﾛｯﾄﾞ	1	1	
3-16		916103-0550	BOLT ﾎﾞﾙﾄ	1	1	
3-17		940103-0500	WASHER ﾜｯｼｬ	1	1	
3-18		362-02100-1	REED VALVE ASSY ﾘｰﾄﾞﾊﾞﾙﾌﾞｱｯｼ	1	1	
3-19		921503-0620	SCREW ｽｸﾘｭ	1	1	
3-20		916103-0680	BOLT ﾎﾞﾙﾄ	2	2	
3-21		940103-0600	WASHER ﾜｯｼｬ	2	2	
3-22		3G2-67196-0	ROD SNAP 3.4-1.6 ﾛｯﾄﾞｽﾅｯﾌﾟ 3.4-1.6	1	1	
3-23		3AD-02230-0	FUEL FILTER ASSY ﾌｭｴﾙﾌｨﾙﾀｱｯｼ	1	1	
3-24		3AD-02237-0	* CUP * ｶｯﾌﾟ	1	1	
3-25		3AD-02235-0	* O-RING * Oﾘﾝｸﾞ	1	1	
3-26		3AD-02234-0	* FILTER * ﾌｨﾙﾀ	1	1	
3-27		930103-0800	NUT ﾅｯﾄ	1	1	
3-28		940203-0800	WASHER 8.4-15.5-1.6 ﾜｯｼｬ	2	2	
3-29		98AB-50-220	HOSE ﾎｰｽ	1	1	Fuel Filter-Fuel Pump 98AB-501000

Fig. 3 INTAKE MANIFOLD
インテークマニホールド




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
3-30		338-02215-0	CLIP φ10 ｸﾘｯﾌﾟ φ10	2	2	
3-31		3G2-02411-0	INTAKE SILENCER ｲﾝﾃｰｸｻｲﾚﾝｻ	1	1	
3-32		345-67117-0	* GROMMET 17-2.7 *ｸﾞﾛﾒｯﾄ 17-2.7	2	2	
3-33		922553-0512	SCREW ｽｸﾘｭ	2	2	
3-34		3G2-67152-0	CHOKE LEVER ﾁｮｰｸﾚﾊﾞｰ	1	1	
3-35		350-67154-0	PLASTIC RIVET 6.5 ﾌﾟﾗｽﾁｯｸﾘﾍﾞｯﾄ 6.5	2	2	
3-36		3G2-02414-1	INTAKE SILENCER GASKET ｲﾝﾃｰｸｻｲﾚﾝｻｶﾞｽｹｯﾄ	1	1	

Fig. 4 CARBURETOR
キャブレタ




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
4-1	3	3LD-03100-2	CARBURETOR ASSY ｷｬﾌﾞﾚﾀｱｯｼ	1	1	3LDX
4-2	2	3M2-04616-0	* MAIN JET (#116) * ﾒｲﾝｼﾞｪｯﾄ (#116)	1	1	
4-3	2	3M2-04560-0	* SLOW JET (#60) * ｽﾛｰｼﾞｪｯﾄ (#60)	1	1	
4-4		3C8-03169-0	* PLUG * ﾌﾟﾗｸﾞ	1	1	
4-5	2	3LD-03147-0	* FLOAT VALVE * ﾌﾛｰﾄﾊﾞﾙﾌﾞ	1	1	
4-6		3C8-03126-0	* FLOAT ARM PIN * ﾌﾛｰﾄｱｰﾑﾋﾟﾝ	1	1	
4-7		3C8-03125-0	* FLOAT * ﾌﾛｰﾄ	1	1	
4-8		921722-0410	* SCREW * ｽｸﾘｭ	1	1	
4-9		3C8-03179-1	* STOP SCREW * ｽﾄｯﾌﾟｽｸﾘｭ	1	1	
4-10		3C8-03157-0	* SPRING * ｽﾌﾟﾘﾝｸﾞ	2	2	
4-11		3G2-03156-0	* ADJUST SCREW * ｱｼﾞｬｽﾄｽｸﾘｭ ｽﾛｯﾄﾙﾌﾘｸｼｮﾝ	1	1	
4-12		3G2-03120-0	* FLOAT CHAMBER * ﾌﾛｰﾄﾁｬﾝﾊﾞ	1	1	
4-13		3C8-03121-0	* FLOAT CHAMBER GASKET * ﾌﾛｰﾄﾁｬﾝﾊﾞｶﾞｽｹｯﾄ	1	1	
4-14		922503-0410	* SCREW * ｽｸﾘｭ	6	6	Float Chamber Carburetor Cover
4-15		910306-0405	* BOLT * ﾎﾞﾙﾄ	1	1	
4-16		3C8-03193-0	* GASKET * ｶﾞｽｹｯﾄ ﾄﾞﾚﾝｽｸﾘｭ	1	1	
4-17	2	3G2-03141-0	* MAIN NOZZLE * ﾒｲﾝﾉｽﾞﾙ	1	1	
4-18		3C8-03181-0	* CARBURETOR COVER * ｷｬﾌﾞﾚﾀｶﾊﾞｰ	1	1	
4-19		3C8-03182-0	* CARBURETOR COVER GASKET * ｷｬﾌﾞﾚﾀｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	
4-20		3C8-03180-0	* RUBBER PLUG * ﾗﾊﾞｰﾌﾟﾗｸﾞ	1	1	
4-21	2	3M3-04004-0	* PUMP COVER * ﾎﾟﾝﾌﾟｶﾊﾞｰ	1	1	
4-22		3E3-64333-0	* PRE-COATED SCREW * ﾌﾟﾚｺｰﾄｽｸﾘｭ	4	4	
4-23		3C8-04018-0	* PUMP COVER GASKET * ﾎﾟﾝﾌﾟｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	
4-24		350-04014-0	* CHECK VALVE * ﾁｪｯｸﾊﾞﾙﾌﾞ	2	2	
4-25		921703-0305	* SCREW * ｽｸﾘｭ	2	2	
4-26		930203-0300	* NUT * ﾅｯﾄ	2	2	
4-27		350-04005-0	* PUMP DIAPHRAGM * ﾎﾟﾝﾌﾟﾀﾞｲﾔﾌﾗﾑ	1	1	
4-28		3C8-04028-0	* PUMP BODY GASKET * ﾎﾟﾝﾌﾟﾎﾞﾃﾞｨｶﾞｽｹｯﾄ	1	1	
4-29		3C8-04002-0	* PUMP BODY * ﾎﾟﾝﾌﾟﾎﾞﾃﾞｨ	1	1	

Fig. 4 CARBURETOR
キャブレタ




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
4-30		3C8-02011-0	CARBURETOR GASKET ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ	1	1	

Fig. 5 RECOIL STARTER
リコイルスタータ




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
5-1	2	3LD-05000-0	RECOIL STARTER ASSY ﾘｺｲﾙｽﾀｰﾀｱｯｼ	1	1	
5-2		350-05105-1	* STARTER CASE *ｽﾀｰﾀｹｰｽ	1	1	
5-3		350-05104-1	* REEL ASSY *ﾘｰﾙｱｯｼ	1	1	
5-4		345-05003-1	* RATCHET *ﾗﾁｪｯﾄ	1	1	
5-5		345-05135-1	* BUSHING 14.7-15.9-6 *ﾌﾞｯｼﾝｸﾞ 14.7-15.9-6	1	1	
5-6		945303-0500	* E-RING d=5 *Eﾘﾝｸﾞ d=5	1	1	
5-7		346-67115-0	* WASHER 6.5-21-1 *ﾜｯｼｬ 6.5-21-1	1	1	
5-8		350-05123-0	* RETURN SPRING *ﾘﾀｰﾝｽﾌﾟﾘﾝｸﾞ A	2	2	
5-9		350-05124-0	* RETURN SPRING *ﾘﾀｰﾝｽﾌﾟﾘﾝｸﾞ B	1	1	
5-10		345-05004-1	* STARTER SPRING *ｽﾀｰﾀｽﾌﾟﾘﾝｸﾞ	1	1	
5-11		951403-0316	* SPRING PIN 3-16 *ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-16	1	1	
5-12		350-05132-0	* STARTER SHAFT *ｽﾀｰﾀｼｬﾌﾄ	1	1	
5-13		910114-0635	* BOLT *ﾎﾞﾙﾄ	1	1	
5-14		930103-0600	* NUT *ﾅｯﾄ	1	1	
5-15		940121-0600	* WASHER *ﾜｯｼｬ	2	2	
5-16		941322-0600	* SPRING WASHER *ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ	1	1	
5-17		338-05019-0	* STARTER HANDLE *ｽﾀｰﾀﾊﾝﾄﾞﾙ	1	1	
5-18		350-05013-1	* STARTER ROPE φ5-1600 *ｽﾀｰﾀﾛｰﾌﾟ φ5-1600	1	1	
5-19		338-05131-0	* ROPE ANCHOR *ﾛｰﾌﾟｱﾝｶ	1	1	
5-20		350-05116-1	* SEALING PLATE *ｼｰﾘﾝｸﾞﾌﾟﾚｰﾄ ｽﾀｰﾀ	1	1	
5-21a		3LD-05912-0	* SEAL *ｼｰﾙｸﾞﾛﾒｯﾄ	1	1	
5-22		3KM-67503-0	STARTER SEAL ｽﾀｰﾀｼｰﾙ	1	1	
5-23		3PR-06972-0	CLAMP 6.5-47.5P ｸﾗﾝﾌﾟ 6.5-47.5P	1	1	
5-24		3M3-02319-0	BOLT 30mm ﾎﾞﾙﾄ 30mm	3	3	Recoil Starter
5-25		940103-0600	WASHER ﾜｯｼｬ	3	3	
5-26		921503-5430	SCREW ｽｸﾘｭ	1	1	
5-27		338-05255-0	COLLAR 4-6-21 ｶﾗｰ 4-6-21	1	1	
5-28		338-05216-0	STARTER LOCK SPRING ｽﾀｰﾀﾛｯｸｽﾌﾟﾘﾝｸﾞ	1	1	
5-29		338-05252-0	STARTER LOCK ｽﾀｰﾀﾛｯｸ	1	1	

Fig. 5 RECOIL STARTER
リコイルスタータ




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
5-30		350-05253-0	STARTER LOCK CAM ｽﾀｰﾀﾛｯｸｶﾑ	1	1	
5-31		941403-0800	WAVE WASHER d=8 ｳｪｰﾌﾞﾜｯｼｬ d=8	1	1	
5-32		921503-7616	SCREW ｽｸﾘｭ	1	1	
5-33		3M2-05215-0	COLLAR 6.1-8-4 ｶﾗｰ 6.1-8-4	1	1	
5-34		350-05217-0	STARTER LOCK ROD ｽﾀｰﾀﾛｯｸﾛｯﾄﾞ	1	1	
5-35		345-05223-1	ROD SNAP 3.5-2 ﾛｯﾄﾞｽﾅｯﾌﾟ 3.5-2	2	2	
5-36		3F0-72185-0	CAUTION DECAL ｺｰｼｮﾝﾃﾞｶｰﾙ	1	1	Front Side
5-37		314-72185-0	CAUTION DECAL ｺｰｼｮﾝﾃﾞｶｰﾙ	1	1	Rear Side

Fig. 6 **MAGNETO・ELECTRIC PARTS**
マグネト・エレクトリックパーツ




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
6-1		350-00121-0	OIL SEAL 25-45-8 ｵｲﾙｼｰﾙ 25-45-8	1	1	
6-2		350-01401-0	MAGNETO BASEMENT ﾏｸﾞﾈﾄﾍﾞｰｽ	1	1	
6-3		338-01403-0	O-RING 2-55.5 Oﾘﾝｸﾞ 2-55.5	1	1	
6-4		910121-6620	BOLT ﾎﾞﾙﾄ	2	2	
6-5		3M3-06001-1	FLYWHEEL ﾌﾗｲﾎｲｰﾙ	1	1	FF 5114 mark 46
6-7		3LD-06102-0	COIL PLATE ASSY ｺｲﾙﾌﾟﾚｰﾄｱｯｼ W/O ｵﾙﾀﾈｰﾀ	1	1	without Alternator
6-10		3G3-06021-1	* EXCITER COIL * ｴｷｻｲﾀｺｲﾙ	1	1	
6-11		921521-6525	* SCREW * ｽｸﾘｭ	2	2	Exciter Coil
6-13		350-06025-0	* HOLDER * ﾎﾙﾀﾞ ﾏｸﾞﾈﾄｺｰﾄﾞ	1	1	
6-14	2	921521-6406	* SCREW * ｽｸﾘｭ	2	2	
6-16		334-00131-0	KEY 19-7-5 ｷｰ 19-7-5	1	1	Magneto
6-17		931121-1600	NUT ﾅｯﾄ	1	1	
6-18		334-00133-0	WASHER 17-30-1.6 ﾜｯｼｬ 17-30-1.6	1	1	
6-20		346-63722-2	GUIDE PLATE ｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	
6-21		350-63723-0	SETTING RING ｾｯﾃｨﾝｸﾞﾘﾝｸﾞ	1	1	
6-22		346-05228-1	BALL JOINT ﾎﾞｰﾙｼﾞｮｲﾝﾄ B	1	1	
6-23		921503-0525	SCREW ｽｸﾘｭ	1	1	
6-24		930103-0500	NUT ﾅｯﾄ	1	1	
6-25	2	921503-6510	SCREW ｽｸﾘｭ	4	4	
6-26		3PR-06972-0	CLAMP 6.5-47.5P ｸﾗﾝﾌﾟ 6.5-47.5P	1	1	
6-27		921503-5510	SCREW ｽｸﾘｭ	1	1	
6-28	2	3LD-63718-0	THROTTLE CAM ｽﾛｯﾄﾙｶﾑ		1	
6-28	3	364-63718-0	THROTTLE CAM ｽﾛｯﾄﾙｶﾑ	1		
6-29		910103-5514	BOLT ﾎﾞﾙﾄ	2	2	
6-30		336-76091-0	LEAD WIRE BAND 100 ﾘｰﾄﾞﾜｲﾔﾊﾞﾝﾄﾞ 100	1	1	
6-32		3G2-06060-4	CD UNIT CDﾕﾆｯﾄ	1	1	CU 2556
6-33		3G2-06061-1	CD UNIT BRACKET CDﾕﾆｯﾄﾌﾞﾗｹｯﾄ	1	1	
6-34		910103-6616	BOLT ﾎﾞﾙﾄ	1	1	
6-35		3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	1	1	

Fig. 6 **MAGNETO・ELECTRIC PARTS**
マグネト・エレクトリックパーツ




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
6-37	2	3LD-06050-1	IGNITION COIL W/CAP ｲｸﾞﾆｯｼｮﾝｺｲﾙ W/ｷｬｯﾌﾟ	1	1	
6-38		3LD-06921-0	* PLUG CAP *ﾌﾟﾗｸﾞｷｬｯﾌﾟ	2	2	
6-39		3M2-06926-0	* PLUG CAP TERMINAL *ﾌﾟﾗｸﾞｷｬｯﾌﾟﾀｰﾐﾅﾙ	2	2	
6-40		3T5-84398-0	* BAND 104 *ﾊﾞﾝﾄﾞ	2	2	
6-47	2	910103-7630	BOLT ﾎﾞﾙﾄ	2	2	
6-49		940103-0600	WASHER ﾜｯｼｬ	2	2	

Fig. 8 **DRIVE SHAFT HOUSING**
ドライブシャフトハウジング




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
8-2	1	3LDQ61191-0	DRIVE SHAFT HOUSING (S) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞ (S)	1	1	for Transom "S"
8-2	2	3LDQ61192-2	DRIVE SHAFT HOUSING (L) ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞ (L)	1	1	for Transom "L" & "UL"
8-3		345-01111-0	DOWEL PIN 6-12 ﾀﾞｳｪﾙﾋﾟﾝ 6-12	4	4	Drive Shaft Housing-Bottom Cowl -Engine Basement
8-4		350-65204-0	WATER PIPE AUXILIARY MOUNT ｳｫｰﾀﾊﾟｲﾌﾟｵｳｷｼﾘｱﾘﾏｳﾝﾄ	1	1	Water Pipe Guide Rubber
8-5		398-61207-0	IDLE EXHAUST PORT GROMMET ｱｲﾄﾞﾙｴｷｿﾞｰｽﾄﾎﾟｰﾄｸﾞﾛﾒｯﾄ	1	1	
8-6		3BJ-60001-0	BOLT 8-31 ﾎﾞﾙﾄ	4	4	
8-7	2	3LD-02311-0	EXHAUST PIPE ｴｷｿﾞｰｽﾄﾊﾟｲﾌﾟ	1	1	
8-8		362-02312-2	EXHAUST PIPE GASKET ｴｷｿﾞｰｽﾄﾊﾟｲﾌﾟｶﾞｽｹｯﾄ	1	1	
8-9		910103-5625	BOLT ﾎﾞﾙﾄ	5	5	
8-10		350Q61110-0	EXTENSION HOUSING ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞ		1	for Transom "UL"
8-11		3BJ-60001-0	BOLT 8-31 ﾎﾞﾙﾄ		4	for Transom "UL"
8-14	1	350-65100-0	WATER PIPE (S) ｳｫｰﾀﾊﾟｲﾌﾟ (S)	1	1	for Transom "S"
8-14	2	350-65110-0	WATER PIPE (L) ｳｫｰﾀﾊﾟｲﾌﾟ (L)	1	1	for Transom "L"
8-14	3	350-65120-0	WATER PIPE (UL) ｳｫｰﾀﾊﾟｲﾌﾟ (UL)		1	for Transom "UL"
8-15		350-65206-0	WATER PIPE SEAL (UPPER) ｳｫｰﾀﾊﾟｲﾌﾟｼｰﾙ (ｱｯﾊﾟ)	1	1	
8-16		350-65205-0	COLLAR ｶﾗｰ ｳｫｰﾀﾊﾟｲﾌﾟ	1	1	

Fig. 9 GEAR CASE
ギヤケース




Ref.No. 見出番号	Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
9-1	3LD-64325-0	GIRD PIPE ASSY ｶﾞｰﾄﾞﾊﾟｲﾌﾟｱｯｼ	1	1	
9-3	350-64326-1	GROMMET 26.1-11.5 ｸﾞﾛﾒｯﾄ ｱｯﾊﾟﾄﾞﾗｲﾌﾞｼｬﾌﾄ	1	1	
9-4	3V9Q60000-1	GEAR CASE ASSY ｷﾞﾔｹｰｽｱｯｼ	1	1	
9-5	350-60211-0	* ROLLER BEARING 16-24-20 * ﾛｰﾗﾍﾞｱﾘﾝｸﾞ 16-24-20	1	1	
9-6	332-60005-3	PLUG 8-8 ﾌﾟﾗｸﾞ 8-8	3	3	
9-7	332-60006-1	GASKET 8.1-15-1 ｶﾞｽｹｯﾄ	3	3	
9-8	9601-0-6205	BALL BEARING 6205 ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6205	1	1	
9-9	398Q60100-2	PROPELLER SHAFT HOUSING ASSY ﾌﾟﾛﾍﾟﾗｼｬﾌﾄﾊｳｼﾞﾝｸﾞｱｯｼ	1	1	
9-10	3BKQ60101-2	* PROPELLER SHAFT HOUSING * ﾌﾟﾛﾍﾟﾗｼｬﾌﾄﾊｳｼﾞﾝｸﾞ	1	1	
9-11	9601-0-6205	* BALL BEARING 6205 * ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6205	1	1	
9-12	362-60211-0	* ROLLER BEARING 17-24-20 * ﾛｰﾗﾍﾞｱﾘﾝｸﾞ 17-24-20	1	1	
9-13	121-32071-0	* O-RING 2.4-59.6 * Oﾘﾝｸﾞ 2.4-59.6	1	1	
9-14	346-65013-0	* OIL SEAL 17-30-9 * ｵｲﾙｼｰﾙ 17-30-9	1	1	
9-15	3BJ-60108-0	BOLT ﾌﾟﾚｺｰﾄﾎﾞﾙﾄ	2	2	
9-17	910103-5620	BOLT ﾎﾞﾙﾄ	1	1	
9-18	350-64010-2	BEVEL GEAR ASSY (A) ﾍﾞﾍﾞﾙｷﾞｱｱｯｼ (A)	1	1	
9-19	350-64020-1	BEVEL GEAR B ﾍﾞﾍﾞﾙｷﾞｱ B	1	1	
9-20	346-64027-1	NUT ﾅｯﾄ ﾍﾞﾍﾞﾙｷﾞﾔ B	1	1	
9-21	362-64030-1	BEVEL GEAR C ﾍﾞﾍﾞﾙｷﾞｱ C	1	1	
9-22	350-64032-0	WASHER 17.1-22-1.5 ﾜｯｼｬ 17.1-22-1.5	1	1	
9-23	362-64211-3	PROPELLER SHAFT ﾌﾟﾛﾍﾟﾗｼｬﾌﾄ	1	1	
9-24	362-64215-0	CLUTCH ｸﾗｯﾁ	1	1	
9-25	350-64218-0	PIN φ5-30 ﾋﾟﾝ ｸﾗｯﾁ φ5-30	1	1	
9-26	350-64219-0	SNAP ｽﾅｯﾌﾟ ｸﾗｯﾁﾋﾟﾝ	1	1	
9-27	332-64221-0	SPRING ｽﾌﾟﾘﾝｸﾞ ｸﾗｯﾁ	1	1	
9-28	350-64222-1	SPRING RETAINER ｽﾌﾟﾘﾝｸﾞﾘﾃｰﾅ ｸﾗｯﾁ	1	1	
9-29	350-64223-1	PUSH ROD ﾌﾟｯｼｭﾛｯﾄﾞ ｸﾗｯﾁ	1	1	
9-30	362-60206-1	WATER STRAINER ｳｫｰﾀｽﾄﾚｰﾅ	2	2	
9-31	921503-0430	SCREW ｽｸﾘｭ	1	1	

Fig. 9 GEAR CASE
ギヤケース




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
9-32		930403-0400	NYLON NUT 4-P0.7 ﾅｲﾛﾝﾅｯﾄ 4-P0.7	1	1	
9-33		369-60206-0	WATER STRAINER ｳｫｰﾀｽﾄﾚｰﾅ ｻﾌﾞ	1	1	
9-34		921803-0620	SCREW ｽｸﾘｭ	1	1	
9-35	2	3LD-65021-0	WATER PUMP IMPELLER ｲﾝﾍﾟﾗｳｫｰﾀﾎﾟﾝﾌﾟ	1	1	
9-36		3RS-65022-1	KEY φ2-16 ｷｰ ﾎﾟﾝﾌﾟｲﾝﾍﾟﾗ φ2-16	1	1	
9-37		350-65016-1	PUMP CASE (UPPER) ﾎﾟﾝﾌﾟｹｰｽ (ｱｯﾊﾟ)	1	1	
9-38		350-65011-1	PUMP CASE LINER ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ	1	1	
9-39		350-65014-0	WATER PIPE SEAL (LOWER) ｳｫｰﾀﾊﾟｲﾌﾟｼｰﾙ (ﾛﾜ)	1	1	
9-40	2	3NT-65017-0	PUMP CASE (LOWER) ﾎﾟﾝﾌﾟｹｰｽ (ﾛﾜ)	1	1	
9-41		332-60223-0	OIL SEAL 13.8-26-9.5 ｵｲﾙｼｰﾙ 13.8-26-9.5	1	1	
9-42		336-62415-0	O-RING 3.5-36 Oﾘﾝｸﾞ 3.5-36	1	1	
9-43		3FS-65029-0	GUIDE PLATE GASKET ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	
9-44		350-65025-0	WATER PUMP GUIDE PLATE ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	
9-45		9101E3-5652	BOLT ﾎﾞﾙﾄ	3	3	
9-46	1	346-64081-0	SHIM 35-41.9-0.1 ｼﾑ 35-41.9-0.1	A	A	
9-46	2	346-64082-0	SHIM 35-41.9-0.15 ｼﾑ 35-41.9-0.15	A	A	
9-46	3	346-64083-0	SHIM 35-41.9-0.3 ｼﾑ 35-41.9-0.3	A	A	
9-46	4	346-64084-0	SHIM 35-41.9-0.5 ｼﾑ 35-41.9-0.5	A	A	
9-47	1	350-64301-0	DRIVE SHAFT (S) ﾄﾞﾗｲﾌﾞｼｬﾌﾄ (S)	1	1	for Transom "S"
9-47	2	350-64302-0	DRIVE SHAFT (L) ﾄﾞﾗｲﾌﾞｼｬﾌﾄ (L)	1	1	for Transom "L"
9-47	3	350-64303-0	DRIVE SHAFT (UL) ﾄﾞﾗｲﾌﾞｼｬﾌﾄ (UL)		1	for Transom "UL"
9-48		9601-0-6302	BALL BEARING 6302 ﾎﾞｰﾙﾍﾞｱﾘﾝｸﾞ 6302	1	1	
9-49	1	398-66012-0	CAM ROD (S) ｶﾑﾛｯﾄﾞ (S)	1	1	for Transom "S"
9-49	2	398-66013-0	CAM ROD (L) ｶﾑﾛｯﾄﾞ (L)	1	1	for Transom "L"
9-49	3	398-66014-0	CAM ROD (UL) ｶﾑﾛｯﾄﾞ (UL)		1	for Transom "UL"
9-50		3C8-66011-0	CLUTCH CAM ｸﾗｯﾁｶﾑ	1	1	
9-51		951407-0312	SPRING PIN 3-12 ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-12	2	2	
9-52		398-66031-0	CAM ROD BUSHING ｶﾑﾛｯﾄﾞﾌﾞｯｼﾝｸﾞ	1	1	
9-53		332-66021-0	O-RING 2.4-5.8 Oﾘﾝｸﾞ 2.4-5.8	2	2	

Fig. 9 GEAR CASE
ギヤケース




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
9-54		336-62415-0	O-RING 3.5-36 Oﾘﾝｸﾞ 3.5-36	1	1	
9-55		332-66033-0	STOPPER ｽﾄｯﾊﾟ ｶﾑﾛｯﾄﾞﾌﾞｯｼﾝｸﾞ	1	1	
9-56		910103-6512	BOLT ﾎﾞﾙﾄ	1	1	
9-59	1	362B64107-1	PROPELLER ASSY (6″) ﾌﾟﾛﾍﾟﾗｱｯｼ (6″)	1	1	OPT 3 x 234 x 155
9-59	2	3BAB64516-1	PROPELLER ASSY (8″) ﾌﾟﾛﾍﾟﾗｱｯｼ (8″)	1	1	M9.9/15:L STD 3 x 235 x 203
9-59	3	3BAB64518-1	PROPELLER ASSY (9″) ﾌﾟﾛﾍﾟﾗｱｯｼ (9″)	1	1	M9.9/15: S M18: S/L STD 3 x 235 x 203
9-59	4	3BAB64521-1	PROPELLER ASSY (10″) ﾌﾟﾛﾍﾟﾗｱｯｼ (10″)	1	1	OPT 3 x 235 x 254
9-59	5	3BAB64524-1	PROPELLER ASSY (11.5″) ﾌﾟﾛﾍﾟﾗｱｯｼ (11.5″)	1	1	OPT 3 x 235 x 292
9-60	2	3RS-87326-0	PROPELLER HARDWARE KIT ﾌﾟﾛﾍﾟﾗﾊｰﾄﾞｳｪｱｷｯﾄ	1	1	
9-61	2	3RS-64231-0	* THRUST HOLDER * ｽﾗｽﾄﾎﾙﾀﾞ	1	1	Stainless steel
9-62		346-64124-5	* WASHER 12.5-32-2.5 * ﾜｯｼｬ 12.5-32-2.5	1	1	
9-63		346-64121-5	* PROPELLER NUT * ﾌﾟﾛﾍﾟﾗﾅｯﾄ	1	1	
9-64		951503-0322	* SPLIT PIN 3-22 * ｽﾌﾟﾘｯﾄﾋﾟﾝ 3-22	1	1	
9-67		3LD-60218-0	ANODE ｱﾉｰﾄﾞ	1	1	

Fig. 10 BRACKET
ブラケット




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
10-1		3V6Q62112-2	CLAMP BRACKET (R) ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (R)	1	1	Starboard Side
10-2		3V6Q62113-1	CLAMP BRACKET (L) ｸﾗﾝﾌﾟﾌﾞﾗｹｯﾄ (L)	1	1	Port Side
10-3		338-60218-2	ANODE ｱﾉｰﾄﾞ	1	1	
10-4		910103-5620	BOLT ﾎﾞﾙﾄ	1	1	
10-5		3V6-62117-0	DISTANCE PIECE ﾃﾞｨｽﾀﾝｽﾋﾟｰｽ	1	1	
10-6		9401E3-0600	WASHER ﾜｯｼｬ	2	2	
10-7		9401E3-0600	WASHER ﾜｯｼｬ	2	2	
10-8		930103-0600	NUT ﾅｯﾄ	2	2	
10-9		3AC-62191-0	SWIVEL BRACKET SHAFT ASSY ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄｼｬﾌﾄｱｯｼ	1	1	Bracket Bolt
10-10		346-62124-1	NYLON NUT 7/8-14 ﾅｲﾛﾝﾅｯﾄ 7/8-14	1	1	
10-11		349-62126-0	BUSHING ﾌﾞｯｼﾝｸﾞ	2	2	
10-12		346-62127-0	CAP NUT ｷｬｯﾌﾟﾅｯﾄ ﾌﾞﾗｹｯﾄﾎﾞﾙﾄ	2	2	
10-13		350-62121-2	THRUST ROD ｽﾗｽﾄﾛｯﾄﾞ	1	1	
10-14		369-62122-2	THRUST ROD SPRING ｽﾗｽﾄﾛｯﾄﾞｽﾌﾟﾘﾝｸﾞ	1	1	
10-15		3G2Q62310-1	SWIVEL BRACKET ｽｲﾍﾞﾙﾌﾞﾗｹｯﾄ	1	1	
10-16		344-67177-1	GREASE FITTING ｸﾞﾘｽﾌｨｯﾃｨﾝｸﾞ	3	3	
10-17		345-62441-0	FRICTION PIECE ﾌﾘｸｼｮﾝﾋﾟｰｽ	1	1	
10-18		346-62421-1	FRICTION SPRING ﾌﾘｸｼｮﾝｽﾌﾟﾘﾝｸﾞ	1	1	
10-19		9101E3-0830	BOLT ﾎﾞﾙﾄ	1	1	
10-20	2	3LDQ62010-1	STEERING SHAFT ASSY ｽﾃｱﾘﾝｸﾞｼｬﾌﾄｱｯｼ	1	1	
10-21		350-63064-1	UNIVERSAL PINION ﾕﾆﾊﾞｰｻﾙﾋﾟﾆｵﾝ	1	1	for MF/EF Type
10-22		350-62417-0	BUSHING 24-30-30 ﾌﾞｯｼﾝｸﾞ 24-30-30	2	2	
10-23		350-62423-0	THRUST PLATE (UPPER) ｽﾗｽﾄﾌﾟﾚｰﾄ (ｱｯﾊﾟｰ)	2	2	
10-24		350-62415-0	O-RING 3.5-22 Oﾘﾝｸﾞ 3.5-22	1	1	
10-25		350-61301-1	RUBBER MOUNT (UPPER) ﾗﾊﾞｰﾏｳﾝﾄ (ｱｯﾊﾟｰ)	2	2	
10-26		350-61337-0	DAMPER (UPPER) ﾀﾞﾝﾊﾟｰ (ｱｯﾊﾟｰ)	1	1	
10-27		398-61307-0	BOLT 10-45 ﾎﾞﾙﾄ 10-45	2	2	
10-28		940103-1000	WASHER ﾜｯｼｬ	2	2	
10-29		398-61308-2	WASHER 10.5-27-1.2 ﾜｯｼｬ ﾏｳﾝﾄﾗﾊﾞｰｱｯﾊﾟｰ	2	2	

Fig. 10 BRACKET
ブラケット




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
10-30		350-61302-0	RUBBER MOUNT (LOWER) ﾗﾊﾞｰﾏｳﾝﾄ (ﾛﾜ)	2	2	
10-31		350-61336-0	DAMPER (LOWER) ﾀﾞﾝﾊﾟ (ﾛﾜ)	1	1	
10-32		350Q61402-2	MOUNT BRACKET (L) ﾏｳﾝﾄﾌﾞﾗｹｯﾄ (L)	1	1	Port Side
10-33	2	350Q61401-1	MOUNT BRACKET (R) ﾏｳﾝﾄﾌﾞﾗｹｯﾄ (R)	1	1	Starboard Side
10-34		3M3-61343-0	BOLT M8-80 ﾎﾞﾙﾄ	1	1	
10-35		3M4-61343-0	BOLT M8-50 ﾎﾞﾙﾄ	1	1	
10-37		3P0-66233-0	WASHER 8.1-16-1.5 ﾜｯｼｬ 8.1-16-1.5	2	2	
10-38		338-60218-2	ANODE ｱﾉｰﾄﾞ	1	1	
10-39		910103-5620	BOLT ﾎﾞﾙﾄ	1	1	
10-40		3G2Q62993-1	TILT STOPPER ﾁﾙﾄｽﾄｯﾊﾟ	1	1	
10-41		951403-0540	SPRING PIN ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ	1	1	
10-42		350-62437-0	BUSHING 8.2-10-26.5 ﾌﾞｯｼﾝｸﾞ 8.2-10-26.5	1	1	
10-43		350-62439-1	SETTING PLATE ｾｯﾃｨﾝｸﾞﾌﾟﾚｰﾄ	1	1	
10-44		9101E3-5818	BOLT ﾎﾞﾙﾄ	2	2	
10-45		3C8-62421-1	FRICTION SPRING ﾌﾘｸｼｮﾝｽﾌﾟﾘﾝｸﾞ	1	1	
10-46		346-62438-0	SETTING PIECE ｾｯﾃｨﾝｸﾞﾋﾟｰｽ ﾁﾙﾄｽﾄｯﾊﾟ	1	1	
10-47		398-62396-1	GROUND L=130 ｸﾞﾗﾝﾄﾞ (ｱｰｽﾜｲﾔ) L=130	1	1	Drive Shaft Housing-Mount Bracket(L)
10-49		398-62396-1	GROUND L=130 ｸﾞﾗﾝﾄﾞ (ｱｰｽﾜｲﾔ) L=130	1	1	Clanp Bracket-Swivel Bracket
10-50		910103-5612	BOLT ﾎﾞﾙﾄ	4	4	
10-51		3A3-62396-1	GROUND L=110 ｸﾞﾗﾝﾄﾞ (ｱｰｽﾜｲﾔ) L=110	1	1	Swivel Bracket-Mount Bracket(L)
10-52		3G2-66311-1	REVERSE LOCK LEVER ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰ	1	1	
10-53		3AL-66333-0	REVERSE LOCK LEVER GRIP ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰｸﾞﾘｯﾌﾟ	1	1	
10-54		346-66334-0	STOPPER ｽﾄｯﾊﾟ ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰｸﾞﾘｯﾌﾟ	1	1	
10-55		3R0-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	1	1	
10-56		3AA-83719-0	WASHER 8.5-18-1.6 ﾜｯｼｬ 8.5-18-1.6	1	1	
10-57		3AL-05254-0	SHOULDER BOLT 6-8 ｼｮﾙﾀﾞﾎﾞﾙﾄ 6-8	1	1	
10-58		940103-0800	WASHER ﾜｯｼｬ	1	1	
10-59		3AL-05212-0	BUSHING 8.1-20 ﾌﾞｯｼﾝｸﾞ 8.1-20	1	1	
10-60		3G2-66351-0	REVERSE LOCK (R) ﾘﾊﾞｰｽﾛｯｸ (R)	1	1	

Fig. 10 BRACKET
ブラケット




Ref.No. 見出番号	Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
10-61	3G2-66313-1	REVERSE LOCK ARM ﾘﾊﾞｰｽﾛｯｸｱｰﾑ	1	1	
10-62	3G2-66319-1	REVERSE LOCK SHAFT ﾘﾊﾞｰｽﾛｯｸｼｬﾌﾄ A	1	1	
10-63	945303-0600	E-RING d=6 Eﾘﾝｸﾞ d=6	2	2	
10-64	3G2-66321-0	REVERSE LOCK ROD ﾘﾊﾞｰｽﾛｯｸﾛｯﾄﾞ A	1	1	
10-65	951503-0212	SPLIT PIN 2-12 ｽﾌﾟﾘｯﾄﾋﾟﾝ 2-12	1	1	
10-66	3G2-66312-2	REVERSE LOCK LINK ﾘﾊﾞｰｽﾛｯｸﾘﾝｸ	1	1	
10-67	350-66315-0	REVERSE LOCK SPRING ﾘﾊﾞｰｽﾛｯｸｽﾌﾟﾘﾝｸﾞ	1	1	
10-68	3G2-66331-0	REVERSE LOCK SPRING (S) ﾘﾊﾞｰｽﾛｯｸｽﾌﾟﾘﾝｸﾞ (S)	2	2	
10-69	910103-0885	BOLT ﾎﾞﾙﾄ	2	2	OPT
10-70	930103-0800	NUT ﾅｯﾄ	2	2	OPT
10-71	940103-0800	WASHER ﾜｯｼｬ	4	4	OPT
10-72	3V1Q62105-2	CLAMP SCREW KIT ｸﾗﾝﾌﾟｽｸﾘｭｷｯﾄ	2	2	
10-73	3V1Q62108-1	* CLAMP SCREW ASSY * ｸﾗﾝﾌﾟｽｸﾘｭｱｯｼ	1	1	
10-74	3M3-62106-0	** CLAMP SCREW ** ｸﾗﾝﾌﾟｽｸﾘｭ	1	1	
10-75	3RSQ62102-0	** CLAMP SCREW HANDLE ** ｸﾗﾝﾌﾟｽｸﾘｭﾊﾝﾄﾞﾙ	1	1	
10-76	951403-0622	** SPRING PIN ** ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ	1	1	
10-77	332-62101-1	* CLAMP SCREW PAD * ｸﾗﾝﾌﾟｽｸﾘｭﾊﾟｯﾄﾞ	1	1	
10-78	945303-0500	* E-RING d=5 * Eﾘﾝｸﾞ d=5	1	1	

Fig. 11 TILLER HANDLE
ティラハンドル




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
11-1	2	3NTQ63003-1	TILLER HANDLE ASSY ﾃｨﾗﾊﾝﾄﾞﾙｱｯｼ	1	1	
11-2	2	3NTQ63005-1	* TILLER HANDLE SUB-ASSY * ﾃｨﾗﾊﾝﾄﾞﾙｻﾌﾞｱｯｼ	1	1	
11-3		3NTQ63011-0	** TILLER HANDLE ** ﾃｨﾗｰﾊﾝﾄﾞﾙ	1	1	
11-4		369-72019-2	** THROTTLE DECAL ** ｽﾛｯﾄﾙﾃﾞｶｰﾙ	1	1	
11-5		398-63053-0	** SPACER ** ｽﾍﾟｰｻ ｽﾛｯﾄﾙｼｬﾌﾄ A	1	1	
11-6		345-63048-0	** THROTTLE SHAFT DAMPER ** ｽﾛｯﾄﾙｼｬﾌﾄﾀﾞﾝﾊﾟ A	1	1	
11-7		350-63046-0	** BUSHING 8.4-10-11 ** ﾌﾞｯｼﾝｸﾞ 8.4-10-11	1	1	
11-8		3NT-63046-0	** BUSHING ** ﾌﾞｯｼﾝｸﾞ	1	1	
11-9		398-63012-0	** GRIP ** ｸﾞﾘｯﾌﾟ	1	1	
11-10		921803-0525	** SCREW ** ｽｸﾘｭ	1	1	
11-11		951403-0310	** SPRING PIN 3-10 ** ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-10	1	1	
11-12	2	3LD-63041-0	** THROTTLE SHAFT ** ｽﾛｯﾄﾙｼｬﾌﾄ	1	1	
11-13		3V1-63035-1	** FRICTION PIECE ** ﾌﾘｸｼｮﾝﾋﾟｰｽ	1	1	
11-14		3V1-63077-0	** ADJUSTING NUT ** ｱｼﾞｬｽﾄﾅｯﾄ	1	1	
11-15		3V1-63036-0	** SPRING ** ｽﾌﾟﾘﾝｸﾞ	1	1	
11-16		910103-0625	** BOLT ** ﾎﾞﾙﾄ	1	1	
11-17		9101E3-5675	** BOLT ** ﾎﾞﾙﾄ	1	1	
11-18		930403-0600	** NYLON NUT 6-P1.0 ** ﾅｲﾛﾝﾅｯﾄ 6-P1.0	1	1	
11-19		346-63201-3	* BOLT 9.7-11-12-8.5 * ﾎﾞﾙﾄ	2	2	
11-20		3NT-63207-0	* COLLAR * ｶﾗｰ	2	2	

Fig. 12 BOTTOM COWL
ボトムカウル




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
12-1	2	3NTQ67100-0	BOTTOM COWL ﾎﾞﾄﾑｶｳﾙ	1	1	
12-3		3M4-60108-0	PRE-COATED BOLT 6-20 ﾌﾟﾚｺｰﾄﾎﾞﾙﾄ	2	2	
12-4		3G2-67151-2	CHOKE ROD ﾁｮｰｸﾛｯﾄﾞ	1	1	
12-5		350-67104-0	CHOKE ROD BUSHING ﾁｮｰｸﾛｯﾄﾞﾌﾞｯｼﾝｸﾞ	1	1	
12-6		338Q67141-0	HOOK LEVER ﾌｯｸﾚﾊﾞｰ	1	1	
12-7		338-67147-0	SEAL RING 13.8-22-3.7 ｼｰﾙﾘﾝｸﾞ 13.8-22-3.7	1	1	
12-8		350-67105-0	HOOK LEVER BUSHING 14-16.5-17.7 ﾌｯｸﾚﾊﾞｰﾌﾞｯｼﾝｸﾞ 14-16.5-17.7	1	1	
12-9		3C8-67146-0	WASHER 14-22-1 ﾜｯｼｬ 14-22-1	1	1	
12-10		941403-1400	WAVE WASHER d=14 ｳｪｰﾌﾞﾜｯｼｬ d=14	1	1	
12-11		345-67142-1	COVER HOOK ｶﾊﾞｰﾌｯｸ	1	1	
12-12		910103-0612	BOLT ﾎﾞﾙﾄ	1	1	
12-13		3C8-66308-0	WASHER 6-16-1.5 ﾜｯｼｬ 6-16-1.5	1	1	
12-14		345-66226-0	GROMMET 17-3 ｸﾞﾛﾒｯﾄ 17-3	1	1	Throttle Shaft for MF/EF Type
12-17		346-67165-0	GROMMET 68-20-2.8 ｸﾞﾛﾒｯﾄ B ﾎﾞﾄﾑｶｳﾙ	1	1	
12-18		353-67162-0	GROMMET 41-14-3 ｸﾞﾛﾒｯﾄ ﾊﾞｯﾃﾘｺｰﾄﾞ	1	1	
12-19		3M2-66226-0	GROMMET 17-3 ｸﾞﾛﾒｯﾄ ｼﾌﾄﾛｯﾄﾞ 17-3	1	1	
12-21		398-06830-0	STOP SWITCH ASSY ｽﾄｯﾌﾟｽｲｯﾁｱｯｼ	1	1	for MF/EF Type
12-22		353-06821-0	* STOP SWITCH LANYARD ASSY * ｽﾄｯﾌﾟｽｲｯﾁﾗﾝﾔｰﾄﾞｱｯｼ	1	1	
12-23	1	336-06973-0	CLAMP 6-9.5L ｸﾗﾝﾌﾟ 6-9.5L	1	1	for MF Type
12-25		921503-5612	SCREW ｽｸﾘｭ	1	1	
12-26		3B2-70260-1	FUEL CONNECTOR (MALE) ﾌｭｴﾙｺﾈｸﾀ (ｴﾝｼﾞﾝﾒｰﾙ)	1	1	
12-27		332-70261-0	NUT 10-P1.25 ﾅｯﾄ 10-P1.25	1	1	
12-28		336-70112-0	GASKET 10.2-16-0.5 ｶﾞｽｹｯﾄ 10.2-16-0.5	1	1	
12-29		98AB-50-185	HOSE ﾎｰｽ	1	1	Fuel Connector-Fuel Filter 98AB-501000
12-30		338-02215-0	CLIP φ10 ｸﾘｯﾌﾟ φ10	2	2	
12-31		350-63061-1	THROTTLE SHAFT ｽﾛｯﾄﾙｼｬﾌﾄ B	1	1	for MF/EF Type
12-32		945303-0600	E-RING d=6 Eﾘﾝｸﾞ d=6	1	1	for MF/EF Type
12-33		350-63063-0	THROTTLE SHAFT SUPPORT ｽﾛｯﾄﾙｼｬﾌﾄｻﾎﾟｰﾄ	2	2	for MF/EF Type
12-34		910103-7630	BOLT ﾎﾞﾙﾄ	1	1	for MF/EF Type

Fig. 12 BOTTOM COWL
ボトムカウル




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
12-35	2	369-72025-1	SPARK PLUG DECAL (BP7HS10) ｽﾊﾟｰｸﾌﾟﾗｸﾞﾃﾞｶｰﾙ	1	1	
12-36		350-61012-2	DRIVE SHAFT HOUSING GASKET ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾞｽｹｯﾄ	1	1	
12-37		9101E3-0518	BOLT ﾎﾞﾙﾄ	1	1	
12-38		9401E3-0500	WASHER ﾜｯｼｬ	1	1	
12-39		9301E3-0500	NUT ﾅｯﾄ	1	1	
12-40		9101E3-0416	BOLT ﾎﾞﾙﾄ	1	1	
12-41		9401E3-0400	WASHER ﾜｯｼｬ	1	1	
12-42		9301E3-0400	NUT ﾅｯﾄ	1	1	
12-43		3AC-72200-0	STOP SWITCH DECAL ｽﾄｯﾌﾟｽｲｯﾁﾃﾞｶｰﾙ	1	1	

Fig. 13 SHIFT
シフト




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
13-1		350-66110-0	SHIFT LEVER ｼﾌﾄﾚﾊﾞｰ	1	1	
13-2		941403-1200	WAVE WASHER d=12 ｳｪｰﾌﾞﾜｯｼｬ d=12	1	1	
13-3		3K9-66137-0	OIL SEAL 14-20-4.5 ｵｲﾙｼｰﾙ 14-20-4.5	1	1	
13-4		350-66121-0	SHIFT DETENT ｼﾌﾄﾃﾞｨﾃﾝﾄ	1	1	
13-5	2	910103-0616	BOLT ﾎﾞﾙﾄ	1	1	
13-6		940103-0600	WASHER ﾜｯｼｬ	1	1	
13-7		350-66115-0	SHIFT LEVER STOP ADJUST ｼﾌﾄﾚﾊﾞｰｽﾄｯﾌﾟｱｼﾞｬｽﾄ	1	1	
13-8		951503-2522	SPLIT PIN 2.5-22 ｽﾌﾟﾘｯﾄﾋﾟﾝ 2.5-22	1	1	
13-9		3M4-66113-0	SHIFT DETENT SPRING ｼﾌﾄﾃﾞｨﾃﾝﾄｽﾌﾟﾘﾝｸﾞ	1	1	
13-10	2	910103-0616	BOLT ﾎﾞﾙﾄ	1	1	
13-11		941303-0600	SPRING WASHER ｽﾌﾟﾘﾝｸﾞﾜｯｼｬ	1	1	
13-12		350-67101-0	BUSHING ﾌﾞｯｼﾝｸﾞ ｼﾌﾄﾚﾊﾞｰｼｬﾌﾄ	2	2	
13-13	1	350-66214-0	SHIFT ROD (S) ｼﾌﾄﾛｯﾄﾞ (S)	1	1	for Transom "S"
13-13	2	350-66215-0	SHIFT ROD (L) ｼﾌﾄﾛｯﾄﾞ (L)	1	1	for Transom "L" & "UL"
13-14		350-66241-0	SHIFT ROD JOINT ｼﾌﾄﾛｯﾄﾞｼﾞｮｲﾝﾄ	1	1	
13-15		951403-0312	SPRING PIN 3-12 ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-12	2	2	
13-16		350-66225-0	SHIFT ROD LEVER ｼﾌﾄﾛｯﾄﾞﾚﾊﾞｰ	1	1	
13-17		951503-2520	SPLIT PIN 2.5-20 ｽﾌﾟﾘｯﾄﾋﾟﾝ 2.5-20	1	1	
13-18		350-66223-0	PIN ﾋﾟﾝ ｼﾌﾄﾛｯﾄﾞﾚﾊﾞｰ	1	1	
13-19		951503-1610	SPLIT PIN 1.6-10 ｽﾌﾟﾘｯﾄﾋﾟﾝ 1.6-10	1	1	
13-20		3B7-67179-0	DRAIN PLUG (ENGINE BASEMENT) ﾄﾞﾚﾝﾌﾟﾗｸﾞ (ｴﾝｼﾞﾝﾍﾞｰｽ)	1	1	

Fig. 15 TOP COWL
トップカウル




Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数		Remarks 備 考
				MX15E2	MX18E2	
15-2		3NTH67645-2	TOP COWL ASSY ﾄｯﾌﾟｶｳﾙｱｯｼ	1	1	Silver
15-4		3NTH67640-0	* TOP COWL SUB-ASSY *ﾄｯﾌﾟｶｳﾙｻﾌﾞｱｯｼ	1	1	Silver
15-6		3NTH67521-0	** TILT HANDLE **ﾁﾙﾄﾊﾝﾄﾞﾙ	1	1	Silver
15-7		930403-0600	** NYLON NUT 6-P1.0 **ﾅｲﾛﾝﾅｯﾄ 6-P1.0	4	4	
15-8		3C8-66308-0	** WASHER 6-16-1.5 **ﾜｯｼｬ 6-16-1.5	4	4	
15-10		3NT-67501-0	** TOP COWL SEAL **ﾄｯﾌﾟｶｳﾙｼｰﾙ	1	1	
15-12	1	3LD-87801-2	* DECAL SET (MX18E2) *ﾃﾞｶｰﾙｾｯﾄ (MX18E2)		1	
15-12	2	3NT-87801-2	* DECAL SET (MX15E2) *ﾃﾞｶｰﾙｾｯﾄ (MX15E2)	1		
15-13		3F0-72185-0	CAUTION DECAL ｺｰｼｮﾝﾃﾞｶｰﾙ	1	1	


Fig. 16 FUEL TANK
フュエルタンク





Ref.No. 見出番号	Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
16-1	3B7-70200-5	PRIMER BULB ASSY ﾌﾟﾗｲﾏﾊﾞﾙﾌﾞｱｯｼ	1	1	
16-2	3C7-70220-1	* JOINT ASSY (INLET) *ｼﾞｮｲﾝﾄｱｯｼ (ｲﾝﾚｯﾄ)	1	1	
16-3	3C7-70224-1	* JOINT ASSY (OUTLET) *ｼﾞｮｲﾝﾄｱｯｼ (ｱｳﾄﾚｯﾄ)	1	1	
16-4	3C7-70211-1	* PRIMER BULB *ﾌﾟﾗｲﾏﾊﾞﾙﾌﾞ	1	1	
16-5	3C7-70217-0	* CLAMP *ｸﾗﾝﾌﾟ	2	2	
16-6	98AB-70-700	* HOSE *ﾎｰｽ	1	1	98AB-701000
16-7	98AB-701600	* HOSE *ﾎｰｽ	1	1	98AB-701000 x2
16-8	3B7-70280-1	* FUEL CONNECTOR MARK *ﾌｭｴﾙｺﾈｸﾀﾏｰｸ	1	1	
16-9	3GF-70281-0	* FUEL CONNECTOR *ﾌｭｴﾙｺﾈｸﾀ (ﾀﾝｸﾌｨﾒｰﾙ)	1	1	
16-10	3GF-70250-1	* FUEL CONNECTOR *ﾌｭｴﾙｺﾈｸﾀ	1	1	
16-11	332-70201-0	* CLAMP *ｸﾗﾝﾌﾟ	4	4	
16-12	3KZ-70177-0	FUEL TANK ASSY 25L ﾌｭｴﾙﾀﾝｸｱｯｼ 25L (ﾄｰﾊﾂ)	1	1	
16-13	3RS-70020-0	* FUEL TANK CAP ASSY *ﾌｭｴﾙﾀﾝｸｷｬｯﾌﾟｱｯｼ	1	1	
16-14	3RS-70021-0	** TANK FILLER CAP GASKET **ﾀﾝｸﾌｨﾗｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	
16-15	3E0-70270-0	* QUICK-CONNECTOR (MALE) *ｸｲｯｸｺﾈｸﾀ (ﾀﾝｸﾒｰﾙ)	1	1	
16-16	3AC-70157-0	* FUEL PICK-UP ASSY W/GAUGE *ﾌｭｴﾙﾋﾟｯｸｱｯﾌﾟｱｯｼ W/ｹﾞｰｼﾞ	1	1	
16-17	3AC-70140-0	* SCREW *ｽｸﾘｭ	4	4	
16-18	3AC-70145-0	* WASHER *ﾜｯｼｬ	4	4	
16-19	3AC-70150-0	* GASKET *ｶﾞｽｹｯﾄ	1	1	

Fig. 19 OPTIONAL PARTS・ACCESSORIES
オプショナルパーツ・アクセサリ











Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
19-1		3C8-72100-1	TOOL KIT ツールキット	1	1	
19-13		336-60007-0	FLUSHING PLUG フラッシングプラグ	1	1	
19-16		3NT-06128-0	ALTERNATOR KIT オルタネータキット	1	1	
19-17		3G2-06023-1	* ALTERNATOR ASSY * オルタネータアッシ	1	1	
19-18		921521-6530	* SCREW * スクリュ	2	2	
19-19		3G2-06025-1	* HOLDER * ホルダ	1	1	
19-20		921521-6406	* SCREW * スクリュ	1	1	
19-21		3LDQ60233-0	ANTI-SPLASH PLATE アンチスプラッシュプレート	1	1	

Fig. 20 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ





CARBURETOR REPAIR KIT
キャブレタリペアキット — 20

POWER HEAD GASKET SET
パワーヘッドガスケットセット — 21


WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 22

WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット （クロムメッキ） — 23

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 24


TILLER HANDLE KIT
ティラハンドルキット — 25


CONNECTING ROD KIT
コネクティングロッドキット — 27



Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
20-1	4	3NTQ87301-1	LOWER UNIT ASSY (S) ﾛﾜﾕﾆｯﾄｱｯｼ (S)	1	1	for Transom "S"
20-1	5	3NTQ87302-1	LOWER UNIT ASSY (L) ﾛﾜﾕﾆｯﾄｱｯｼ (L)	1	1	for Transom "L"
20-1	6	3NTQ87304-1	LOWER UNIT ASSY (UL) ﾛﾜﾕﾆｯﾄｱｯｼ (UL)		1	for Transom "UL"
20-2		3G2-66901-0	REVERSE LOCK SHIFT LEVER KIT ﾘﾊﾞｰｽﾛｯｸｼﾌﾄﾚﾊﾞｰｷｯﾄ	1	1	OPT
20-3		3B2-66322-1	* REVERSE LOCK * ﾘﾊﾞｰｽﾛｯｸ	1	1	
20-4		3G2-66324-0	* REVERSE LOCK SHAFT * ﾘﾊﾞｰｽﾛｯｸｼｬﾌﾄ B	1	1	
20-5		945303-0500	* E-RING d=5 * Eﾘﾝｸﾞ d=5	2	2	
20-6		369-62434-0	* SPRING * ｽﾌﾟﾘﾝｸﾞ ﾁﾙﾄｽﾄｯﾊﾟ	1	1	
20-7		3G2-66305-0	* REVERSE LOCK LINK * ﾘﾊﾞｰｽﾛｯｸﾘﾝｸ B	1	1	
20-8		3G2-62434-0	* SPRING * ｽﾌﾟﾘﾝｸﾞ ﾘﾊﾞｰｽﾛｯｸﾚﾊﾞｰ B	1	1	
20-9		350-66223-0	* PIN * ﾋﾟﾝ ｼﾌﾄﾛｯﾄﾞﾚﾊﾞｰ	1	1	
20-10		951403-0535	* SPRING PIN * ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ	1	1	
20-11		345-05224-0	* ROD SNAP 5-2.5 * ﾛｯﾄﾞｽﾅｯﾌﾟ 5-2.5	1	1	
20-12		350-66337-0	* SPACER 6.1-12-12 * ｽﾍﾟｰｻ 6.1-12-12	1	1	
20-13		350-66302-0	* REVERSE LOCK LINK JOINT * ﾘﾊﾞｰｽﾛｯｸﾘﾝｸｼﾞｮｲﾝﾄ	1	1	
20-14		951503-0212	* SPLIT PIN 2-12 * ｽﾌﾟﾘｯﾄﾋﾟﾝ 2-12	1	1	
20-15		951503-1610	* SPLIT PIN 1.6-10 * ｽﾌﾟﾘｯﾄﾋﾟﾝ 1.6-10	1	1	
20-16		951403-0312	* SPRING PIN 3-12 * ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 3-12	1	1	
20-19	2	3LDJ87090-8	ENGINE SHORT BLOCK KIT ｴﾝｼﾞﾝｼｮｰﾄﾌﾞﾛｯｸｷｯﾄ	1	1	Gray
20-20	1	3G2-87122-2	CARBURETOR REPAIR KIT ｷｬﾌﾞﾚﾀﾘﾍﾟｱｷｯﾄ	1	1	
20-20	2	3C8-02011-0	* CARBURETOR GASKET * ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ	1	1	
20-20	3	3C8-03169-0	* PLUG * ﾌﾟﾗｸﾞ	1	1	
20-20	4	3LD-03147-0	* FLOAT VALVE * ﾌﾛｰﾄﾊﾞﾙﾌﾞ	1	1	
20-20	5	3C8-03126-0	* FLOAT ARM PIN * ﾌﾛｰﾄｱｰﾑﾋﾟﾝ	1	1	
20-20	6	3C8-03125-0	* FLOAT * ﾌﾛｰﾄ	1	1	
20-20	7	3C8-03121-0	* FLOAT CHAMBER GASKET * ﾌﾛｰﾄﾁｬﾝﾊﾞｶﾞｽｹｯﾄ	1	1	

Fig. 20 ASSEMBLY・KIT PARTS
アッセンブリ・キットパーツ





CARBURETOR REPAIR KIT
キャブレタリペアキット — 20

POWER HEAD GASKET SET
パワーヘッドガスケットセット — 21


WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 22

WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット （クロムメッキ） — 23

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 24


TILLER HANDLE KIT
ティラハンドルキット — 25

CONNECTING ROD KIT
コネクティングロッドキット — 27



Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
20-20	8	3C8-03193-0	* GASKET * ｶﾞｽｹｯﾄ ﾄﾞﾚﾝｽｸﾘｭ	1	1	
20-20	9	3C8-03182-0	* CARBURETOR COVER GASKET * ｷｬﾌﾞﾚﾀｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	
20-20	10	922503-0410	* SCREW * ｽｸﾘｭ	6	6	
20-21	3	3LD-87121-1	POWER HEAD GASKET SET ﾊﾟﾜｰﾍｯﾄﾞｶﾞｽｹｯﾄｾｯﾄ	1	1	
20-21	5	3M4-01005-0	* CYLINDER HEAD GASKET * ｼﾘﾝﾀﾞﾍｯﾄﾞｶﾞｽｹｯﾄ	1	1	
20-21	6	346-01032-0	* THERMOSTAT CAP GASKET * ｻｰﾓｽﾀｯﾄｷｬｯﾌﾟｶﾞｽｹｯﾄ	1	1	
20-21	7	350-02305-2	* EXHAUST COVER GASKET * ｴｷｿﾞｰｽﾄｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	
20-21	8	350-02306-2	* EXHAUST COVER GASKET * ｴｷｿﾞｰｽﾄｶﾊﾞｰｶﾞｽｹｯﾄ	1	1	
20-21	9	350-00121-0	* OIL SEAL 25-45-8 * ｵｲﾙｼｰﾙ 25-45-8	1	1	
20-21	11	338-01403-0	* O-RING 2-55.5 * Oﾘﾝｸﾞ 2-55.5	2	2	Crankcase Head Magneto Basement
20-21	13	3LD-00121-0	* OIL SEAL 25-47-6 * ｵｲﾙｼｰﾙ 25-47-6	1	1	Crankcase Head
20-21	14	350-02104-2	* INTAKE MANIFOLD GASKET * ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｶﾞｽｹｯﾄ A	1	1	
20-21	15	350-02105-3	* INTAKE MANIFOLD GASKET * ｲﾝﾃｰｸﾏﾆﾎｰﾙﾄﾞｶﾞｽｹｯﾄ B	1	1	
20-21	16	3C8-03121-0	* FLOAT CHAMBER GASKET * ﾌﾛｰﾄﾁｬﾝﾊﾞｶﾞｽｹｯﾄ	1	1	
20-21	17	3C8-02011-0	* CARBURETOR GASKET * ｷｬﾌﾞﾚﾀｶﾞｽｹｯﾄ	1	1	
20-21	18	3C8-03193-0	* GASKET * ｶﾞｽｹｯﾄ ﾄﾞﾚﾝｽｸﾘｭ	1	1	
20-21	19	350-61012-2	* DRIVE SHAFT HOUSING GASKET * ﾄﾞﾗｲﾌﾞｼｬﾌﾄﾊｳｼﾞﾝｸﾞｶﾞｽｹｯﾄ	1	1	
20-21	20	350-01215-1	* OIL SEAL 12.8-25-7 * ｵｲﾙｼｰﾙ 12.8-25-7	1	1	Bottom Cowl Crankcase Head
20-21	21	3M3-01303-0	* ENGINE BASEMENT GASKET * ｴﾝｼﾞﾝﾍﾞｰｽｶﾞｽｹｯﾄ	1	1	
20-21	22	3G2-02414-1	* INTAKE SILENCER GASKET * ｲﾝﾃｰｸｻｲﾚﾝｻｶﾞｽｹｯﾄ	1	1	
20-22	2	3LD-87322-0	WATER PUMP REPAIR KIT ｳｫｰﾀﾎﾟﾝﾌﾟﾘﾍﾟｱｷｯﾄ	1	1	
20-22	3	3FS-65029-0	* GUIDE PLATE GASKET * ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	
20-22	5	3LD-65021-0	* WATER PUMP IMPELLER * ｲﾝﾍﾟﾗｳｫｰﾀﾎﾟﾝﾌﾟ	1	1	
20-22	6	3RS-65022-1	* KEY * ｷｰ	1	1	
20-22	7	350-65011-1	* PUMP CASE LINER * ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ	1	1	
20-22	8	350-65025-0	* WATER PUMP GUIDE PLATE * ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ	1	1	
20-22	9	9101E3-5652	* BOLT * ﾎﾞﾙﾄ	3	3	

Fig. 20 **ASSEMBLY・KIT PARTS**
アッセンブリ・キットパーツ



CARBURETOR REPAIR KIT
キャブレタリペアキット — 20

POWER HEAD GASKET SET
パワーヘッドガスケットセット — 21


WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 22


WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット （クロムメッキ） — 23

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 24

TILLER HANDLE KIT
ティラハンドルキット — 25


CONNECTING ROD KIT
コネクティングロッドキット — 27






Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
20-23	2	3LD-65231-0	WATER PUMP KIT (CHROME PLATED) ｳｫｰﾀﾎﾟﾝﾌﾟｷｯﾄ(ｸﾛｰﾑﾒｯｷ)	1	1	
20-23	3	3FS-65029-0	* GUIDE PLATE GASKET *ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	
20-23	5	3LD-65021-0	* WATER PUMP IMPELLER *ｲﾝﾍﾟﾗｳｫｰﾀﾎﾟﾝﾌﾟ	1	1	
20-23	6	362-65238-0	* PUMP CASE LINER *ﾎﾟﾝﾌﾟｹｰｽﾗｲﾅ ｸﾛﾑﾒｯｷ	1	1	Chrome Plated
20-23	8	362-65239-0	* WATER PUMP GUIDE PLATE *ｳｫｰﾀﾎﾟﾝﾌﾟｶﾞｲﾄﾞﾌﾟﾚｰﾄ ｸﾛﾑﾒｯｷ	1	1	
20-24	1	398-87321-3	LOWER UNIT GASKET SET ﾛﾜﾕﾆｯﾄｶﾞｽｹｯﾄｾｯﾄ	1	1	
20-24	2	3FS-65029-0	* GUIDE PLATE GASKET *ｶﾞｲﾄﾞﾌﾟﾚｰﾄｶﾞｽｹｯﾄ	1	1	
20-24	3	332-60006-1	* GASKET 8.1-15-1 *ｶﾞｽｹｯﾄ	3	3	
20-24	4	121-32071-0	* O-RING 2.4-59.6 *Oﾘﾝｸﾞ 2.4-59.6	1	1	Propeller Shaft Housing
20-24	5	346-65013-0	* OIL SEAL 17-30-9 *ｵｲﾙｼｰﾙ 17-30-9	1	1	Propeller Shaft
20-24	6	332-60223-0	* OIL SEAL 13.8-26-9.5 *ｵｲﾙｼｰﾙ 13.8-26-9.5	1	1	Pump Case (Lower)
20-24	7	336-62415-0	* O-RING 3.5-36 *Oﾘﾝｸﾞ 3.5-36	2	2	Pump Case (Lower) Cam Rod Bushing
20-24	8	332-66021-0	* O-RING 2.4-5.8 *Oﾘﾝｸﾞ 2.4-5.8	2	2	Cam Rod
20-25	2	3NTQ63000-1	TILLER HANDLE KIT ﾃｨﾗﾊﾝﾄﾞﾙｷｯﾄ	1	1	
20-25	4	3NTQ63003-1	* TILLER HANDLE ASSY *ﾃｨﾗﾊﾝﾄﾞﾙｱｯｼ	1	1	
20-25	5	350-63064-1	* UNIVERSAL PINION *ﾕﾆﾊﾞｰｻﾙﾋﾟﾆｵﾝ	1	1	
20-25	6	350-63061-1	* THROTTLE SHAFT *ｽﾛｯﾄﾙｼｬﾌﾄ B	1	1	
20-25	7	350-63063-0	* THROTTLE SHAFT SUPPORT *ｽﾛｯﾄﾙｼｬﾌﾄｻﾎﾟｰﾄ	2	2	
20-25	8	910103-7630	* BOLT *ﾎﾞﾙﾄ	1	1	
20-25	9	945303-0600	* E-RING d=6 *Eﾘﾝｸﾞ d=6	1	1	
20-25	10	345-66226-0	* GROMMET 17-3 *ｸﾞﾛﾒｯﾄ 17-3	1	1	
20-25	11	353-83728-1	* PIN *ﾋﾟﾝ ｹｰﾌﾞﾙ	1	1	
20-25	12	930103-0600	* NUT *ﾅｯﾄ	1	1	
20-25	13	3AA-83719-0	* WASHER 8.5-18-1.6 *ﾜｯｼｬ 8.5-18-1.6	1	1	
20-25	14	951603-0800	* SNAP PIN d=8 *ｽﾅｯﾌﾟﾋﾟﾝ d=8	1	1	
20-25	15	3B7-63733-0	* ROD SNAP 5-2.5 *ﾛｯﾄﾞｽﾅｯﾌﾟ 5-2.5	1	1	
20-25	16	398-63717-1	* ROD 5-65L *ﾛｯﾄﾞ 5-65L	1	1	

Fig. 20 ASSEMBLY・KIT PARTS
アッセンブリ・キットパーツ





CARBURETOR REPAIR KIT
キャブレタリペアキット — 20

POWER HEAD GASKET SET
パワーヘッドガスケットセット — 21


WATER PUMP REPAIR KIT
ウォータポンプリペアキット — 22

WATER PUMP KIT (CHROME PLATED)
ウォータポンプキット （クロムメッキ） — 23

LOWER UNIT GASKET SET
ロワユニットガスケットセット — 24

TILLER HANDLE KIT
ティラハンドルキット — 25

CONNECTING ROD KIT
コネクティングロッドキット — 27



Ref.No. 見出番号		Part No. 部品番号	Description 部 品 名	Q'ty/個数 MX15E2	 MX18E2	Remarks 備 考
20-25	17	930103-0500	* NUT * ナット	1	1	
20-25	18	346-67165-0	* GROMMET 68-20-2.8 * ｸﾞﾛﾒｯﾄ B ﾎﾞﾄﾑｶｳﾙ	1	1	
20-25	19	353-67162-0	* GROMMET 41-14-3 * ｸﾞﾛﾒｯﾄ ﾊﾞｯﾃﾘｺｰﾄﾞ	1	1	
20-25	20	346-05234-0	* ROD JOINT φ5 * ﾛｯﾄﾞｼﾞｮｲﾝﾄ φ5	1	1	
20-26	1	398Q87314-1	EXTENSION HOUSING KIT (UL) ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞｷｯﾄ(UL)	1	1	for Transom "L"⇒"UL"
20-26	2	350Q61110-0	* EXTENSION HOUSING * ｴｸｽﾃﾝｼｮﾝﾊｳｼﾞﾝｸﾞ	1	1	
20-26	3	3BJ-60001-0	* BOLT 8-31 * ﾎﾞﾙﾄ	4	4	
20-26	4	350-65120-0	* WATER PIPE (UL) * ｳｫｰﾀﾊﾟｲﾌﾟ (UL)	1	1	
20-26	5	350-64303-0	* DRIVE SHAFT (UL) * ﾄﾞﾗｲﾌﾞｼｬﾌﾄ (UL)	1	1	
20-26	6	398-66014-0	* CAM ROD (UL) * ｶﾑﾛｯﾄﾞ (UL)	1	1	
20-27	1	3LD-00039-1	CONNECTING ROD KIT ｺﾝﾛｯﾄﾞｷｯﾄ	1	1	
20-27	2	3LD-00090-0	* NEEDLE ROLLER SET * ﾆｰﾄﾞﾙﾛｰﾗｾｯﾄ	1	1	
20-27	3	350-00040-0	* CONNECTING ROD * ｺﾝﾛｯﾄﾞ	1	1	
20-27	4	3LD-00046-1	* SMALL END BEARING WASHER * ｽﾓｰﾙｴﾝﾄﾞﾍﾞｱﾘﾝｸﾞﾜｯｼｬ	2	2	
20-27	5	3G4-00043-0	* ROLLER BEARING 20-26-16 * ﾛｰﾗﾍﾞｱﾘﾝｸﾞ 20-26-16	1	1	
20-27	6	350-00061-1	* CRANK PIN * ｸﾗﾝｸﾋﾟﾝ	1	1	

索引

<C>

CDユニット 6-32
CDユニットブラケット 6-33
Cリング 2-21

<E>

Eリング d=5 5-6
Eリング d=5 10-78
Eリング d=5 20-5
Eリング d=6 10-63
Eリング d=6 12-32
Eリング d=6 20-25-9

<O>

Oリング 3-25
Oリング 1.9-13 1-76
Oリング 2.4-5.8 9-53
Oリング 2.4-5.8 20-24-8
Oリング 2.4-59.6 9-13
Oリング 2.4-59.6 20-24-4
Oリング 2-55.5 2-25
Oリング 2-55.5 6-3
Oリング 2-55.5 20-21-11
Oリング 3.5-22 10-24
Oリング 3.5-36 9-42
Oリング 3.5-36 9-54
Oリング 3.5-36 20-24-7

<ア>

アイドルエキゾーストポートグロメット 8-5
アジャストスクリュ スロットルフリクション 4-11
アジャストナット 11-14
アドバンサアーム 1-46
アノード 1-78
アノード 10-3
アノード 10-38
アノードプラグ 1-75
アノードプラグアッシ 1-74
アノ-ド 9-67
アンチスプラッシュプレート 19-21

<イ>

イグニッションコイル W/キャップ 6-37-2
インテークサイレンサ 3-31
インテークサイレンサガスケット 3-36
インテークサイレンサガスケット 20-21-22
インテークマニホールドアッシ 3-1-2
インテークマニホールドガスケット A 3-3
インテークマニホールドガスケット A 20-21-14
インテークマニホールドガスケット B 3-4
インテークマニホールドガスケット B 20-21-15
インペラウォータポンプ 9-35-2
インペラウォータポンプ 20-22-5
インペラウォータポンプ 20-23-5

<ウ>

ウェーブワッシャ d=12 13-2
ウェーブワッシャ d=14 12-10
ウェーブワッシャ d=8 1-43
ウェーブワッシャ d=8 5-31
ウェルチプラグ 1-12
ウォータストレーナ 9-30
ウォータストレーナ サブ 9-33
ウォータパイプ (L) 8-14-2
ウォータパイプ (S) 8-14-1
ウォータパイプ (UL) 8-14-3
ウォータパイプ (UL) 20-26-4
ウォータパイプオウキシリアリマウント 8-4
ウォータパイプシール (アッパ) 8-15
ウォータパイプシール (ロワ) 9-39
ウォータポンプガイドプレート 9-44
ウォータポンプガイドプレート 20-22-8
ウォータポンプガイドプレート クロムメッキ 20-23-8
ウォータポンプキット（クロームメッキ） 20-23-2
ウォータポンプリペアキット 20-22-2

<エ>

エキサイタコイル 6-10
エキゾーストカバー (インナ) 1-25-2
エキゾーストカバーアッシ 1-22-2
エキゾーストカバーガスケット 1-26
エキゾーストカバーガスケット 1-27
エキゾーストカバーガスケット 20-21-7
エキゾーストカバーガスケット 20-21-8
エキゾーストパイプ 8-7-2
エキゾーストパイプガスケット 8-8
エクステンションハウジング 8-10
エクステンションハウジング 20-26-2
エクステンションハウジングキット(UL) 20-26-1
エンジンショートブロックキット 20-19-2
エンジンベースガスケット 1-69
エンジンベースガスケット 20-21-21

<オ>

オイルシール 12.8-25-7 2-24
オイルシール 12.8-25-7 20-21-20
オイルシール 13.8-26-9.5 9-41
オイルシール 13.8-26-9.5 20-24-6
オイルシール 14-20-4.5 13-3
オイルシール 17-30-9 9-14
オイルシール 17-30-9 20-24-5
オイルシール 25-45-8 6-1
オイルシール 25-45-8 20-21-9
オイルシール 25-47-6 2-23
オイルシール 25-47-6 20-21-13
オルタネータアッシ 19-17
オルタネータキット 19-16

<カ>

ガードパイプアッシ 9-1
ガイドプレート 6-20
ガイドプレートガスケット 9-43
ガイドプレートガスケット 20-22-3
ガイドプレートガスケット 20-23-3
ガイドプレートガスケット 20-24-2
ガスケット 1-24
ガスケット 9-7
ガスケット 16-19
ガスケット 20-24-3
ガスケット 10.2-16-0.5 12-28
ガスケット ドレンスクリュ 4-16
ガスケット ドレンスクリュ 20-20-8
ガスケット ドレンスクリュ 20-21-18
カップ 3-24
カバーフック 12-11
カムロッド (L) 9-49-2
カムロッド (S) 9-49-1
カムロッド (UL) 9-49-3
カムロッド (UL) 20-26-6
カムロッドブッシング 9-52
カラー 11-20
カラー 4-6-21 5-27
カラー 6.1-8-4 5-33
カラー ウォータパイプ 8-16

<キ>

キー 20-22-6
キー 19-7-5 6-16
キー ポンプインペラ φ2-16 9-36
ギヤケースアッシ 9-4
キャップナット ブラケットボルト 10-12
キャブレタアッシ 4-1-3
キャブレタガスケット 4-30
キャブレタガスケット 20-20-2
キャブレタガスケット 20-21-17
キャブレタカバー 4-18
キャブレタカバーガスケット 4-19
キャブレタカバーガスケット 20-20-9
キャブレタリペアキット 20-20-1

<ク>

クイックコネクタ (タンクメール) 16-15
クラッチ 9-24
クラッチカム 9-50
クランクケースヘッド 2-22
クランクシャフト A 2-10
クランクシャフト B 2-11-2
クランクシャフト C 2-14-2
クランクシャフト D 2-15
クランクシャフトサブアッシ 2-7-2
クランクピン 2-17
クランクピン 20-27-6
グランド (アースワイヤ) L=110 10-51
グランド (アースワイヤ) L=130 10-47
グランド (アースワイヤ) L=130 10-49
グランドケーブル (AV2) L=120 1-72
クランプ 1-65
クランプ 1-67

クランプ 16-5
クランプ 16-11
クランプ 6.5-47.5P 5-23
クランプ 6.5-47.5P 6-26
クランプ 6-9.5L 12-23-1
クランプスクリュ 10-74
クランプスクリュアッシ 10-73
クランプスクリュキット 10-72
クランプスクリュパッド 10-77
クランプスクリュハンドル 10-75
クランプブラケット (L) 10-2
クランプブラケット (R) 10-1
グリスフィッティング 10-16
グリップ 11-9
クリップ φ10 3-30
クリップ φ10 12-30
クリップ φ7 1-36
クリップ φ7 1-39
クリップ φ8 1-35
グロメット 17-2.7 3-32
グロメット 17-3 12-14
グロメット 17-3 20-25-10
グロメット B ボトムカウル 12-17
グロメット B ボトムカウル 20-25-18
グロメット アッパ ドライブシャフト 9-3
グロメット シフトロッド 17-3 12-19
グロメット バッテリコード 12-18
グロメット バッテリコード 20-25-19
<コ>
コイルプレートアッシ W/O オルタネータ 6-7
コーションデカール 5-36
コーションデカール 5-37
コーションデカール 15-13
コンロッド 2-8
コンロッド 20-27-3
コンロッドキット 20-27-1
<サ>
サーモスタット 1-16
サーモスタットキャップ 1-17-2
サーモスタットキャップガスケット 1-18
サーモスタットキャップガスケット 20-21-6
<シ>
シーリングプラグ 2-16
シーリングプレート スタータ 5-20
シールグロメット 5-21a
シールリング 13.8-22-3.7 12-7
シフトディテント 13-4
シフトディテントスプリング 13-9
シフトレバー 13-1
シフトレバーストップアジャスト 13-7
シフトロッド (L) 13-13-2
シフトロッド (S) 13-13-1
シフトロッドジョイント 13-14
シフトロッドレバー 13-16
シム 35-41.9-0.1 9-46-1
シム 35-41.9-0.15 9-46-2
シム 35-41.9-0.3 9-46-3
シム 35-41.9-0.5 9-46-4
ジョイントアッシ (アウトレット) 16-3
ジョイントアッシ (インレット) 16-2
ショルダボルト 6-8 10-57
シリンダブロック＆クランクケ-スアッシ 1-1-3
シリンダヘッドアッシ 1-11-3
シリンダヘッドガスケット 1-13-2
シリンダヘッドガスケット 20-21-5
シリンダヘッドボルト 1-8-2
シリンダヘッドボルト 1-14-2
シリンダヘッドボルト 1-70
<ス>
スイベルブラケット 10-15
スイベルブラケットシャフトアッシ 10-9
スクリュ 1-52
スクリュ 1-77
スクリュ 3-19
スクリュ 3-33
スクリュ 4-8
スクリュ 4-14
スクリュ 4-25
スクリュ 5-26
スクリュ 5-32
スクリュ 6-11
スクリュ 6-14-2
スクリュ 6-23
スクリュ 6-25-2
スクリュ 6-27
スクリュ 9-31
スクリュ 9-34
スクリュ 11-10
スクリュ 12-25
スクリュ 16-17
スクリュ 19-18
スクリュ 19-20
スクリュ 20-20-10
スタータケース 5-2
スタータシール 5-22
スタータシャフト 5-12
スタータスプリング 5-10
スタータハンドル 5-17
スタータロープ φ5-1600 5-18
スタータロック 5-29
スタータロックカム 5-30
スタータロックスプリング 5-28
スタータロックロッド 1-44
スタータロックロッド 5-34
スタッド 1-48-2
スタッド 3-7-2
スタッド 3-9-2
ステアリングシャフトアッシ 10-20-2
ストッパ カムロッドブッシング 9-55
ストッパ リバースロックレバーグリップ 10-54
ストップスイッチアッシ 12-21
ストップスイッチデカ-ル 12-43
ストップスイッチランヤードアッシ 12-22
ストップスクリュ 4-9
スナップ クラッチピン 9-26
スナップピン d=8 1-60
スナップピン d=8 20-25-14
スパークプラグ (BP7HS-10) 1-68-2
スパークプラグデカール 12-35-2
スプリットピン 1.6-10 13-19
スプリットピン 1.6-10 20-15
スプリットピン 2.5-20 13-17
スプリットピン 2.5-22 13-8
スプリットピン 2-12 10-65
スプリットピン 2-12 20-14
スプリットピン 3-22 9-64
スプリング 4-10
スプリング 11-15
スプリング クラッチ 9-27
スプリング チルトストッパ 20-6
スプリング リバースロックレバー B 20-8
スプリングピン 10-41
スプリングピン 10-76
スプリングピン 20-10
スプリングピン 3-10 11-11
スプリングピン 3-12 9-51
スプリングピン 3-12 13-15
スプリングピン 3-12 20-16
スプリングピン 3-16 5-11
スプリングピン 3-8 2-13
スプリングリテーナ クラッチ 9-28
スプリングワッシャ 5-16
スプリングワッシャ 13-11
スペーサ 25.2-34-1.6 2-20
スペーサ 6.1-12-12 20-12
スペーサ スロットルシャフト A 11-5
スモールエンドベアリングワッシャ 2-6
スモールエンドベアリングワッシャ 20-27-4
スラストプレート 2-2
スラストプレート (アッパ) 10-23
スラストプレート クランクシャフト 2-1-2
スラストホルダ 9-61-2
スラストロッド 10-13
スラストロッドスプリング 10-14
スロージェット (#60) 4-3-2
スロットルカム 6-28-2
スロットルカム 6-28-3
スロットルシャフト 11-12-2
スロットルシャフト B 12-31
スロットルシャフト B 20-25-6
スロットルシャフトサポート 12-33
スロットルシャフトサポート 20-25-7
スロットルシャフトダンパ A 11-6
スロットルデカール 11-4
スロットルリミッタアーム 1-41
スロットルリミッタシャフト 1-42-2

スロットルレバーアッシ 3-11
スロットルレバーエンド 3-13
スロットルローラ 3-12
<セ>
セッティングピース チルトストッパ 10-46
セッティングプレート 10-43
セッティングリング 6-21
<タ>
ダウェルピン 6-12 1-10
ダウェルピン 6-12 8-3
タンクフィラキャップガスケット 16-14
ダンパ (アッパ) 10-26
ダンパ (ロワ) 10-31
<チ>
チェックバルブ 1-34
チェックバルブ 4-24
チョークレバー 3-34
チョークロッド 12-4
チョークロッドブッシング 12-5
チルトストッパ 10-40
チルトハンドル 15-6
<ツ>
ツールキット 19-1
<テ>
ディスタンスピース 10-5
ティラ-ハンドル 11-3
ティラハンドルアッシ 11-1-2
ティラハンドルアッシ 20-25-4
ティラハンドルキット 20-25-2
ティラハンドルサブアッシ 11-2-2
デカールセット (MX15E2) 15-12-2
デカールセット (MX18E2) 15-12-1
<ト>
トップカウルアッシ 15-2
トップカウルサブアッシ 15-4
トップカウルシール 15-10
ドライブシャフト (L) 9-47-2
ドライブシャフト (S) 9-47-1
ドライブシャフト (UL) 9-47-3
ドライブシャフト (UL) 20-26-5
ドライブシャフトハウジング (L) 8-2-2
ドライブシャフトハウジング (S) 8-2-1
ドライブシャフトハウジングガスケット 12-36
ドライブシャフトハウジングガスケット 20-21-19
ドレンプラグ (エンジンベース) 13-20
<ナ>
ナイロンナット 4-P0.7 9-32
ナイロンナット 6-P1.0 11-18
ナイロンナット 6-P1.0 15-7
ナイロンナット 7/8-14 10-10
ナイロンナット 8-P1.25 1-50
ナット 1-53
ナット 1-55
ナット 1-61
ナット 1-63
ナット 3-8-2
ナット 3-27
ナット 4-26
ナット 5-14
ナット 6-17
ナット 6-24
ナット 10-8
ナット 10-70
ナット 12-39
ナット 12-42
ナット 20-25-12
ナット 20-25-17
ナット 10-P1.25 12-27
ナット ベベルギヤ B 9-20
<ニ>
ニードルローラセット 2-46
ニードルローラセット 20-27-2
ニップル 4.8-5 1-5
ニップル 4.8-5 3-2
ニップル 5.5-5 1-6
ニップル L 1-7
<ハ>
パワーヘッドガスケットセット 20-21-3
バンド 1-37
バンド 6-40
<ヒ>
ピストン 2-43-1
ピストン (0.5 O/S) 2-43-2
ピストンピン 2-44
ピストンピンクリップ 2-45
ピストンリペアキット 2-42-1
ピストンリペアキット (0.5 O/S) 2-42-2
ピストンリング 2-32-1
ピストンリング 2-33-1
ピストンリング (0.5 O/S) 2-32-2
ピストンリング (0.5 O/S) 2-33-2
ピストンリングセット 2-31-1
ピストンリングセット (0.5 O/S) 2-31-2
ピン クラッチ φ5-30 9-25
ピン ケーブル 1-58
ピン ケーブル 20-25-11
ピン シフトロッドレバー 13-18
ピン シフトロッドレバー 20-9
<フ>
フィルタ 3-26
フックレバー 12-6
フックレバーブッシング 14-16.5-17.7 12-8
プッシュロッド クラッチ 9-29
ブッシング 10-11
ブッシング 11-8
ブッシング 14.7-15.9-6 5-5
ブッシング 24-30-30 10-22
ブッシング 8.1-20 10-59
ブッシング 8.2-10-26.5 10-42
ブッシング 8.4-10-11 11-7
ブッシング 8-14-4 1-49
ブッシング シフトレバーシャフト 13-12
フュエルコネクタ 16-10
フュエルコネクタ (エンジンメール) 12-26
フュエルコネクタ (タンクフィメール) 16-9
フュエルコネクタマーク 16-8
フュエルタンクアッシ 25L (トーハツ) 16-12
フュエルタンクキャップアッシ 16-13
フュエルピックアップアッシ W/ゲージ 16-16
フュエルフィルタアッシ 3-23
フライホイール 6-5
プライマバルブ 16-4
プライマバルブアッシ 16-1
プラグ 4-4
プラグ 20-20-3
プラグ 8-8 9-6
プラグキャップ 6-38
プラグキャップターミナル 6-39
プラスチックリベット 6.5 3-35
フラッシングプラグ 19-13
フリクションスプリング 10-18
フリクションスプリング 10-45
フリクションピース 10-17
フリクションピース 11-13
プレコートスクリュ 4-22
プレコートボルト 9-15
プレコートボルト 12-3
フロート 4-7
フロート 20-20-6
フロートアームピン 4-6
フロートアームピン 20-20-5
フロートチャンバ 4-12
フロートチャンバガスケット 4-13
フロートチャンバガスケット 20-20-7
フロートチャンバガスケット 20-21-16
フロートバルブ 4-5-2
フロートバルブ 20-20-4
プロペラアッシ (10") 9-59-4
プロペラアッシ (11.5") 9-59-5
プロペラアッシ (6") 9-59-1
プロペラアッシ (8") 9-59-2
プロペラアッシ (9") 9-59-3
プロペラシャフト 9-23
プロペラシャフトハウジング 9-10
プロペラシャフトハウジングアッシ 9-9
プロペラナット 9-63
プロペラハードウェアキット 9-60-2
<ヘ>
ベベルギア B 9-19
ベベルギア C 9-21
ベベルギャアッシ (A) 9-18
<ホ>
ホース 1-32
ホース 1-33
ホース 1-38
ホース 3-29

ホース 12-29
ホース 16-6
ホース 16-7
ボールジョイント B. 6-22
ボールジョイントコネクタ 1-64
ボールベアリング. 2-18
ボールベアリング. 2-19
ボールベアリング 6205 9-8
ボールベアリング 6205 9-11
ボールベアリング 6302 9-48
ボトムカウル. 12-1-2
ホルダ 19-19
ホルダ マグネトコード. 6-13
ボルト 1-19-2
ボルト 1-23
ボルト 1-40
ボルト 1-66
ボルト 1-73
ボルト 3-5-2
ボルト 3-14
ボルト 3-16
ボルト 3-20
ボルト 4-15
ボルト 5-13
ボルト 6-4
ボルト 6-29
ボルト 6-34
ボルト 6-47-2
ボルト 8-6
ボルト 8-9
ボルト 8-11
ボルト 9-17
ボルト 9-45
ボルト 9-56
ボルト 10-4
ボルト 10-19
ボルト 10-34
ボルト 10-35
ボルト 10-39
ボルト 10-44
ボルト 10-50
ボルト 10-69
ボルト 11-16
ボルト 11-17
ボルト 11-19
ボルト 12-12
ボルト 12-34
ボルト 12-37
ボルト 12-40
ボルト 13-5-2
ボルト 13-10-2
ボルト 20-22-9
ボルト 20-25-8
ボルト 20-26-3
ボルト 10-45 10-27
ボルト 25mm. 1-28
ボルト 30mm. 5-24
ボルト 35mm. 3-6-2
ポンプカバー. 4-21-2
ポンプカバーガスケット 4-23
ポンプケース (アッパ) 9-37
ポンプケース (ロワ). 9-40-2
ポンプケースライナ 9-38
ポンプケースライナ 20-22-7
ポンプケースライナ クロムメッキ 20-23-6
ポンプダイヤフラム 4-27
ポンプボディ. 4-29
ポンプボディガスケット 4-28
<マ>
マウントブラケット (L) 10-32
マウントブラケット (R) 10-33-2
マグネトベース 6-2
<メ>
メインジェット (#116). 4-2-2
メインノズル. 4-17-2
<ユ>
ユニバーサルピニオン. 10-21
ユニバーサルピニオン. 20-25-5
<ラ>
ラチェット 5-4
ラバープラグ. 4-20
ラバーマウント (アッパ). 10-25
ラバーマウント (ロワ) 10-30
ラビリンスパッキン 2-12
<リ>
リードバルブアッシ 3-18
リードワイヤバンド 100. 6-30
リールアッシ. 5-3
リコイルスタータアッシ 5-1-2
リターンスプリング A 5-8
リターンスプリング B 5-9
リバースロック 20-3
リバースロック (R) 10-60
リバースロックアーム. 10-61
リバースロックシフトレバーキット 20-2
リバースロックシャフト A 10-62
リバースロックシャフト B 20-4
リバースロックスプリング 10-67
リバースロックスプリング (S) 10-68
リバースロックリンク 10-66
リバースロックリンク B. 20-7
リバースロックリンクジョイント. 20-13
リバースロックレバー 10-52
リバースロックレバーグリップ 10-53
リバースロックロッド A. 10-64
<ロ>
ロープアンカ. 5-19
ローラベアリング 16-24-20. 9-5
ローラベアリング 17-24-20. 9-12
ローラベアリング 20-26-16. 2-9
ローラベアリング 20-26-16. 20-27-5
ロッド 3-15
ロッド 5-65L 1-54
ロッド 5-65L 20-25-16
ロッド アドバンサリンク B 5-60L. 1-62
ロッドジョイント φ5 1-56
ロッドジョイント φ5 20-25-20
ロッドスナップ 3.4-1.6. 3-22
ロッドスナップ 3.5-2. 1-45
ロッドスナップ 3.5-2. 5-35
ロッドスナップ 5-2.5. 1-47
ロッドスナップ 5-2.5. 1-57
ロッドスナップ 5-2.5. 20-11
ロッドスナップ 5-2.5. 20-25-15
ロワユニットアッシ (L) 20-1-5
ロワユニットアッシ (S) 20-1-4
ロワユニットアッシ (UL) 20-1-6
ロワユニットガスケットセット 20-24-1
<ワ>
ワッシャ. 1-9-2
ワッシャ. 1-15
ワッシャ. 1-29
ワッシャ. 1-51
ワッシャ. 1-71
ワッシャ. 3-10-2
ワッシャ. 3-17
ワッシャ. 3-21
ワッシャ. 3-28
ワッシャ. 5-15
ワッシャ. 5-25
ワッシャ. 6-49
ワッシャ. 10-6
ワッシャ. 10-7
ワッシャ. 10-28
ワッシャ. 10-58
ワッシャ. 10-71
ワッシャ. 12-38
ワッシャ. 12-41
ワッシャ. 13-6
ワッシャ. 16-18
ワッシャ 12.5-32-2.5 9-62
ワッシャ 14-22-1 12-9
ワッシャ 17.1-22-1.5 9-22
ワッシャ 17-30-1.6 6-18
ワッシャ 6.5-21-1 5-7
ワッシャ 6-16-1.5 6-35
ワッシャ 6-16-1.5 10-55
ワッシャ 6-16-1.5 12-13
ワッシャ 6-16-1.5 15-8
ワッシャ 8.1-16-1.5. 10-37
ワッシャ 8.5-18-1.6. 1-59
ワッシャ 8.5-18-1.6. 10-56
ワッシャ 8.5-18-1.6. 20-25-13
ワッシャ マウントラバーアッパ. 10-29

INDEX

<A>
ADJUST SCREW 4-11
ADJUSTING NUT 11-14
ADVANCER ARM 1-46
ALTERNATOR ASSY 19-17
ALTERNATOR KIT 19-16
ANODE 1-78
ANODE 9-67
ANODE 10-3
ANODE 10-38
ANODE PLUG 1-75
ANODE PLUG ASSY 1-74
ANTI-SPLASH PLATE 19-21
<B>
BALL BEARING 2-18
BALL BEARING 2-19
BALL BEARING 6205 9-8
BALL BEARING 6205 9-11
BALL BEARING 6302 9-48
BALL JOINT 6-22
BALL JOINT CONNECTOR 1-64
BAND 104 1-37
BAND 104 6-40
BEVEL GEAR ASSY (A) 9-18
BEVEL GEAR B 9-19
BEVEL GEAR C 9-21
BOLT 1-19-2
BOLT 1-23
BOLT 1-40
BOLT 1-66
BOLT 1-73
BOLT 3-5-2
BOLT 3-14
BOLT 3-16
BOLT 3-20
BOLT 4-15
BOLT 5-13
BOLT 6-4
BOLT 6-29
BOLT 6-34
BOLT 6-47-2
BOLT 8-9
BOLT 9-15
BOLT 9-17
BOLT 9-45
BOLT 9-56
BOLT 10-4
BOLT 10-19
BOLT 10-39
BOLT 10-44
BOLT 10-50
BOLT 10-69
BOLT 11-16
BOLT 11-17
BOLT 12-12
BOLT 12-34
BOLT 12-37
BOLT 12-40
BOLT 13-5-2
BOLT 13-10-2
BOLT 20-22-9
BOLT 20-25-8
BOLT 10-45 10-27
BOLT 25mm 1-28
BOLT 30mm 5-24
BOLT 35mm 3-6-2
BOLT 8-31 8-6
BOLT 8-31 8-11
BOLT 8-31 20-26-3
BOLT 9.7-11-12-8.5 11-19
BOLT M8-50 10-35
BOLT M8-80 10-34
BOTTOM COWL 12-1-2
BUSHING 10-11
BUSHING 11-8
BUSHING 13-12
BUSHING 14.7-15.9-6 5-5
BUSHING 24-30-30 10-22
BUSHING 8.1-20 10-59
BUSHING 8.2-10-26.5 10-42
BUSHING 8.4-10-11 11-7
BUSHING 8-14-4 1-49
<C>
CAM ROD (L) 9-49-2
CAM ROD (S) 9-49-1
CAM ROD (UL) 9-49-3
CAM ROD (UL) 20-26-6
CAM ROD BUSHING 9-52
CAP NUT 10-12
CARBURETOR ASSY 4-1-3
CARBURETOR COVER 4-18
CARBURETOR COVER GASKET 4-19
CARBURETOR COVER GASKET 20-20-9
CARBURETOR GASKET 4-30
CARBURETOR GASKET 20-20-2
CARBURETOR GASKET 20-21-17
CARBURETOR REPAIR KIT 20-20-1
CAUTION DECAL 5-36
CAUTION DECAL 5-37
CAUTION DECAL 15-13
CD UNIT 6-32
CD UNIT BRACKET 6-33
CHECK VALVE 1-34
CHECK VALVE 4-24
CHOKE LEVER 3-34
CHOKE ROD 12-4
CHOKE ROD BUSHING 12-5
CLAMP 16-5
CLAMP 16-11
CLAMP 6.5-47.5P 5-23
CLAMP 6.5-47.5P 6-26
CLAMP 6.5-67P 1-65
CLAMP 6.5-67P 1-67
CLAMP 6-9.5L 12-23-1
CLAMP BRACKET (L) 10-2
CLAMP BRACKET (R) 10-1
CLAMP SCREW 10-74
CLAMP SCREW ASSY 10-73
CLAMP SCREW HANDLE 10-75
CLAMP SCREW KIT 10-72
CLAMP SCREW PAD 10-77
CLIP φ10 3-30
CLIP φ10 12-30
CLIP φ7 1-36
CLIP φ7 1-39
CLIP φ8 1-35
CLUTCH 9-24
CLUTCH CAM 9-50
COIL PLATE ASSY 6-7
COLLAR 8-16
COLLAR 11-20
COLLAR 4-6-21 5-27
COLLAR 6.1-8-4 5-33
CONNECTING ROD 2-8
CONNECTING ROD 20-27-3
CONNECTING ROD KIT 20-27-1
COVER HOOK 12-11
CRANK PIN 2-17
CRANK PIN 20-27-6
CRANKCASE HEAD 2-22
CRANKSHAFT A 2-10
CRANKSHAFT B 2-11-2
CRANKSHAFT C 2-14-2
CRANKSHAFT D 2-15
CRANKSHAFT SUB-ASSY 2-7-2
C-RING 2-21
CUP 3-24
CYL BLOCK & CRANKCASE ASSY 1-1-3
CYLINDER HEAD ASSY 1-11-3
CYLINDER HEAD BOLT 1-8-2
CYLINDER HEAD BOLT 1-14-2
CYLINDER HEAD BOLT 1-70
CYLINDER HEAD GASKET 1-13-2
CYLINDER HEAD GASKET 20-21-5
<D>
DAMPER (LOWER) 10-31
DAMPER (UPPER) 10-26
DECAL SET (MX15E2) 15-12-2
DECAL SET (MX18E2) 15-12-1
DISTANCE PIECE 10-5
DOWEL PIN 6-12 1-10
DOWEL PIN 6-12 8-3
DRAIN PLUG (ENGINE BASEMENT) 13-20
DRIVE SHAFT (L) 9-47-2
DRIVE SHAFT (S) 9-47-1
DRIVE SHAFT (UL) 9-47-3
DRIVE SHAFT (UL) 20-26-5
DRIVE SHAFT HOUSING (L) 8-2-2
DRIVE SHAFT HOUSING (S) 8-2-1
DRIVE SHAFT HOUSING GASKET 12-36
DRIVE SHAFT HOUSING GASKET 20-21-19
<E>
ENGINE BASEMENT GASKET 1-69
ENGINE BASEMENT GASKET 20-21-21
ENGINE SHORT BLOCK KIT 20-19-2
E-RING d=5 5-6
E-RING d=5 10-78
E-RING d=5 20-5
E-RING d=6 10-63
E-RING d=6 12-32
E-RING d=6 20-25-9
EXCITER COIL 6-10
EXHAUST COVER (INNER) 1-25-2
EXHAUST COVER ASSY 1-22-2
EXHAUST COVER GASKET 1-26
EXHAUST COVER GASKET 1-27
EXHAUST COVER GASKET 20-21-7
EXHAUST COVER GASKET 20-21-8
EXHAUST PIPE 8-7-2
EXHAUST PIPE GASKET 8-8
EXTENSION HOUSING 8-10
EXTENSION HOUSING 20-26-2
EXTENSION HOUSING KIT (UL) 20-26-1
<F>
FILTER 3-26
FLOAT 4-7
FLOAT 20-20-6
FLOAT ARM PIN 4-6
FLOAT ARM PIN 20-20-5
FLOAT CHAMBER 4-12
FLOAT CHAMBER GASKET 4-13
FLOAT CHAMBER GASKET 20-20-7
FLOAT CHAMBER GASKET 20-21-16
FLOAT VALVE 4-5-2
FLOAT VALVE 20-20-4
FLUSHING PLUG 19-13
FLYWHEEL 6-5
FRICTION PIECE 10-17
FRICTION PIECE 11-13
FRICTION SPRING 10-18
FRICTION SPRING 10-45
FUEL CONNECTOR 16-9
FUEL CONNECTOR 16-10
FUEL CONNECTOR (MALE) 12-26
FUEL CONNECTOR MARK 16-8
FUEL FILTER ASSY 3-23
FUEL PICK-UP ASSY W/GAUGE 16-16
FUEL TANK ASSY 25L 16-12
FUEL TANK CAP ASSY 16-13
<G>
GASKET 4-16
GASKET 16-19
GASKET 20-20-8
GASKET 20-21-18
GASKET 10.2-16-0.5 12-28
GASKET 8.1-15-1 1-24
GASKET 8.1-15-1 9-7
GASKET 8.1-15-1 20-24-3
GEAR CASE ASSY 9-4
GIRD PIPE ASSY 9-1
GREASE FITTING 10-16
GRIP 11-9
GROMMET 17-2.7 3-32
GROMMET 17-3 12-14
GROMMET 17-3 12-19
GROMMET 17-3 20-25-10
GROMMET 26.1-11.5 9-3

GROMMET 41-14-3 12-18
GROMMET 41-14-3 20-25-19
GROMMET 68-20-2.8..... 12-17
GROMMET 68-20-2.8..... 20-25-18
GROUND CABLE L=120 1-72
GROUND L=110 10-51
GROUND L=130 10-47
GROUND L=130 10-49
GUIDE PLATE 6-20
GUIDE PLATE GASKET..... 9-43
GUIDE PLATE GASKET..... 20-22-3
GUIDE PLATE GASKET..... 20-23-3
GUIDE PLATE GASKET..... 20-24-2
<H>
HOLDER..... 6-13
HOLDER..... 19-19
HOOK LEVER 12-6
HOOK LEVER BUSHING 14-16.5-17.7... 12-8
HOSE..... 1-32
HOSE..... 1-33
HOSE..... 1-38
HOSE..... 3-29
HOSE..... 12-29
HOSE..... 16-6
HOSE..... 16-7
<I>
IDLE EXHAUST PORT GROMMET..... 8-5
IGNITION COIL W/CAP 6-37-2
INTAKE MANIFOLD ASSY..... 3-1-2
INTAKE MANIFOLD GASKET 3-3
INTAKE MANIFOLD GASKET 3-4
INTAKE MANIFOLD GASKET 20-21-14
INTAKE MANIFOLD GASKET 20-21-15
INTAKE SILENCER..... 3-31
INTAKE SILENCER GASKET..... 3-36
INTAKE SILENCER GASKET..... 20-21-22
<J>
JOINT ASSY (INLET) 16-2
JOINT ASSY (OUTLET)..... 16-3
<K>
KEY 20-22-6
KEY 19-7-5 6-16
KEY φ2-16 9-36
<L>
LABYRINTH PACKING 2-12
LEAD WIRE BAND 100..... 6-30
LOWER UNIT ASSY (L)..... 20-1-5
LOWER UNIT ASSY (S)..... 20-1-4
LOWER UNIT ASSY (UL) 20-1-6
LOWER UNIT GASKET SET 20-24-1
<M>
MAGNETO BASEMENT 6-2
MAIN JET (#116) 4-2-2
MAIN NOZZLE..... 4-17-2
MOUNT BRACKET (L)..... 10-32
MOUNT BRACKET (R)..... 10-33-2
<N>
NEEDLE ROLLER SET 2-46
NEEDLE ROLLER SET 20-27-2
NIPPLE 4.8-5..... 1-5
NIPPLE 4.8-5..... 3-2
NIPPLE 5.5-5..... 1-6
NIPPLE 5-4-5 1-7
NUT..... 1-53
NUT..... 1-55
NUT..... 1-61
NUT..... 1-63
NUT..... 3-8-2
NUT..... 3-27
NUT..... 4-26
NUT..... 5-14
NUT..... 6-17
NUT..... 6-24
NUT..... 9-20
NUT..... 10-8
NUT..... 10-70
NUT..... 12-39
NUT..... 12-42
NUT..... 20-25-12
NUT..... 20-25-17
NUT 10-P1.25..... 12-27
NYLON NUT 4-P0.7 9-32
NYLON NUT 6-P1.0 11-18
NYLON NUT 6-P1.0 15-7
NYLON NUT 7/8-14 10-10
NYLON NUT 8-P1.25 1-50
<O>
OIL SEAL 12.8-25-7 2-24
OIL SEAL 12.8-25-7 20-21-20
OIL SEAL 13.8-26-9.5..... 9-41
OIL SEAL 13.8-26-9.5..... 20-24-6
OIL SEAL 14-20-4.5 13-3
OIL SEAL 17-30-9 9-14
OIL SEAL 17-30-9 20-24-5
OIL SEAL 25-45-8 6-1
OIL SEAL 25-45-8 20-21-9
OIL SEAL 25-47-6 2-23
OIL SEAL 25-47-6 20-21-13
O-RING..... 3-25
O-RING 1.9-13 1-76
O-RING 2.4-5.8..... 9-53
O-RING 2.4-5.8..... 20-24-8
O-RING 2.4-59.6 9-13
O-RING 2.4-59.6 20-24-4
O-RING 2-55.5 2-25
O-RING 2-55.5 6-3
O-RING 2-55.5 20-21-11
O-RING 3.5-22 10-24
O-RING 3.5-36 9-42
O-RING 3.5-36 9-54
O-RING 3.5-36 20-24-7
<P>
PIN..... 1-58
PIN..... 13-18
PIN..... 20-9
PIN..... 20-25-11
PIN φ5-30 9-25
PISTON..... 2-43-1
PISTON (0.5 O/S)..... 2-43-2
PISTON PIN..... 2-44
PISTON PIN CLIP..... 2-45
PISTON REPAIR KIT..... 2-42-1
PISTON REPAIR KIT (0.5 O/S)..... 2-42-2
PISTON RING 2-32-1
PISTON RING 2-33-1
PISTON RING (0.5 O/S) 2-32-2
PISTON RING (0.5 O/S) 2-33-2
PISTON RING SET 2-31-1
PISTON RING SET (0.5 O/S) 2-31-2
PLASTIC RIVET 6.5 3-35
PLUG..... 4-4
PLUG..... 20-20-3
PLUG 8-8..... 9-6
PLUG CAP 6-38
PLUG CAP TERMINAL 6-39
POWER HEAD GASKET SET 20-21-3
PRE-COATED BOLT 6-20..... 12-3
PRE-COATED SCREW..... 4-22
PRIMER BULB..... 16-4
PRIMER BULB ASSY 16-1
PROPELLER ASSY (10") 9-59-4
PROPELLER ASSY (11.5") 9-59-5
PROPELLER ASSY (6") 9-59-1
PROPELLER ASSY (8") 9-59-2
PROPELLER ASSY (9") 9-59-3
PROPELLER HARDWARE KIT 9-60-2
PROPELLER NUT..... 9-63
PROPELLER SHAFT..... 9-23
PROPELLER SHAFT HOUSING..... 9-10
PROPELLER SHAFT HOUSING ASSY 9-9
PUMP BODY..... 4-29
PUMP BODY GASKET 4-28
PUMP CASE (LOWER) 9-40-2
PUMP CASE (UPPER)..... 9-37
PUMP CASE LINER 9-38
PUMP CASE LINER 20-22-7
PUMP CASE LINER 20-23-6
PUMP COVER..... 4-21-2
PUMP COVER GASKET 4-23
PUMP DIAPHRAGM..... 4-27
PUSH ROD..... 9-29
<Q>
QUICK-CONNECTOR (MALE)..... 16-15
<R>
RATCHET..... 5-4
RECOIL STARTER ASSY 5-1-2
REED VALVE ASSY 3-18
REEL ASSY..... 5-3
RETURN SPRING 5-8
RETURN SPRING 5-9
REVERSE LOCK..... 20-3
REVERSE LOCK (R) 10-60
REVERSE LOCK ARM 10-61
REVERSE LOCK LEVER 10-52
REVERSE LOCK LEVER GRIP..... 10-53
REVERSE LOCK LINK..... 10-66
REVERSE LOCK LINK..... 20-7
REVERSE LOCK LINK JOINT 20-13
REVERSE LOCK ROD..... 10-64
REVERSE LOCK SHAFT..... 10-62
REVERSE LOCK SHAFT..... 20-4
REVERSE LOCK SHIFT LEVER KIT 20-2
REVERSE LOCK SPRING..... 10-67
REVERSE LOCK SPRING (S)..... 10-68
ROD..... 3-15
ROD 5-60L..... 1-62
ROD 5-65L..... 1-54
ROD 5-65L..... 20-25-16
ROD JOINT φ5 1-56
ROD JOINT φ5 20-25-20
ROD SNAP 3.4-1.6 3-22
ROD SNAP 3.5-2 1-45
ROD SNAP 3.5-2 5-35
ROD SNAP 5-2.5 1-47
ROD SNAP 5-2.5 1-57
ROD SNAP 5-2.5 20-11
ROD SNAP 5-2.5 20-25-15
ROLLER BEARING 16-24-20..... 9-5
ROLLER BEARING 17-24-20..... 9-12
ROLLER BEARING 20-26-16..... 2-9
ROLLER BEARING 20-26-16..... 20-27-5
ROPE ANCHOR 5-19
RUBBER MOUNT (LOWER)..... 10-30
RUBBER MOUNT (UPPER) 10-25
RUBBER PLUG 4-20
<S>
SCREW..... 1-52
SCREW..... 1-77
SCREW..... 3-19
SCREW..... 3-33
SCREW..... 4-8
SCREW..... 4-14
SCREW..... 4-25
SCREW..... 5-26
SCREW..... 5-32
SCREW..... 6-11
SCREW..... 6-14-2
SCREW..... 6-23
SCREW..... 6-25-2
SCREW..... 6-27
SCREW..... 9-31
SCREW..... 9-34
SCREW..... 11-10
SCREW..... 12-25
SCREW..... 16-17
SCREW..... 19-18
SCREW..... 19-20
SCREW..... 20-20-10
SEAL 5-21a
SEAL RING 13.8-22-3.7 12-7
SEALING PLATE..... 5-20
SEALING PLUG..... 2-16
SETTING PIECE..... 10-46
SETTING PLATE 10-43
SETTING RING 6-21
SHIFT DETENT 13-4
SHIFT DETENT SPRING 13-9
SHIFT LEVER..... 13-1
SHIFT LEVER STOP ADJUST..... 13-7
SHIFT ROD (L) 13-13-2
SHIFT ROD (S) 13-13-1
SHIFT ROD JOINT 13-14
SHIFT ROD LEVER..... 13-16
SHIM 35-41.9-0.1 9-46-1
SHIM 35-41.9-0.15 9-46-2
SHIM 35-41.9-0.3 9-46-3
SHIM 35-41.9-0.5 9-46-4
SHOULDER BOLT 6-8..... 10-57
SLOW JET (#60)..... 4-3-2

SMALL END BEARING WASHER 2-6
SMALL END BEARING WASHER 20-27-4
SNAP 9-26
SNAP PIN d=8 1-60
SNAP PIN d=8 20-25-14
SPACER 11-5
SPACER 25.2-34-1.6 2-20
SPACER 6.1-12-12 20-12
SPARK PLUG DECAL (BP7HS10) 12-35-2
SPARK PLUG(BP7HS-10) 1-68-2
SPLIT PIN 1.6-10 13-19
SPLIT PIN 1.6-10 20-15
SPLIT PIN 2.5-20 13-17
SPLIT PIN 2.5-22 13-8
SPLIT PIN 2-12 10-65
SPLIT PIN 2-12 20-14
SPLIT PIN 3-22 9-64
SPRING 4-10
SPRING 9-27
SPRING 11-15
SPRING 20-6
SPRING 20-8
SPRING PIN 10-41
SPRING PIN 10-76
SPRING PIN 20-10
SPRING PIN 3-10 11-11
SPRING PIN 3-12 9-51
SPRING PIN 3-12 13-15
SPRING PIN 3-12 20-16
SPRING PIN 3-16 5-11
SPRING PIN 3-8 2-13
SPRING RETAINER 9-28
SPRING WASHER 5-16
SPRING WASHER 13-11
STARTER CASE 5-2
STARTER HANDLE 5-17
STARTER LOCK 5-29
STARTER LOCK CAM 5-30
STARTER LOCK ROD 1-44
STARTER LOCK ROD 5-34
STARTER LOCK SPRING 5-28
STARTER ROPE φ5-1600 5-18
STARTER SEAL 5-22
STARTER SHAFT 5-12
STARTER SPRING 5-10
STEERING SHAFT ASSY 10-20-2
STOP SCREW 4-9
STOP SWITCH ASSY 12-21
STOP SWITCH DECAL 12-43
STOP SWITCH LANYARD ASSY 12-22
STOPPER 9-55
STOPPER 10-54
STUD 1-48-2
STUD 3-7-2
STUD 3-9-2
SWIVEL BRACKET 10-15
SWIVEL BRACKET SHAFT ASSY 10-9
<T>
TANK FILLER CAP GASKET 16-14
THERMOSTAT 1-16
THERMOSTAT CAP 1-17-2
THERMOSTAT CAP GASKET 1-18
THERMOSTAT CAP GASKET 20-21-6
THROTTLE CAM 6-28-2
THROTTLE CAM 6-28-3
THROTTLE DECAL 11-4
THROTTLE LEVER ASSY 3-11
THROTTLE LEVER END 3-13
THROTTLE LIMITER ARM 1-41
THROTTLE LIMITER SHAFT 1-42-2
THROTTLE ROLLER 3-12
THROTTLE SHAFT 11-12-2
THROTTLE SHAFT 12-31
THROTTLE SHAFT 20-25-6
THROTTLE SHAFT DAMPER 11-6
THROTTLE SHAFT SUPPORT 12-33
THROTTLE SHAFT SUPPORT 20-25-7
THRUST HOLDER 9-61-2
THRUST PLATE 2-1-2
THRUST PLATE 2-2
THRUST PLATE (UPPER) 10-23
THRUST ROD 10-13
THRUST ROD SPRING 10-14
TILLER HANDLE 11-3
TILLER HANDLE ASSY 11-1-2
TILLER HANDLE ASSY 20-25-4
TILLER HANDLE KIT 20-25-2
TILLER HANDLE SUB-ASSY 11-2-2
TILT HANDLE 15-6
TILT STOPPER 10-40
TOOL KIT 19-1
TOP COWL ASSY 15-2
TOP COWL SEAL 15-10
TOP COWL SUB-ASSY 15-4
<U>
UNIVERSAL PINION 10-21
UNIVERSAL PINION 20-25-5
<W>
WASHER 1-9-2
WASHER 1-15
WASHER 1-29
WASHER 1-71
WASHER 3-10-2
WASHER 3-17
WASHER 3-21
WASHER 5-15
WASHER 5-25
WASHER 6-49
WASHER 10-6
WASHER 10-7
WASHER 10-28
WASHER 10-58
WASHER 10-71
WASHER 12-38
WASHER 12-41
WASHER 13-6
WASHER 16-18
WASHER 10.5-27-1.2 10-29
WASHER 12.5-32-2.5 9-62
WASHER 14-22-1 12-9
WASHER 17.1-22-1.5 9-22
WASHER 17-30-1.6 6-18
WASHER 6.5-21-1 5-7
WASHER 6-16-1.5 6-35
WASHER 6-16-1.5 10-55
WASHER 6-16-1.5 12-13
WASHER 6-16-1.5 15-8
WASHER 8.1-16-1.5 10-37
WASHER 8.4-15.5-1.6 1-51
WASHER 8.4-15.5-1.6 3-28
WASHER 8.5-18-1.6 1-59
WASHER 8.5-18-1.6 10-56
WASHER 8.5-18-1.6 20-25-13
WATER PIPE (L) 8-14-2
WATER PIPE (S) 8-14-1
WATER PIPE (UL) 8-14-3
WATER PIPE (UL) 20-26-4
WATER PIPE AUXILIARY MOUNT 8-4
WATER PIPE SEAL (LOWER) 9-39
WATER PIPE SEAL (UPPER) 8-15
WATER PUMP GUIDE PLATE 9-44
WATER PUMP GUIDE PLATE 20-22-8
WATER PUMP GUIDE PLATE 20-23-8
WATER PUMP IMPELLER 9-35-2
WATER PUMP IMPELLER 20-22-5
WATER PUMP IMPELLER 20-23-5
WATER PUMP KIT (CHROME PLATED) 20-23-2
WATER PUMP REPAIR KIT 20-22-2
WATER STRAINER 9-30
WATER STRAINER 9-33
WAVE WASHER d=12 13-2
WAVE WASHER d=14 12-10
WAVE WASHER d=8 1-43
WAVE WASHER d=8 5-31
WELCH PLUG 1-12

INDEX (Parts Number)

121-32071-0 9-13
121-32071-0 20-24-4
314-72185-0 5-37
332-60005-3 9-6
332-60006-1 1-24
332-60006-1 9-7
332-60006-1 20-24-3
332-60223-0 9-41
332-60223-0 20-24-6
332-62101-1 10-77
332-64221-0 9-27
332-66021-0 9-53
332-66021-0 20-24-8
332-66033-0 9-55
332-70201-0 16-11
332-70261-0 12-27
334-00131-0 6-16
334-00133-0 6-18
336-06973-0 12-23-1
336-60007-0 19-13
336-62415-0 9-42
336-62415-0 9-54
336-62415-0 20-24-7
336-70112-0 12-28
336-76091-0 6-30
338-01131-1 1-5
338-01131-1 3-2
338-01133-0 1-36
338-01133-0 1-39
338-01403-0 2-25
338-01403-0 6-3
338-01403-0 20-21-11
338-02215-0 3-30
338-02215-0 12-30
338-05019-0 5-17
338-05131-0 5-19
338-05216-0 5-28
338-05252-0 5-29
338-05255-0 5-27
338-60218-2 10-3
338-60218-2 10-38
338-67147-0 12-7
338Q67141-0. 12-6
344-67177-1 10-16
345-01111-0 1-10
345-01111-0 8-3
345-05003-1 5-4
345-05004-1 5-10
345-05135-1 5-5
345-05223-1 1-45
345-05223-1 5-35
345-05224-0 20-11
345-62441-0 10-17
345-63048-0 11-6
345-63713-0 1-49
345-66226-0 12-14
345-66226-0 20-25-10
345-67117-0 3-32
345-67142-1 12-11
346-00116-0 2-20
346-01032-0 1-18
346-01032-0 20-21-6
346-05228-1 6-22
346-05234-0 1-56
346-05234-0 20-25-20
346-62124-1 10-10
346-62127-0 10-12
346-62421-1 10-18
346-62438-0 10-46
346-63201-3 11-19
346-63722-2 6-20
346-64027-1 9-20
346-64081-0 9-46-1
346-64082-0 9-46-2
346-64083-0 9-46-3
346-64084-0 9-46-4
346-64121-5 9-63
346-64124-5 9-62
346-65013-0 9-14
346-65013-0 20-24-5
346-66334-0 10-54
346-67115-0 5-7
346-67165-0 12-17
346-67165-0 20-25-18
349-62126-0 10-11
350-00011-0 2-33-1
350-00014-0 2-33-2
350-00021-1 2-44
350-00024-1 2-45
350-00034-2 2-15
350-00040-0 2-8
350-00040-0 20-27-3
350-00051-1 2-12
350-00061-1 2-17
350-00061-1 20-27-6
350-00062-0 2-16
350-00107-0 2-2
350-00115-0 2-1-2
350-00121-0 6-1
350-00121-0 20-21-9
350-01030-1 1-16
350-01093-0 1-12
350-01215-1 2-24
350-01215-1 20-21-20
350-01401-0 6-2
350-02104-2 3-3
350-02104-2 20-21-14
350-02105-3 3-4
350-02105-3 20-21-15
350-02305-2 1-26
350-02305-2 20-21-7
350-02306-2 1-27
350-02306-2 20-21-8
350-03174-0 3-15
350-03176-0 3-13
350-04005-0 4-27
350-04014-0 4-24
350-05013-1 5-18
350-05104-1 5-3
350-05105-1 5-2
350-05116-1 5-20
350-05123-0 5-8
350-05124-0 5-9
350-05132-0 5-12
350-05211-0 1-41
350-05217-0 5-34
350-05222-0 1-44
350-05227-2 1-42-2
350-05253-0 5-30
350-06025-0 6-13
350-60211-0 9-5
350-61012-2 12-36
350-61012-2 20-21-19
350-61301-1 10-25
350-61302-0 10-30
350-61336-0 10-31
350-61337-0 10-26
350-62121-2 10-13
350-62415-0 10-24
350-62417-0 10-22
350-62423-0 10-23
350-62437-0 10-42
350-62439-1 10-43
350-63046-0 11-7
350-63061-1 12-31
350-63061-1 20-25-6
350-63063-0 12-33
350-63063-0 20-25-7
350-63064-1 10-21
350-63064-1 20-25-5
350-63711-2 1-46
350-63715-1 1-62
350-63723-0 6-21
350-64010-2 9-18
350-64020-1 9-19
350-64032-0 9-22
350-64218-0 9-25
350-64219-0 9-26
350-64222-1 9-28
350-64223-1 9-29
350-64301-0 9-47-1
350-64302-0 9-47-2
350-64303-0 9-47-3
350-64303-0 20-26-5
350-64326-1 9-3
350-65011-1 9-38
350-65011-1 20-22-7
350-65014-0 9-39
350-65016-1 9-37
350-65025-0 9-44
350-65025-0 20-22-8
350-65100-0 8-14-1
350-65110-0 8-14-2
350-65120-0 8-14-3
350-65120-0 20-26-4
350-65204-0 8-4
350-65205-0 8-16
350-65206-0 8-15
350-66110-0 13-1
350-66115-0 13-7
350-66121-0 13-4
350-66214-0 13-13-1
350-66215-0 13-13-2
350-66223-0 13-18
350-66223-0 20-9
350-66225-0 13-16
350-66241-0 13-14
350-66302-0 20-13
350-66315-0 10-67
350-66337-0 20-12
350-67101-0 13-12
350-67104-0 12-5
350-67105-0 12-8
350-67154-0 3-35
350J02300-1 1-22-2
350J02302-1 1-25-2
350Q61110-0. 8-10
350Q61110-0. 20-26-2
350Q61401-1. 10-33-2
350Q61402-2. 10-32
353-06821-0 12-22
353-67162-0 12-18
353-67162-0 20-25-19
353-83728-1 1-58
353-83728-1 20-25-11
362-02100-1 3-18
362-02312-2 8-8
362-60206-1 9-30
362-60211-0 9-12
362-64030-1 9-21
362-64211-3 9-23
362-64215-0 9-24
362-65238-0 20-23-6
362-65239-0 20-23-8
362B64107-1 9-59-1
364-63718-0 6-28-3
369-60206-0 9-33
369-62122-2 10-14
369-62434-0 20-6
369-72019-2 11-4
369-72025-1 12-35-2
393-01131-0 1-6
393-01137-0 1-7
398-06830-0 12-21
398-06972-1 1-65
398-06972-1 1-67
398-61207-0 8-5
398-61307-0 10-27
398-61308-2 10-29
398-62396-1 10-47
398-62396-1 10-49
398-63012-0 11-9
398-63053-0 11-5
398-63717-1 1-54
398-63717-1 20-25-16
398-66012-0 9-49-1
398-66013-0 9-49-2
398-66014-0 9-49-3
398-66014-0 20-26-6
398-66031-0 9-52
398-87321-3 20-24-1
398Q60100-2. 9-9
398Q87314-1. 20-26-1
3A3-62396-1 10-51
3AA-83719-0 1-59
3AA-83719-0 10-56
3AA-83719-0 20-25-13
3AC-62191-0 10-9
3AC-70140-0 16-17
3AC-70145-0 16-18
3AC-70150-0 16-19
3AC-70157-0 16-16
3AC-72200-0 12-43
3AD-02230-0 3-23
3AD-02234-0 3-26
3AD-02235-0 3-25
3AD-02237-0 3-24
3AL-05212-0 10-59
3AL-05254-0 10-57
3AL-66333-0 10-53
3B2-66322-1 20-3
3B2-70260-1 12-26
3B7-05243-0 1-64
3B7-63733-0 1-47
3B7-63733-0 1-57
3B7-63733-0 20-25-15
3B7-67179-0 13-20
3B7-70200-5 16-1
3B7-70280-1 16-8
3B7-76142-1 1-72
3BAB64516-1. 9-59-2
3BAB64518-1. 9-59-3
3BAB64521-1. 9-59-4
3BAB64524-1. 9-59-5
3BJ-60001-0 8-6
3BJ-60001-0 8-11
3BJ-60001-0 20-26-3
3BJ-60108-0 9-15
3BKQ60101-2. 9-10
3C7-70211-1 16-4
3C7-70217-0 16-5
3C7-70220-1 16-2
3C7-70224-1 16-3
3C8-02011-0 4-30
3C8-02011-0 20-20-2
3C8-02011-0 20-21-17
3C8-03121-0 4-13
3C8-03121-0 20-20-7
3C8-03121-0 20-21-16
3C8-03125-0 4-7
3C8-03125-0 20-20-6
3C8-03126-0 4-6
3C8-03126-0 20-20-5
3C8-03157-0 4-10
3C8-03169-0 4-4
3C8-03169-0 20-20-3
3C8-03179-1 4-9
3C8-03180-0 4-20
3C8-03181-0 4-18
3C8-03182-0 4-19
3C8-03182-0 20-20-9
3C8-03193-0 4-16
3C8-03193-0 20-20-8
3C8-03193-0 20-21-18
3C8-04002-0 4-29
3C8-04018-0 4-23
3C8-04028-0 4-28
3C8-62421-1 10-45
3C8-66011-0 9-50
3C8-66308-0 6-35
3C8-66308-0 12-13
3C8-66308-0 15-8
3C8-67146-0 12-9
3C8-72100-1 19-1
3E0-70270-0 16-15
3E3-64333-0 4-22


3F0-72185-0 5-36
3F0-72185-0 15-13
3FS-65029-0 9-43
3FS-65029-0 20-22-3
3FS-65029-0 20-23-3
3FS-65029-0 20-24-2
3G2-02411-0 3-31
3G2-02414-1 3-36
3G2-02414-1 20-21-22
3G2-03120-0 4-12
3G2-03141-0 4-17-2
3G2-03156-0 4-11
3G2-06023-1 19-17
3G2-06025-1 19-19
3G2-06060-4 6-32
3G2-06061-1 6-33
3G2-62434-0 20-8
3G2-66305-0 20-7
3G2-66311-1 10-52
3G2-66312-2 10-66
3G2-66313-1 10-61
3G2-66319-1 10-62
3G2-66321-0 10-64
3G2-66324-0 20-4
3G2-66331-0 10-68
3G2-66351-0 10-60
3G2-66901-0 20-2
3G2-67151-2 12-4
3G2-67152-0 3-34
3G2-67196-0 3-22
3G2-87122-2 20-20-1
3G2Q62310-1 10-15
3G2Q62993-1 10-40
3G3-06021-1 6-10
3G4-00043-0 2-9
3G4-00043-0 20-27-5
3GF-70250-1 16-10
3GF-70281-0 16-9
3H6J01031-0 1-17-2
3K9-66137-0 13-3
3KK-01012-0 1-8-2
3KK-01012-0 1-70
3KK-63104-0 1-48-2
3KM-01142-0. 1-74
3KM-67503-0. 5-22
3KZ-70177-0 16-12
3LC-01160-0 1-34
3LD-00001-0 2-43-1
3LD-00004-0 2-43-2
3LD-00011-0 2-32-1
3LD-00014-0 2-32-2
3LD-00032-0 2-11-2
3LD-00033-0 2-14-2
3LD-00039-1 20-27-1
3LD-00046-1 2-6
3LD-00046-1 20-27-4
3LD-00069-0 2-7-2
3LD-00090-0 2-46
3LD-00090-0 20-27-2
3LD-00121-0 2-23
3LD-00121-0 20-21-13
3LD-01012-0 1-14-2
3LD-01291-0 2-22
3LD-02095-0 3-5-2
3LD-02311-0 8-7-2
3LD-03100-2 4-1-3
3LD-03147-0 4-5-2
3LD-03147-0 20-20-4
3LD-05000-0 5-1-2
3LD-05912-0 . . . . . .5-21a
3LD-06050-1 6-37-2
3LD-06102-0 6-7
3LD-06921-0 6-38
3LD-60218-0 9-67
3LD-63041-0 11-12-2
3LD-63104-0 3-7-2
3LD-63718-0 6-28-2
3LD-64325-0 9-1
3LD-65021-0 9-35-2
3LD-65021-0 20-22-5
3LD-65021-0 20-23-5
3LD-65231-0 20-23-2
3LD-87121-1 20-21-3
3LD-87123-1 2-31-1
3LD-87124-1 2-31-2
3LD-87130-0 2-42-1
3LD-87131-0 2-42-2
3LD-87322-0 20-22-2
3LD-87801-2 15-12-1
3LDJ01001-0 1-11-3
3LDJ01100-3 1-1-3
3LDJ87090-8 20-19-2
3LDQ60233-0. 19-21
3LDQ61191-0. 8-2-1
3LDQ61192-2. 8-2-2
3LDQ62010-1. 10-20-2
3M2-00031-1 2-10
3M2-03167-0 3-11
3M2-03171-0 3-12
3M2-04560-0 4-3-2
3M2-04616-0 4-2-2
3M2-05215-0 5-33
3M2-06926-0 6-39
3M2-66226-0 12-19
3M2J02010-1. 3-1-2
3M3-01303-0 1-69
3M3-01303-0 20-21-21
3M3-02319-0 5-24
3M3-04004-0 4-21-2
3M3-06001-1 6-5
3M3-61343-0 10-34
3M3-62106-0 10-74
3M4-01005-0 1-13-2
3M4-01005-0 20-21-5
3M4-60108-0 12-3
3M4-61343-0 10-35
3M4-66113-0 13-9
3MY-63104-0 3-9-2
3NT-02095-0 3-6-2
3NT-02319-0 1-28
3NT-06128-0 19-16
3NT-63046-0 11-8
3NT-63207-0 11-20
3NT-65017-0 9-40-2
3NT-67501-0 15-10
3NT-87801-2 15-12-2
3NTH67521-0. 15-6
3NTH67640-0. 15-4
3NTH67645-2. 15-2
3NTQ63000-1. 20-25-2
3NTQ63003-1. 11-1-2
3NTQ63003-1. 20-25-4
3NTQ63005-1. 11-2-2
3NTQ63011-0. 11-3
3NTQ67100-0. 12-1-2
3NTQ87301-1. 20-1-4
3NTQ87302-1. 20-1-5
3NTQ87304-1. 20-1-6
3P0-01143-0 1-75
3P0-60218-0 1-78
3P0-66233-0 10-37
3PR-06972-0 5-23
3PR-06972-0 6-26
3R0-66308-0 10-55
3RS-64231-0 9-61-2
3RS-65022-1 9-36
3RS-65022-1 20-22-6
3RS-70020-0 16-13
3RS-70021-0 16-14
3RS-87326-0 9-60-2
3RSQ62102-0. 10-75
3T5-01133-0 1-35
3T5-10046-0 1-76
3T5-84398-0 1-37
3T5-84398-0 6-40
3V1-63035-1 11-13
3V1-63036-0 11-15
3V1-63077-0 11-14
3V1Q62105-2. 10-72
3V1Q62108-1. 10-73
3V6-62117-0 10-5
3V6Q62112-2. 10-1
3V6Q62113-1. 10-2
3V9Q60000-1. 9-4
910103-0612 12-12
910103-0616 13-5-2
910103-0616 13-10-2
910103-0625 11-16
910103-0885 10-69
910103-5514 6-29
910103-5612 1-40
910103-5612 1-66
910103-5612 1-73
910103-5612 10-50
910103-5620 9-17
910103-5620 10-4
910103-5620 10-39
910103-5625 8-9
910103-6512 9-56
910103-6616 6-34
910103-7630 6-47-2
910103-7630 12-34
910103-7630 20-25-8
910114-0635 5-13
910121-6620 6-4
9101E3-0416 12-40
9101E3-0518 12-37
9101E3-0830 10-19
9101E3-5630 1-19-2
9101E3-5652 9-45
9101E3-5652 20-22-9
9101E3-5675 11-17
9101E3-5818 10-44
910306-0405 4-15
9106E3-0808 1-23
910903-0506 3-14
916103-0550 3-16
916103-0680 3-20
921503-0430 9-31
921503-0525 1-52
921503-0525 6-23
921503-0530 1-77
921503-0620 3-19
921503-5430 5-26
921503-5510 6-27
921503-5612 12-25
921503-6510 6-25-2
921503-7616 5-32
921521-6406 6-14-2
921521-6406 19-20
921521-6525 6-11
921521-6530 19-18
921703-0305 4-25
921722-0410 4-8
921803-0525 11-10
921803-0620 9-34
922503-0410 4-14
922503-0410 20-20-10
922553-0512 3-33
930103-0500 1-53
930103-0500 1-55
930103-0500 1-63
930103-0500 6-24
930103-0500 20-25-17
930103-0600 1-61
930103-0600 3-8-2
930103-0600 5-14
930103-0600 10-8
930103-0600 20-25-12
930103-0800 3-27
930103-0800 10-70
9301E3-0400 12-42
9301E3-0500 12-39
930203-0300 4-26
930403-0400 9-32
930403-0600 11-18
930403-0600 15-7
930403-0800 1-50
931121-1600 6-17
940103-0500 3-17
940103-0600 1-29
940103-0600 3-10-2
940103-0600 3-21
940103-0600 5-25
940103-0600 6-49
940103-0600 13-6
940103-0800 1-9-2
940103-0800 1-15
940103-0800 10-58
940103-0800 10-71
940103-1000 10-28
940121-0600 5-15
9401E3-0400 12-41
9401E3-0500 12-38
9401E3-0600 10-6
9401E3-0600 10-7
9401E3-0800 1-71
940203-0800 1-51
940203-0800 3-28
941303-0600 13-11
941322-0600 5-16
941403-0800 1-43
941403-0800 5-31
941403-1200 13-2
941403-1400 12-10
945102-2500 2-21
945303-0500 5-6
945303-0500 10-78
945303-0500 20-5
945303-0600 10-63
945303-0600 12-32
945303-0600 20-25-9
951403-0310 11-11
951403-0312 13-15
951403-0312 20-16
951403-0316 5-11
951403-0535 20-10
951403-0540 10-41
951403-0622 10-76
951407-0308 2-13
951407-0312 9-51
951503-0212 10-65
951503-0212 20-14
951503-0322 9-64
951503-1610 13-19
951503-1610 20-15
951503-2520 13-17
951503-2522 13-8
951603-0800 1-60
951603-0800 20-25-14
9601-0-6205 9-8
9601-0-6205 9-11
9601-0-6302 9-48
9603-3-6305 2-18
9603-3-6305 2-19
9701-1-1010 1-68-2
98AB-30-270 1-38
98AB-50-185 12-29
98AB-50-220 3-29
98AB-701600. 16-7
98AB-70-700 16-6
98AL-40-030 1-32
98AL-40-220 1-33

Copyright © 2023 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means without the express written permission of Tohatsu Corporation.

2023 PARTS CATALOG

MX 15E2
MX 18E2
Models

Serial Number 000001BC～
OB No.002-21043X0BC 350X 2301



トーハツ株式会社

〒174-0051
東京都板橋区小豆沢 3-5-4
Tel: 03 (3966) 3116

TOHATSU CORPORATION

5-4, Azusawa 3-Chome, Itabashi-Ku
Tokyo 174-0051, Japan
Tel: +81-3-3966-3117　Fax: +81-3-3966-2951
www.tohatsu.com