

2025 PARTS CATALOG



TOHATSU

Feel the Wind™

BFT 200D
BFT 225D
BFT 250D
Models
EU



TOHATSU CORPORATION

Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of January 1, 2025.**
- See the Service Bulletin for any revision that is made after January 1, 2025.
- **Always specify the part number when ordering a part.**
- Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
- Note that the illustrations (part drawings) can differ from the actual parts in shape.
Illustrations are given just to help you to refer to the parts.
- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times.**

Initial version issue date January 1, 2025

CONTENTS

E-1	CYLINDER HEAD COVER	1
E-3	CYLINDER BLOCK	3
E-3-10	CRANK CASE	13
E-4	EXHAUST MANIFOLD/THERMOSTAT	17
E-5	OILPUMP/FLYWHEEL	21
E-6	OIL PAN	25
E-6-10	MOUNT CASE	27
E-7	CRANK SHAFT/PISTON	33
E-9	CYLINDER HEAD	37
E-9-10	CAMSHAFT/ROCKERARM	39
E-13	TIMING BELT	45
E-13-10	TIMINGBELT COVER	49
E-14	FUEL PIPE/INJECTOR	51
E-14-10	INTAKE MANIFOLD	57
E-15	THROTTLE BODY	61
E-18	VAPOR SEPARATOR ASSY	65
E-18-1	FUEL STRAINER	73
E-18-10	PIPING	75
E-19	A. C. GENERATOR	79
E-20	SPARK PLUG	83
E-20-10	ELECTRONIC CONTROL UNIT	85
E-21	STARTER MOTOR	89
EOP-1	GASKET KIT	93
F-2	SHIFT SHAFT	95
F-3	GEAR CASE	101
F-3-10	GEAR CASE ASSY	103
F-3-20	EXTENSION CASE	105
F-3-30	UNDER COVER	113
F-4	WATER PUMP/VERTICAL SHAFT	119
F-5	PROPELLER SHAFT	123
F-5-1	PROPELLER SHAFT (COUNTERROTATION)	127
F-6	FUEL TUBE	131
F-7	WIRE HARNESS	133
F-7-10	STARTER CABLE	135
F-7-20	FUSEBOX/RELAY	141
F-8	ENGINE COVER	143
F-10	STERN BRACKET/SWIVEL CASE	145
F-11	POWER TRIM-TILT	155
F-12	LABEL	167
F-13	TOOL	169
FOP-1	RIGGING HOSE KIT	171
FOP-2	WATER PUMP IMPELLER SET	173
FOP-3	REMOTE CONTROL (TOP MOUNT SINGLETYPE) (RIGHT)	175
FOP-3-1	REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)	179
FOP-3-2	REMOTE CONTROL (TOP MOUNT DUALTYPE) (RIGHT)	181
FOP-3-3	REMOTE CONTROL (NHK MEC)	185
FOP-3-4	REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (NHK MEC)	191
FOP-3-5	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (NHK MEC)	195
FOP-4	METER	201
FOP-5	SWITCH PANEL KIT (1)	203
FOP-5-1	SWITCH PANEL KIT (2)	205
FOP-5-2	SWITCH PANEL KIT (3)	207
FOP-5-3	SWITCH PANEL KIT (4)	209
FOP-5-4	SWITCH PANEL KIT (5)	213
FOP-7	INTERFACE CABLE KIT	215
FOP-10	CABLE KIT	217
FOP-14	TRIM ADJUST PLATE SET	219
FOP-15	PROPELLER	221
FOP-17	GEAR CASE KIT	223
FOP-18	MAINTENANCE KIT (200)	225
FOP-18-1	MAINTENANCE KIT (400)	229
INDEX	(Parts Number)	233

6-1 CYLINDER HEAD COVER	6-2 CYLINDER BLOCK	6-3-10 CRANKCASE
6-4 EXHAUST MANIFOLD/THERMOSTAT	6-5 OIL PUMP/FLYWHEEL	6-6 OIL PAN

E-15 THROTTLE BODY




RefNo.	Part No.	Description	Q'ty OF STOCK	Remarks
E-15	1	KZ70-18018-000	1	
E-15	2	KZ70-18178-000	1	
E-15	3	KZ71-18600-A01	1	
E-15	4	KZ32-18400-000	1	
E-15	5	KZ75-18400-000	1	
E-15	7	HPF03-17400-000	1	
E-15	8	KZ77-17310-000	1	
E-15	9	KX20-17314-000	1	
E-15	10	KZ77-17910-013	2	
E-15	11	HW65-15600-010	1	
E-15	12	KZ73-06030-000	1	
E-15	18	HW56-00102-000	4	
E-15	19	KWH1-06010-000	2	
E-15	20	HW71-06017-000	1	
E-15	21	HW73-00030-000	1	
E-15	22	HW40-00034-000	2	
E-15	23	HW73-00037-000	4	
E-15	34	HW73-00030-000	2	
E-15	25	HW64-11300-A02	1	
E-15	26	HW65-01531-010	4	
E-15	27	HW40-00010-000	1	
E-15	28	KZ32-18540-010	1	

INDEX (Parts Number)					
100103150	1545	304440504	1734260	304430314	1734260
100007150	87	304440514	1734260	304430414	1734260
100007150	90	304440514	1734260	304430514	1734260
100007150	813	304441336	1734260	304430614	8421
100007150	900	304441336	1734260	304430714	8421
100007150	900	304441336	1734260	304430814	8421
112400000	90	304441336	1734260	304430914	1734260
112400000	90	304441336	1734260	304431014	1734260
112400000	1163	304441336	1734260	304431114	1734260
112400000	1163	304441336	1734260	304431214	1734260
112400000	1164	304441336	26256	304431314	1734260
112400000	1164	304441336	26256	304431414	1734260
112400000	1164	304441336	26256	304431514	1734260
112400000	1164	304441336	26256	304431614	1734260
112400000	1164	304441336	26256	304431714	1734260
112400000	1164	304441336	26256	304431814	1734260
112400000	1164	304441336	26256	304431914	1734260
112400000	1164	304441336	26256	304432014	1734260
112400000	1164	304441336	26256	304432114	1734260
112400000	1164	304441336	26256	304432214	1734260
112400000	1164	304441336	26256	304432314	1734260
112400000	1164	304441336	26256	304432414	1734260
112400000	1164	304441336	26256	304432514	1734260
112400000	1164	304441336	26256	304432614	1734260
112400000	1164	304441336	26256	304432714	1734260
112400000	1164	304441336	26256	304432814	1734260
112400000	1164	304441336	26256	304432914	1734260
112400000	1164	304441336	26256	304433014	1734260
112400000	1164	304441336	26256	304433114	1734260
112400000	1164	304441336	26256	304433214	1734260
112400000	1164	304441336	26256	304433314	1734260
112400000	1164	304441336	26256	304433414	1734260
112400000	1164	304441336	26256	304433514	1734260
112400000	1164	304441336	26256	304433614	1734260
112400000	1164	304441336	26256	304433714	1734260
112400000	1164	304441336	26256	304433814	1734260
112400000	1164	304441336	26256	304433914	1734260
112400000	1164	304441336	26256	304434014	1734260
112400000	1164	304441336	26256	304434114	1734260
112400000	1164	304441336	26256	304434214	1734260
112400000	1164	304441336	26256	304434314	1734260
112400000	1164	304441336	26256	304434414	1734260
112400000	1164	304441336	26256	304434514	1734260
112400000	1164	304441336	26256	304434614	1734260
112400000	1164	304441336	26256	304434714	1734260
112400000	1164	304441336	26256	304434814	1734260
112400000	1164	304441336	26256	304434914	1734260
112400000					


[illegible]

Part catalogue structure



- ① Fig. Number
- ② Fig. Title
- ③ Ref. Number
- ④ Parts Number
- ⑤ Parts Name
- ⑥ Q.ty
- ⑦ Remarks
- ⑧ Defferent specification
- ⑨ Direction Arrow
- ⑩ Parts enclosed within a dotted line are sub assembly parts.
- ⑪ A solid arrow indicates the block No. the part in question is connected to.

How to check the part block and serial numbers



Models, parts catalogue codes and applicable serial numbers

- Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Type	Parts catalogue type	Engine		Applicable engine serial No.	Applicable frame serial No.
			Model	Type		
BFT200D	LRU	LRU	BF200D	SE2	BEBRJ-1000001~	BBRJ-6000001~
	XCRU	XCRU				BBRJ-7000001~
	XRD	XRD				BBRJ-6000001~
	XRU	XRU				
BFT225D	XCRU	XCRU	BF225D		BEBPJ-1000001~	BBPJ-7000001~
	XRD	XRD				BBPJ-6000001~
	XRU	XRU				
BFT250D	XCRU	XCRU	BF250D		BEBNJ-1000001~	BBNJ-7000001~
	XRD	XRD				BBNJ-6000001~
	XRU	XRU				

Features of each type

- See the following table for the features of each type. (Items in brackets are optional)


Model Type		BFT 200D				BFT 225D			BFT 250D		
		LRU	XCRU	XRD	XRU	XCRU	XRD	XRU	XCRU	XRD	XRU
Specifications	508 mm	●									
	635 mm		●	●	●	●	●	●	●	●	●
Counter rotation			●			●			●		

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets () underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name. (For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

Bulk part number of fuel hose, general purpose hose and vinyl hose.


Example: 95001-75001-50M



CAUTION: It is DANGEROUS to confuse the fuel hose with the general purpose hose or vinyl hose.


Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.

E-1 CYLINDER HEAD COVER



E-3 CYLINDER BLOCK


FR. 



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-3	1	HZVL-11200-000	COVER ASSY. , CRANKCASE UPPER	1			~1002626
E-3	1	HZVL-11200-000	COVER ASSY. , CRANKCASE UPPER		1		~1002916
E-3	1	HZVL-11200-000	COVER ASSY. , CRANKCASE UPPER			1	~1007539
E-3	1	HZVL-11200-010	COVER ASSY. , CRANKCASE UPPER	1			1002627~
E-3	1	HZVL-11200-010	COVER ASSY. , CRANKCASE UPPER		1		1002917~
E-3	1	HZVL-11200-010	COVER ASSY. , CRANKCASE UPPER			1	1007540~
E-3	2	HZY3-11300-000	CASE ASSY. , OIL SEAL	1	1	1	
E-3	3	HZVL-12000-000ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY	1			~1002573
E-3	3	HZVL-12000-000ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY		1		~1002650
E-3	3	HZVL-12000-000ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY			1	~1007292
E-3	3	HZVL-12000-010ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY	1			1002574~1007206
E-3	3	HZVL-12000-010ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY		1		1002651~1005809
E-3	3	HZVL-12000-010ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY			1	1007293~1020694
E-3	3	HZVL-12000-020ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY	1			1007207~
E-3	3	HZVL-12000-020ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY		1		1005810~
E-3	3	HZVL-12000-020ZA	BLOCK ASSY. , CYLINDER *NH8* DARK GRAY			1	1020695~
E-3	4	HZV4-12155-A00	METAL, ANODE	6			~1007206
E-3	4	HZV4-12155-A00	METAL, ANODE		6		~1005809
E-3	4	HZV4-12155-A00	METAL, ANODE			6	~1020694
E-3	4	HZV4-12155-A01	METAL, ANODE	6			1007207~
E-3	4	HZV4-12155-A01	METAL, ANODE		6		1005810~
E-3	4	HZV4-12155-A01	METAL, ANODE			6	1020695~
E-3	5	HZY3-12155-000	METAL, ANODE	2			~1007206
E-3	5	HZY3-12155-000	METAL, ANODE		2		~1005809
E-3	5	HZY3-12155-000	METAL, ANODE			2	~1020694
E-3	5	HZY3-12155-010	METAL, ANODE	2			1007207~
E-3	5	HZY3-12155-010	METAL, ANODE		2		1005810~
E-3	5	HZY3-12155-010	METAL, ANODE			2	1020695~
E-3	6	HZY3-12164-000	BOLT, SEALING, 22MM			6	

E-3 CYLINDER BLOCK


FR. 



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-3	7	HZY3-12171-305	WASHER, SEALING, 22MM	6	6	6	
E-3	8	HZV5-12214-000	WASHER, SEALING(22MM)	1	1	1	
E-3	9	HP8A-15115-A01	PACKING, OIL HOLE	1	1	1	
E-3	10	HP8A-15140-A00	ORIFICE ASSY., OIL CONTROL	2	2	2	
E-3	11	HP8A-15142-A00	O-RING, 8.8X2.4	2	2	2	
E-3	12	HP8A-15150-A00	JOINT ASSY., OIL PIPE	1	1	1	
E-3	13	HR70-15280-A00	BODY, OIL JET	3	3	3	
E-3	14	HRJA-15290-000	BOLT COMP., OIL JET	3	3	3	
E-3	15	HZVL-15655-000	GAUGE COMP., OIL LEVEL	1	1	1	
E-3	16	HZVL-15656-000	COVER, OIL LEVEL GAUGE	1	1	1	
E-3	17	HZY3-15657-000	PACKING, OIL LEVEL GAUGE	1	1	1	
E-3	18	HZY2-15810-000ZA	VALVE ASSY., SPOOL	1			*NH8*
E-3	18	HZVL-15810-003ZA	VALVE ASSY., SPOOL		1	1	*NH8*
E-3	19	HZY2-15825-000	FILTER ASSY., SPOOL VALVE	1			
E-3	19	HZY3-15825-003	FILTER ASSY., SPOOL VALVE		1	1	
E-3	20	H5YS-30530-J01	SENSOR, KNOCK	1	1	1	
E-3	21	HZVL-32114-000	BRACKET, CLIP B	1	1	1	
E-3	22	HZVL-32193-000	CORD, SWITCH	1	1	1	
E-3	23	HZY3-35673-003	SENSOR ASSY., WATER	1	1	1	
E-3	24	HRNA-37260-A01	SENSOR, OIL PRESSURE	1	1	1	
E-3	25	HPNB-37500-003	SENSOR ASSY., CRANK	1	1	1	
E-3	26	HZVL-90001-000	BOLT, FLANGE, 12X95	2			~1002493
E-3	26	HZVL-90001-000	BOLT, FLANGE, 12X95		2		~1002583
E-3	26	HZVL-90001-000	BOLT, FLANGE, 12X95			2	~1006951
E-3	26	HZVL-90001-010	BOLT, FLANGE, 12X95	2			1002494~
E-3	26	HZVL-90001-010	BOLT, FLANGE, 12X95		2		1002584~
E-3	26	HZVL-90001-010	BOLT, FLANGE, 12X95			2	1006952~
E-3	27	HZVL-90006-003	BOLT-WASHER, 10X109	1			~1002573
E-3	27	HZVL-90006-013	BOLT-WASHER, 10X109	1			1002574~

E-3 CYLINDER BLOCK


FR. 



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-3	27	HZVL-90006-003	BOLT-WASHER, 10X109		1		~1002650
E-3	27	HZVL-90006-013	BOLT-WASHER, 10X109		1		1002651~
E-3	27	HZVL-90006-003	BOLT-WASHER, 10X109			1	~1007292
E-3	27	HZVL-90006-013	BOLT-WASHER, 10X109			1	1007293~
E-3	28	HZVL-90008-003	BOLT-WASHER, 10X60	5			~1002573
E-3	28	HZVL-90008-013	BOLT-WASHER, 10X60	5			1002574~
E-3	28	HZVL-90008-003	BOLT-WASHER, 10X60		5		~1002650
E-3	28	HZVL-90008-013	BOLT-WASHER, 10X60		5		1002651~
E-3	28	HZVL-90008-003	BOLT-WASHER, 10X60			5	~1007292
E-3	28	HZVL-90008-013	BOLT-WASHER, 10X60			5	1007293~
E-3	29	HZVL-90009-003	BOLT-WASHER, 10X80	2			~1002573
E-3	29	HZVL-90009-013	BOLT-WASHER, 10X80	2			1002574~
E-3	29	HZVL-90009-003	BOLT-WASHER, 10X80		2		~1002650
E-3	29	HZVL-90009-013	BOLT-WASHER, 10X80		2		1002651~
E-3	29	HZVL-90009-003	BOLT-WASHER, 10X80			2	~1007292
E-3	29	HZVL-90009-013	BOLT-WASHER, 10X80			2	1007293~
E-3	30	HZZ5-90021-M00	BOLT, FLANGE, 6X14 (CT200)	1			~1002570
E-3	30	HZZ5-90021-M00	BOLT, FLANGE, 6X14 (CT200)		1		~1002916
E-3	30	HZZ5-90021-M00	BOLT, FLANGE, 6X14 (CT200)			1	~1007289
E-3	30	HZZ5-90021-M01	BOLT, FLANGE, 6X14 (CT200)	1			1002571~
E-3	30	HZZ5-90021-M01	BOLT, FLANGE, 6X14 (CT200)		1		1002917~
E-3	30	HZZ5-90021-M01	BOLT, FLANGE, 6X14 (CT200)			1	1007290~
E-3	31	HRCA-90014-A01	BOLT-WASHER, 11X105	8	8	8	
E-3	32	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	1	
E-3	33	HZZ5-90019-M00	BOLT, FLANGE, 6X35	7	7	7	
E-3	34	HZVL-90020-000	BOLT, FLANGE, 8X50	2			~1002549
E-3	34	HZVL-90020-000	BOLT, FLANGE, 8X50		2		~1002617
E-3	34	HZVL-90020-000	BOLT, FLANGE, 8X50			2	~1007152
E-3	34	HZVL-90020-010	BOLT, FLANGE, 8X50	2			1002550~

E-3 CYLINDER BLOCK


FR. 




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-3	34	HZVL-90020-010	BOLT, FLANGE, 8X50		2		1002618~
E-3	34	HZVL-90020-010	BOLT, FLANGE, 8X50			2	1007153~
E-3	35	HZVL-90028-000	BOLT, FLANGE, 6X18	4			~1002549
E-3	35	HZVL-90028-000	BOLT, FLANGE, 6X18		4		~1002617
E-3	35	HZVL-90028-000	BOLT, FLANGE, 6X18			4	~1007152
E-3	35	HZVL-90028-010	BOLT, FLANGE, 6X18	4			1002550~
E-3	35	HZVL-90028-010	BOLT, FLANGE, 6X18		4		1002618~
E-3	35	HZVL-90028-010	BOLT, FLANGE, 6X18			4	1007153~
E-3	36	HZZ5-90030-M00	BOLT, FLANGE, 6X22	8	8	8	
E-3	37	HZVL-90038-000	BOLT, FLANGE, 8X75	1			~1002549
E-3	37	HZVL-90038-000	BOLT, FLANGE, 8X75		1		~1002617
E-3	37	HZVL-90038-000	BOLT, FLANGE, 8X75			1	~1007152
E-3	37	HZVL-90038-010	BOLT, FLANGE, 8X75	1			1002550~
E-3	37	HZVL-90038-010	BOLT, FLANGE, 8X75		1		1002618~
E-3	37	HZVL-90038-010	BOLT, FLANGE, 8X75			1	1007153~
E-3	38	HZY9-90054-M00	BOLT, FLANGE, 8X35	1			~1002549
E-3	38	HZY9-90054-M00	BOLT, FLANGE, 8X35		1		~1002617
E-3	38	HZY9-90054-M00	BOLT, FLANGE, 8X35			1	~1007152
E-3	38	HZY9-90054-M01	BOLT, FLANGE, 8X35	1			1002550~
E-3	38	HZY9-90054-M01	BOLT, FLANGE, 8X35		1		1002618~
E-3	38	HZY9-90054-M01	BOLT, FLANGE, 8X35			1	1007153~
E-3	39	HZZ5-90081-M00	BOLT, SEALING, 22MM	1			~1002626
E-3	39	HZZ5-90081-M00	BOLT, SEALING, 22MM		1		~1002916
E-3	39	HZZ5-90081-M00	BOLT, SEALING, 22MM			1	~1007539
E-3	39	HZZ5-90081-M01	BOLT, SEALING, 22MM	1			1002627~
E-3	39	HZZ5-90081-M01	BOLT, SEALING, 22MM		1		1002917~
E-3	39	HZZ5-90081-M01	BOLT, SEALING, 22MM			1	1007540~
E-3	40	HPH7-90715-000	DOWEL PIN, 13X37	8	8	8	
E-3	41	HZY3-91212-003	OIL SEAL, 41X66X8	1	1	1	

E-3 CYLINDER BLOCK

FR. 




E-3-10 CRANKCASE



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-3-10	1	HZVL-11100-900	CRANKCASE COMP.	1			~1002677
E-3-10	1	HZVL-11100-900	CRANKCASE COMP.		1		~1002916
E-3-10	1	HZVL-11100-900	CRANKCASE COMP.			1	~1007539
E-3-10	1	HZVL-11100-901	CRANKCASE COMP.	1			1002678~
E-3-10	1	HZVL-11100-901	CRANKCASE COMP.		1		1002917~
E-3-10	1	HZVL-11100-901	CRANKCASE COMP.			1	1007540~
E-3-10	2	HZX2-11911-000	HANGER, ENGINE	1			~1002833
E-3-10	2	HZX2-11911-010	HANGER, ENGINE	1			1002834~
E-3-10	2	HZX2-11911-000	HANGER, ENGINE		1		~1002881
E-3-10	2	HZX2-11911-010	HANGER, ENGINE		1		1002882~
E-3-10	2	HZX2-11911-000	HANGER, ENGINE			1	~1008207
E-3-10	2	HZX2-11911-010	HANGER, ENGINE			1	1008208~
E-3-10	3	HZV5-12214-000	WASHER, SEALING (22MM)	1	1	1	
E-3-10	4	HRTA-15400-003	CARTRIDGE, OIL FILTER	1	1	1	
E-3-10	5	HZY9-15600-M00	CAP ASSY., OIL FILLER	1	1	1	
E-3-10	6	HZY9-15631-000	EXTENSION, OIL FILLER	1	1	1	
E-3-10	7	HZZ5-90014-M00	BOLT, FLANGE, 6X25	2	2	2	
E-3-10	8	HPH1-90015-013	HOLDER, OIL FILTER	1	1	1	
E-3-10	9	HZZ5-90032-M00	BOLT, FLANGE, 6X32	15			~1002549
E-3-10	9	HZZ5-90032-M00	BOLT, FLANGE, 6X32		15		~1002617
E-3-10	9	HZZ5-90032-M00	BOLT, FLANGE, 6X32			15	~1007152
E-3-10	9	HZZ5-90032-M01	BOLT, FLANGE, 6X32	15			1002550~
E-3-10	9	HZZ5-90032-M01	BOLT, FLANGE, 6X32		15		1002618~
E-3-10	9	HZZ5-90032-M01	BOLT, FLANGE, 6X32			15	1007153~
E-3-10	10	HZVL-90041-000	BOLT, FLANGE, 10X55	2	2	2	
E-3-10	11	HZZ5-90047-M00	BOLT, FLANGE, 6X55	2			~1002549
E-3-10	11	HZZ5-90047-M00	BOLT, FLANGE, 6X55		2		~1002617
E-3-10	11	HZZ5-90047-M00	BOLT, FLANGE, 6X55			2	~1007152
E-3-10	11	HZZ5-90047-M01	BOLT, FLANGE, 6X55	2			1002550~

E-3-10 CRANKCASE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-3-10	11	HZZ5-90047-M01	BOLT, FLANGE, 6X55		2		1002618~
E-3-10	11	HZZ5-90047-M01	BOLT, FLANGE, 6X55			2	1007153~
E-3-10	12	HZVL-90063-000	BOLT, FLANGE, 6X37	2			~1002549
E-3-10	12	HZVL-90063-000	BOLT, FLANGE, 6X37		2		~1002617
E-3-10	12	HZVL-90063-000	BOLT, FLANGE, 6X37			2	~1007152
E-3-10	12	HZVL-90063-010	BOLT, FLANGE, 6X37	2			1002550~
E-3-10	12	HZVL-90063-010	BOLT, FLANGE, 6X37		2		1002618~
E-3-10	12	HZVL-90063-010	BOLT, FLANGE, 6X37			2	1007153~
E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM	1			~1002677
E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM		1		~1002916
E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM			1	~1007539
E-3-10	13	HZZ5-90081-M01	BOLT, SEALING, 22MM	1			1002678~
E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM		1		1002917~
E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM			1	1007540~
E-3-10	14	HZY3-90082-003	CAP, BOLT, 10MM	1	1	1	
E-3-10	15	HZZ0-90151-M00	BOLT, FLANGE, 8X25	2			~1002549
E-3-10	15	HZZ0-90151-M00	BOLT, FLANGE, 8X25		2		~1002617
E-3-10	15	HZZ0-90151-M00	BOLT, FLANGE, 8X25			2	~1007152
E-3-10	15	HZZ0-90151-M01	BOLT, FLANGE, 8X25	2			1002550~
E-3-10	15	HZZ0-90151-M01	BOLT, FLANGE, 8X25		2		1002618~
E-3-10	15	HZZ0-90151-M01	BOLT, FLANGE, 8X25			2	1007153~
E-3-10	16	HZVL-90204-000	NUT, FLANGE CAP, 10MM	2	2	2	
E-3-10	17	HMAL-91302-601	O-RING, 18.1X3.6	1	1	1	
E-3-10	18	HPF4-91324-004	O-RING, 28.3X2.4(NOK)	1	1	1	
E-3-10	19	HCO-94301-08140	DOWEL PIN, 8X14	2	2	2	

FR.



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-4	1	HZV5-12155-000	METAL, ANODE	4			~1007135
E-4	1	HZV5-12155-000	METAL, ANODE		4		~1005671
E-4	1	HZV5-12155-000	METAL, ANODE			4	~1020694
E-4	1	HZV5-12155-010	METAL, ANODE	4			1007136~
E-4	1	HZV5-12155-010	METAL, ANODE		4		1005672~
E-4	1	HZV5-12155-010	METAL, ANODE			4	1020695~
E-4	2	HZVL-18110-000ZA	MANIFOLD COMP., R. EX.	1	1	1	
E-4	3	HZY3-18115-003	GASKET, R. EX. MANIFOLD	1	1	1	
E-4	4	HZVL-18120-000ZA	MANIFOLD COMP., L. EX.	1	1	1	*NH8*
E-4	5	HZY3-18125-003	GASKET, L. EX. MANIFOLD	1	1	1	
E-4	6	HZVL-19255-010	TUBE, R. WATER RETURN		1		~1003857
E-4	6	HZVL-19255-010	TUBE, R. WATER RETURN			1	~1011828
E-4	6	HZVL-19255-020	TUBE, R. WATER RETURN	1			
E-4	6	HZVL-19255-020	TUBE, R. WATER RETURN		1		1003858~
E-4	6	HZVL-19255-020	TUBE, R. WATER RETURN			1	1011829~
E-4	7	HZY3-19256-010	TUBE, WATER RELIEF	2	2	2	
E-4	8	HZY3-19257-010	TUBE, WATER	2	2	2	
E-4	9	HZY3-19261-000	TUBE, L. WATER RETURN	1	1	1	
E-4	10	HZX2-19300-003	THERMOSTAT ASSY.	2	2	2	
E-4	11	HZX2-19303-003	RUBBER, RING	2	2	2	
E-4	12	HZVL-19313-010ZA	SPACER, THERMOSTAT COVER	1	1	1	*NH8*
E-4	13	HZVL-19315-010ZA	COVER, THERMOSTAT	2	2	2	*NH8*
E-4	14	HZY3-35673-003	SENSOR ASSY., WATER	2	2	2	
E-4	15	HZZ5-90019-M00	BOLT, FLANGE, 6X35	1	1	1	
E-4	16	HZY9-90027-M00	BOLT, FLANGE, 8X60	8	8	8	
E-4	17	HZVL-90034-000	BOLT, FLANGE, 6X60	5	5	5	
E-4	18	HZZ5-90055-M00	BOLT, FLANGE, 8X40	8	8	8	
E-4	19	HZY3-90601-030	CLAMP, TUBE (D10.5)	2	2	2	
E-4	20	HZY3-90603-020	CLAMP, TUBE (D29)	4	4	4	


E-4 EXHAUST MANIFOLD/THERMOSTAT



[illegible]

E-5 OIL PUMP/FLYWHEEL


FR. 



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-5	1	HZVL-15100-000ZA	PUMP ASSY., OIL	1			~1002630 *NH8*
E-5	1	HZVL-15100-000ZA	PUMP ASSY., OIL		1		~1002916 *NH8*
E-5	1	HZVL-15100-000ZA	PUMP ASSY., OIL			1	~1007614 *NH8*
E-5	1	HZVL-15100-010ZA	PUMP ASSY., OIL	1			1002631~ *NH8*
E-5	1	HZVL-15100-010ZA	PUMP ASSY., OIL		1		1002917~ *NH8*
E-5	1	HZVL-15100-010ZA	PUMP ASSY., OIL			1	1007615~ *NH8*
E-5	2	HZY3-15112-013	PACKING, OIL PUMP BODY	1	1	1	
E-5	3	HZY3-15113-000	RUBBER, OIL PUMP	1	1	1	
E-5	4	HZY3-15121-000	COVER, OIL PUMP	1	1	1	
E-5	5	HZY3-15131-405	ROTOR, OIL PUMP INNER	1	1	1	
E-5	6	HZY3-15132-405	ROTOR, OIL PUMP OUTER	1	1	1	
E-5	7	HZY3-15220-020	STRAINER COMP., OIL	1	1	1	
E-5	8	HPE0-15231-000	VALVE, RELIEF	1	1	1	
E-5	9	HPG6-15232-000	SPRING, RELIEF VALVE	1	1	1	
E-5	10	HPC6-15233-000	BOLT, SEALING, 18MM	1	1	1	
E-5	11	HZX2-31110-000ZA	FLYWHEEL COMP.	1	1	1	*TBLACK*
E-5	12	HZY3-31116-000	BOSS, FLYWHEEL	1	1	1	
E-5	13	HZX2-90001-000	BOLT, 12MM	8	8	8	
E-5	14	HZW5-90002-013	BOLT, SPECIAL, 8MM	8	8	8	
E-5	15	HZZ5-90081-M00	BOLT, SEALING, 22MM	2			~1002630
E-5	15	HZZ5-90081-M00	BOLT, SEALING, 22MM		2		~1002916
E-5	15	HZZ5-90081-M00	BOLT, SEALING, 22MM			2	~1007614
E-5	15	HZZ5-90081-M01	BOLT, SEALING, 22MM	2			1002631~1005855
E-5	15	HZZ5-90081-M01	BOLT, SEALING, 22MM		2		1002917~1004879
E-5	15	HZZ5-90081-M01	BOLT, SEALING, 22MM			2	1007615~1015842
E-5	15	HPH7-90081-000	BOLT, SEALING, 22MM	2			1005856~
E-5	15	HPH7-90081-000	BOLT, SEALING, 22MM		2		1004880~
E-5	15	HPH7-90081-000	BOLT, SEALING, 22MM			2	1015843~
E-5	16	HPW5-90701-000	DOWEL PIN, 14X15	1	1	1	


E-5 OIL PUMP/FLYWHEEL

FR. 



[illegible]

E-6 OIL PAN




[illegible]

FR.



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-6-10	1	HZY3-12155-000	METAL, ANODE	2			
E-6-10	1	HZY3-12155-000	METAL, ANODE		2		
E-6-10	1	HZY3-12155-000	METAL, ANODE			2	
E-6-10	1	HZY3-12155-010	METAL, ANODE	2			
E-6-10	1	HZY3-12155-010	METAL, ANODE		2		
E-6-10	1	HZY3-12155-010	METAL, ANODE			2	
E-6-10	2	HGHB-16163-610	CLIP, TUBE	1	1	1	
E-6-10	3	HZY3-18141-A00ZA	GUIDE, R. EX.	1	1	1	*TGRAY*
E-6-10	4	HZY3-18148-003	SEAL, EXHAUST GUIDE	2	2	2	
E-6-10	5	HZY3-18149-A01	SEAL B, EX. GUIDE	2	2	2	
E-6-10	6	HZY3-18151-A00ZA	GUIDE, L. EX.	1	1	1	*TGRAY*
E-6-10	7	HZVL-19257-000	TUBE, WATER	1	1	1	
E-6-10	8	HZY3-19277-000ZA	COVER, FLUSH VALVE	1	1	1	*NH8*
E-6-10	9	HZY3-19278-000	CASE, FLUSH VALVE	1	1	1	
E-6-10	10	HZW9-19279-010	SPRING, FLUSH VALVE	1	1	1	
E-6-10	11	HZW5-19291-000	VALVE, RELIEF	2	2	2	
E-6-10	12	HZW9-19291-000	VALVE, FLASH	1	1	1	
E-6-10	13	HZW5-19292-000	SPRING, RELIEF VALVE	2	2	2	
E-6-10	14	HZY3-19294-000ZB	SPACER, R. RELIEF VALVE	1	1	1	*TGRAY*
E-6-10	15	HZY3-19295-000	COVER, R. RELIEF VALVE	1	1	1	
E-6-10	16	HZY3-19296-000	PACKING, RELIEF VALVE COVER	2	2	2	
E-6-10	17	HZW5-19297-000	PACKING, RELIEF VALVE	2	2	2	
E-6-10	18	HZW9-19297-010	PACKING, FLASH VALVE	1	1	1	
E-6-10	19	HZY3-19297-000	COVER, L. RELIEF VALVE	1	1	1	
E-6-10	20	HZY3-19298-000ZB	SPACER, L. RELIEF VALVE	1	1	1	*TGRAY*
E-6-10	21	HZVL-19361-010	COVER, R. WATER JACKET	1	1	1	
E-6-10	22	HZVL-19362-000	PACKING, WATER JACKET COVER	2	2	2	
E-6-10	23	HZVL-19366-010	COVER, L. WATER JACKET	1	1	1	
E-6-10	24	HZVL-23170-020ZA	CASE COMP., MOUNT	1	1	1	*NH8* DARK GRAY

E-6-10 MOUNT CASE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-6-10	25	HZVL-23172-003	GASKET, MOUNT CASE	1	1	1	
E-6-10	26	H371-90009-015	BOLT, FLANGE, 10X120 (SATO)	1	1	1	
E-6-10	27	HZY3-90010-000	BOLT, HEX., 12X120	2	2	2	
E-6-10	28	HZY3-90011-000	BOLT, HEX., 12X65	1	1	1	
E-6-10	29	HZY3-90013-000	BOLT, HEX., 10X85	1	1	1	
E-6-10	30	HZY3-90015-000	BOLT, HEX., 10X60	2	2	2	
E-6-10	31	HZZ5-90030-M00	BOLT, FLANGE, 6X22	2	2	2	
E-6-10	32	HZZ5-90032-M00	BOLT, FLANGE, 6X32	4			~1002549
E-6-10	32	HZZ5-90032-M00	BOLT, FLANGE, 6X32		4		~1002617
E-6-10	32	HZZ5-90032-M00	BOLT, FLANGE, 6X32			4	~1007152
E-6-10	32	HZZ5-90032-M01	BOLT, FLANGE, 6X32	4			1002550~
E-6-10	32	HZZ5-90032-M01	BOLT, FLANGE, 6X32		4		1002618~
E-6-10	32	HZZ5-90032-M01	BOLT, FLANGE, 6X32			4	1007153~
E-6-10	33	HZVL-90045-000	BOLT, STUD, 10X45	2			~1002549
E-6-10	33	HZVL-90045-000	BOLT, STUD, 10X45		2		~1002617
E-6-10	33	HZVL-90045-000	BOLT, STUD, 10X45			2	~1007152
E-6-10	33	HZVL-90045-010	BOLT, STUD, 10X45	2			1002550~
E-6-10	33	HZVL-90045-010	BOLT, STUD, 10X45		2		1002618~
E-6-10	33	HZVL-90045-010	BOLT, STUD, 10X45			2	1007153~
E-6-10	34	HZVL-90046-000	BOLT, FLANGE, 8X120	8	8	8	
E-6-10	35	HZVL-90049-000	BOLT, FLANGE, 8X30	4			~1002549
E-6-10	35	HZVL-90049-000	BOLT, FLANGE, 8X30		4		~1002617
E-6-10	35	HZVL-90049-000	BOLT, FLANGE, 8X30			4	~1007152
E-6-10	35	HZVL-90049-010	BOLT, FLANGE, 8X30	4			1002550~
E-6-10	35	HZVL-90049-010	BOLT, FLANGE, 8X30		4		1002618~
E-6-10	35	HZVL-90049-010	BOLT, FLANGE, 8X30			4	1007153~
E-6-10	36	HZY3-90059-000	BOLT-WASHER, 6X29	1	1	1	
E-6-10	37	HHW1-90207-671	BOLT, FLANGE, 6X40	2	2	2	
E-6-10	38	HZV5-90559-000	WASHER, PLAIN, 12MM	3	3	3	

FR.




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-6-10	39	HZV5-90563-000	WASHER, PLAIN, 10MM	3	3	3	
E-6-10	40	HZY3-90601-030	CLAMP, TUBE (D10.5)	1	1	1	
E-6-10	41	HZV4-90605-000	CLIP, TUBE (B12.5)	1	1	1	
E-6-10	42	HPW5-90701-000	DOWEL PIN, 14X15	1	1	1	
E-6-10	43	HZY3-91001-003	BEARING, NEEDLE, 20X28X13	1	1	1	
E-6-10	44	HZW5-91202-003	SEAL, WATER, 22X35X7	2	2	2	
E-6-10	45	H800-91303-000	O-RING, 16MM	1	1	1	
E-6-10	46	HZY3-91304-000	O-RING, 49.4X3.1	2	2	2	
E-6-10	47	HZY3-91305-003	O-RING, 33.5X2	2	2	2	
E-6-10	48	HZY3-91306-003	O-RING, 23.5X2	2	2	2	
E-6-10	49	HZY3-91405-000	TUBE, FLUSH VALVE	1	1	1	
E-6-10	50	HCO-93500-05016-4J	SCREW, PAN, 5X16	2	2	2	
E-6-10	51	HCO-94302-10160	PIN B, DOWEL, 10X16	1	1	1	
E-6-10	52	HCO-95701-10070-09	BOLT, FLANGE, 10X70	2	2	2	
E-6-10	53	HCO-95701-12120-09	BOLT, FLANGE, 12X120	2	2	2	
E-6-10	54	HZVD-90602-000	CLIP, TUBE (B1 11)	1			1002464~
E-6-10	54	HZVD-90602-000	CLIP, TUBE (B1 11)		1		1002618~
E-6-10	54	HZVD-90602-000	CLIP, TUBE (B1 11)			1	1007153~
E-6-10	55	HZV4-90605-000	CLIP, TUBE (B12.5)	1			~1002815
E-6-10	55	HZV4-90605-000	CLIP, TUBE (B12.5)		1		~1002916
E-6-10	55	HZV4-90605-000	CLIP, TUBE (B12.5)			1	~1008195
E-6-10	55	HZY6-90651-000	CLIP B1, TUBE	1			1002816~
E-6-10	55	HZY6-90651-000	CLIP B1, TUBE		1		1002917~
E-6-10	55	HZY6-90651-000	CLIP B1, TUBE			1	1008196~

E-7 CRANKSHAFT/PISTON




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-7	1	HZX2-13010-000	RING SET, PISTON (STD.) (RIKEN)	6	6	6	
E-7	1	HZX2-13011-000	RING SET, PISTON (0.25) (RIKEN)	6	6	6	
E-7	2	HZX2-13101-000	PISTON	6	6	6	
E-7	2	HZX2-13102-000	PISTON (0.25)	6	6	6	
E-7	3	HPEA-13111-000	PIN, PISTON	6	6	6	
E-7	4	HP5A-13115-000	CLIP, PISTON PIN	12	12	12	
E-7	5	HP8A-13204-A01	BOLT, CONNECTING ROD	12	12	12	
E-7	6	HRKG-13210-000	ROD COMP., CONNECTING	6	6	6	
E-7	7	HRYE-13211-A01	BEARING A, CONNECTING ROD	12	12	12	
E-7	7	HRYE-13212-A01	BEARING B, CONNECTING ROD	12	12	12	
E-7	7	HRYE-13213-A01	BEARING C, CONNECTING ROD	12	12	12	
E-7	7	HRYE-13214-A01	BEARING D, CONNECTING ROD	12	12	12	
E-7	7	HRYE-13215-A01	BEARING E, CONNECTING ROD	12	12	12	
E-7	8	HZX2-13310-000	CRANKSHAFT COMP.	1	1	1	
E-7	9	HZX2-13321-003	BEARING A, MAIN UPPER (BLACK)	4	4	4	
E-7	9	HZX2-13322-003	BEARING B, MAIN UPPER (BROWN)	4	4	4	
E-7	9	HZX2-13323-003	BEARING C, MAIN UPPER (GREEN)	4	4	4	
E-7	9	HZX2-13324-003	BEARING D, MAIN UPPER (YELLOW)	4	4	4	
E-7	9	HZX2-13325-003	BEARING E, MAIN UPPER (PINK)	4	4	4	
E-7	9	HZX2-13326-003	BEARING F, MAIN UPPER (RED)	4	4	4	
E-7	10	HZY3-13331-A06	WASHER, THRUST	2	2	2	
E-7	11	HZX2-13341-003	BEARING A, MAIN LOWER (BLACK)	4	4	4	
E-7	11	HZX2-13342-003	BEARING B, MAIN LOWER (BROWN)	4	4	4	
E-7	11	HZX2-13343-003	BEARING C, MAIN LOWER (GREEN)	4	4	4	
E-7	11	HZX2-13344-003	BEARING D, MAIN LOWER (YELLOW)	4	4	4	
E-7	11	HZX2-13345-003	BEARING E, MAIN LOWER (PINK)	4	4	4	
E-7	11	HZX2-13346-003	BEARING F, MAIN LOWER (RED)	4	4	4	
E-7	12	HZY3-13391-010	RETAINER, SPRING	1	1	1	
E-7	13	HZX2-13392-000	SEAT, SPRING (250)	1	1	1	

E-7 CRANKSHAFT/PISTON




E-9 CYLINDER HEAD

FR. 




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-9	1	HZY3-11911-010	HANGER, ENGINE	2	2	2	
E-9	4	HPZ1-12210-004	SEAL A, VALVE STEM(NOK)	12	12	12	
E-9	5	HZVL-12210-000ZA	HEAD COMP., CYLINDER	2			*NH8*DARK GRAY ~1005722
E-9	5	HZVL-12210-000ZA	HEAD COMP., CYLINDER		2		*NH8*DARK GRAY ~1004733
E-9	5	HZVL-12210-000ZA	HEAD COMP., CYLINDER			2	*NH8*DARK GRAY ~1015425
E-9	5	HZVL-12210-010ZA	HEAD COMP., CYLINDER	2			*NH8*DARK GRAY 1005723~
E-9	5	HZVL-12210-010ZA	HEAD COMP., CYLINDER		2		*NH8*DARK GRAY 1004734~
E-9	5	HZVL-12210-010ZA	HEAD COMP., CYLINDER			2	*NH8*DARK GRAY 1015426~
E-9	6	HPZ1-12211-004	SEAL B, VALVE STEM(NOK)	12	12	12	
E-9	7	HZVL-12231-000	COVER, R. CAMSHAFT THRUST	1	1	1	
E-9	8	HZY3-12241-000	COVER, L. CAMSHAFT THRUST	1	1	1	
E-9	9	HZY3-12251-A01	GASKET COMP., CYLINDER HEAD	2	2	2	
E-9	10	HP8F-14820-A01	MOTION COMP., LOST		6	6	
E-9	11	HPT0-90005-003	BOLT-WASHER, 12X163	16	16	16	
E-9	12	HZY9-90026-M00	BOLT, FLANGE, 8X20	4	4	4	
E-9	13	HZVL-90035-000	BOLT, FLANGE, 8X28	4	4	4	
E-9	14	HP8A-90701-A00	DOWEL PIN, 6X10	4	4	4	
E-9	15	HPT0-90705-000	DOWEL PIN, 16X22	4	4	4	
E-9	16	HRKG-91213-003	OIL SEAL, 39X53X8 (NOK)	2	2	2	
E-9	17	HP8A-91301-A00	O-RING, 48.5X2.4	2	2	2	
E-9	18	HCO-94302-06100	PIN B, DOWEL, 6X10	4	4	4	

FR.




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-9-10	1	HZVJ-14111-000	CAMSHAFT, R.	1			
E-9-10	1	HZX2-14111-000	CAMSHAFT, R.		1	1	
E-9-10	2	HZVJ-14211-000	CAMSHAFT, L.	1			
E-9-10	2	HZX2-14211-000	CAMSHAFT, L.		1	1	
E-9-10	3	HRDV-14610-J00	ARM ASSY., FR. INTAKE ROCKER	6			
E-9-10	4	HP8A-14620-A01	ARM ASSY., INTAKE ROCKER		6	6	
E-9-10	5	HP8A-14626-A00	ARM COMP. A, EX. ROCKER	6			~1005854
E-9-10	5	HP8A-14626-A00	ARM COMP. A, EX. ROCKER		6		~1004879
E-9-10	5	HP8A-14626-A00	ARM COMP. A, EX. ROCKER			6	~1015842
E-9-10	5	HZVL-14626-700	ARM COMP. A, EX. ROCKER	6			1005855~
E-9-10	5	HZVL-14626-700	ARM COMP. A, EX. ROCKER		6		1004880~
E-9-10	5	HZVL-14626-700	ARM COMP. A, EX. ROCKER			6	1015843~
E-9-10	6	HP8A-14627-A00	ARM COMP. B, EX. ROCKER	6			~1005854
E-9-10	6	HP8A-14627-A00	ARM COMP. B, EX. ROCKER		6		~1004879
E-9-10	6	HP8A-14627-A00	ARM COMP. B, EX. ROCKER			6	~1015842
E-9-10	6	HZVL-14627-700	ARM COMP. B, EX. ROCKER	6			1005855~
E-9-10	6	HZVL-14627-700	ARM COMP. B, EX. ROCKER		6		1004880~
E-9-10	6	HZVL-14627-700	ARM COMP. B, EX. ROCKER			6	1015843~
E-9-10	7	HRDV-14631-J00	SHAFT COMP., FR. INTAKE ROCKER	2			
E-9-10	7	HP8A-14631-A00	SHAFT COMP., INTAKE ROCKER ARM		2	2	
E-9-10	8	HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM	2			~1005854
E-9-10	8	HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM		2		~1004879
E-9-10	8	HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM			2	~1015842
E-9-10	8	HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM	2			1005855~
E-9-10	8	HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM		2		1004880~
E-9-10	8	HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM			2	1015843~
E-9-10	9	HP8A-14645-A01	SPRING, ROCKER ARM	6			~1005854
E-9-10	9	HP8A-14645-A01	SPRING, ROCKER ARM		6		~1004879
E-9-10	9	HP8A-14645-A01	SPRING, ROCKER ARM			6	~1015842

E-9-10 CAMSHAFT/ROCKER ARM




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-9-10	9	HZVL-14645-700	SPRING, ROCKER ARM	6			1005855~
E-9-10	9	HZVL-14645-700	SPRING, ROCKER ARM		6		1004880~
E-9-10	9	HZVL-14645-700	SPRING, ROCKER ARM			6	1015843~
E-9-10	10	HRDV-14646-J00	WASHER, THRUST	12			
E-9-10	11	HRJA-14711-000	VALVE, IN.	12	12	12	
E-9-10	12	HRJA-14721-E00	VALVE, EX.	12	12	12	
E-9-10	13	HPM3-14744-000	SCREW, TAPPET ADJUSTING	12			
E-9-10	14	HPT0-14744-004	SCREW, TAPPET ADJUSTING		12	12	
E-9-10	15	HRKG-14761-003	SPRING, VALVE (PINK)	12	12	12	
E-9-10	16	HP8E-14762-A01	SPRING, EX. VALVE	12	12	12	
E-9-10	17	HRDV-14765-J00	RETAINER, VALVE SPRING	24	24	24	
E-9-10	18	HPM3-14775-000	SEAT, VALVE SPRING	24	24	24	
E-9-10	19	HRGM-14781-A01	COTTER, VALVE (FUJI VALVE)	48	48	48	
E-9-10	20	HP8A-90003-A00	BOLT, FLANGE, 8X30	12	12	12	
E-9-10	21	HP8A-90004-A00	BOLT, FLANGE, 8X40	8	8	8	
E-9-10	22	HPM3-90206-004	NUT, TAPPET ADJUSTING	12			
E-9-10	23	HPT0-90206-004	NUT, TAPPET ADJUSTING		12	12	
E-9-10	24	HR70-14646-A00	WASHER, THRUST	12			1005855~
E-9-10	24	HR70-14646-A00	WASHER, THRUST		12		1004880~
E-9-10	24	HR70-14646-A00	WASHER, THRUST			12	1015843~
E-9-10	25	HZVL-14646-700	WASHER, THRUST	24			1005855~
E-9-10	25	HZVL-14646-700	WASHER, THRUST		24		1004880~
E-9-10	25	HZVL-14646-700	WASHER, THRUST			24	1015843~
E-9-10	26	HPT0-14744-004	SCREW, TAPPET ADJUSTING	12			~1005854
E-9-10	26	HPT0-14744-004	SCREW, TAPPET ADJUSTING		12		~1004879
E-9-10	26	HPT0-14744-004	SCREW, TAPPET ADJUSTING			12	~1015842
E-9-10	26	HZVL-90017-701	SCREW, TAPPET ADJUSTING	12			1005855~
E-9-10	26	HZVL-90017-701	SCREW, TAPPET ADJUSTING		12		1004880~
E-9-10	26	HZVL-90017-701	SCREW, TAPPET ADJUSTING			12	1015843~

E-9-10 CAMSHAFT/ROCKER ARM




[illegible]

E-13 TIMING BELT




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-13	1	HZY3-13621-C01	PULLEY, TIMING BELT DRIVE	1	1	1	
E-13	2	HZVL-13622-000	PLATE, CRANK PULSER	1	1	1	
E-13	3	HZX2-13811-000	PULLEY, CRANKSHAFT	1	1	1	
E-13	4	HZY3-14261-C00	PULLEY COMP., R. TIMING BELT	1	1	1	
E-13	5	HZVL-14270-000	PULLEY COMP., L. TIMING BELT	1	1	1	
E-13	6	HP8A-14400-A01	BELT, TIMING (197YU26 B-323)	1	1	1	
E-13	7	HZY3-14510-003	TENSIONER COMP., TIMING BELT	1	1	1	
E-13	8	HZY3-14515-000	CAP, TIMING BELT TENSIONER	3	3	3	
E-13	9	HZY3-14520-000	SPRING COMP., TIMING BELT	1	1	1	
E-13	10	HZVL-14526-415ZA	BASE COMP., TIMING BELT TENSIONER *NH8* DARK GRAY	1	1	1	
E-13	11	HZY3-14529-000	O-RING, TIMING BELT TENSIONER	1	1	1	
E-13	12	HZY3-14550-003	IDLER, TIMING BELT (KOYO SEIKO)	1	1	1	
E-13	13	HP8A-14551-A01	BOLT, IDLER	1	1	1	
E-13	14	HZVL-14553-003	BOLT, TIMING BELT IDLER	1			~1002549
E-13	14	HZVL-14553-003	BOLT, TIMING BELT IDLER		1		~1002617
E-13	14	HZVL-14553-003	BOLT, TIMING BELT IDLER			1	~1007152
E-13	14	HZVL-14553-013	BOLT, TIMING BELT IDLER	1			1002550~
E-13	14	HZVL-14553-013	BOLT, TIMING BELT IDLER		1		1002618~
E-13	14	HZVL-14553-013	BOLT, TIMING BELT IDLER			1	1007153~
E-13	15	HZY3-14555-003	IDLER B, TIMING BELT	1	1	1	
E-13	16	HZX2-19511-000	FAN, COOLING	1	1	1	
E-13	17	HZY3-31638-003	BELT, A. C. GENERATOR	1	1	1	
E-13	18	HZVL-32111-000	BRACKET, COUPLER D	1	1	1	
E-13	19	HZV0-41122-000	PIN, VERTICAL SHAFT	1	1	1	
E-13	20	HZZ5-90011-M00	BOLT, FLANGE, 6X14 (CT200)	1	1	1	
E-13	21	HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTING	1			~1002549
E-13	21	HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTING		1		~1002617
E-13	21	HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTING			1	~1007152
E-13	21	HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTING	1			1002550~

E-13 TIMING BELT




[illegible]

E-13-10 TIMING BELT COVER




[illegible]

E-14 FUEL PIPE/INJECTOR




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-14	1	HZY6-16450-003	INJECTOR ASSY., FUEL	6	6	6	
E-14	2	HZY3-16451-000	CLIP, INJECTOR	6	6	6	
E-14	3	HZY3-16611-A00	PIPE, R. FUEL	1	1	1	
E-14	4	HP56-16614-003	MESH, FUEL FILTER	1	1	1	
E-14	5	HZY3-16620-A00	PIPE COMP., L. FUEL	1	1	1	
E-14	6	HZY3-16740-A01	REGULATOR ASSY., PRESSURE	1	1	1	
E-14	7	HPG7-16741-005	O-RING, PRESSURE REGULATOR	1	1	1	
E-14	8	HZVL-16748-000	TUBE, PRESSURE REGULATOR	1	1	1	
E-14	9	HZY3-16752-A00	JOINT, FUEL PIPE	3	3	3	
E-14	10	HZVL-16755-003	HOSE COMP., FUEL	1	1	1	
E-14	11	HZY3-16757-003	HOSE COMP., FUEL JOINT	1	1	1	
E-14	12	HZVL-16765-003	HOSE COMP. B. FUEL	1	1	1	
E-14	13	HZVL-16910-003	STRAINER COMP., FUEL (HIGH)	1	1	1	
E-14	14	HZVL-16917-000	SUSPENSION, STRAINER	1	1	1	
E-14	15	HVM0-16965-771	CLAMP, HOSE	1	1	1	
E-14	16	HZY3-17051-A00	BASE, R. INJECTOR	1	1	1	
E-14	17	HRCA-17055-A01	GASKET, FR. INJECTOR BASE	1	1	1	
E-14	18	HZY3-17061-A00	BASE, L. INJECTOR	1	1	1	
E-14	19	HRCA-17065-A01	GASKET, RR. INJECTOR BASE	1	1	1	
E-14	20	HP8E-17105-A01	GASKET, INTAKE MANIFOLD	1	1	1	
E-14	21	HZY3-17108-000	SPACER, INTAKE MANIFOLD	1	1	1	
E-14	22	HSOX-17711-931	RETAINER (BLUE GREEN) (TOKAI)	2	2	2	
E-14	23	HZY3-32112-000	BRACKET, HARNESS CLIP A	4	4	4	
E-14	24	HZZ5-90014-M00	BOLT, FLANGE, 6X25	4	4	4	
E-14	25	HZZ5-90019-M00	BOLT, FLANGE, 6X35	4			~1002570
E-14	25	HZZ5-90019-M00	BOLT, FLANGE, 6X35		4		~1002916
E-14	25	HZZ5-90019-M00	BOLT, FLANGE, 6X35			4	~1007289
E-14	25	HZZ5-90019-M01	BOLT, FLANGE, 6X35	4			1002571~
E-14	25	HZZ5-90019-M01	BOLT, FLANGE, 6X35		4		1002917~

E-14 FUEL PIPE/INJECTOR




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-14	25	HZZ5-90019-M01	BOLT, FLANGE, 6X35			4	1007290~
E-14	26	HZZ5-90021-M00	BOLT, FLANGE, 6X14	6			~1002570
E-14	26	HZZ5-90021-M00	BOLT, FLANGE, 6X14		6		~1002916
E-14	26	HZZ5-90021-M00	BOLT, FLANGE, 6X14			6	~1007289
E-14	26	HZZ5-90021-M01	BOLT, FLANGE, 6X14	6			1002571~
E-14	26	HZZ5-90021-M01	BOLT, FLANGE, 6X14		6		1002917~
E-14	26	HZZ5-90021-M01	BOLT, FLANGE, 6X14			6	1007290~
E-14	27	HZY9-90042-M00	BOLT, FLANGE, 6X10	6			~1002570
E-14	27	HZY9-90042-M00	BOLT, FLANGE, 6X10		6		~1002916
E-14	27	HZY9-90042-M00	BOLT, FLANGE, 6X10			6	~1007289
E-14	27	HZY9-90042-M01	BOLT, FLANGE, 6X10	6			1002571~
E-14	27	HZY9-90042-M01	BOLT, FLANGE, 6X10		6		1002917~
E-14	27	HZY9-90042-M01	BOLT, FLANGE, 6X10			6	1007290~
E-14	28	HZVL-90043-000	BOLT, STUD, 8X28	8			~1002549
E-14	28	HZVL-90043-000	BOLT, STUD, 8X28		8		~1002617
E-14	28	HZVL-90043-000	BOLT, STUD, 8X28			8	~1007152
E-14	28	HZVL-90043-010	BOLT, STUD, 8X28	8			1002550~
E-14	28	HZVL-90043-010	BOLT, STUD, 8X28		8		1002618~
E-14	28	HZVL-90043-010	BOLT, STUD, 8X28			8	1007153~
E-14	29	HZY3-90044-000	BOLT, STUD, 8X45	2			~1002570
E-14	29	HZY3-90044-000	BOLT, STUD, 8X45		2		~1002916
E-14	29	HZY3-90044-000	BOLT, STUD, 8X45			2	~1007289
E-14	29	HZY3-90044-010	BOLT, STUD, 8X45	2			1002571~
E-14	29	HZY3-90044-010	BOLT, STUD, 8X45		2		1002917~
E-14	29	HZY3-90044-010	BOLT, STUD, 8X45			2	1007290~
E-14	30	HZY9-90205-M00	NUT, FLANGE, 8MM	8	8	8	
E-14	31	HSB2-90650-003	CLIP, WIRE HARNESS, 10MM	4	4	4	
E-14	32	HMJO-91301-003	O-RING, 7. 8X1. 9 (ARAI)	6	6	6	
E-14	33	HPLC-91301-000	O-RING, 7. 47X3. 6	6	6	6	

E-14 FUEL PIPE/INJECTOR




[illegible]

E-14-10 INTAKE MANIFOLD



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-14-10	1	HZY3-17105-004	GASKET, INTAKE MANIFOLD	1	1	1	
E-14-10	2	HZY3-17109-004	PACKING, THROTTLE BODY	1	1	1	
E-14-10	3	HZVL-17110-003	MANIFOLD COMP., INLET	1	1	1	
E-14-10	4	HZVL-17131-000ZA	COVER, INTAKE MANIFOLD UPPER	1	1	1	*NH8*
E-14-10	5	HZY3-17138-004	PACKING, INTAKE MANIFOLD UP	1	1	1	
E-14-10	6	HRNA-37830-A01	SENSOR ASSY., MAP	1	1	1	
E-14-10	7	HZVL-37831-000	STAY, MAP SENSOR	1	1	1	
E-14-10	8	HZVL-37832-000	COLLAR, 5.5X6.8	1			~1002549
E-14-10	8	HZVL-37832-000	COLLAR, 5.5X6.8		1		~1002617
E-14-10	8	HZVL-37832-000	COLLAR, 5.5X6.8			1	~1007152
E-14-10	8	HZVL-37832-010	COLLAR, 5.5X6.8	1			1002550~
E-14-10	8	HZVL-37832-010	COLLAR, 5.5X6.8		1		1002618~
E-14-10	8	HZVL-37832-010	COLLAR, 5.5X6.8			1	1007153~
E-14-10	9	HPGK-37835-A01	O-RING	1	1	1	
E-14-10	10	HMB9-83551-000	GROMMET	1	1	1	
E-14-10	11	HZVL-90013-000	BOLT-WASHER, 5X12	1			~1002628
E-14-10	11	HZVL-90013-000	BOLT-WASHER, 5X12		1		~1002949
E-14-10	11	HZVL-90013-000	BOLT-WASHER, 5X12			1	~1007539
E-14-10	11	HZVL-90013-010	BOLT-WASHER, 5X12	1			1002629~
E-14-10	11	HZVL-90013-010	BOLT-WASHER, 5X12		1		1002950~
E-14-10	11	HZVL-90013-010	BOLT-WASHER, 5X12			1	1007540~
E-14-10	12	HZVL-90014-000	BOLT-WASHER, 5X28	1			~1002630
E-14-10	12	HZVL-90014-000	BOLT-WASHER, 5X28		1		~1002946
E-14-10	12	HZVL-90014-000	BOLT-WASHER, 5X28			1	~1007539
E-14-10	12	HZVL-90014-010	BOLT-WASHER, 5X28	1			1002631~
E-14-10	12	HZVL-90014-010	BOLT-WASHER, 5X28		1		1002947~
E-14-10	12	HZVL-90014-010	BOLT-WASHER, 5X28			1	1007540~
E-14-10	13	HZVL-90023-000	BOLT, FLANGE, 6X22	10	10	10	
E-14-10	14	HZY3-90031-000	BOLT, FLANGE, 6X32	1			~1002549

E-14-10 INTAKE MANIFOLD



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-14-10	14	HZY3-90031-000	BOLT, FLANGE, 6X32		1		~1002617
E-14-10	14	HZY3-90031-000	BOLT, FLANGE, 6X32			1	~1007152
E-14-10	14	HZZ5-90032-M01	BOLT, FLANGE, 6X32	1			1002550~
E-14-10	14	HZZ5-90032-M01	BOLT, FLANGE, 6X32		1		1002618~
E-14-10	14	HZZ5-90032-M01	BOLT, FLANGE, 6X32			1	1007153~
E-14-10	15	HZW4-90156-000	BOLT, FLANGE, 8X50	7			~1002549
E-14-10	15	HZW4-90156-000	BOLT, FLANGE, 8X50		7		~1002617
E-14-10	15	HZW4-90156-000	BOLT, FLANGE, 8X50			7	~1007152
E-14-10	15	HZVL-90020-010	BOLT, FLANGE, 8X50	7			1002550~
E-14-10	15	HZVL-90020-010	BOLT, FLANGE, 8X50		7		1002618~
E-14-10	15	HZVL-90020-010	BOLT, FLANGE, 8X50			7	1007153~
E-14-10	16	HZY3-90205-000	NUT, FLANGE, 8MM	2	2	2	
E-14-10	17	HZZ5-90301-M00	NUT, FLANGE, 5MM	1			~1002549
E-14-10	17	HZZ5-90301-M00	NUT, FLANGE, 5MM		1		~1002617
E-14-10	17	HZZ5-90301-M00	NUT, FLANGE, 5MM			1	~1007152
E-14-10	17	HZZ5-90301-M01	NUT, FLANGE, 5MM	1			1002550~
E-14-10	17	HZZ5-90301-M01	NUT, FLANGE, 5MM		1		1002618~
E-14-10	17	HZZ5-90301-M01	NUT, FLANGE, 5MM			1	1007153~
E-14-10	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	1			~1003126
E-14-10	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM		1		~1003040
E-14-10	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM			1	~1008834
E-14-10	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM	1			1003127~
E-14-10	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM		1		1003041~
E-14-10	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM			1	1008835~

FR.




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-15	1	HZY3-16016-003	SCREW SET	1	1	1	
E-15	2	HZY3-16176-000	GASKET, THROTTLE BODY	1	1	1	
E-15	3	HZVK-16400-003	THROTTLE BODY ASSY.	1			~1004454
E-15	3	HZVK-16400-003	THROTTLE BODY ASSY.		1		~1004482
E-15	3	HZVK-16400-013	THROTTLE BODY ASSY.	1			1004455~1005212
E-15	3	HZVK-16400-023	THROTTLE BODY ASSY.	1			1005213~
E-15	3	HZY3-16400-A01	THROTTLE BODY ASSY.		1		1004483~
E-15	3	HZY3-16400-A02	THROTTLE BODY ASSY.			1	~1014098
E-15	3	HZY3-16400-A03	THROTTLE BODY ASSY.			1	1014099~1014025
E-15	3	HZY3-16400-A03	THROTTLE BODY ASSY.			1	1014026~
E-15	4	HZX2-16404-000	SPACER, THROTTLE BODY	1	1	1	
E-15	5	HZY3-16405-000	GASKET, EAC VALVE	1	1	1	
E-15	6	HPY3-17249-000	SPRING, AIR FLOW TUBE	1	1	1	
E-15	7	HZY9-17315-M00	BAND, AIR FLOW	1	1	1	
E-15	8	HZX2-17374-000	GROMMET, SILENCER	1	1	1	
E-15	9	HZVL-17910-003	CABLE COMP., THROTTLE	2	2	2	
E-15	10	HZVL-19540-000	COVER ASSY., COOLING FAN	1			~1002817
E-15	10	HZVL-19540-000	COVER ASSY., COOLING FAN		1		~1002916
E-15	10	HZVL-19540-000	COVER ASSY., COOLING FAN			1	~1008195
E-15	10	HZVL-19540-010	COVER ASSY., COOLING FAN	1			1002818~
E-15	10	HZVL-19540-010	COVER ASSY., COOLING FAN		1		1002917~
E-15	10	HZVL-19540-010	COVER ASSY., COOLING FAN			1	1008196~
E-15	11	HZW5-35665-003	SENSOR ASSY., AIR TEMPERATURE	1	1	1	
E-15	12	HZY3-36550-003	VALVE ASSY., EAC	1	1	1	
E-15	13	HZV5-40102-000	GROMMET, UNDER CASE	4	4	4	
E-15	14	HSOX-46392-A01	CLIP, BRAKE PIPE	2	2	2	
E-15	15	HZZ5-90013-M00	BOLT-WASHER, 6X25	2			~1002549
E-15	15	HZZ5-90013-M00	BOLT-WASHER, 6X25		2		~1002617
E-15	15	HZZ5-90013-M00	BOLT-WASHER, 6X25			2	~1007152

FR.




[illegible]

E-18 VAPOR SEPARATOR ASSY




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-18	1	HZY3-16011-A01	VALVE SET, FLOAT	1	1	1	
E-18	2	HZY3-16013-000	FLOAT SET	1	1	1	
E-18	3	HZVL-16015-000	BODY	1	1	1	
E-18	4	HZVL-16020-003	COVER COMP.	1	1	1	
E-18	5	HZY3-16024-000	SCREW SET, DRAIN	1	1	1	
E-18	6	HZY3-16026-000	JOINT SET	1	1	1	
E-18	7	HZVL-16030-003	PUMP UNIT SET A, FUEL	1	1	1	
E-18	8	HZY3-16031-010	STAY, PLATE	1			~1004616
E-18	8	HZY3-16031-010	STAY, PLATE		1		~1004092
E-18	8	HZY3-16031-010	STAY, PLATE			1	~1012174
E-18	8	HZY3-16031-020	STAY, PLATE	1			1004617~
E-18	8	HZY3-16031-020	STAY, PLATE		1		1004093~
E-18	8	HZY3-16031-020	STAY, PLATE			1	1012175~
E-18	9	HZY3-16036-003	PUMP UNIT SET B, FUEL	1	1	1	
E-18	10	HZY3-16041-000	PLATE	1	1	1	
E-18	11	HZY3-16042-000	HOLDER	1	1	1	
E-18	12	HZY3-16061-010	COVER, WATER JACKET	1	1	1	
E-18	13	HZY3-16072-000	O-RING	1	1	1	
E-18	14	HZY3-16073-000	O-RING	1	1	1	
E-18	15	HZY3-16074-000	O-RING	1	1	1	
E-18	16	HZY3-16075-000	O-RING	1	1	1	
E-18	17	HZY3-16076-000	O-RING	1	1	1	
E-18	18	HZY3-16077-000	O-RING	2	2	2	
E-18	19	HZY3-16078-000	O-RING	1	1	1	
E-18	20	HZW5-16081-010	SCREW-WASHER	21	21	21	
E-18	21	HZY3-16082-000	SCREW, PAN	2	2	2	
E-18	22	HZY3-16083-000	SCREW, WASHER	1	1	1	
E-18	23	HZW5-16086-000	COLLAR, SET	8	8	8	
E-18	24	HZW5-16087-000	WASHER, PLAIN	8	8	8	

E-18 VAPOR SEPARATOR ASSY



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-18	25	HZY3-16087-000	WASHER, PLAIN	1	1	1	
E-18	26	HZY3-16088-000	COLLAR	1	1	1	
E-18	27	HZVL-16700-003	PUMP ASSY., FUEL	1	1	1	
E-18	28	HZX2-16701-003	CASE COMP., PUMP	1	1	1	
E-18	29	HZY3-16708-000	COVER, PUMP	1	1	1	
E-18	30	HZVL-16710-000	RUBBER, FUEL PUMP	2	2	2	
E-18	31	HZW5-16715-023	COVER, PUMP (A)	1	1	1	
E-18	32	HZY6-16718-013	INSULATOR COMP.	1	1	1	
E-18	33	HZY3-16721-000	INSULATOR	1	1	1	
E-18	34	HZY6-16723-003	RING	1	1	1	
E-18	35	HZVL-16725-000	STAY COMP. A, FUEL PUMP	1	1	1	
E-18	36	HZVL-16726-000	STAY COMP. B, FUEL PUMP	1	1	1	
E-18	37	HZVL-16730-023	SEPARATOR ASSY., VAPOR	1			~1004478
E-18	37	HZVL-16730-023	SEPARATOR ASSY., VAPOR		1		~1003857
E-18	37	HZVL-16730-023	SEPARATOR ASSY., VAPOR			1	~1011828
E-18	37	HZVL-16730-033	SEPARATOR ASSY., VAPOR	1			1004479~1004616
E-18	37	HZVL-16730-033	SEPARATOR ASSY., VAPOR		1		1003858~1004092
E-18	37	HZVL-16730-033	SEPARATOR ASSY., VAPOR			1	1011829~1012174
E-18	37	HZVL-16730-043	SEPARATOR ASSY., VAPOR	1			1004617~
E-18	37	HZVL-16730-043	SEPARATOR ASSY., VAPOR		1		1004093~
E-18	37	HZVL-16730-043	SEPARATOR ASSY., VAPOR			1	1012175~
E-18	38	HZW5-16733-000	GROMMET, VAPOR SEPARATOR	1	1	1	
E-18	39	HZY3-16733-000	GROMMET, VAPOR SEPARATOR	2	2	2	
E-18	40	HZY3-16734-000	STAY, PLATE	1	1	1	
E-18	41	HZY3-16735-004	PUMP UNIT, FUEL	1	1	1	
E-18	42	HZY3-16752-000	JOINT, FUEL PIPE	1	1	1	
E-18	43	HZX2-32166-003	HARNESS COMP.	1	1	1	
E-18	44	HZW5-32168-003	BAND	1	1	1	
E-18	45	HPP4-90009-E01	BOLT, SEALING, 6MM	1	1	1	

E-18 VAPOR SEPARATOR ASSY




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF12000	BF1225D	BF1250D	
E-18	46	HZY9-90014-M00	BOLT-WASHER, 8X35	3	3	3	
E-18	47	HZZ5-90014-M00	BOLT, FLANGE, 6X25	2			~1004478
E-18	47	HZZ5-90014-M00	BOLT, FLANGE, 6X25		2		~1003857
E-18	47	HZZ5-90014-M00	BOLT, FLANGE, 6X25			2	~1011828
E-18	47	HZZ5-90014-M01	BOLT, FLANGE, 6X25	2			1004479~
E-18	47	HZZ5-90014-M01	BOLT, FLANGE, 6X25		2		1003858~
E-18	47	HZZ5-90014-M01	BOLT, FLANGE, 6X25			2	1011829~
E-18	48	HZZ5-90016-M00	BOLT, FLANGE, 6X28	2			~1004478
E-18	48	HZZ5-90016-M00	BOLT, FLANGE, 6X28		2		~1003857
E-18	48	HZZ5-90016-M00	BOLT, FLANGE, 6X28			2	~1011828
E-18	48	HZZ5-90016-M01	BOLT, FLANGE, 6X28	2			1004479~
E-18	48	HZZ5-90016-M01	BOLT, FLANGE, 6X28		2		1003858~
E-18	48	HZZ5-90016-M01	BOLT, FLANGE, 6X28			2	1011829~
E-18	49	HZZ5-90017-M00	BOLT, FLANGE, 6X16	2			~1004478
E-18	49	HZZ5-90017-M00	BOLT, FLANGE, 6X16		2		~1003857
E-18	49	HZZ5-90017-M00	BOLT, FLANGE, 6X16			2	~1011828
E-18	49	HZZ5-90017-M01	BOLT, FLANGE, 6X16	2			1004479~
E-18	49	HZZ5-90017-M01	BOLT, FLANGE, 6X16		2		1003858~
E-18	49	HZZ5-90017-M01	BOLT, FLANGE, 6X16			2	1011829~
E-18	50	HZZ5-90021-M00	BOLT, FLANGE, 6X14	2			~1002570
E-18	50	HZZ5-90021-M00	BOLT, FLANGE, 6X14		2		~1002916
E-18	50	HZZ5-90021-M00	BOLT, FLANGE, 6X14			2	~1007289
E-18	50	HZZ5-90021-M01	BOLT, FLANGE, 6X14	2			1002571~
E-18	50	HZZ5-90021-M01	BOLT, FLANGE, 6X14		2		1002917~
E-18	50	HZZ5-90021-M01	BOLT, FLANGE, 6X14			2	1007290~
E-18	51	HPD6-90430-003	WASHER, SEALING, 6MM	1	1	1	
E-18	52	HZB7-90691-003	CLIP, HARNESS	2	2	2	
E-18	53	HMJ0-91301-003	O-RING, 7.8X1.9 (ARAI)	2	2	2	

FR.




E-18-1 FUEL STRAINER




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-18-1	1	HZY3-16818-003	O-RING	1	1	1	
E-18-1	2	HZVL-16840-000	TUBE COMP. A, FUEL	1	1	1	
E-18-1	3	HZVL-16841-000	STAY, FUEL TUBE	1	1	1	
E-18-1	4	HZVL-16850-000	TUBE COMP. B, FUEL	1	1	1	
E-18-1	5	HZY9-16896-003	CLAMP B, FUEL TUBE	5	5	5	
E-18-1	6	HZVL-16900-003	STRAINER ASSY., FUEL (LOW)	1	1	1	
E-18-1	7	HZY3-16901-003	STRAINER, FUEL	1	1	1	
E-18-1	8	HZY3-16904-003	SCREW, PAN, 5X12	3	3	3	
E-18-1	9	HZVL-16914-000	STAY A, FUEL STRAINER	1	1	1	
E-18-1	10	HZY3-16915-010	SUSPENSION, STRAINER	1	1	1	
E-18-1	11	HZY3-16918-003	O-RING	1	1	1	
E-18-1	12	HZY3-16919-003	PLATE	1	1	1	
E-18-1	13	HZY3-17738-000	PLUG, FUEL TUBE	1	1	1	
E-18-1	14	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1			~1002570
E-18-1	14	HZZ5-90021-M00	BOLT, FLANGE, 6X14		1		~1002916
E-18-1	14	HZZ5-90021-M00	BOLT, FLANGE, 6X14			1	~1007289
E-18-1	14	HZZ5-90021-M01	BOLT, FLANGE, 6X14	1			1002571~
E-18-1	14	HZZ5-90021-M01	BOLT, FLANGE, 6X14		1		1002917~
E-18-1	14	HZZ5-90021-M01	BOLT, FLANGE, 6X14			1	1007290~
E-18-1	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10	2			~1002549
E-18-1	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10		2		~1002617
E-18-1	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10			2	~1007152
E-18-1	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10	2			1002550~
E-18-1	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10		2		1002618~
E-18-1	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10			2	1007153~
E-18-1	16	HZW5-90602-030	CLAMP, TUBE (D12)	1	1	1	
E-18-1	17	HZV0-90604-000	CLIP, TUBE (B12)	2	2	2	
E-18-1	18	HSTK-91540-003	CLIP, HARNESS BAND (BLACK)	1	1	1	
E-18-1	19	HZVL-16805-003	CUP SET, WATER SEPARATER	1	1	1	

E-18-10 PIPING



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-18-10	1	HZY3-16193-A00	CLAMP, CHECK VALVE	1	1	1	
E-18-10	2	HZY3-16196-A00	TUBE, CHECK VALVE	1	1	1	
E-18-10	3	HZY3-16197-000	TUBE A, AIR VENT	1	1	1	
E-18-10	4	HZY3-16198-A00	TUBE B, AIR VENT	1	1	1	
E-18-10	5	HZY3-16199-A00	TUBE COMP., AIR VENT	1	1	1	
E-18-10	6	HRMA-16723-E00	JOINT, FUEL FEED HOSE	1	1	1	
E-18-10	7	HZVL-16760-003	VALVE COMP., RELIEF	1	1	1	
E-18-10	8	HZVL-16770-000	TUBE, RELIEF	1	1	1	
E-18-10	9	HZVL-16860-000	TUBE COMP. C, FUEL	1	1	1	
E-18-10	10	HZVL-16870-000	TUBE D, FUEL	1	1	1	
E-18-10	11	HZVL-16875-000	JOINT, THREE WAY	1	1	1	
E-18-10	12	HZVL-16880-000	TUBE E, FUEL	1	1	1	
E-18-10	13	HZVL-16890-000	TUBE F, FUEL	1	1	1	
E-18-10	14	H759-16911-003	STRAINER, FUEL PUMP	1	1	1	
E-18-10	15	HZW5-16915-000	SUSPENSION, STRAINER	1	1	1	
E-18-10	16	HVMO-16965-771	CLAMP, HOSE	7	7	7	
E-18-10	17	HZY3-17721-000	JOINT, FUEL RETURN	1	1	1	
E-18-10	18	HZY3-17723-A01	HOSE A, PRESSURE REGULATOR	1	1	1	
E-18-10	19	HZY3-17724-010	HOSE B, PRESSURE REGULATOR	1	1	1	
E-18-10	20	HZY3-19258-010	TUBE, WATER IN.	1	1	1	
E-18-10	21	HZY3-19259-000	TUBE, WATER OUTLET	1	1	1	
E-18-10	22	HZY6-19269-000	T-JOINT	1	1	1	
E-18-10	23	HZY6-36135-003	VALVE, CHECK	1	1	1	
E-18-10	24	HSE0-53740-953	CLIP, SENSOR HOSE	1	1	1	
E-18-10	25	HZW5-90601-030	CLAMP, TUBE (D10.7)	4	4	4	
E-18-10	26	HZY3-90601-030	CLAMP, TUBE (D10.5)	4	4	4	
E-18-10	27	HZW5-90602-030	CLAMP, TUBE (D12)	3	3	3	
E-18-10	28	HZV0-90604-000	CLIP, TUBE (B12)	7	7	7	
E-18-10	29	HZW5-90652-003	CLAMP, 6MM-12MM	1	1	1	


E-18-10 PIPING



[illegible]


E-19 A.C. GENERATOR

FR. 




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-19	1	HPR7-31105-A01	HOLDER ASSY., BRUSH	1	1	1	
E-19	2	HPT0-31111-003	BEARING, RR. GENERATOR	1	1	1	
E-19	3	HPT0-31114-013	BEARING, FR. GENERATOR	1	1	1	
E-19	4	HPT0-31118-003	BUSH, INSULATION	4	4	4	
E-19	5	HPD1-31138-004	COVER, BEARING	1	1	1	
E-19	6	HP13-31141-003	PULLEY	1	1	1	
E-19	7	HPD1-31142-004	NUT, PULLEY LOCK	1	1	1	
E-19	8	HPD1-31145-004	BOLT, STUD, 6X68	4	4	4	
E-19	9	HPT0-31146-003	SCREW	4	4	4	
E-19	10	HP13-31147-003	SCREW	1	1	1	
E-19	11	HPT0-31147-003	SCREW-WASHER	3	3	3	
E-19	12	HP13-31148-003	SCREW, WAVE WASHER	4	4	4	
E-19	13	HPT0-31148-003	SCREW, WAVE WASHER	2	2	2	
E-19	14	HZY3-31630-013	GENERATOR ASSY., A. C.	1	1	1	
E-19	15	HZY3-31631-003	ROTOR ASSY.	1	1	1	
E-19	16	HZVL-31637-000	STAY, A. C. GENERATOR	1	1	1	
E-19	17	HZY3-31639-003	END COVER, RR.	1	1	1	
E-19	18	HZY3-31694-003	BUSH, INSULATION	1	1	1	
E-19	19	HZY3-31710-003	RECTIFIER ASSY.	1	1	1	
E-19	20	HZY3-31750-003	REGULATOR ASSY.	1	1	1	
E-19	21	HZX2-90002-000	BOLT, FLANGE, 10X90	1			~1002549
E-19	21	HZX2-90002-000	BOLT, FLANGE, 10X90		1		~1002617
E-19	21	HZX2-90002-000	BOLT, FLANGE, 10X90			1	~1007152
E-19	21	HZX2-90002-010	BOLT, FLANGE, 10X90	1			1002550~
E-19	21	HZX2-90002-010	BOLT, FLANGE, 10X90		1		1002618~
E-19	21	HZX2-90002-010	BOLT, FLANGE, 10X90			1	1007153~
E-19	22	HZVL-90011-000	BOLT, SPECIAL ADJUSTER	1	1	1	
E-19	23	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	1	
E-19	24	HZY3-90055-000	BOLT, TENSIONER	1			~1002549

E-19 A.C. GENERATOR




[illegible]

E-20 SPARK PLUG




E-20-10 ELECTRONIC CONTROL UNIT




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-20-10	1	HZVL-30416-000	CASE, ELECTRONIC PARTS	1			~1000781
E-20-10	1	HZVL-30416-000	CASE, ELECTRONIC PARTS		1		~1000697
E-20-10	1	HZVL-30416-000	CASE, ELECTRONIC PARTS			1	~1001981
E-20-10	1	HZVL-30416-010	CASE, ELECTRONIC PARTS	1			1000782~1002549 XCRU
E-20-10	1	HZVL-30416-010	CASE, ELECTRONIC PARTS		1		1000698~1002617
E-20-10	1	HZVL-30416-010	CASE, ELECTRONIC PARTS			1	1001982~1007152
E-20-10	1	HZVL-30416-020	CASE, ELECTRONIC PARTS	1			1002550~
E-20-10	1	HZVL-30416-020	CASE, ELECTRONIC PARTS		1		1002618~
E-20-10	1	HZVL-30416-020	CASE, ELECTRONIC PARTS			1	1007153~
E-20-10	2	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	8	8	8	
E-20-10	3	HZVL-32101-000	BRACKET, A. C. GENERATOR FUSE	4	4	4	
E-20-10	4	HZVL-32102-000	BRACKET, COUPLER A	1	1	1	
E-20-10	5	HZW9-32117-000	BRACKET, COUPLER D		1	1	
E-20-10	6	HZVJ-34750-901	CONTROL UNIT, ELECTRONIC	1			~1000808
E-20-10	6	HZVJ-34750-902	CONTROL UNIT, ELECTRONIC	1			1000809~1004021
E-20-10	6	HZVJ-34750-903	CONTROL UNIT, ELECTRONIC	1			1004022~
E-20-10	6	HZVK-34750-901	CONTROL UNIT, ELECTRONIC		1		~1000737
E-20-10	6	HZVK-34750-902	CONTROL UNIT, ELECTRONIC		1		1000738~1003549
E-20-10	6	HZVK-34750-903	CONTROL UNIT, ELECTRONIC		1		1003550~
E-20-10	6	HZVL-34750-901	CONTROL UNIT, ELECTRONIC			1	~1002101
E-20-10	6	HZVL-34750-902	CONTROL UNIT, ELECTRONIC			1	1002102~1010800
E-20-10	6	HZVL-34750-903	CONTROL UNIT, ELECTRONIC			1	1010801~
E-20-10	7	HZVL-34754-000	CASE, ELECTRONIC CONTROL UNIT	1	1	1	
E-20-10	8	HZVL-90015-000	BOLT-WASHER, 6X27	8	8	8	
E-20-10	9	HZZ0-90102-M00	BOLT, TORX (M6X20)	2			~1002700
E-20-10	9	HZZ0-90102-M00	BOLT, TORX (M6X20)		2		~1002916
E-20-10	9	HZZ0-90102-M00	BOLT, TORX (M6X20)			2	~1007868
E-20-10	9	HZZ0-90102-M01	BOLT, TORX (M6X20)	2			1002701~
E-20-10	9	HZZ0-90102-M01	BOLT, TORX (M6X20)		2		1002917~

E-20-10 ELECTRONIC CONTROL UNIT




E-21 STARTER MOTOR




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
E-21	1	HZY3-31200-003	MOTOR ASSY., STARTER	1	1	1	
E-21	2	HP5A-31201-005	ROTOR COMP.	1	1	1	
E-21	3	HZY9-31207-H01	CLUTCH COMP., OVERRUNNING	1	1	1	
E-21	4	HPY3-31215-004	GEAR ASSY., PLANETARY	3	3	3	
E-21	5	HZY3-31216-003	YOKE COMP.	1	1	1	
E-21	6	HPY3-31218-004	BALL, STEEL	1	1	1	
E-21	7	HZY3-31226-003	BRUSH SET	1	1	1	
E-21	8	HZY9-31226-H01	SCREW, PAN, 6X22	2	2	2	
E-21	9	HZY9-31229-H01	STOPPER SET, SLEEVE	1	1	1	
E-21	10	HZY3-31232-003	HOLDER COMP., BRUSH	1	1	1	
E-21	11	HZY3-31235-003	BRACKET, FR.	1	1	1	
E-21	12	HZY3-31236-003	BRACKET, RR.	1	1	1	
E-21	13	HZY3-31241-003	SWITCH ASSY., MAGNET	1	1	1	
E-21	14	HP5A-31243-005	BOLT A, THROUGH	2	2	2	
E-21	15	HZY3-31243-003	SHAFT ASSY., CLUTCH	1	1	1	
E-21	16	HZY9-31246-H01	SHAFT ASSY., GEAR	1	1	1	
E-21	17	HZY3-31250-003	LEVER SET	1	1	1	
E-21	18	HZY3-31251-003	GEAR ASSY., INTERNAL	1	1	1	
E-21	19	HZVL-90003-000	BOLT, FLANGE, 10X110	1			~1002549
E-21	19	HZVL-90003-000	BOLT, FLANGE, 10X110		1		~1002617
E-21	19	HZVL-90003-000	BOLT, FLANGE, 10X110			1	~1007152
E-21	19	HZVL-90003-010	BOLT, FLANGE, 10X110	1			1002550~
E-21	19	HZVL-90003-010	BOLT, FLANGE, 10X110		1		1002618~
E-21	19	HZVL-90003-010	BOLT, FLANGE, 10X110			1	1007153~
E-21	20	HZVL-90005-000	BOLT, FLANGE, 10X90	1			~1002549
E-21	20	HZVL-90005-000	BOLT, FLANGE, 10X90		1		~1002617
E-21	20	HZVL-90005-000	BOLT, FLANGE, 10X90			1	~1007152
E-21	20	HZVL-90005-010	BOLT, FLANGE, 10X90	1			1002550~
E-21	20	HZVL-90005-010	BOLT, FLANGE, 10X90		1		1002618~

E-21 STARTER MOTOR




[illegible]

EOP-1 GASKET KIT



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
EOP-1	1	HZVL-06115-010	GASKET KIT (BF175/200/225/250)	1	1	1	
EOP-1	2	HZVL-11381-003	PACKING, OIL PAN	1	1	1	
EOP-1	3	HZY3-12251-A01	GASKET COMP., CYLINDER HEAD	2	2	2	(NIPPON LEAKLESS)
EOP-1	4	HZY3-12312-000	PACKING, HEAD COVER	2	2	2	
EOP-1	5	HZY3-14529-000	O-RING, TIMING BELT TENSIONER	1	1	1	BASE
EOP-1	6	HZY3-15112-013	PACKING, OIL PUMP BODY	1	1	1	
EOP-1	7	HRCA-17055-A01	GASKET, FR. INJECTOR BASE	1	1	1	
EOP-1	8	HRCA-17065-A01	GASKET, RR. INJECTOR BASE	1	1	1	
EOP-1	9	HP8E-17105-A01	GASKET, INTAKE MANIFOLD	1	1	1	
EOP-1	10	HZY3-18115-003	GASKET, R. EX. MANIFOLD	1	1	1	
EOP-1	11	HZY3-18125-003	GASKET, L. EX. MANIFOLD	1	1	1	
EOP-1	12	HZVL-18333-003	GASKET, EX. PIPE	2	2	2	
EOP-1	13	HZVL-23172-003	GASKET, MOUNT CASE	1	1	1	
EOP-1	14	HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	1	1	1	
EOP-1	15	HMJ0-91301-003	O-RING, 7.8X1.9 (ARAI)	2	2	2	
EOP-1	16	HZY3-91301-003	O-RING, 66.4X3.1	2	2	2	
EOP-1	17	HPF0-91302-003	O-RING, 26.9X2.4 (NOK)	1	1	1	
EOP-1	18	HZY3-91303-000	O-RING, 59.4X3.1	1	1	1	
EOP-1	19	HPNA-91307-003	O-RING, 9.5X1.9	1	1	1	
EOP-1	20	HPR3-91319-003	O-RING, 13X1.5 (ARAI)	1	1	1	
EOP-1	21	HPC6-91324-000	O-RING, 20.6X2.6	1	1	1	
EOP-1	22	HZVL-91356-003	O-RING, 31.5X2.4 (ARAI)	1	1	1	


F-2 SHIFT SHAFT



ZVJ3F0200A

Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-2	1	HKN5-17224-670	WASHER, AIR CLEANER COVER	2	2	2	
F-2	2	HZVL-17877-900	PLATE, REMOTE CONTROL CABLE	1	1	1	
F-2	3	HZVL-17878-900	COVER, REMOTE CONTROL CABLE	1	1	1	
F-2	4	HZY3-17931-000	ARM, THROTTLE	1	1	1	
F-2	5	HZVL-17932-900	SHAFT, THROTTLE ARM	1	1	1	
F-2	6	H921-17936-000	WASHER, PIVOT	3	3	3	
F-2	7	HZW1-24210-010	SPRING COMP., CLICK	1	1	1	
F-2	8	HZY3-24221-000	SPRING, CLICK ASSIST	1	1	1	
F-2	9	HZW1-24327-000	RING, STOPPER	1	1	1	
F-2	10	HZY3-24610-A00	SHAFT COMP., SHIFT(A)	1	1	1	
F-2	13	HZY3-24617-000	COLLAR, SHIFT SLIDER	2	2	2	
F-2	14	HZY3-24618-000	PIVOT, SHIFT	1	1	1	
F-2	15	HZY3-24619-000	PLATE, LOCK	1	1	1	
F-2	16	HZY3-24620-000	SHAFT COMP., SHIFT(B)	1	1	1	
F-2	17	HZVL-24621-000	PIVOT, THROTTLE	1	1	1	
F-2	18	HZVL-24622-000	PLATE, LOCK	1	1	1	
F-2	20	HZVL-24627-900	GUIDE, SHIFT LINK (MECH)	1	1	1	
F-2	21	HZVL-24628-900	BRACKET, SHIFT LINK (MECH)	1	1	1	
F-2	22	HZW1-24629-000	HOLDER, SEAL	1	1	1	
F-2	23	HZX2-35470-013	SWITCH ASSY., NEUTRAL	1	1	1	
F-2	24	HZY3-35476-010	BRACKET, NEUTRAL SWITCH	1	1	1	
F-2	25	HZVL-35477-000	COVER, NEUTRAL SWITCH	1	1	1	
F-2	26	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	1	
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14	4			~6010052 LRU, XRD, XRU
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14	4			~7010006 XCRU
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14		4		~6010057 XRD, XRU
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14		4		~7010010 XCRU
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14			4	~6010095 XRD, XRU
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14			4	~7010024 XCRU


F-2 SHIFT SHAFT



ZVJ3F0200A

Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14	4			6010053~ LRU, XRD, XRU
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14	4			7010007~ XCRU
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14		4		6010058~ XRD, XRU
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14		4		7010011~ XCRU
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14			4	6010096~ XRD, XRU
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14			4	7010025~ XCRU
F-2	28	HZX2-90101-C00	BOLT-WASHER, 6X16	3	3	3	
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11	2			~6010052 LRU, XRD, XRU
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11	2			~7010006 XCRU
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11		2		~6010057 XRD, XRU
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11		2		~7010010 XCRU
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11			2	~6010095 XRD, XRU
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11			2	~7010024 XCRU
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11	2			6010053~ LRU, XRD, XRU
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11	2			7010007~ XCRU
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11		2		6010058~ XRD, XRU
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11		2		7010011~ XCRU
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11			2	6010096~ XRD, XRU
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11			2	7010025~ XCRU
F-2	30	H881-90114-000	BOLT, HEX., 6X40	1	1	1	
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM	2			~6010042 LRU, XRD, XRU
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM	2			~7010006 XCRU
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM		2		~6010040 XRD, XRU
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM		2		~7010010 XCRU
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM			2	~6010087 XRD, XRU
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM			2	~7010028 XCRU
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM	2			6010043~ LRU, XRD, XRU
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM	2			7010007~ XCRU
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM		2		6010041~ XRD, XRU


F-2 SHIFT SHAFT



ZVJ3F0200A

Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM		2		7010011~ XCRU
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM			2	6010088~ XRD, XRU
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM			2	7010029~ XCRU
F-2	32	HZV5-90302-003	NUT, HEX., 20MM	1	1	1	
F-2	33	HHA0-90402-000	WASHER, THRUST, 14MM	1	1	1	
F-2	34	H958-90428-000	WASHER B, THRUST, 14MM	1	1	1	
F-2	35	HZV7-90508-000	WASHER	1	1	1	
F-2	36	HZZ5-90508-M01	WASHER, PLAIN, 6MM	1		1	XCRU, XRU
F-2	36	HZZ5-90508-M00	WASHER, PLAIN, 6MM	1			~6010098 LRU, XRD
F-2	36	HZZ5-90508-M01	WASHER, PLAIN, 6MM	1			6010099~ LRU, XRD
F-2	36	HZZ5-90508-M01	WASHER, PLAIN, 6MM		1		XRU
F-2	36	HZZ5-90508-M00	WASHER, PLAIN, 6MM		1		~6010071 XRD
F-2	36	HZZ5-90508-M00	WASHER, PLAIN, 6MM		1		~7010010 XCRU
F-2	36	HZZ5-90508-M01	WASHER, PLAIN, 6MM		1		6010072~ XRD
F-2	36	HZZ5-90508-M01	WASHER, PLAIN, 6MM		1		7010011~ XCRU
F-2	36	HZZ5-90508-M00	WASHER, PLAIN, 6MM			1	~6010157 XRD
F-2	36	HZZ5-90508-M01	WASHER, PLAIN, 6MM			1	6010158~ XRD
F-2	38	HZV4-90512-000	WASHER, PLAIN, 6MM	1	1	1	
F-2	40	HZY3-90751-000	PIN, LINK	1	1	1	
F-2	41	HZY3-91152-003	RING, INNER(15X20X23)	1	1	1	
F-2	42	HZW5-91251-003	OIL SEAL, 14X26X6	1	1	1	
F-2	43	HZY3-91255-003	SEAL, WATER(14X26X8)	1	1	1	
F-2	44	HPF0-91302-003	O-RING, 26.9X2.4(NOK)	1	1	1	
F-2	45	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)	1	1	1	
F-2	46	HCO-94540-04029	E-RING, 4MM	3	3	3	
F-2	47	HCO-94540-12029	E-RING, 12MM	2	2	2	
F-2	48	HZVL-24640-900	LINK ASSY., SHIFT	1	1	1	


F-3 GEAR CASE



FR.

Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-3	1	HZW1-19286-B00	PLATE, RUBBER SETTING	1	1	1	
F-3	2	HZX2-41101-C01ZC	CASE, GEAR	1	1	1	*T107*
F-3	3	HZW1-41102-B00	GROMMET, GEAR CASE	1	1	1	
F-3	4	HZX2-41102-E00ZC	COVER, GEAR CASE	1	1	1	*T107* XCRU
F-3	5	HZY3-41104-C01	SCREEN, R. WATER	1	1	1	
F-3	6	HZY3-41105-C01	SCREEN, L. WATER	1	1	1	
F-3	7	HZX2-41107-C00ZC	TAB, TRIM	1	1	1	*T107*LRU, XRD, XRU
F-3	8	HZW1-41109-B00	METAL COMP., ANODE	2	2	2	
F-3	9	HZX2-41110-305ZB	CASE COMP., GEAR	1	1	1	*T107*
F-3	10	HZW9-90101-003	BOLT, OIL CHECK	1	1	1	
F-3	11	HZZ0-90101-000	SCREW, FLAT, 5X55	1	1	1	
F-3	12	HZY6-90103-000	BOLT-WASHER, 10X32	1	1	1	
F-3	13	HZX2-90107-C00	BOLT-WASHER, 10X47	6	6	6	
F-3	14	HZY3-90120-000	BOLT, DRAIN PLUG	1	1	1	
F-3	15	HZY3-90124-000	BOLT, STUD, 12X40	1	1	1	
F-3	16	HZY1-90205-000	NUT, SELF-LOCK, 6MM	1	1	1	
F-3	17	HZV4-90302-000	NUT, SELF-LOCK, 5MM	1	1	1	
F-3	18	HZW1-90308-003	NUT, SELF-LOCK, 12MM	1	1	1	
F-3	19	HZV5-90559-000	WASHER, PLAIN, 12MM	1	1	1	
F-3	20	HZV5-90756-000	DOWEL PIN, 6X10	2	2	2	
F-3	21	HZW4-91301-003	O-RING, 6.9X1.45	2	2	2	
F-3	22	HCO-92101-06055-4J	BOLT, HEX., 6X55	1	1	1	


F-3-10 GEAR CASE ASSY



FR.


[illegible]

F-3-20 EXTENSION CASE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT2000	BFT225D	BFT250D	
F-3-20	1	HGHB-16075-830	O-RING, 1.9X10	1	1	1	
F-3-20	2	HZY3-19270-000	NUT, WATER MOUTH	1	1	1	
F-3-20	3	HZY3-19271-000	JOINT, WATER HOSE	1	1	1	
F-3-20	4	HZY3-19272-000	SEAT, WATER MOUTH	1	1	1	
F-3-20	5	HZVL-19274-000	SEAT, WATER JOINT	1	1	1	
F-3-20	6	HZY3-19289-000	CAP, WATER JOINT	1	1	1	
F-3-20	7	HZY3-23173-010	RUBBER, MOUNT CASE SEAL	3	3	3	
F-3-20	8	HZY3-35640-013	SWITCH ASSY., POWER TILT	1	1	1	
F-3-20	9	HZY9-35645-000	STAY, POWER TILT SWITCH	1	1	1	
F-3-20	10	HZVL-40100-000	CASE ASSY., ENGINE UNDER	1			~6010044 LRU, XRD, XRU
F-3-20	10	HZVL-40100-000	CASE ASSY., ENGINE UNDER	1			~7010006 XCRL
F-3-20	10	HZVL-40100-000	CASE ASSY., ENGINE UNDER		1		~6010049 XRD, XRU
F-3-20	10	HZVL-40100-000	CASE ASSY., ENGINE UNDER		1		~7010010 XCRL
F-3-20	10	HZVL-40100-000	CASE ASSY., ENGINE UNDER			1	~6010089 XRD, XRU
F-3-20	10	HZVL-40100-000	CASE ASSY., ENGINE UNDER			1	~7010030 XCRL
F-3-20	10	HZVL-40100-010	CASE ASSY., ENGINE UNDER	1			6010045~ LRU, XRD, XRU
F-3-20	10	HZVL-40100-010	CASE ASSY., ENGINE UNDER	1			7010007~ XCRL
F-3-20	10	HZVL-40100-010	CASE ASSY., ENGINE UNDER		1		6010050~ XRD, XRU
F-3-20	10	HZVL-40100-010	CASE ASSY., ENGINE UNDER		1		7010011~ XCRL
F-3-20	10	HZVL-40100-010	CASE ASSY., ENGINE UNDER			1	6010090~ XRD, XRU
F-3-20	10	HZVL-40100-010	CASE ASSY., ENGINE UNDER			1	7010031~ XCRL
F-3-20	11	HZVL-40102-000	SEAL A, UNDER CASE	1	1	1	
F-3-20	12	HZVL-40103-000	SEAL B, UNDER CASE	1	1	1	
F-3-20	13	HZVL-40105-900	GROMMET, UNDER CASE (MECH)	1	1	1	
F-3-20	14	HZVL-40110-000	STAY COMP., HARNESS	1			~6010057 LRU, XRD, XRU
F-3-20	14	HZVL-40110-000	STAY COMP., HARNESS	1			~7010008 XCRL
F-3-20	14	HZVL-40110-000	STAY COMP., HARNESS		1		~6010061 XRD, XRU
F-3-20	14	HZVL-40110-000	STAY COMP., HARNESS		1		~7010010 XCRL
F-3-20	14	HZVL-40110-000	STAY COMP., HARNESS			1	~6010099 XRD, XRU

F-3-20 EXTENSION CASE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-3-20	14	HZVL-40110-000	STAY COMP., HARNESS			1	~7010030 XCRU
F-3-20	14	HZVL-40110-010	STAY COMP., HARNESS	1			6010058~ LRU, XRD, XRU
F-3-20	14	HZVL-40110-010	STAY COMP., HARNESS	1			7010009~ XCRU
F-3-20	14	HZVL-40110-010	STAY COMP., HARNESS		1		6010062~ XRD, XRU
F-3-20	14	HZVL-40110-010	STAY COMP., HARNESS		1		7010011~ XCRU
F-3-20	14	HZVL-40110-010	STAY COMP., HARNESS			1	6010100~ XRD, XRU
F-3-20	14	HZVL-40110-010	STAY COMP., HARNESS			1	7010031~ XCRU
F-3-20	15	HZVL-40116-000	PORT, IDLE EXHAUST	1	1	1	
F-3-20	16	HZVL-40151-000	COVER, SEPARATE	1	1	1	
F-3-20	17	HZVL-40154-000	BRACKET, UNDER CASE FR.	1	1	1	
F-3-20	18	HZVL-40201-000	CASE, EXTENSION (XL)	1	1	1	XCRU, XRD, XRU
F-3-20	19	HZVL-40201-900	CASE, EXTENSION (L)	1			LRU
F-3-20	20	HZVL-40209-000	RUBBER, DRAIN PLUG	1	1	1	
F-3-20	21	HZY3-40210-610	BUSH COMP., VERTICAL SHAFT	1	1	1	XCRU, XRD, XRU
F-3-20	22	HZY3-50111-020	HOUSING, LOWER MOUNTING	2	2	2	
F-3-20	23	HZY3-50155-000	MOUNT COMP., LOWER RUBBER	2	2	2	
F-3-20	24	HZY3-50157-010	STOPPER, LOWER MOUNT	2	2	2	
F-3-20	25	H121-51640-730	RUBBER, FR. CARRIER CUSHION	6	6	6	
F-3-20	26	HZVL-63119-000	SPRING, LEVER RETURN	3	3	3	
F-3-20	27	HZVL-63210-000	LEVER, COVER LOCK FR.	1	1	1	
F-3-20	28	HZVL-63212-000	HOOK COMP., COVER LOCK R.	2	2	2	
F-3-20	29	HZVL-63213-000	COLLAR A, COVER LOCK	3	3	3	
F-3-20	30	HZVL-63214-000	COLLAR B, COVER LOCK	3	3	3	
F-3-20	31	HZVL-63220-000	LEVER, COVER LOCK R.	1	1	1	
F-3-20	32	HZVL-63222-000	HOOK COMP., COVER LOCK L.	1	1	1	
F-3-20	33	HZVL-63230-000	LEVER, COVER LOCK L.	1	1	1	
F-3-20	34	HZC0-63515-700	CAP, L. SIDE COVER	1	1	1	
F-3-20	35	HZVL-82873-000	GROMMET, WATER CHECK	1	1	1	
F-3-20	36	HZZ5-90051-M00	BOLT, FLANGE, 8X18	2	2	2	

F-3-20 EXTENSION CASE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-3-20	37	HZVL-90102-000	BOLT-WASHER, 10X35	6	6	6	
F-3-20	38	HZW9-90102-000	BOLT, FLANGE, 6X12	1			~6010057 LRU, XRD, XRU
F-3-20	38	HZW9-90102-000	BOLT, FLANGE, 6X12	1			~7010008 XCRU
F-3-20	38	HZW9-90102-000	BOLT, FLANGE, 6X12		1		~6010061 XRD, XRU
F-3-20	38	HZW9-90102-000	BOLT, FLANGE, 6X12		1		~7010010 XCRU
F-3-20	38	HZW9-90102-000	BOLT, FLANGE, 6X12			1	~6010099 XRD, XRU
F-3-20	38	HZW9-90102-000	BOLT, FLANGE, 6X12			1	~7010030 XCRU
F-3-20	38	HZVL-90109-000	BOLT, FLANGE, 6X25	1			6010058~ LRU, XRD, XRU
F-3-20	38	HZVL-90109-000	BOLT, FLANGE, 6X25	1			7010009~ XCRU
F-3-20	38	HZVL-90109-000	BOLT, FLANGE, 6X25		1		6010062~ XRD, XRU
F-3-20	38	HZVL-90109-000	BOLT, FLANGE, 6X25		1		7010011~ XCRU
F-3-20	38	HZVL-90109-000	BOLT, FLANGE, 6X25			1	6010100~ XRD, XRU
F-3-20	38	HZVL-90109-000	BOLT, FLANGE, 6X25			1	7010031~ XCRU
F-3-20	39	HZVL-90103-000	BOLT-WASHER, 12X50	11	11	11	
F-3-20	40	HZY3-90105-010	BOLT, HEX., 14X180	2	2	2	
F-3-20	41	HZVL-90107-000	BOLT-WASHER, 8X35	6	6	6	
F-3-20	42	HZVL-90109-000	BOLT, FLANGE, 6X25	2	2	2	
F-3-20	43	H921-90302-000	NUT, HEX., 16MM	1	1	1	
F-3-20	44	HZY3-90302-000	NUT, SELF-LOCK, 14MM	2	2	2	
F-3-20	45	HZY3-90503-610	WASHER, 30MM	1	1	1	XCRU, XRD, XRU
F-3-20	46	HZY3-90511-000	WASHER, PLAIN, 14MM	2	2	2	
F-3-20	47	HZV4-90605-000	CLIP, TUBE (B12.5)	1			~6010066 LRU, XRD, XRU
F-3-20	47	HZV4-90605-000	CLIP, TUBE (B12.5)	1			~7010008 XCRU
F-3-20	47	HZV4-90605-000	CLIP, TUBE (B12.5)		1		~6010061 XRD, XRU
F-3-20	47	HZV4-90605-000	CLIP, TUBE (B12.5)		1		~7010010 XCRU
F-3-20	47	HZV4-90605-000	CLIP, TUBE (B12.5)			1	~6010109 XRD, XRU
F-3-20	47	HZV4-90605-000	CLIP, TUBE (B12.5)			1	~7010035 XCRU
F-3-20	47	HZY6-90651-000	CLIP B1, TUBE	1			6010067~ LRU, XRD, XRU
F-3-20	47	HZY6-90651-000	CLIP B1, TUBE	1			7010009~ XCRU

F-3-20 EXTENSION CASE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-3-20	47	HZY6-90651-000	CLIP B1, TUBE		1		6010062~ XRD, XRU
F-3-20	47	HZY6-90651-000	CLIP B1, TUBE		1		7010011~ XCRU
F-3-20	47	HZY6-90651-000	CLIP B1, TUBE			1	6010110~ XRD, XRU
F-3-20	47	HZY6-90651-000	CLIP B1, TUBE			1	7010036~ XCRU
F-3-20	48	HZY3-90652-000	CIRCLIP, INTERNAL, 43	1	1	1	XCRU, XRD, XRU
F-3-20	49	HZVL-90751-000	PIN, SPRING, 6X22	3	3	3	
F-3-20	50	HZVL-90752-000	PIN, LOCK SPRING	3	3	3	
F-3-20	51	HZV5-90756-000	DOWEL PIN, 6X10	2	2	2	
F-3-20	52	HZVL-91451-000	TUBE, WATER JOINT	1			~6010066 LRU, XRD, XRU
F-3-20	52	HZVL-91451-000	TUBE, WATER JOINT	1			~7010008 XCRU
F-3-20	52	HZVL-91451-000	TUBE, WATER JOINT		1		~6010061 XRD, XRU
F-3-20	52	HZVL-91451-000	TUBE, WATER JOINT		1		~7010010 XCRU
F-3-20	52	HZVL-91451-000	TUBE, WATER JOINT			1	~6010109 XRD, XRU
F-3-20	52	HZVL-91451-000	TUBE, WATER JOINT			1	~7010035 XCRU
F-3-20	52	HZVL-91451-010	TUBE, WATER JOINT	1			6010067~ LRU, XRD, XRU
F-3-20	52	HZVL-91451-010	TUBE, WATER JOINT	1			7010009~ XCRU
F-3-20	52	HZVL-91451-010	TUBE, WATER JOINT		1		6010062~ XRD, XRU
F-3-20	52	HZVL-91451-010	TUBE, WATER JOINT		1		7010011~ XCRU
F-3-20	52	HZVL-91451-010	TUBE, WATER JOINT			1	6010110~ XRD, XRU
F-3-20	52	HZVL-91451-010	TUBE, WATER JOINT			1	7010036~ XCRU
F-3-20	53	HZY9-91504-M00	COLLAR, 8.5X14.5	6	6	6	
F-3-20	54	HZZ0-91601-M00	GROMMET, 1WAY	2	2	2	
F-3-20	55	HCO-95011-63000	RUBBER C, STAND STOPPER	2	2	2	

F-3-30 UNDER COVER




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-3-30	1	HZV5-40102-000	GROMMET, UNDER CASE	5	5	5	
F-3-30	2	H196-47117-000	RUBBER, STOPPER	2	2	2	
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	1		1	*T107*BAY BLUE XRD
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	1			*T107*BAY BLUE ~6011057 XRU
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	1			*T107*BAY BLUE ~7011009 XCRU
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)		1		*T107*BAY BLUE XCRU, XRD
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)		1		*T107*BAY BLUE ~6011050 XRU
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)			1	*T107*BAY BLUE ~6011155 XRU
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)			1	*T107*BAY BLUE ~7011052 XCRU
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	1			*T107*BAY BLUE 6011058~ XRU
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	1			*T107*BAY BLUE 7011010~ XCRU
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)		1		*T107*BAY BLUE 6011051~ XRU
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)			1	*T107*BAY BLUE 6011156~ XRU
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)			1	*T107*BAY BLUE 7011053~ XCRU
F-3-30	4	HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R.	1			*T107* LRU
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	1	1		*T107*BAY BLUE ~6011057 XRU
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	1		1	*T107*BAY BLUE XRD
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	1			*T107*BAY BLUE ~7011009 XCRU
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)		1		*T107*BAY BLUE XCRU, XRD
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)			1	*T107*BAY BLUE ~6011155 XRU
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)			1	*T107*BAY BLUE ~7011052 XCRU
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. (XL)	1	1		*T107*BAY BLUE 6011058~ XRU
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. (XL)	1			*T107*BAY BLUE 7011010~ XCRU
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. (XL)			1	*T107*BAY BLUE 6011156~ XRU
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. (XL)			1	*T107*BAY BLUE 7011053~ XCRU
F-3-30	6	HZVL-63715-900ZA	COVER COMP., ENGINE UNDER L.	1			*T107* LRU
F-3-30	7	HZVL-63721-000	COVER, RR.	1			LRU, XRD
F-3-30	7	HZVL-63730-000	COVER COMP., RR.	1		1	XCRU, XRU
F-3-30	7	HZVL-63721-000	COVER, RR.		1		XCRU, XRD

F-3-30 UNDER COVER




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-3-30	7	HZVL-63730-000	COVER COMP. , RR.		1		XRU
F-3-30	7	HZVL-63721-000	COVER, RR.			1	XRD
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25	5			~6010066 LRU, XRD, XRU
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25	5			~7010008 XCRU
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25		5		~6010061 XRD, XRU
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25		5		~7010010 XCRU
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25			5	~6010109 XRD, XRU
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25			5	~7010035 XCRU
F-3-30	9	HZY3-90111-000	BOLT, SPECIAL, 6X17	14	14	14	XCRU, XRD, XRU
F-3-30	9	HZY3-90111-000	BOLT, SPECIAL, 6X17	12			LRU
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM	5			~6010066 LRU, XRD, XRU
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM	5			~7010008 XCRU
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM		5		~6010061 XRD, XRU
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM		5		~7010010 XCRU
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM			5	~6010109 XRD, XRU
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM			5	~7010035 XCRU
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5	3			~6010089 LRU, XRD, XRU
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5	3			~7010008 XCRU
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5		3		~6010061 XRD, XRU
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5		3		~7010010 XCRU
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5			3	~6010109 XRD, XRU
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5			3	~7010035 XCRU
F-3-30	11	HZVL-91551-010	COLLAR, 12X6. 5	3			6010090~ LRU, XRD, XRU
F-3-30	11	HZVL-91551-010	COLLAR, 12X6. 5	3			7010009~ XCRU
F-3-30	11	HZVL-91551-010	COLLAR, 12X6. 5		3		6010062~ XRD, XRU
F-3-30	11	HZVL-91551-010	COLLAR, 12X6. 5		3		7010011~ XCRU
F-3-30	11	HZVL-91551-010	COLLAR, 12X6. 5			3	6010110~ XRD, XRU
F-3-30	11	HZVL-91551-010	COLLAR, 12X6. 5			3	7010036~ XCRU
F-3-30	12	HZVL-91551-000	COLLAR, 12X6. 5	2			~6010066 XRD, XRU

F-3-30 UNDER COVER




[illegible]

F-4 WATER PUMP/VERTICAL SHAFT




Ref. No.		Part No.	Description	Q' t y			Remarks
				BF12000	BF12250	BF12500	
F-4	1	HZY3-19210-003	IMPELLER, PUMP	1	1	1	
F-4	2	HZY3-19221-010	HOUSING, IMPELLER	1	1	1	
F-4	3	HZY3-19223-000	LINER, PUMP	1	1	1	
F-4	4	HZY3-19231-000	COVER, IMPELLER	1	1	1	
F-4	5	HZX2-19234-C00	GASKET B, IMPELLER	1	1	1	
F-4	6	HZVL-19241-000	HOUSING, WATER PUMP	1	1	1	
F-4	6	HZVL-19241-000	HOUSING, WATER PUMP	1			~7011008 XCRU
F-4	6	HZVL-19241-010	HOUSING, WATER PUMP	1			7011009~ XCRU
F-4	7	HZY3-19251-611	TUBE, WATER (XL)	1	1	1	XCRU, XRD, XRU
F-4	7	HZY3-19251-000	TUBE, WATER (L)	1			LRU
F-4	8	HZY3-19253-000	RING, WATER TUBE SEAL	1	1	1	
F-4	9	HZY3-24310-C00	ROD COMP., SHIFT	1	1	1	LRU, XRD, XRU
F-4	9	HZY3-24310-E00	ROD COMP., SHIFT	1	1	1	XCRU
F-4	10	HZY3-24318-000	SPRING, SHIFT ROD	1	1	1	
F-4	11	HZY6-24320-610	ROD COMP. A, SHIFT (XL)	1	1	1	XCRU, XRD, XRU
F-4	11	HZY6-24320-000	ROD COMP. A, SHIFT (L)	1			LRU
F-4	12	HZW1-24343-B02	HOLDER, SHIFT ROD	1	1	1	
F-4	13	HZY3-40204-000	GROMMET, EXTENSION CASE	1	1	1	
F-4	14	HZX2-41112-C10	SHAFT, VERTICAL (XL)	1	1	1	XCRU, XRD, XRU
F-4	14	HZX2-41112-C00	SHAFT, VERTICAL (L)	1			LRU
F-4	15	HZY3-41116-000	SLINGER, OIL	1	1	1	
F-4	17	HZX2-90105-C00	BOLT-WASHER, 8X60	4	4	4	
F-4	18	HHW1-90215-671	BOLT, FLANGE, 6X16	1	1	1	
F-4	19	HZX2-90301-C00	NUT, LOCK, 68MM	1	1	1	
F-4	20	HZX2-90303-C00	NUT, HEX., 18MM	1	1	1	
F-4	21	H723-90472-000	WASHER, PLAIN, 12MM	1	1	1	
F-4	22	HZX2-90518-C00	SHIM A, GEAR (0.10)	1	1	1	
F-4	22	HZX2-90519-C00	SHIM B, GEAR (0.15)	1	1	1	
F-4	22	HZX2-90520-C00	SHIM C, GEAR (0.30)	1	1	1	

F-4 WATER PUMP/VERTICAL SHAFT




Ref. No.		Part No.	Description	Q' t y			Remarks
				BF12000	BF12250	BF12500	
F-4	22	HZX2-90521-C00	SHIM D, GEAR(0.50)	1	1	1	
F-4	23	HZY3-90752-003	KEY, WOODRUFF	1	1	1	
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10	2			LRU, XRD
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10	2			XRU ~6011077
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10	2			XCRU ~7011015
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10		2		XCRU, XRD
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10		2		XRU ~6011059
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10			2	XRD
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10			2	XRU ~6011188
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10			2	XCRU ~7011063
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10	2			XRU 6011078~
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10	2			XCRU 7011016~
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10		2		XRU 6011060~
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10			2	XRU 6011189~
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10			2	XCRU 7011064~
F-4	25	HZX2-91053-C01	BEARING, NEEDLE, 30.5X47X37	1	1	1	
F-4	26	HZX2-91056-C01	BEARING, TAPER ROLLER,	1	1	1	
F-4	27	HZY3-91251-C01	SEAL, WATER, 26X42X7	2	2	2	
F-4	28	HZY3-91254-003	SEAL, WATER, 12X21X6	2	2	2	
F-4	29	HMJ0-91308-003	O-RING	1	1	1	
F-4	30	HZY3-91356-003	O-RING, WATER PUMP	1	1	1	
F-4	31	HZX2-91358-C00	O-RING, WATER PUMP HOUSING	1	1	1	
F-4	32	HZX2-91359-C00	O-RING, 65.4X2.4	1	1	1	
F-4	33	HZY3-91551-000	COLLAR, DISTANCE	4	4	4	
F-4	34	HCO-94520-47000	CIRCLIP, INTERNAL, 47MM	1	1	1	
F-4	35	HCO-94540-10019	E-RING, 10MM	1	1	1	

F-5 PROPELLER SHAFT




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-5	1	HZX2-24101-C00	SHIFTER, CLUTCH	1	1	1	LRU, XRD, XRU
F-5	2	HZY3-24102-000	PIN, SHIFTER, 8X50	1	1	1	LRU, XRD, XRU
F-5	3	HZY3-24103-000	RING, CROSS PIN	1	1	1	LRU, XRD, XRU
F-5	4	HZY3-24113-A01	SLIDER COMP., SHIFT	1	1	1	LRU, XRD, XRU
F-5	5	HZY3-24122-A01	SLIDER, SHIFT	1	1	1	LRU, XRD, XRU
F-5	6	HZY3-24123-000	SPRING, SHIFT	2	2	2	LRU, XRD, XRU
F-5	7	HZY3-24124-310	PLATE, SHIFT	1	1	1	LRU, XRD, XRU
F-5	8	HZX2-41140-C00	GEAR COMP., BEVEL (FORWARD)	1	1	1	LRU, XRD
F-5	9	HZX2-41151-C00	GEAR, BEVEL (REVERSE) (24T)	1	1	1	LRU, XRD, XRU
F-5	10	HZX2-41161-C00	SHAFT, PROPELLER	1	1	1	LRU, XRD, XRU
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	1	1	1	LRU, XRD
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	1			~6011009 XRU
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE		1		~6011020 XRU
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE			1	~6011033 XRU
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	1			6011010~ XRU
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE		1		6011021~ XRU
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE			1	6011034~ XRU
F-5	12	HZX2-41202-C00	HOLDER, BEARING	1	1	1	LRU, XRD, XRU
F-5	13	HZY3-90123-000	BOLT, HEX., 12X45	2	2	2	
F-5	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	1	LRU, XRD, XRU
F-5	15	HZX2-90506-C00	WASHER, PROPELLER THRUST	1	1	1	LRU, XRD, XRU
F-5	16	HZW5-90509-711	WASHER, THRUST BEARING	1	1	1	LRU, XRD, XRU
F-5	17	HZX2-90512-C00	WASHER, PROPELLER	1	1	1	LRU, XRD, XRU
F-5	18	HZX2-90528-C00	SHIM A, BEVEL (0.10)	2	2	2	LRU, XRD, XRU
F-5	18	HZX2-90529-C00	SHIM B, BEVEL (0.15)	2	2	2	LRU, XRD, XRU
F-5	18	HZX2-90530-C00	SHIM C, BEVEL (0.30)	2	2	2	LRU, XRD, XRU
F-5	18	HZX2-90531-C00	SHIM D, BEVEL (0.50)	2	2	2	LRU, XRD, XRU
F-5	19	HZY3-90548-000	SHIM A, THRUST (2.75)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90549-000	SHIM B, THRUST (2.80)	1	1	1	LRU, XRD, XRU

F-5 PROPELLER SHAFT




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-5	19	HZY3-90550-000	SHIM C, THRUST (2. 85)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90551-000	SHIM D, THRUST (2. 90)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90552-000	SHIM E, THRUST (2. 95)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90553-000	SHIM F, THRUST (3. 00)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90554-000	SHIM G, THRUST (3. 05)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90555-000	SHIM H, THRUST (3. 10)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90556-000	SHIM I, THRUST (2. 70)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90557-000	SHIM J, THRUST (2. 65)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90558-000	SHIM K, THRUST (2. 60)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90559-000	SHIM L, THRUST (2. 55)	1	1	1	LRU, XRD, XRU
F-5	19	HZY3-90560-000	SHIM M, THRUST (2. 50)	1	1	1	LRU, XRD, XRU
F-5	20	HZV5-90559-000	WASHER, PLAIN, 12MM	2	2	2	LRU, XRD, XRU
F-5	21	HZX2-90651-C00	RING, SETTING (39)	1	1	1	LRU, XRD
F-5	22	HZW1-90758-B00	PIN, SPLIT, 4. 0	1	1	1	LRU, XRD, XRU
F-5	23	HPT2-91005-N01	BEARING, THRUST (F)	1	1	1	LRU, XRD, XRU
F-5	24	HZX2-91051-C01	BEARING, TAPER ROLLER,	1	1	1	LRU, XRD, XRU
F-5	25	HZX2-91055-C01	BEARING, RADIAL BALL,	1	1	1	LRU, XRD, XRU
F-5	26	HZY3-91056-711	BEARING, NEEDLE, 28X39X30	1	1	1	LRU, XRD
F-5	27	HZY3-91057-003	BEARING, NEEDLE, 32X42X30	1	1	1	LRU, XRD, XRU
F-5	28	HZY3-91151-000	ROLLER, 3X13. 8	1	1	1	LRU, XRD, XRU
F-5	29	HZZ3-91252-003	SEAL, WATER, 30X45X7	2	2	2	LRU, XRD, XRU
F-5	30	HZX2-91351-C00	O-RING, 121X3. 1	1	1	1	LRU, XRD, XRU
F-5	31	HCO-94510-15000	CIRCLIP, EXTERNAL, 15MM	1	1	1	LRU, XRD, XRU
F-5	32	HCO-96211-07000	BALL, STEEL, #7 (7/32)	2	2	2	LRU, XRD, XRU
F-5	33	HCO-96211-12000	BALL, STEEL, #12 (3/8)	2	2	2	LRU, XRD, XRU
F-5	34	HZX2-06400-C00	GEAR KIT	1	1	1	XRU
F-5	35	HZX2-41131-C00	GEAR, PINION	1	1	1	LRU, XRD

F-5-1 PROPELLER SHAFT (COUNTER ROTATION)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-5-1	1	HZX2-24101-C00	SHIFTER, CLUTCH	1	1	1	XCRU
F-5-1	2	HZY3-24102-000	PIN, SHIFTER, 8X50	1	1	1	XCRU
F-5-1	3	HZY3-24103-000	RING, CROSS PIN	1	1	1	XCRU
F-5-1	4	HZY3-24113-A01	SLIDER COMP., SHIFT	1	1	1	XCRU
F-5-1	5	HZY3-24122-A01	SLIDER, SHIFT	1	1	1	XCRU
F-5-1	6	HZY3-24123-000	SPRING, SHIFT	2	2	2	XCRU
F-5-1	7	HZY3-24124-310	PLATE, SHIFT	1	1	1	XCRU
F-5-1	8	HZX2-41141-E00	GEAR, BEVEL (FORWARD) (24T)		1		XCRU
F-5-1	9	HZX2-41150-E00	GEAR COMP., BEVEL (REVERSE)	1	1	1	XCRU
F-5-1	10	HZX2-41161-E00	SHAFT, PROPELLER	1	1	1	XCRU
F-5-1	11	HZX2-41200-E00	HOLDER ASSY., BEARING	1	1	1	XCRU
F-5-1	12	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	1			~7011001 XCRU
F-5-1	12	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE		1		~7011002 XCRU
F-5-1	12	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE			1	~7011012 XCRU
F-5-1	12	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	1			7011002~ XCRU
F-5-1	12	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE		1		7011003~ XCRU
F-5-1	12	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE			1	7011013~ XCRU
F-5-1	13	HZY3-90123-000	BOLT, HEX., 12X45	2	2	2	XCRU
F-5-1	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	1	XCRU
F-5-1	15	HZX2-90506-C00	WASHER, PROPELLER THRUST	1	1	1	XCRU
F-5-1	16	HZW5-90509-711	WASHER, THRUST BEARING	1	1	1	XCRU
F-5-1	17	HZX2-90512-C00	WASHER, PROPELLER	1	1	1	XCRU
F-5-1	18	HZX2-90528-C00	SHIM A, BEVEL (0.10)	1	1	1	XCRU
F-5-1	18	HZX2-90529-C00	SHIM B, BEVEL (0.15)	1	1	1	XCRU
F-5-1	18	HZX2-90530-C00	SHIM C, BEVEL (0.30)	1	1	1	XCRU
F-5-1	18	HZX2-90531-C00	SHIM D, BEVEL (0.50)	1	1	1	XCRU
F-5-1	19	HZX2-90528-E00	SHIM A, BEVEL (0.10)	1	1	1	XCRU
F-5-1	19	HZX2-90529-E00	SHIM B, BEVEL (0.15)	1	1	1	XCRU
F-5-1	19	HZX2-90530-E00	SHIM C, BEVEL (0.30)	1	1	1	XCRU

F-5-1 PROPELLER SHAFT (COUNTER ROTATION)




F-6 FUEL TUBE




[illegible]

F-7 WIRE HARNESS




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-7	1	HZVJ-32100-900	HARNESS ASSY., MAIN WIRE	1			
F-7	1	HZVL-32100-900	HARNESS ASSY., MAIN WIRE		1	1	
F-7	2	HZVL-32106-000	BRACKET, JUNCTION CONNECTOR	1	1	1	
F-7	3	HZVL-32108-003	DUMMY, WATER PROOF CONNECTOR	1	1	1	
F-7	4	HZZ3-32127-000	SUSPENSION, COUPLER	1	1	1	
F-7	5	HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED)	1	1	1	
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1			~6010052 LRU, XRD, XRU
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1			~7010006 XCRU
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14	1			6010053~ LRU, XRD, XRU
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14	1			7010007~ XCRU
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14		1		~6010057 XRD, XRU
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14		1		~7010010 XCRU
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14		1		6010058~ XRD, XRU
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14		1		7010011~ XCRU
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14			1	~6010095 XRD, XRU
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14			1	~7010024 XCRU
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14			1	6010096~ XRD, XRU
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14			1	7010025~ XCRU
F-7	7	HZZ5-90105-M00	BOLT, FLANGE, 6X12	2	2	2	
F-7	8	HZY3-90653-003	CLIP, WIRE HARNESS	3	3	3	
F-7	9	HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	12			
F-7	9	HS0A-91541-003	CLIP, HARNESS BAND (BLACK)		13	13	

F-7-10 STARTER CABLE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-7-10	1	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	3	3	3	
F-7-10	2	HZVL-32103-000	BRACKET, COUPLER C	2	2	2	
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER	1			XCRU ~7010002
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER	1			LRU, XRD, XRU #~6010028
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER	1			LRU, XRD, XRU #6010029~
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER		1		XRD, XRU #~6010018
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER		1		XCRU #~7010008
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER		1		XRD, XRU #6010019~
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER		1		XCRU #7010009~
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER	1			XCRU 7010003~
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER			1	XRD, XRU #~6010056
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER			1	XCRU #~7010005
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER			1	XRD, XRU #6010057~
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER			1	XCRU #7010006~
F-7-10	4	HZY3-32411-003	COVER, STARTER TERMINAL	1	1	1	
F-7-10	5	HZX2-32414-300	COVER B, TERMINAL (L)	2	2	2	
F-7-10	6	HZY6-32414-640	COVER B, TERMINAL	1	1	1	
F-7-10	7	HZX2-32415-000	CABLE ASSY., POWER TILT RELAY	1	1	1	
F-7-10	8	HZVL-32421-000	PLATE, STARTER CABLE	1	1	1	
F-7-10	9	HZX2-32435-000	CORD, A. C. GENERATOR	1	1	1	
F-7-10	10	HZVL-38550-003	RELAY ASSY., POWER TILT	1	1	1	
F-7-10	11	HZW1-38551-000	GROMMET, RELAY	2	2	2	
F-7-10	12	HZX2-38552-000	CASE, POWER TILT RELAY	1	1	1	
F-7-10	13	HZZ5-90013-M01	BOLT-WASHER, 6X25	2	2	2	
F-7-10	14	HZVL-90015-010	BOLT-WASHER, 6X27	3	3	3	
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10	2			~6010052 LRU, XRD, XRU
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10	2			~7010006 XCRU
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10		2		~6010057 XRD, XRU
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10		2		~7010010 XCRU

F-7-10 STARTER CABLE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10			2	~6010095 XRD, XRU
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10			2	~7010024 XCRU
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10	2			6010053~ LRU, XRD, XRU
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10	2			7010007~ XCRU
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10		2		6010058~ XRD, XRU
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10		2		7010011~ XCRU
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10			2	6010096~ XRD, XRU
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10			2	7010025~ XCRU
F-7-10	16	HZZ5-90105-M00	BOLT, FLANGE, 6X12	4	4	4	
F-7-10	17	HZY3-90107-000	BOLT, FLANGE, 8X18	1	1	1	
F-7-10	18	HZW1-90203-000	NUT-WASHER, 8MM	2	2	2	
F-7-10	19	HZY3-90304-000	NUT-WASHER, 6MM	1	1	1	
F-7-10	20	HZY3-90405-000	WASHER, PLAIN, 8MM	1	1	1	
F-7-10	21	HKV6-90651-003	BAND, WIRE, 165MM (BLACK)	1	1	1	
F-7-10	22	H763-90681-A01	CLIP, WIRE HARNESS	1	1	1	
F-7-10	23	HZX2-90683-003	CLIP, WIRE HARNESS	2	2	2	
F-7-10	24	HZZ5-91501-010	COLLAR, MOUNTING (6MM)	2	2	2	
F-7-10	25	HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	3			~6010052 LRU, XRD, XRU
F-7-10	25	HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	3			~7010006 XCRU
F-7-10	25	HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE		3		~6010057 XRD, XRU
F-7-10	25	HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE		3		~7010010 XCRU
F-7-10	25	HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE			3	~6010095 XRD, XRU
F-7-10	25	HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE			3	~7010024 XCRU
F-7-10	25	HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE	3			6010053~ LRU, XRD, XRU
F-7-10	25	HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE	3			7010007~ XCRU
F-7-10	25	HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE		3		6010058~ XRD, XRU
F-7-10	25	HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE		3		7010011~ XCRU
F-7-10	25	HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE			3	6010096~ XRD, XRU
F-7-10	25	HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE			3	7010025~ XCRU

F-7-10 STARTER CABLE




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-7-10	26	HSOA-91541-003	CL IP, HARNESS BAND (BLACK)	3	3	3	
F-7-10	27	HZVL-31575-000	HARNESS ASSY. , POWER	1			6010029~ LRU, XRD
F-7-10	27	HZVL-31575-010	HARNESS ASSY. , POWER	1			6010029~ XRU
F-7-10	27	HZVL-31575-010	HARNESS ASSY. , POWER	1			7010003~ XCRU
F-7-10	27	HZVL-31575-000	HARNESS ASSY. , POWER		1		6010019~ XRD
F-7-10	27	HZVL-31575-010	HARNESS ASSY. , POWER		1		6010019~ XRU
F-7-10	27	HZVL-31575-000	HARNESS ASSY. , POWER		1		7010009~ XCRU
F-7-10	27	HZVL-31575-000	HARNESS ASSY. , POWER			1	6010057~ XRD
F-7-10	27	HZVL-31575-010	HARNESS ASSY. , POWER			1	6010057~ XRU
F-7-10	27	HZVL-31575-010	HARNESS ASSY. , POWER			1	7010006~ XCRU
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)	2			LRU, XRD, XRU #6010029~
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)		2		XRD, XRU #6010019~
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)		2		XCRU #7010009~
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)	2			XCRU 7010003~
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)			2	XRD, XRU #6010057~
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)			2	XCRU #7010006~
F-7-10	29	HZZ3-38216-003	COVER ASSY. , FUSE (40A)	1			LRU, XRD, XRU #6010029~
F-7-10	29	HZZ3-38216-003	COVER ASSY. , FUSE (40A)		1		XRD, XRU #6010019~
F-7-10	29	HZZ3-38216-003	COVER ASSY. , FUSE (40A)		1		XCRU #7010009~
F-7-10	29	HZZ3-38216-003	COVER ASSY. , FUSE (40A)	1			XCRU 7010003~
F-7-10	29	HZZ3-38216-003	COVER ASSY. , FUSE (40A)			1	XRD, XRU #6010057~
F-7-10	29	HZZ3-38216-003	COVER ASSY. , FUSE (40A)			1	XCRU #7010006~
F-7-10	30	HZW9-90102-M00	BOLT, FLANGE, 6X12	1	1	1	

F-7-20 FUSE BOX/RELAY



[illegible]

F-8 ENGINE COVER




FR.



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-10	1	HZW1-06411-020	METAL KIT, ANODE	1			LRU
F-10	2	HZY3-06532-U00	ROD KIT, STEERING	1	1	1	
F-10	3	H747-16731-003	CLIP, TUBE	1	1	1	
F-10	4	HZV1-24210-010	SPRING COMP., CLICK	1	1	1	
F-10	5	HZV4-24221-010	SPRING, CLICK ASSIST	1	1	1	
F-10	6	HKM3-32161-003	BAND, WIRE	2	2	2	
F-10	7	HZY3-35660-003	SENSOR ASSY., TRIM ANGLE	1	1	1	
F-10	8	HZZ3-35745-743	SWITCH ASSY., TILT LIMIT	1	1	1	
F-10	9	HZY3-40219-023	WIRE, LEAD (1.5X116MM)	1	1	1	
F-10	10	HZV5-41171-000	END, NIPPLE	1	1	1	
F-10	11	HZV5-41172-000	NIPPLE, SENSOR	1	1	1	
F-10	12	HZV5-41172-000	NIPPLE, SENSOR	1	1	1	
F-10	13	HZVL-50100-000	FRAME COMP., MOUNTING (XL)	1			XCRU
F-10	13	HZVL-50100-000	FRAME COMP., MOUNTING (XL)	1			~6010102 XRD, XRU
F-10	13	HZVL-50100-900	FRAME COMP., MOUNTING (L)	1			~6010116 LRU
F-10	13	HZVL-50100-010	FRAME COMP., MOUNTING (XL)	1			6010103~ XRD, XRU
F-10	13	HZVL-50100-901	FRAME COMP., MOUNTING (L)	1			6010117~ LRU
F-10	13	HZVL-50100-000	FRAME COMP., MOUNTING (XL)		1		~6010073 XRD, XRU
F-10	13	HZVL-50100-000	FRAME COMP., MOUNTING (XL)		1		~7010010 XCRU
F-10	13	HZVL-50100-010	FRAME COMP., MOUNTING (XL)		1		6010074~ XRD, XRU
F-10	13	HZVL-50100-010	FRAME COMP., MOUNTING (XL)		1		7010011~ XCRU
F-10	13	HZVL-50100-000	FRAME COMP., MOUNTING (XL)			1	~6010157 XRD, XRU
F-10	13	HZVL-50100-000	FRAME COMP., MOUNTING (XL)			1	~7010039 XCRU
F-10	13	HZVL-50100-010	FRAME COMP., MOUNTING (XL)			1	6010158~ XRD, XRU
F-10	13	HZVL-50100-010	FRAME COMP., MOUNTING (XL)			1	7010040~ XCRU
F-10	14	HZVL-50109-000	HOUSING, UPPER MOUNTING	1	1	1	
F-10	15	HZY3-50151-000	MOUNT COMP., UPPER RUBBER	2	2	2	
F-10	16	HZY3-50153-000	RUBBER, UPPER MOUNT STOPPER	2	2	2	
F-10	17	HZY3-50161-610	HOUSING, LOWER CENTER MOUNTING	1	1	1	XCRU, XRD, XRU

F-10 STERN BRACKET/SWIVEL CASE


FR. →



Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-10	17	HZY3-50161-000ZD	HOUSING, LOWER CENTER MOUNTING	1			*T107* LRU
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT	1			LRU, XRD
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT	1			XRU ~6011067
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT	1			XCRU ~7011011
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT		1		XCRU, XRD
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT		1		XRU ~6011057
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT			1	XRD
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT			1	XRU ~6011160
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT			1	XCRU ~7011052
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT	1			XRU 6011068~
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT	1			XCRU 7011012~
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT		1		XRU 6011058~
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT			1	XRU 6011161~
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT			1	XCRU 7011053~
F-10	19	HZVL-50201-000ZA	CASE, SWIVEL (XL)	1	1	1	*T107* XCRU, XRD, XRU
F-10	19	HZVL-50201-900ZA	CASE, SWIVEL (L)	1			*T107*LRU
F-10	20	HZY3-50211-000	LINER, SWIVEL CASE	2	2	2	
F-10	21	HZY3-50214-000	BUSH, SWIVEL CASE	2	2	2	
F-10	22	HZVL-50222-000	BRACKET, TILT LIMIT SWITCH	1	1	1	
F-10	23	HZZ3-50223-000	CAM A, TILT LIMIT ANGLE	1	1	1	
F-10	24	HZZ3-50224-000	CAM B, TILT LIMIT ANGLE	1	1	1	
F-10	25	HZY3-50301-030ZC	BRACKET, R. STERN	1	1	1	*T107*
F-10	26	HZVL-50311-000ZA	BRACKET, L. STERN	1	1	1	*T107*
F-10	27	HZVL-50381-000	SHAFT, TILTING	1			~6010066 LRU, XRD, XRU
F-10	27	HZVL-50381-000	SHAFT, TILTING	1			~7010008 XCRU
F-10	27	HZVL-50381-000	SHAFT, TILTING		1		~6010061 XRD, XRU
F-10	27	HZVL-50381-000	SHAFT, TILTING			1	~6010109 XRD, XRU
F-10	27	HZVL-50381-000	SHAFT, TILTING			1	~7010035 XCRU
F-10	27	HZVL-50381-010	SHAFT, TILTING	1			6010067~ LRU, XRD, XRU

F-10 STERN BRACKET/SWIVEL CASE


FR. →



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-10	27	HZVL-50381-010	SHAFT, TILTING	1			7010009~ XCRU
F-10	27	HZVL-50381-010	SHAFT, TILTING		1		6010062~ XRD, XRU
F-10	27	HZVL-50381-010	SHAFT, TILTING			1	6010110~ XRD, XRU
F-10	27	HZVL-50381-010	SHAFT, TILTING			1	7010036~ XCRU
F-10	28	HZY3-50522-000	BUSH, TILT ARM	2	2	2	
F-10	29	HZY3-50527-000	BRACKET, TILTING	1	1	1	
F-10	30	HZVL-50529-000	STOPPER, TILT	2	2	2	
F-10	31	HZY3-56516-A00	RECEIVER, THRUST	2	2	2	
F-10	32	HZY3-56518-A00	BUSH A, THRUST RECEIVE	2	2	2	
F-10	33	HZY3-56519-A00	BUSH B, THRUST RECEIVE	2	2	2	
F-10	34	HZVL-56539-000	SHAFT, LOWER CYLINDER	1	1	1	
F-10	35	HZW9-90005-030	BOLT, FLANGE, 6X20	7	7	7	
F-10	36	HZW9-90009-000	BOLT, FLANGE, 6X23	2			LRU
F-10	37	HZW1-90102-000	BOLT, 1/4-28UNF	2	2	2	
F-10	38	HZW9-90102-000	BOLT, FLANGE, 6X12	1	1	1	
F-10	39	HZW9-90103-010	BOLT, FLANGE, 6X12	1	1	1	
F-10	40	HZY6-90103-000	BOLT-WASHER, 10X32	3	3	3	
F-10	41	HZY3-90104-010	BOLT, HEX., 12X200	2	2	2	
F-10	42	HZVL-90105-000	BOLT, STUD, 10X28	1	1	1	
F-10	43	HZW9-90105-000	BOLT, FLANGE, 6X20	2	2	2	
F-10	44	HZY3-90106-A00	BOLT, FLANGE, 8X22	1	1	1	
F-10	45	H881-90110-000	BOLT, HEX., 6X14	1	1	1	
F-10	46	HZY3-90117-000	BOLT, 3/8-24UNF	1	1	1	
F-10	47	HZV5-90119-000	SCREW, PAN, 6X8	1	1	1	
F-10	48	HZVL-90129-000	BOLT, HEX., 12X150	6	6	6	
F-10	48	HZX2-90129-000	BOLT, HEX., 12X130	6	6	6	
F-10	49	HZY1-90205-000	NUT, SELF-LOCK, 6MM	2	2	2	
F-10	50	HZW5-90302-003	NUT, FLANGE, 12MM	2	2	2	
F-10	51	HZV5-90304-013	NUT, SELF-LOCK (7/8-14UNF)	1	1	1	

F-10 STERN BRACKET/SWIVEL CASE


FR. →



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-10	52	HZW4-90306-003	NUT, FLANGE, 10MM	1	1	1	
F-10	53	HZV5-90307-003	NUT, SELF-LOCK (3/8-24UNF)	2	2	2	
F-10	54	HZW4-90401-000	WASHER, PLAIN, 4MM	1	1	1	
F-10	55	HZV5-90501-000	WASHER, WAVE, 40MM	1	1	1	
F-10	56	HZY3-90501-A00	WASHER, WAVE, 12MM	2	2	2	
F-10	57	HZV5-90502-000	WASHER, WAVE, 26MM	2	2	2	
F-10	58	HZV5-90504-000	WASHER, THRUST, 34MM	1	1	1	
F-10	59	HZX2-90504-C00	WASHER, UPPER MOUNTING STOPPER	2	2	2	
F-10	60	HZY3-90509-000	WASHER, 7/8"	1	1	1	
F-10	61	H921-90511-000	WASHER, PLAIN, 10MM	1	1	1	
F-10	62	HZV4-90512-000	WASHER, PLAIN, 6MM	2	2	2	
F-10	63	HZV4-90514-000	WASHER, 10MM	3	3	3	
F-10	64	HZV5-90552-000	WASHER, PLAIN, 12MM	6	6	6	
F-10	65	HZV5-90559-000	WASHER, PLAIN, 12MM	14	14	14	
F-10	66	HZV5-90651-000	CIRCLIP, EXTERNAL, 39MM	1	1	1	
F-10	67	H763-90681-A01	CLIP, WIRE HARNESS	1	1	1	
F-10	68	HZV7-90951-010	NIPPLE, GREASE	6	6	6	
F-10	69	HZV5-91256-003	OIL SEAL, 39.5X52X6 (ARA1)	1	1	1	
F-10	70	HZY3-91560-000	COLLAR, STEERING ROD	1	1	1	
F-10	71	HCO-93500-04014-4J	SCREW, PAN, 4X14	1	1	1	
F-10	72	HCO-93500-05020-4J	SCREW, PAN, 5X20	2	2	2	
F-10	73	HCO-94001-05490-0S	NUT, HEX. , 5MM	2	2	2	
F-10	74	HCO-94001-12490-0S	NUT, HEX. , 12MM	12	12	12	
F-10	75	HCO-94002-04490-0S	NUT, HEX. , 4MM	1	1	1	
F-10	76	HCO-94305-30203	PIN, SPRING, 3X20	2	2	2	
F-10	77	HCO-95005-50045-30	TUBE, 5X45 (95005-50001-30M)	1	1	1	
F-10	78	HCO-95005-50250-30	TUBE, 5X250 (95005-50001-30M)	1			LRU
F-10	79	HCO-95005-50340-30	TUBE, 5X340 (95005-50001-30M)	1	1	1	XCRU, XRD, XRU
F-10	80	HMG9-35701-950	BAND (BLACK 3.5X140)	1	1	1	

F-10 STERN BRACKET/SWIVEL CASE

FR. →



FR.



Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
F-11	1	HZX2-30280-003	BREAKER ASSY.	1			~6011044 XRU
F-11	1	HZX2-30280-003	BREAKER ASSY.	1			~7011008 XCRU
F-11	1	HZX2-30280-003	BREAKER ASSY.		1		~6011043 XRU
F-11	1	HZX2-30280-003	BREAKER ASSY.			1	~6011114 XRU
F-11	1	HZX2-30280-003	BREAKER ASSY.			1	~7011043 XCRU
F-11	1	HZX2-30280-013	BREAKER ASSY.	1			6011045~ XRU
F-11	1	HZX2-30280-013	BREAKER ASSY.	1			7011009~ XCRU
F-11	1	HZX2-30280-013	BREAKER ASSY.		1		6011044~ XRU
F-11	1	HZX2-30280-013	BREAKER ASSY.			1	6011115~ XRU
F-11	1	HZX2-30280-013	BREAKER ASSY.			1	7011044~ XCRU
F-11	2	HZX2-31106-003	BRUSH ASSY.	1			~6011044 XRU
F-11	2	HZX2-31106-003	BRUSH ASSY.	1			~7011008 XCRU
F-11	2	HZX2-31106-003	BRUSH ASSY.		1		~6011043 XRU
F-11	2	HZX2-31106-003	BRUSH ASSY.			1	~6011114 XRU
F-11	2	HZX2-31106-003	BRUSH ASSY.			1	~7011043 XCRU
F-11	2	HZX2-31106-013	BRUSH ASSY.	1			6011045~ XRU
F-11	2	HZX2-31106-013	BRUSH ASSY.	1			7011009~ XCRU
F-11	2	HZX2-31106-013	BRUSH ASSY.		1		6011044~ XRU
F-11	2	HZX2-31106-013	BRUSH ASSY.			1	6011115~ XRU
F-11	2	HZX2-31106-013	BRUSH ASSY.			1	7011044~ XCRU
F-11	3	HMG9-35701-950	BAND (BLACK 3.5X140)	1	1	1	
F-11	4	HZVL-36104-000	TUBE, SPIRAL (12X14.6)	1	1	1	
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT	1			~6011044 XRU
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT	1			~7011008 XCRU
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT		1		~6011043 XRU
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT			1	~6011114 XRU
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT			1	~7011043 XCRU
F-11	5	HZX2-36120-023	MOTOR ASSY., POWER TILT	1			6011045~ XRU
F-11	5	HZX2-36120-023	MOTOR ASSY., POWER TILT	1			7011009~ XCRU

FR. →



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-11	5	HZX2-36120-023	MOTOR ASSY. , POWER TILT		1		6011044~ XRU
F-11	5	HZX2-36120-023	MOTOR ASSY. , POWER TILT			1	6011115~ XRU
F-11	5	HZX2-36120-023	MOTOR ASSY. , POWER TILT			1	7011044~ XCRU
F-11	6	HZX2-36122-003	BRACKET ASSY.	1			~6010052 LRU, XRD, XRU
F-11	6	HZX2-36122-003	BRACKET ASSY.	1			~7010006 XCRU
F-11	6	HZX2-36122-003	BRACKET ASSY.		1		~6010057 XRD, XRU
F-11	6	HZX2-36122-003	BRACKET ASSY.		1		~7010010 XCRU
F-11	6	HZX2-36122-003	BRACKET ASSY.			1	~6010095 XRD, XRU
F-11	6	HZX2-36122-003	BRACKET ASSY.			1	~7010024 XCRU
F-11	6	HZX2-36122-013	BRACKET ASSY.	1			6010053~6011044 XRU
F-11	6	HZX2-36122-013	BRACKET ASSY.	1			7010007~7011008 XCRU
F-11	6	HZX2-36122-013	BRACKET ASSY.		1		6010058~6011043 XRU
F-11	6	HZX2-36122-013	BRACKET ASSY.		1		7010011~ XCRU
F-11	6	HZX2-36122-013	BRACKET ASSY.			1	6010096~6011114 XRU
F-11	6	HZX2-36122-013	BRACKET ASSY.			1	7010025~7011043 XCRU
F-11	6	HZX2-36122-023	BRACKET ASSY.	1			6011045~ XRU
F-11	6	HZX2-36122-023	BRACKET ASSY.	1			7011009~ XCRU
F-11	6	HZX2-36122-023	BRACKET ASSY.		1		6011044~ XRU
F-11	6	HZX2-36122-023	BRACKET ASSY.			1	6011115~ XRU
F-11	6	HZX2-36122-023	BRACKET ASSY.			1	7011044~ XCRU
F-11	7	HZY3-36123-013	ARMATURE COMP.	1	1	1	
F-11	8	HZX2-36129-003	YOKE ASSY.	1	1	1	
F-11	9	HZV5-36136-821	SPRING, MOTOR	2	2	2	
F-11	10	HZW1-40107-700	GROMMET, UNDER CASE (C)	1	1	1	
F-11	11	HZY3-40219-023	WIRE, LEAD (1.5X116MM)	1	1	1	
F-11	12	HZV5-50214-003	BUSH, SWIVEL CASE	2	2	2	
F-11	13	HZX2-56000-043	TRIM-TILT ASSY. , POWER	1			~6010052 LRU, XRD, XRU
F-11	13	HZX2-56000-043	TRIM-TILT ASSY. , POWER	1			~7010006 XCRU
F-11	13	HZX2-56000-043	TRIM-TILT ASSY. , POWER		1		~6010057 XRD, XRU


FR. →



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER		1		~7010010 XCRU
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER			1	~6010095 XRD, XRU
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER			1	~7010024 XCRU
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER	1			6010053~6010057 LRU, XRD, XRU
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER	1			7010007~7010008 XCRU
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER		1		6010058~6010061 XRD, XRU
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER			1	6010096~6010099 XRD, XRU
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER			1	7010025~7010030 XCRU
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER	1			6010058~ LRU, XRD
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER	1			6010058~6011044 XRU
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER	1			7010009~7011008 XCRU
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER		1		6010062~ XRD
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER		1		6010062~6011043 XRU
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER		1		7010011~ XCRU
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER			1	6010100~ XRD
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER			1	6010100~6011114 XRU
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER			1	7010031~7011043 XCRU
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER	1			6011045~ XRU
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER	1			7011009~ XCRU
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER		1		6011044~ XRU
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER			1	6011115~ XRU
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER			1	7011044~ XCRU
F-11	14	HZY3-56100-013	PUMP ASSY.	1			~6010052 LRU, XRD, XRU
F-11	14	HZY3-56100-013	PUMP ASSY.	1			~7010006 XCRU
F-11	14	HZY3-56100-013	PUMP ASSY.		1		~6010057 XRD, XRU
F-11	14	HZY3-56100-013	PUMP ASSY.		1		~7010010 XCRU
F-11	14	HZY3-56100-013	PUMP ASSY.			1	~6010095 XRD, XRU
F-11	14	HZY3-56100-013	PUMP ASSY.			1	~7010024 XCRU
F-11	14	HZY3-56100-023	PUMP ASSY.	1			6010053~ LRU, XRD, XRU

F-11 POWER TRIM-TILT


FR. 



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-11	14	HZY3-56100-023	PUMP ASSY.	1			7010007~ XCRU
F-11	14	HZY3-56100-023	PUMP ASSY.		1		6010058~ XRD, XRU
F-11	14	HZY3-56100-023	PUMP ASSY.		1		7010011~ XCRU
F-11	14	HZY3-56100-023	PUMP ASSY.			1	6010096~ XRD, XRU
F-11	14	HZY3-56100-023	PUMP ASSY.			1	7010025~ XCRU
F-11	15	HZW1-56110-701	ROD COMP., PISTON(B)	2	2	2	
F-11	16	HZW1-56113-701	JOINT, DRIVE	1	1	1	
F-11	17	HZY9-56115-023	GUIDE COMP., ROD	2	2	2	
F-11	18	HZW1-56116-701	FILTER B	1	1	1	
F-11	19	HZV5-56117-821	RING, BACK UP	1	1	1	
F-11	20	HZV5-56118-820	BUSH, MOTOR CODE	1	1	1	
F-11	21	HZY3-56120-023	ROD COMP., PISTON	1	1	1	
F-11	22	HZW1-56130-702	PISTON COMP., FREE	1	1	1	
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL	1			~6010052 LRU, XRD, XRU
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL	1			~7010006 XCRU
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL		1		~6010057 XRD, XRU
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL		1		~7010010 XCRU
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL			1	~6010095 XRD, XRU
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL			1	~7010024 XCRU
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL	1			6010053~ LRU, XRD, XRU
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL	1			7010007~ XCRU
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL		1		6010058~ XRD, XRU
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL		1		7010011~ XCRU
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL			1	6010096~ XRD, XRU
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL			1	7010025~ XCRU
F-11	24	HZW1-56180-701	VALVE COMP., RESERVOIR	1	1	1	
F-11	25	HZV5-56513-000	BUSH, LOWER CYLINDER	2	2	2	
F-11	26	HZX2-56532-C00	PIN, UPPER CYLINDER	1	1	1	
F-11	27	HZW1-56851-703	TANK, OIL	1	1	1	

F-11 POWER TRIM-TILT

FR. 





Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
F-11	28	HZW1-56860-701	CAP COMP., OIL TANK	1	1	1	
F-11	29	HZW1-90113-702	BOLT, RECESSED	3	3	3	
F-11	30	HZW1-90114-702	BOLT, SOCKET (A)	1	1	1	
F-11	31	HZW1-90115-702	BOLT, SOCKET (B)	2	2	2	
F-11	32	HZW1-90116-702	BOLT, HEX.	4	4	4	
F-11	33	HZV5-90119-000	SCREW, PAN, 6X8	1	1	1	
F-11	34	HZW1-90652-702	CIRCLIP, INTERNAL	1	1	1	
F-11	35	HZV5-91203-821	OIL SEAL	1	1	1	
F-11	36	HZW1-91207-013	O-RING, 2.0X70.5	1	1	1	
F-11	37	HZV5-91302-821	O-RING, 1.8X69.6	1	1	1	
F-11	38	HZV5-91316-821	O-RING, 3.5X38.7	2	2	2	
F-11	39	HZX2-91352-003	O-RING, 1.68X7.25	6	6	6	
F-11	40	HZW1-91353-703	O-RING, 1.9X11	1	1	1	
F-11	41	HZW1-91354-701	O-RING, 3.5X35.7	2	2	2	
F-11	42	HZW1-91355-701	O-RING, 3.5X41.7	1	1	1	
F-11	43	HZW1-91357-701	O-RING SET, 3.5X31.7	2	2	2	
F-11	44	HZX2-91358-003	SEAL, WATER	2	2	2	
F-11	45	HZW1-91361-701	PACKING	2	2	2	
F-11	46	HZW1-91557-701	COLLAR, ORIFICE	1			~6010057 LRU, XRD, XRU
F-11	46	HZW1-91557-701	COLLAR, ORIFICE	1			~7010008 XCRU
F-11	46	HZW1-91557-701	COLLAR, ORIFICE		1		~6010061 XRD, XRU
F-11	46	HZW1-91557-701	COLLAR, ORIFICE		1		~7010010 XCRU
F-11	46	HZW1-91557-701	COLLAR, ORIFICE			1	~6010099 XRD, XRU
F-11	46	HZW1-91557-701	COLLAR, ORIFICE			1	~7010030 XCRU
F-11	46	HZX2-91557-003	COLLAR, ORIFICE	1			6010058~ LRU, XRD, XRU
F-11	46	HZX2-91557-003	COLLAR, ORIFICE	1			7010009~ XCRU
F-11	46	HZX2-91557-003	COLLAR, ORIFICE		1		6010062~ XRD, XRU
F-11	46	HZX2-91557-003	COLLAR, ORIFICE		1		7010011~ XCRU
F-11	46	HZX2-91557-003	COLLAR, ORIFICE			1	6010100~ XRD, XRU

FR. →




[illegible]


F-12 LABEL







F-13 TOOL



FOP-1 RIGGING HOSE KIT




FOP-2 WATER PUMP IMPELLER SET



FR.


Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-2	1	HZX2-06192-C00	PUMP KIT, IMPELLER	1	1	1	LRU, XRD
FOP-2	2	HZX2-06193-C00	PUMP KIT, IMPELLER	1	1	1	LRU, XRD
FOP-2	3	HZY3-19210-003	IMPELLER, PUMP	1	1	1	
FOP-2	4	HZY3-19221-010	HOUSING, IMPELLER	1	1	1	
FOP-2	5	HZY3-19223-000	LINER, PUMP	1	1	1	
FOP-2	6	HZY3-19231-000	COVER, IMPELLER	1	1	1	
FOP-2	7	HZX2-19234-C00	GASKET B, IMPELLER	1	1	1	
FOP-2	8	HZY3-19253-000	RING, WATER TUBE SEAL	1	1	1	
FOP-2	9	HZX2-90105-C00	BOLT-WASHER, 8X60	4	4	4	
FOP-2	10	HZY3-90752-003	KEY, WOODRUFF	1	1	1	
FOP-2	11	HZY3-91356-003	O-RING, WATER PUMP	1	1	1	
FOP-2	12	HZX2-91358-C00	O-RING, WATER PUMP HOUSING	1	1	1	
FOP-2	13	HZX2-91359-C00	O-RING, 65.4X2.4	1	1	1	
FOP-2	14	HZY3-91551-000	COLLAR, DISTANCE	4	4	4	
FOP-2	15	HZX2-06192-C02	PUMP KIT, IMPELLER	1		1	XCRU, XRU
FOP-2	15	HZX2-06192-C01	PUMP KIT, IMPELLER		1		XCRU
FOP-2	15	HZX2-06192-C02	PUMP KIT, IMPELLER		1		XRU
FOP-2	16	HZX2-06193-C02	PUMP KIT, IMPELLER	1		1	XCRU, XRU
FOP-2	16	HZX2-06193-C01	PUMP KIT, IMPELLER		1		XCRU
FOP-2	16	HZX2-06193-C02	PUMP KIT, IMPELLER		1		XRU
FOP-2	17	HZVL-90756-000	DOWEL PIN, 6X10	2		2	XCRU, XRU
FOP-2	17	HZV5-90756-000	DOWEL PIN, 6X10		2		XCRU
FOP-2	17	HZVL-90756-000	DOWEL PIN, 6X10		2		XRU

FOP-3 REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT25D	BFT30D	
FOP-3	1	HZZ3-06240-R31	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE) (R.)	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	2	HZW5-24810-U01	HOUSING ASSY., L. INNER (TOP MOUNT)	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	3	HZW5-24811-U01	HANDLE, REMOTE CONTROL	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	4	HZW5-24812-U01	COVER, L. GRIP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	5	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	6	HZW5-24814-U01	CAP, GRIP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	7	HZW5-24815-U01	CAP, SWITCH	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	8	HZW5-24816-U01	BUTTON, THROTTLE	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	9	HZW5-24817-U01	PLATE, HANDLE	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	10	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	11	HZW5-24819-U01	BRACKET, REMOTE CONTROL HOUSING	2	2	2	LRU, XCRU, XRD, XRU
FOP-3	12	HZZ3-24820-R12	HOUSING COMP., REMOTE CONTROL BOX	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	13	HZW5-24825-U01	HOUSING, LEAD	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	14	HZW5-24826-U01	PLATE, DWELL	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	15	HZW5-24831-U01	TERMINAL, CABLE	2	2	2	LRU, XCRU, XRD, XRU
FOP-3	16	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	17	HZW5-24834-U01	PACKING, SINGLE	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	18	HZW7-32530-U00	SUB HARNESS ASSY., POWER TRIM-TILT (A)	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	19	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT (A)	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	20	HZZ3-87703-R82	MARK, REMOTE CONTROL (SINGLE)	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	21	HZW5-90101-U00	SCREW, PAN, 5X16	2	2	2	LRU, XCRU, XRD, XRU
FOP-3	22	HZW5-90102-U00	SCREW, PAN, 5X10	1	1	1	LRU, XCRU, XRD, XRU
FOP-3	23	HZW5-90103-U01	SCREW, PAN, 5X20	2	2	2	LRU, XCRU, XRD, XRU
FOP-3	24	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	LRU, XCRU, XRD, XRU
FOP-3	25	HZW5-90105-U01	SCREW, PAN, 4X10	2	2	2	LRU, XCRU, XRD, XRU
FOP-3	26	HZW5-90106-U00	SCREW, PAN, 6X18	2	2	2	LRU, XCRU, XRD, XRU
FOP-3	27	HZW5-90107-U00	SCREW, PAN, 5X40	4	4	4	LRU, XCRU, XRD, XRU
FOP-3	28	HZW5-90301-U00	NUT, HEX., 5MM	4	4	4	LRU, XCRU, XRD, XRU
FOP-3	29	HZW5-90501-U00	WASHER, LOCK, 5MM	4	4	4	LRU, XCRU, XRD, XRU

FOP-3 REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT)




FOP-3-1 REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)



Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT2000	BFT2500	BFT2500	
FOP-3-1	1	HZZ3-06240-R41	BOX KIT, REMOTE CONTROL	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	2	HZW7-24810-U01	HOUSING ASSY. , R. INNER	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	3	HZW7-24811-U01	HANDLE, REMOTE CONTROL	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	4	HZW7-24812-U01	COVER, GRIP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	5	HZW7-24813-U01	ARM, NEUTRAL LOCK	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	6	HZW7-24814-U01	COVER, LOCK ARM	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	7	HZW7-24815-U01	SPRING, NEUTRAL LOCK ARM	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	8	HZW5-24816-U01	BUTTON, THROTTLE	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	9	HZW7-24817-U01	SHAFT, THROTTLE BUTTON	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	10	HZW5-24826-U01	PLATE, DWELL	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	11	HZZ3-24830-R42	COVER ASSY.	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	12	HZW5-24831-U01	TERMINAL, CABLE	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-1	13	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	14	HZW7-24832-U01	HOLDER, NEUTRAL LOCK	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	15	HZW7-24833-U01	BASE	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	16	HZW7-32530-U20	SUB HARNESS ASSY. , POWER	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	17	HZW7-35370-U02	SWITCH ASSY. , POWER TRIM-TILT	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	18	HZZ3-87701-R41	MARK, HANDLE FLUSH MOUNT	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	19	HZW7-87703-U00	MARK, FLUSH MOUNT	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	20	HZW5-90101-U00	SCREW, PAN, 5X16	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	21	HZW7-90101-U01	SCREW, TRUSS, 4X12	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-1	22	HZW7-90102-U01	SCREW, PAN, 5X30	4	4	4	LRU, XCRU, XRD, XRU
FOP-3-1	23	HZW7-90103-U01	SCREW, PAN, 6X35	3	3	3	LRU, XCRU, XRD, XRU
FOP-3-1	24	HZW7-90104-U01	SCREW, TAPPING, 6X30	3	3	3	LRU, XCRU, XRD, XRU
FOP-3-1	25	HZW7-90301-U01	NUT, HEX. , 6MM	3	3	3	LRU, XCRU, XRD, XRU
FOP-3-1	26	HZW5-90501-U00	WASHER, LOCK, 5MM	4	4	4	LRU, XCRU, XRD, XRU
FOP-3-1	27	HZW7-90502-U00	WASHER, PLAIN, 6MM	3	3	3	LRU, XCRU, XRD, XRU
FOP-3-1	28	HCO-94540-06029	E-RING, 6MM	2	2	2	LRU, XCRU, XRD, XRU

FOP-3-2 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)


1



Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT25D	BFT300D	
FOP-3-2	1	HZZ3-06240-R61	BOX KIT, REMOTE CONTROL	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	2	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	3	HZW5-24810-U11	HOUSING ASSY., R. INNER	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	4	HZW5-24811-U01	HANDLE, REMOTE CONTROL	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	5	HZW5-24812-U01	COVER, L. GRIP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	6	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	7	HZW5-24813-U21	COVER, DUAL GRIP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	8	HZW5-24814-U01	CAP, GRIP	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	9	HZW5-24816-U01	BUTTON, THROTTLE	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	10	HZW5-24817-U01	PLATE, HANDLE	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	11	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	12	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	13	HZZ3-24820-R22	HOUSING COMP., REMOTE CONTROL	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	14	HZW5-24825-U01	HOUSING, LEAD	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	15	HZW5-24826-U01	PLATE, DWELL	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	16	HZW5-24831-U01	TERMINAL, CABLE	4	4	4	LRU, XCRU, XRD, XRU
FOP-3-2	17	HZW5-24832-U01	SPACER, CABLE CLAMP	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	18	HZW5-24834-U21	PACKING, DUAL	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	19	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	20	HZW7-32530-U10	SUB HARNESS ASSY., POWER	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	21	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	22	HZW5-35370-U12	SWITCH ASSY., POWER TRIM-TILT	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	23	HZZ3-87703-R02	MARK, REMOTE CONTROL (DUAL)	1	1	1	LRU, XCRU, XRD, XRU
FOP-3-2	24	HZW5-90101-U00	SCREW, PAN, 5X16	3	3	3	LRU, XCRU, XRD, XRU
FOP-3-2	25	HZW5-90102-U00	SCREW, PAN, 5X10	2	2	2	LRU, XCRU, XRD, XRU
FOP-3-2	26	HZW5-90103-U01	SCREW, PAN, 5X20	4	4	4	LRU, XCRU, XRD, XRU
FOP-3-2	27	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	LRU, XCRU, XRD, XRU
FOP-3-2	28	HZW5-90105-U01	SCREW, PAN, 4X10	4	4	4	LRU, XCRU, XRD, XRU
FOP-3-2	29	HZW5-90106-U00	SCREW, PAN, 6X18	4	4	4	LRU, XCRU, XRD, XRU


FOP-3-2 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)

1




[illegible]

FOP-3-3 REMOTE CONTROL (NHK MEC)



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-3-3	1	HZZ3-24800-P04	BOX ASSY. , REMOTE CONTROL	1	1	1	LRU, XCRU, XRU
FOP-3-3	1	HZZ3-24800-P14	BOX ASSY. , REMOTE CONTROL	1	1	1	XRD
FOP-3-3	2	HZZ5-24810-D01	PLATE ASSY.	1	1	1	
FOP-3-3	3	HZZ5-24811-D01	LEVER, HAND	1	1	1	
FOP-3-3	4	HZZ5-24812-D01	ARM, NEUTRAL LOCK	1	1	1	
FOP-3-3	5	HZZ5-24813-D01	GRIP	1	1	1	
FOP-3-3	6	HZZ5-24814-D01	COVER, LEVER	1	1	1	
FOP-3-3	7	HZZ5-24815-D01	ARM ASSY. , BRAKE	1	1	1	
FOP-3-3	8	HZZ5-24816-D01	SPRING (2)	1	1	1	
FOP-3-3	9	HZZ5-24817-D01	CLIP, DETENT	1	1	1	
FOP-3-3	10	HZZ5-24818-D01	SPACER (1)	1	1	1	(LOOSE PARTS)
FOP-3-3	11	HZZ5-24819-D01	BRACKET	1	1	1	
FOP-3-3	12	HZZ5-24821-D01	HOUSING, FR.	1	1	1	
FOP-3-3	13	HZZ5-24822-D01	HOUSING, RR.	1	1	1	
FOP-3-3	14	HZZ5-24823-D01	PANEL, BACK	1	1	1	
FOP-3-3	15	HZZ5-24824-D01	BRACKET, WIRE CLAMP	1	1	1	
FOP-3-3	16	HZZ5-24826-D01	CAP, RUBBER	1	1	1	
FOP-3-3	17	HZZ5-24827-D01	ADJUSTER	1	1	1	
FOP-3-3	18	HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	1	1	1	
FOP-3-3	19	HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	1	1	1	(LOOSE PARTS)
FOP-3-3	20	HZZ5-24829-D01	SEAL, RUBBER	1	1	1	
FOP-3-3	21	HZZ5-24831-D01	HOLDER, NEUTRAL LOCK	1	1	1	
FOP-3-3	22	HZZ5-24832-D01	GROMMET, WIRE (14)	1	1	1	
FOP-3-3	23	HZZ5-24833-D01	CAP, TROLLING CONTROL SWITCH	1	1	1	
FOP-3-3	24	HZZ5-24845-D01	GEAR ASSY. , SHIFT	1	1	1	
FOP-3-3	25	HZZ5-24850-D01	GEAR, DRIVE	1	1	1	
FOP-3-3	26	HZZ5-24855-D01	TERMINAL, CABLE	2	2	2	(LOOSE PARTS)
FOP-3-3	27	HZZ5-24875-D01	DRUM ASSY. , FREE THROTTLE	1	1	1	
FOP-3-3	28	HZZ5-24876-D01	SPRING (1)	1	1	1	


FOP-3-3 REMOTE CONTROL (NHK MEC)



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-3-3	29	HZZ5-24878-D01	LEVER, FREE THROTTLE	1	1	1	
FOP-3-3	30	HZZ5-24883-D01	SPRING, DETENT	5	5	5	
FOP-3-3	31	HZZ5-32530-D01	CABLE ASSY., REMOTE CONTROL (B)	1	1	1	
FOP-3-3	32	HZV5-32823-003	PLUG, INNER CONNECTOR	7	7	7	
FOP-3-3	33	HZV5-32824-003	PLUG, OUTER CONNECTOR	1	1	1	
FOP-3-3	34	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	
FOP-3-3	35	HZZ5-35370-D02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
FOP-3-3	36	HZZ3-35645-A41	PLATE, SWITCH	1	1	1	
FOP-3-3	37	HZZ5-35701-D01	BAND, WIRE	1	1	1	
FOP-3-3	38	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-3-3	39	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	
FOP-3-3	40	HZZ5-37210-D02	LAMP ASSY., INDICATION	1	1	1	
FOP-3-3	41	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	
FOP-3-3	42	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	
FOP-3-3	44	HZZ5-87701-D00	MARK, FAST IDLE	1	1	1	
FOP-3-3	45	HZZ5-87702-D00	MARK, EMERGENCY STOP	1	1	1	LRU, XCRU, XRU
FOP-3-3	45	HZZ5-87702-A00	MARK, EMERGENCY STOP (US)	1	1	1	XRD
FOP-3-3	46	HZZ5-87702-A00	MARK, EMERGENCY STOP (US)	1	1	1	(LOOSE PARTS) XRD
FOP-3-3	47	HZZ5-87702-D00	MARK, EMERGENCY STOP	1	1	1	(LOOSE PARTS) LRU, XCRU, XRU
FOP-3-3	48	HZZ5-87703-P01	MARK, EMBLEM	1	1	1	
FOP-3-3	49	HZZ5-87704-D01	LABEL, SIGP	1	1	1	
FOP-3-3	50	HZZ5-90101-D01	SCREW, 5X18	7	7	7	
FOP-3-3	51	HZZ5-90102-D01	SCREW, 4X6	2	2	2	
FOP-3-3	52	HZZ5-90103-D01	SCREW, 5X10	1	1	1	
FOP-3-3	53	HZZ5-90104-D01	SCREW, 4X10	2	2	2	
FOP-3-3	54	HZZ5-90106-D01	SCREW, 5X12	2	2	2	
FOP-3-3	55	HZZ5-90107-D01	SCREW, 6X90	3	3	3	(LOOSE PARTS)
FOP-3-3	56	HZZ5-90108-D01	BOLT, 8X50	1	1	1	
FOP-3-3	57	HZZ5-90109-D01	BOLT, 5X25	1	1	1	


This exploded view diagram illustrates the assembly of a car stereo unit. The components are numbered 1 through 75. The main assembly includes the stereo unit (12), a faceplate (13), a mounting bracket (14), and various connectors and cables (e.g., 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75). A legend in the bottom left corner identifies specific components: 47 (a two-position switch), 46 (a three-position switch), 68 (a button), 66 (a button), 10 (a button), 26 (a button), 69 (a button), and 58 (a button).

FOP-3-4 REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (NHK MEC)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-3-4	1	HZY6-06240-R90	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE)	1	1		LRU, XRD
FOP-3-4	1	HZY6-06240-R91	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE)	1	1		XCRU, XRU
FOP-3-4	1	HZY6-06240-R91	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE)			1	
FOP-3-4	2	HZY6-24810-U11	HOUSING ASSY., L. INNER (TOP MOUNT)	1	1	1	
FOP-3-4	3	HZY6-24811-U11	HANDLE, REMOTE CONTROL	1	1	1	
FOP-3-4	4	HZY6-24812-U11	COVER, GRIP	1	1		LRU, XRD
FOP-3-4	4	HZY6-24812-U12	COVER, GRIP	1	1		XCRU, XRU
FOP-3-4	4	HZY6-24812-U12	COVER, GRIP			1	
FOP-3-4	5	HZY6-24813-U11	GRIP, REMOTE CONTROL HANDLE	1	1		LRU, XRD
FOP-3-4	5	HZY6-24813-U12	GRIP, REMOTE CONTROL HANDLE	1	1		XCRU, XRU
FOP-3-4	5	HZY6-24813-U12	GRIP, REMOTE CONTROL HANDLE			1	
FOP-3-4	6	HZY6-24814-U11	COVER, LEVER	1	1	1	
FOP-3-4	7	HZY6-24816-U11	BUTTON, THROTTLE	1	1	1	
FOP-3-4	8	HZW5-24817-U01	PLATE, HANDLE	1	1	1	
FOP-3-4	9	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	
FOP-3-4	10	HZY6-24819-U11	BRACKET, REMOTE CONTROL HOUSING	2	2	2	
FOP-3-4	11	HZY6-24820-U11	HOUSING, SINGLE REMOTE CONTROL BOX	1	1	1	
FOP-3-4	12	HZY6-24821-U11	PLUG, SINGLE HOUSING	1	1	1	
FOP-3-4	13	HZY6-24824-U11	GUIDE, SINGLE WATER	1	1	1	
FOP-3-4	14	HZY6-24825-U11	HOUSING, LEAD	1	1	1	
FOP-3-4	15	HZW5-24826-U01	PLATE, DWELL	1	1	1	
FOP-3-4	16	HZY6-24826-R11	COVER, HOUSING SIDE	1	1	1	
FOP-3-4	17	HZY6-24827-U11	RING, SNAP	1	1	1	
FOP-3-4	18	HZY6-24828-U11	GROMMET	1	1	1	
FOP-3-4	19	HZW5-24831-U01	TERMINAL, CABLE (LOOSE PARTS)	2	2	2	
FOP-3-4	20	HZW5-24832-U01	SPACER, CABLE CLAMP (LOOSE PARTS)	1	1	1	
FOP-3-4	21	HZY6-24832-U91	CAP, BLANK	1	1	1	
FOP-3-4	22	HZW5-24834-U01	PACKING, SINGLE (LOOSE PARTS)	1	1	1	
FOP-3-4	23	HZY6-35370-U11	SWITCH ASSY., POWER TRIM-TILT	1	1	1	

FOP-3-4 REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (NHK MEC)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT2000	BFT225D	BFT250D	
FOP-3-4	24	HZY6-87703-R11	MARK, REMOTE CONTROL (SINGLE)	1	1	1	
FOP-3-4	25	HZW5-90101-U00	SCREW, PAN, 5X16	1	1	1	
FOP-3-4	26	HZY6-90102-U11	SCREW, TRUSS, 5X10	1	1	1	
FOP-3-4	27	HZY6-90103-U11	SCREW, TRUSS, 5X16 (TAPPING)	2	2	2	
FOP-3-4	28	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	
FOP-3-4	29	HZY6-90104-U11	SCREW, PAN, 5X14 (TAPPING)	1	1	1	
FOP-3-4	30	HZW5-90106-U00	SCREW, PAN, 6X18	2	2	2	
FOP-3-4	31	HZY6-90106-U11	SCREW, PAN, 5X14 (TAPPING)	2	2	2	
FOP-3-4	32	HZW5-90107-U00	SCREW, PAN, 5X40 (LOOSE PARTS)	4	4	4	
FOP-3-4	33	HZY6-90111-U11	BOLT, STOPPER (F)	1	1	1	
FOP-3-4	34	HZY6-90112-U11	BOLT, STOPPER (R)	1	1	1	
FOP-3-4	35	HZW5-90301-U00	NUT, HEX., 5MM (LOOSE PARTS)	4	4	4	
FOP-3-4	36	HZZ5-90301-D01	NUT, 6MM	2	2	2	
FOP-3-4	37	HZW5-90501-U00	WASHER, LOCK, 5MM	3	3	3	
FOP-3-4	38	HZW5-90502-U00	WASHER, LOCK, 6MM	2	2	2	
FOP-3-4	39	HZW5-90503-U00	WASHER, PLAIN, 5MM (LOOSE PARTS)	4	4	4	
FOP-3-4	40	HZZ5-90651-D01	E-RING, 6MM (LOOSE PARTS)	2	2	2	
FOP-3-4	41	HZZ5-90651-D01	E-RING, 6MM	2	2	2	
FOP-3-4	42	HZY6-06241-U10	SPACER KIT, REMOTE CONTROL BOX (TOP MOUNT SINGLE)	1	1	1	XCUR, XRU
FOP-3-4	43	HZV4-90502-000	WASHER, PLAIN, 5MM	4	4	4	XCUR, XRU
FOP-3-4	44	HCO-93500-05065-4J	SCREW, PAN, 5X65	4	4	4	XCUR, XRU
FOP-3-4	45	HCO-94001-05490-0S	NUT, HEX., 5MM	4	4	4	XCUR, XRU

FOP-3-5 REMOTE CONTROL (TOP MOUNT DUAL TYPE)(NHK MEC)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-3-5	1	HZY6-06240-S90	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL)	1	1		LRU, XRD
FOP-3-5	1	HZY6-06240-S91	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL)	1	1		XCRU, XRU
FOP-3-5	1	HZY6-06240-S91	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL)			1	
FOP-3-5	2	HZY6-24810-U11	HOUSING ASSY., L. INNER (TOP MOUNT)	1	1	1	
FOP-3-5	3	HZY6-24810-V11	HOUSING ASSY., R. INNER (TOP MOUNT)	1	1	1	
FOP-3-5	4	HZY6-24811-U11	HANDLE, REMOTE CONTROL	2	2	2	
FOP-3-5	5	HZY6-24812-U11	COVER, GRIP	2	2		LRU, XRD
FOP-3-5	5	HZY6-24812-U12	COVER, GRIP	2	2		XCRU, XRU
FOP-3-5	5	HZY6-24812-U12	COVER, GRIP			2	
FOP-3-5	6	HZY6-24813-U11	GRIP, REMOTE CONTROL HANDLE	2	2		LRU, XRD
FOP-3-5	6	HZY6-24813-U12	GRIP, REMOTE CONTROL HANDLE	2	2		XCRU, XRU
FOP-3-5	6	HZY6-24813-U12	GRIP, REMOTE CONTROL HANDLE			2	
FOP-3-5	7	HZY6-24814-U11	COVER, LEVER	2	2	2	
FOP-3-5	8	HZY6-24816-U11	BUTTON, THROTTLE	2	2	2	
FOP-3-5	9	HZW5-24817-U01	PLATE, HANDLE	2	2	2	
FOP-3-5	10	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	
FOP-3-5	11	HZY6-24819-V11	BRACKET, REMOTE CONTROL HOUSING	2	2	2	
FOP-3-5	12	HZY6-24820-V11	HOUSING, DUAL REMOTE CONTROL BOX	1	1	1	
FOP-3-5	13	HZY6-24821-V11	PLUG, DUAL HOUSING	1	1	1	
FOP-3-5	14	HZY6-24824-V11	GUIDE, DUAL WATER	2	2	2	
FOP-3-5	15	HZY6-24825-U11	HOUSING, LEAD	2	2	2	
FOP-3-5	16	HZW5-24826-U01	PLATE, DWELL	2	2	2	
FOP-3-5	17	HZY6-24827-U11	RING, SNAP	2	2	2	
FOP-3-5	18	HZY6-24828-U11	GROMMET	2	2	2	
FOP-3-5	19	HZW5-24831-U01	TERMINAL, CABLE (LOOSE PARTS)	4	4	4	
FOP-3-5	20	HZW5-24832-U01	SPACER, CABLE CLAMP (LOOSE PARTS)	2	2	2	
FOP-3-5	21	HZY6-24832-U91	CAP, BLANK	2	2	2	
FOP-3-5	22	HZY6-24832-V11	CAP, POWER TRIM-TILT BLANK	1	1	1	
FOP-3-5	23	HZY6-24834-V11	PACKING, DUAL (LOOSE PARTS)	1	1	1	

FOP-3-5 REMOTE CONTROL (TOP MOUNT DUAL TYPE)(NHK MEC)






Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-3-5	24	HZY6-24835-U11	BAND, TY-RAP	1	1	1	
FOP-3-5	25	HZY6-35370-U11	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
FOP-3-5	26	HZY6-35370-V11	SWITCH ASSY., POWER TRIM-TILT (PORT)	1	1	1	
FOP-3-5	27	HZY6-35370-V21	SWITCH ASSY., POWER TRIM-TILT (STAR)	1	1	1	
FOP-3-5	28	HZY6-35375-V90	CABLE ASSY., POWER TRIM-TILT	1	1	1	
FOP-3-5	29	H797-38206-A01	FUSE, BLADE (3A)	2	2	2	
FOP-3-5	30	HZVL-38216-901	COVER ASSY., FUSE (3A)	1	1	1	
FOP-3-5	31	HZY6-38580-V11	RELAY ASSY., CONTROL	2	2	2	
FOP-3-5	32	HZY6-38581-V11	HOLDER, RELAY	2	2	2	
FOP-3-5	33	HZ2E-87117-000	LABEL, FUSE (3A)	1	1	1	
FOP-3-5	34	HZY6-87703-S11	MARK, REMOTE CONTROL (DUAL)	1	1	1	
FOP-3-5	35	HZW5-90101-U00	SCREW, PAN, 5X16	1	1	1	
FOP-3-5	36	HZY6-90102-U11	SCREW, TRUSS, 5X10	2	2	2	
FOP-3-5	37	HZY6-90103-U11	SCREW, TRUSS, 5X16 (TAPPING)	4	4	4	
FOP-3-5	38	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	
FOP-3-5	39	HZY6-90104-U11	SCREW, PAN, 5X14 (TAPPING)	2	2	2	
FOP-3-5	40	HZW5-90106-U00	SCREW, PAN, 6X18	4	4	4	
FOP-3-5	41	HZY6-90106-U11	SCREW, PAN, 5X14 (TAPPING)	4	4	4	
FOP-3-5	42	HZW5-90107-U00	SCREW, PAN, 5X40 (LOOSE PARTS)	4	4	4	
FOP-3-5	43	HZW5-90108-U00	SCREW, PAN, 5X55	3	3	3	
FOP-3-5	44	HZY6-90111-U11	BOLT, STOPPER (F)	2	2	2	
FOP-3-5	45	HZY6-90112-U11	BOLT, STOPPER (R)	2	2	2	
FOP-3-5	46	HZW5-90301-U00	NUT, HEX., 5MM (LOOSE PARTS)	4	4	4	
FOP-3-5	47	HZZ5-90301-D01	NUT, 6MM	4	4	4	
FOP-3-5	48	HZW5-90302-U21	NUT, HEX., 5MM	1	1	1	
FOP-3-5	49	HZW5-90501-U00	WASHER, LOCK, 5MM	6	6	6	
FOP-3-5	50	HZW5-90502-U00	WASHER, LOCK, 6MM	4	4	4	
FOP-3-5	51	HZW5-90503-U00	WASHER, PLAIN, 5MM (LOOSE PARTS)	4	4	4	
FOP-3-5	52	HZZ5-90651-D01	E-RING, 6MM (LOOSE PARTS)	4	4	4	

FOP-3-5 REMOTE CONTROL (TOP MOUNT DUAL TYPE)(NHK MEC)




[illegible]

FOP-4 METER




[illegible]

FOP-5 SWITCH PANEL KIT (1)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-5	1	HZY6-06323-R81	PANEL KIT, SWITCH(SINGLE)	1	1	1	LRU, XCRU, XRU
FOP-5	1	HZY6-06323-R01	PANEL KIT, SWITCH(SINGLE)	1	1	1	XRD
FOP-5	2	HZY6-32340-R81	PANEL ASSY., CONTROL(SINGLE)	1	1	1	LRU, XCRU, XRU
FOP-5	2	HZY6-32340-R01	PANEL ASSY., CONTROL(SINGLE)	1	1	1	XRD
FOP-5	3	HZY6-32346-R81	PANEL, CONTROL(SINGLE)	1	1	1	LRU, XCRU, XRU
FOP-5	3	HZY6-32346-R01	PANEL, CONTROL(SINGLE)	1	1	1	XRD
FOP-5	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	1	1	1	
FOP-5	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	1	1	1	
FOP-5	6	HZV5-32823-003	PLUG, INNER CONNECTOR	9	9	9	
FOP-5	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	7	7	7	
FOP-5	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	1	1	1	
FOP-5	9	HZY6-36180-003	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	
FOP-5	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	1	1	1	
FOP-5	13	HZY9-38410-A01	BUZZER COMP., WARNING	1	1	1	
FOP-5	14	HZY6-38414-003	BRACKET	1	1	1	
FOP-5	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	
FOP-5	16	HZZ5-90301-M01	NUT, FLANGE, 5MM	4	4	4	
FOP-5	17	HZY6-90302-003	NUT	1	1	1	
FOP-5	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM	4	4	4	
FOP-5	19	HZZ5-90502-M01	WASHER, SPRING, 5MM	4	4	4	

FOP-5-1 SWITCH PANEL KIT (2)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-5-1	1	HZY6-06323-R91	PANEL KIT, SWITCH(TWIN)	1	1	1	LRU, XCRU, XRU
FOP-5-1	1	HZY6-06323-R11	PANEL KIT, SWITCH(TWIN)	1	1	1	XRD
FOP-5-1	2	HZY6-32340-R91	PANEL ASSY., CONTROL (TWIN)	1	1	1	LRU, XCRU, XRU
FOP-5-1	2	HZY6-32340-R11	PANEL ASSY., CONTROL (TWIN)	1	1	1	XRD
FOP-5-1	3	HZY6-32346-R91	PANEL, CONTROL (TWIN)	1	1	1	LRU, XCRU, XRU
FOP-5-1	3	HZY6-32346-R11	PANEL, CONTROL (TWIN)	1	1	1	XRD
FOP-5-1	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	2	2	2	
FOP-5-1	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	2	2	2	
FOP-5-1	6	HZV5-32823-003	PLUG, INNER CONNECTOR	18	18	18	
FOP-5-1	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	14	14	14	
FOP-5-1	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	2	2	2	
FOP-5-1	9	HZY6-36180-712	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5-1	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	
FOP-5-1	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5-1	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	2	2	2	
FOP-5-1	13	HZY9-38410-A01	BUZZER COMP., WARNING	2	2	2	
FOP-5-1	14	HZY6-38414-003	BRACKET	2	2	2	
FOP-5-1	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	
FOP-5-1	16	HZZ5-90301-M01	NUT, FLANGE, 5MM	4	4	4	
FOP-5-1	17	HZY6-90302-003	NUT	1	1	1	
FOP-5-1	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM	4	4	4	
FOP-5-1	19	HZZ5-90502-M01	WASHER, SPRING, 5MM	4	4	4	

FOP-5-2 SWITCH PANEL KIT (3)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-5-2	1	HZY6-06323-R31	PANEL KIT, SWITCH (TRIPLE)	1	1	1	LRU, XCRU, XRU
FOP-5-2	1	HZY6-06323-R21	PANEL KIT, SWITCH (TRIPLE)	1	1	1	XRD
FOP-5-2	2	HZY6-32340-R31	PANEL ASSY., CONTROL (TRIPLE)	1	1	1	LRU, XCRU, XRU
FOP-5-2	2	HZY6-32340-R21	PANEL ASSY., CONTROL (TRIPLE)	1	1	1	XRD
FOP-5-2	3	HZY6-32346-R31	PANEL, CONTROL (TRIPLE)	1	1	1	LRU, XCRU, XRU
FOP-5-2	3	HZY6-32346-R21	PANEL, CONTROL (TRIPLE)	1	1	1	XRD
FOP-5-2	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	3	3	3	
FOP-5-2	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	3	3	3	
FOP-5-2	6	HZV5-32823-003	PLUG, INNER CONNECTOR	27	27	27	
FOP-5-2	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	21	21	21	
FOP-5-2	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	3	3	3	
FOP-5-2	9	HZY6-36180-612	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5-2	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	
FOP-5-2	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5-2	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	3	3	3	
FOP-5-2	13	HZY9-38410-A01	BUZZER COMP., WARNING	3	3	3	
FOP-5-2	14	HZY6-38414-003	BRACKET	3	3	3	
FOP-5-2	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	
FOP-5-2	16	HZZ5-90301-M01	NUT, FLANGE, 5MM	4	4	4	
FOP-5-2	17	HZY6-90302-003	NUT	1	1	1	
FOP-5-2	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM	4	4	4	
FOP-5-2	19	HZZ5-90502-M01	WASHER, SPRING, 5MM	4	4	4	

FOP-5-3 SWITCH PANEL KIT (4)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-5-3	1	HZZ3-06323-R04	PANEL KIT, SWITCH(B) (4-LED)	1	1	1	LRU, XCRU, XRU
FOP-5-3	1	HZZ3-06323-R24	PANEL KIT, SWITCH(B) (4-LED)	1	1	1	XRD
FOP-5-3	2	HZZ5-06352-M01	SWITCH KIT, LIGHT	1			LRU
FOP-5-3	3	HZZ3-32341-R02	PANEL ASSY., SWITCH	1	1	1	LRU, XCRU, XRU
FOP-5-3	3	HZZ3-32341-R32	PANEL ASSY., SWITCH	1	1	1	XRD
FOP-5-3	4	HZZ3-32346-R02	PANEL, CONTROL	1	1	1	LRU, XCRU, XRU
FOP-5-3	4	HZZ3-32346-R22	PANEL, CONTROL	1	1	1	XRD
FOP-5-3	5	HZZ3-32347-R02	PANEL, CONTROL	1	1	1	
FOP-5-3	6	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	1	
FOP-5-3	7	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	8	
FOP-5-3	8	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	3	
FOP-5-3	9	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	
FOP-5-3	10	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5-3	11	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	
FOP-5-3	12	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5-3	13	HZZ3-37205-R03	PANEL ASSY., INDICATOR(4-LED)	1	1	1	
FOP-5-3	14	HZZ5-37210-763	LAMP ASSY., INDICATION(4-LED)	1	1	1	
FOP-5-3	15	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	
FOP-5-3	16	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	
FOP-5-3	17	HZZ5-38414-003	BRACKET, BUZZER	1	1	1	
FOP-5-3	18	HZW5-90109-000	SCREW, PAN, 5X40	8	8	8	XCRU, XRD, XRU
FOP-5-3	18	HZW5-90109-000	SCREW, PAN, 5X40	12			LRU
FOP-5-3	19	HZZ5-90301-M01	NUT, FLANGE, 5MM	8	8	8	XCRU, XRD, XRU
FOP-5-3	19	HZZ5-90301-M01	NUT, FLANGE, 5MM	12			LRU
FOP-5-3	20	H921-90302-000	NUT, HEX., 16MM	1	1	1	
FOP-5-3	21	HZZ5-90501-M01	WASHER, PLAIN, 5MM	8	8	8	XCRU, XRD, XRU
FOP-5-3	21	HZZ5-90501-M01	WASHER, PLAIN, 5MM	12			LRU
FOP-5-3	22	HZZ5-90502-M01	WASHER, SPRING, 5MM	8	8	8	XCRU, XRD, XRU
FOP-5-3	22	HZZ5-90502-M01	WASHER, SPRING, 5MM	12			LRU

FOP-5-3 SWITCH PANEL KIT (4)




FOP-5-4 SWITCH PANEL KIT (5)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT25D	BFT30D	
FOP-5-4	1	HZZ3-06323-R14	PANEL KIT, SWITCH(4-LED)	1	1	1	LRU, XCRU, XRU
FOP-5-4	1	HZZ3-06323-R34	PANEL KIT, SWITCH(4-LED)	1	1	1	XRD
FOP-5-4	2	HZZ3-32346-R12	PANEL, CONTROL	1	1	1	LRU, XCRU, XRU
FOP-5-4	2	HZZ3-32346-R32	PANEL, CONTROL	1	1	1	XRD
FOP-5-4	3	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	1	
FOP-5-4	4	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	8	
FOP-5-4	5	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	3	
FOP-5-4	6	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	
FOP-5-4	7	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	
FOP-5-4	8	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	
FOP-5-4	9	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	1	
FOP-5-4	10	HZZ5-37210-713	LAMP ASSY., INDICATION(4-LED)	1	1	1	
FOP-5-4	11	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	
FOP-5-4	12	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	
FOP-5-4	13	HZZ5-38414-003	BRACKET, BUZZER	1	1	1	
FOP-5-4	14	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	
FOP-5-4	15	HZZ5-90301-M01	NUT, FLANGE, 5MM	4	4	4	
FOP-5-4	16	H921-90302-000	NUT, HEX., 16MM	1	1	1	
FOP-5-4	17	HZZ5-90501-M01	WASHER, PLAIN, 5MM	4	4	4	
FOP-5-4	18	HZZ5-90502-M01	WASHER, SPRING, 5MM	4	4	4	
FOP-5-4	19	HSC2-90649-003	BAND, WIRE HARNESS(NATURAL)	1	1	1	

FOP-7 INTERFACE CABLE KIT




FOP-10 CABLE KIT




Ref. No.		Part No.	Description	Q'ty			Remarks
				BFT200D	BFT225D	BFT250D	
FOP-10	1	HZVL-06328-800	CONNECTOR KIT, TERMINATOR	1	1	1	
FOP-10	2	HZVL-32580-900	CABLE ASSY., PANEL INDICATOR	1	1	1	
FOP-10	2	HZVL-32580-910	CABLE ASSY., PANEL INDICATOR	1	1	1	
FOP-10	2	HZVL-32580-920	CABLE ASSY., PANEL INDICATOR	1	1	1	
FOP-10	3	HZVL-32806-000	TERMINATOR (M)	1	1	1	
FOP-10	4	HZVL-32807-000	TERMINATOR (F)	1	1	1	
FOP-10	5	HZVL-32590-900	CABLE ASSY., CONVERSION (6FT)	1			LRU, XRD
FOP-10	5	HZVL-32590-910	CABLE ASSY., CONVERSION (10FT)	1			LRU, XRD
FOP-10	5	HZVL-32590-901	CABLE ASSY., CONVERSION (6FT)	1		1	XCRU, XRU
FOP-10	5	HZVL-32590-911	CABLE ASSY., CONVERSION (10FT)	1		1	XCRU, XRU
FOP-10	5	HZVL-32590-900	CABLE ASSY., CONVERSION (6FT)		1		XCRU, XRD
FOP-10	5	HZVL-32590-910	CABLE ASSY., CONVERSION (10FT)		1		XCRU, XRD
FOP-10	5	HZVL-32590-901	CABLE ASSY., CONVERSION (6FT)		1		XRU
FOP-10	5	HZVL-32590-911	CABLE ASSY., CONVERSION (10FT)		1		XRU
FOP-10	5	HZVL-32590-900	CABLE ASSY., CONVERSION (6FT)			1	XRD
FOP-10	5	HZVL-32590-910	CABLE ASSY., CONVERSION (10FT)			1	XRD
FOP-10	6	HZVL-31576-000	CORD ASSY., EXTENSION POWER	1	1	1	
FOP-10	7	HZVL-32815-000	CABLE ASSY., NETWORK (6FT)	1	1	1	
FOP-10	7	HZVL-32815-600	CABLE ASSY., NETWORK (16FT)	1	1	1	
FOP-10	7	HZVL-32815-700	CABLE ASSY., NETWORK (32FT)	1	1	1	
FOP-10	7	HZVL-32815-800	CABLE ASSY., NETWORK (49FT)	1	1	1	

FOP-14 TRIM ADJUST PLATE SET


1



2




FOP-15 PROPELLER




[illegible]

FOP-17 GEAR CASE KIT




FOP-18 MAINTENANCE KIT (200)




Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-18	1	HZVL-06160-010	STRAINER ASSY., FUEL (HIGH)	1		1	XCRU, XRU
FOP-18	1	HZVL-06160-010	STRAINER ASSY., FUEL (HIGH)		1		XRU
FOP-18	2	HZW1-06411-020	METAL KIT, ANODE	1		1	XCRU, XRU
FOP-18	2	HZW1-06411-020	METAL KIT, ANODE		1		XRU
FOP-18	3	HZVL-06510-010	MAINTENANCE KIT (200)	1		1	XCRU, XRU
FOP-18	3	HZVL-06510-010	MAINTENANCE KIT (200)		1		XRU
FOP-18	4	HRTA-15400-003	CARTRIDGE, OIL FILTER (MAHLE TENNEX)	1		1	XCRU, XRU
FOP-18	4	HRTA-15400-003	CARTRIDGE, OIL FILTER (MAHLE TENNEX)		1		XRU
FOP-18	5	HZY3-19210-003	IMPELLER, PUMP	1		1	XCRU, XRU
FOP-18	5	HZY3-19210-003	IMPELLER, PUMP		1		XRU
FOP-18	6	HZY3-19223-000	LINER, PUMP	1		1	XCRU, XRU
FOP-18	6	HZY3-19223-000	LINER, PUMP		1		XRU
FOP-18	7	HZY3-19231-000	COVER, IMPELLER	1		1	XCRU, XRU
FOP-18	7	HZY3-19231-000	COVER, IMPELLER		1		XRU
FOP-18	8	HZX2-19234-000	GASKET B, IMPELLER	1		1	XCRU, XRU
FOP-18	8	HZX2-19234-000	GASKET B, IMPELLER		1		XRU
FOP-18	9	HZY3-19253-000	RING, WATER TUBE SEAL	1		1	XCRU, XRU
FOP-18	9	HZY3-19253-000	RING, WATER TUBE SEAL		1		XRU
FOP-18	10	HZX2-19300-003	THERMOSTAT ASSY.	2		2	XCRU, XRU
FOP-18	10	HZX2-19300-003	THERMOSTAT ASSY.		2		XRU
FOP-18	11	HZW1-41109-B00	METAL COMP., ANODE	2		2	XCRU, XRU
FOP-18	11	HZW1-41109-B00	METAL COMP., ANODE		2		XRU
FOP-18	12	HZW9-90101-003	BOLT, OIL CHECK	1		1	XCRU, XRU
FOP-18	12	HZW9-90101-003	BOLT, OIL CHECK		1		XRU
FOP-18	13	HZY3-90120-000	BOLT, DRAIN PLUG	1		1	XCRU, XRU
FOP-18	13	HZY3-90120-000	BOLT, DRAIN PLUG		1		XRU
FOP-18	14	HZY1-90205-000	NUT, SELF-LOCK, 6MM	1		1	XCRU, XRU
FOP-18	14	HZY1-90205-000	NUT, SELF-LOCK, 6MM		1		XRU
FOP-18	15	HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	1		1	XCRU, XRU

FOP-18 MAINTENANCE KIT (200)




FOP-18-1 MAINTENANCE KIT (400)



Ref. No.		Part No.	Description	Q'ty			Remarks
				BF1200D	BF1225D	BF1250D	
FOP-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)	1			XRU ~6011098
FOP-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)	1			XCRU ~7011019
FOP-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)		1		XRU ~6011067
FOP-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)			1	XRU ~6011240
FOP-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)			1	XCRU ~7011069
FOP-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)	1			XRU 6011099~
FOP-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)	1			XCRU 7011020~
FOP-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)		1		XRU 6011068~
FOP-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)			1	XRU 6011241~
FOP-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)			1	XCRU 7011070~
FOP-18-1	2	HZV5-12155-000	METAL, ANODE	4			XRU ~6011098
FOP-18-1	2	HZV5-12155-000	METAL, ANODE	4			XCRU ~7011019
FOP-18-1	2	HZV5-12155-000	METAL, ANODE		4		XRU ~6011067
FOP-18-1	2	HZV5-12155-000	METAL, ANODE			4	XRU ~6011240
FOP-18-1	2	HZV5-12155-000	METAL, ANODE			4	XCRU ~7011069
FOP-18-1	2	HZV5-12155-010	METAL, ANODE	4			XRU 6011099~
FOP-18-1	2	HZV5-12155-010	METAL, ANODE	4			XCRU 7011020~
FOP-18-1	2	HZV5-12155-010	METAL, ANODE		4		XRU 6011068~
FOP-18-1	2	HZV5-12155-010	METAL, ANODE			4	XRU 6011241~
FOP-18-1	2	HZV5-12155-010	METAL, ANODE			4	XCRU 7011070~
FOP-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM	6			XRU ~6011098
FOP-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM	6			XCRU ~7011019
FOP-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM		6		XRU ~6011067
FOP-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM			6	XRU ~6011240
FOP-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM			6	XCRU ~7011069
FOP-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM	6			XRU 6011099~
FOP-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM	6			XCRU 7011020~
FOP-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM		6		XRU 6011068~
FOP-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM			6	XRU 6011241~

FOP-18-1 MAINTENANCE KIT (400)



[illegible]

INDEX

332-70201-0	* CLAMP	F-6-8
3C7-70211-1	* PRIMER BULB	F-6-4
3C7-70217-0	* CLAMP	F-6-5
3C7-70220-1	* JOINT ASSY (INLET)	F-6-2
3C7-70224-1	* JOINT ASSY (OUTLET)	F-6-3
3PU-72537-0	METER LEAD WIRE	FOP-4-3
3PU-72571-3	TRIM METER ASSY	FOP-4-1
3PU-72637-2	TACHOMETER HOUR METER	FOP-4-2
3PV-72571-3	TRIM METER ASSY	FOP-4-1
3PV-72637-2	TACHOMETER HOUR METER	FOP-4-2
3T1-70200-1	PRIMER BULB ASSY	F-6-1
98AB-701600	* HOSE	F-6-7
98AB-70-700	* HOSE	F-6-6
H121-51640-730	RUBBER, FR. CARRIER CUSHION	F-3-20-25
H196-47117-000	RUBBER, STOPPER	F-3-30-2
H341-38403-672	PLATE, WINKER BUZZER	FOP-3-3-41
H341-38403-672	PLATE, WINKER BUZZER	FOP-5-3-15
H341-38403-672	PLATE, WINKER BUZZER	FOP-5-4-11
H355-89217-000	WRENCH, BOX (10MM)	F-13-4
H371-89221-000	WRENCH, HEX., 6MM	F-13-5
H371-90009-015	BOLT, FLANGE, 10X120 (SATO)	E-6-10-26
H5YS-30530-J01	SENSOR, KNOCK	E-3-20
H723-90472-000	WASHER, PLAIN, 12MM	F-4-21
H747-16731-003	CLIP, TUBE	F-10-3
H759-16911-003	STRAINER, FUEL PUMP	E-18-10-14
H763-90681-A01	CLIP, WIRE HARNESS	F-7-10-22
H763-90681-A01	CLIP, WIRE HARNESS	F-10-67
H797-38206-A01	FUSE, BLADE (3A)	FOP-3-5-29
H800-91303-000	O-RING, 16MM	E-6-10-45
H881-90110-000	BOLT, HEX., 6X14	F-10-45
H881-90114-000	BOLT, HEX., 6X40	F-2-30
H921-17936-000	WASHER, PIVOT	F-2-6
H921-90302-000	NUT, HEX., 16MM	F-3-20-43
H921-90302-000	NUT, HEX., 16MM	FOP-3-3-59
H921-90302-000	NUT, HEX., 16MM	FOP-5-3-20
H921-90302-000	NUT, HEX., 16MM	FOP-5-4-16
H921-90511-000	WASHER, PLAIN, 10MM	F-10-61
H958-90428-000	WASHER B, THRUST, 14MM	F-2-34
HCO-92101-06055-4J	BOLT, HEX., 6X55	F-3-22
HCO-92101-06055-4J	BOLT, HEX., 6X55	FOP-18-21
HCO-92101-06055-4J	BOLT, HEX., 6X55	FOP-18-21
HCO-93500-04014-4J	SCREW, PAN, 4X14	F-10-71
HCO-93500-05016-4J	SCREW, PAN, 5X16	E-3-51
HCO-93500-05016-4J	SCREW, PAN, 5X16	E-6-10-50
HCO-93500-05020-4J	SCREW, PAN, 5X20	E-3-52
HCO-93500-05020-4J	SCREW, PAN, 5X20	F-10-72

HCO-93500-05065-4J	SCREW, PAN, 5X65	FOP-3-4-44
HCO-93500-06018-4J	SCREW, PAN, 6X18	E-4-25
HCO-93500-06018-4J	SCREW, PAN, 6X18	E-4-25
HCO-93500-06018-4J	SCREW, PAN, 6X18	E-4-25
HCO-93600-06016-0A	SCREW, FLAT, 6X16	E-5-20
HCO-93901-446J0	SCREW, TAPPING, 4X25	FOP-7-6
HCO-94001-05490-0S	NUT, HEX., 5MM	F-10-73
HCO-94001-05490-0S	NUT, HEX., 5MM	FOP-3-4-45
HCO-94001-06080-0S	NUT, HEX., 6MM	E-19-27
HCO-94001-12490-0S	NUT, HEX., 12MM	F-10-74
HCO-94002-04490-0S	NUT, HEX., 4MM	F-10-75
HCO-94301-06100	DOWEL PIN, 6X10	E-3-53
HCO-94301-06100	DOWEL PIN, 6X10	E-13-30
HCO-94301-06100	DOWEL PIN, 6X10	E-15-21
HCO-94301-08140	DOWEL PIN, 8X14	E-3-10-19
HCO-94301-10120	DOWEL PIN, 10X12	E-14-35
HCO-94302-06100	PIN B, DOWEL, 6X10	E-9-18
HCO-94302-10160	PIN B, DOWEL, 10X16	E-5-21
HCO-94302-10160	PIN B, DOWEL, 10X16	E-6-10-51
HCO-94305-30203	PIN, SPRING, 3X20	F-10-76
HCO-94510-15000	CIRCLIP, EXTERNAL, 15MM	F-5-31
HCO-94510-15000	CIRCLIP, EXTERNAL, 15MM	F-5-1-33
HCO-94520-47000	CIRCLIP, INTERNAL, 47MM	F-4-34
HCO-94540-04029	E-RING, 4MM	F-2-46
HCO-94540-06029	E-RING, 6MM	FOP-3-32
HCO-94540-06029	E-RING, 6MM	FOP-3-1-28
HCO-94540-06029	E-RING, 6MM	FOP-3-2-37
HCO-94540-10019	E-RING, 10MM	F-4-35
HCO-94540-12029	E-RING, 12MM	F-2-47
HCO-94540-15029	E-RING, 15MM	F-11-47
HCO-95001-35055-40	TUBE, FUEL, 3. 5X55	E-18-10-30
HCO-95003-05060-31	TUBE, VINYL, 3. 5X6. 5X600	E-18-10-31
HCO-95005-50045-30	TUBE, 5X45 (95005-50001-30M)	F-10-77
HCO-95005-50250-30	TUBE, 5X250 (95005-50001-30M)	F-10-78
HCO-95005-50340-30	TUBE, 5X340 (95005-50001-30M)	F-10-79
HCO-95011-63000	RUBBER C, STAND STOPPER	F-3-20-55
HCO-95701-06014-09	BOLT, FLANGE, 6X14	E-5-22
HCO-95701-06018-09	BOLT, FLANGE, 6X18	E-5-23
HCO-95701-08030-09	BOLT, FLANGE, 8X30	E-5-24
HCO-95701-10070-09	BOLT, FLANGE, 10X70	E-6-10-52
HCO-95701-12120-09	BOLT, FLANGE, 12X120	E-6-10-53
HCO-96211-07000	BALL, STEEL, #7 (7/32)	F-5-32
HCO-96211-07000	BALL, STEEL, #7 (7/32)	F-5-1-34
HCO-96211-12000	BALL, STEEL, #12 (3/8)	F-5-33
HCO-96211-12000	BALL, STEEL, #12 (3/8)	F-5-1-35
HCO-96220-50080	ROLLER, 5X8	E-5-25
HCO-9807B-5617C	PLUG, SPARK (IZFR6K-11E) (NGK)	E-20-3
HCO-98200-41000	FUSE, MINI (10A)	F-7-20-9

HCO-98200-41500	FUSE, MINI (15A)	F-7-20-10
HCO-98200-43000	FUSE, MINI (30A)	F-7-20-11
HCO-99003-10000	DRIVER 1, PLUS SCREW (NO. 2)	F-13-6
HCO-99003-50000	GRIP, SCREW DRIVER	F-13-7
HCO-99006-19000	WRENCH, EYE, 19MM	F-13-8
HCO-99008-02000	BAG, TOOL, 200MM	F-13-9
HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	FOP-5-12
HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	FOP-5-1-12
HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	FOP-5-2-12
HGHB-16075-830	O-RING, 1.9X10	F-3-20-1
HGHB-16163-610	CLIP, TUBE	E-6-10-2
HHA0-90402-000	WASHER, THRUST, 14MM	F-2-33
HHE0-50310-003	CLIP A, WIRE	E-1-11
HHW1-90207-671	BOLT, FLANGE, 6X40	E-6-10-37
HHW1-90214-671	BOLT, FLANGE, 6X25 (SUS-D)	F-10-84
HHW1-90215-671	BOLT, FLANGE, 6X16	F-4-18
HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED)	F-7-5
HKM3-32161-003	BAND, WIRE	F-10-6
HKN5-17224-670	WASHER, AIR CLEANER COVER	F-2-1
HKSV-32501-J00	FUSE, BLADE (40A)	F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A)	F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A)	F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A)	F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A)	F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A)	F-7-10-28
HKV6-90651-003	BAND, WIRE, 165MM (BLACK)	F-7-10-21
HMAL-91302-601	O-RING, 18.1X3.6	E-3-10-17
HMB9-83551-000	GROMMET	E-14-10-10
HMG9-35701-950	BAND (BLACK 3.5X140)	F-10-80
HMG9-35701-950	BAND (BLACK 3.5X140)	F-11-3
HMJ0-91301-003	O-RING, 7.8X1.9 (ARAI)	E-14-32
HMJ0-91301-003	O-RING, 7.8X1.9 (ARAI)	E-18-53
HMJ0-91301-003	O-RING, 7.8X1.9 (ARAI)	EOP-1-15
HMJ0-91308-003	O-RING	F-4-29
HMJ0-91308-003	O-RING	FOP-17-7
HMR5-16966-000	JOINT, FUEL TUBE	F-13-1
HMT2-17193-000	T-JOINT	E-1-7
HP01-91212-003	OIL SEAL, 31X46X7 (NOK)	E-5-18
HP08-12342-004	SEAL, SPARK PLUG TUBE (NOK)	E-1-4
HP0A-91303-A02	O-RING	E-15-19
HPOX-91321-003	O-RING, 25X2.4 (NOK)	E-3-49
HP13-31141-003	PULLEY	E-19-6
HP13-31147-003	SCREW	E-19-10
HP13-31148-003	SCREW, WAVE WASHER	E-19-12
HP5A-13115-000	CLIP, PISTON PIN	E-7-4
HP5A-31201-005	ROTOR COMP.	E-21-2
HP5A-31243-005	BOLT A, THROUGH	E-21-14
HP5G-16614-003	MESH, FUEL FILTER	E-14-4

HP8A-11812-A00	GROMMET, TIMING BELT COVER	E-13-10-1
HP8A-13204-A01	BOLT, CONNECTING ROD	E-7-5
HP8A-14400-A01	BELT, TIMING (197YU26 B-323)	E-13-6
HP8A-14551-A01	BOLT, IDLER	E-13-13
HP8A-14620-A01	ARM ASSY., INTAKE ROCKER	E-9-10-4
HP8A-14626-A00	ARM COMP. A, EX. ROCKER	E-9-10-5
HP8A-14626-A00	ARM COMP. A, EX. ROCKER	E-9-10-5
HP8A-14626-A00	ARM COMP. A, EX. ROCKER	E-9-10-5
HP8A-14627-A00	ARM COMP. B, EX. ROCKER	E-9-10-6
HP8A-14627-A00	ARM COMP. B, EX. ROCKER	E-9-10-6
HP8A-14627-A00	ARM COMP. B, EX. ROCKER	E-9-10-6
HP8A-14631-A00	SHAFT COMP., INTAKE ROCKER ARM	E-9-10-7
HP8A-14645-A01	SPRING, ROCKER ARM	E-9-10-9
HP8A-14645-A01	SPRING, ROCKER ARM	E-9-10-9
HP8A-14645-A01	SPRING, ROCKER ARM	E-9-10-9
HP8A-15115-A01	PACKING, OIL HOLE	E-3-9
HP8A-15140-A00	ORIFICE ASSY., OIL CONTROL	E-3-10
HP8A-15142-A00	O-RING, 8.8X2.4	E-3-11
HP8A-15150-A00	JOINT ASSY., OIL PIPE	E-3-12
HP8A-90003-A00	BOLT, FLANGE, 8X30	E-9-10-20
HP8A-90004-A00	BOLT, FLANGE, 8X40	E-9-10-21
HP8A-90017-A01	BOLT, SPECIAL, 8X29	E-13-10-9
HP8A-90031-A01	BOLT-WASHER, 12X35	E-13-25
HP8A-90701-A00	DOWEL PIN, 6X10	E-9-14
HP8A-91301-A00	O-RING, 48.5X2.4	E-9-17
HP8A-91308-A01	O-RING, 18.3X3.5	E-3-45
HP8A-91309-A01	O-RING, 16.3X3.5	E-3-47
HP8E-14762-A01	SPRING, EX. VALVE	E-9-10-16
HP8E-17105-A01	GASKET, INTAKE MANIFOLD	E-14-20
HP8E-17105-A01	GASKET, INTAKE MANIFOLD	EOP-1-9
HP8F-14820-A01	MOTION COMP., LOST	E-9-10
HPC6-15233-000	BOLT, SEALING, 18MM	E-5-10
HPC6-91324-000	O-RING, 20.6X2.6	E-5-19
HPC6-91324-000	O-RING, 20.6X2.6	EOP-1-21
HPD1-31138-004	COVER, BEARING	E-19-5
HPD1-31142-004	NUT, PULLEY LOCK	E-19-7
HPD1-31145-004	BOLT, STUD, 6X68	E-19-8
HPD1-90231-014	NUT-WASHER, 5MM	E-19-26
HPD6-90430-003	WASHER, SEALING, 6MM	E-18-51
HPE0-15231-000	VALVE, RELIEF	E-5-8
HPEA-13111-000	PIN, PISTON	E-7-3
HPF0-91302-003	O-RING, 26.9X2.4 (NOK)	EOP-1-17
HPF0-91302-003	O-RING, 26.9X2.4 (NOK)	F-2-44
HPF4-91324-004	O-RING, 28.3X2.4 (NOK)	E-3-10-18
HPG4-91033-013	BEARING, NEEDLE, 50X72X4.5	F-5-1-25
HPG6-15232-000	SPRING, RELIEF VALVE	E-5-9
HPG7-16741-005	O-RING, PRESSURE REGULATOR	E-14-7
HPGK-37835-A01	O-RING	E-14-10-9

HPH1-90015-013	HOLDER, OIL FILTER	E-3-10-8
HPH7-90081-000	BOLT, SEALING, 22MM	E-5-15
HPH7-90081-000	BOLT, SEALING, 22MM	E-5-15
HPH7-90081-000	BOLT, SEALING, 22MM	E-5-15
HPH7-90715-000	DOWEL PIN, 13X37	E-3-40
HPK1-91308-003	O-RING, 26.2X2.4 (NOK)	E-3-46
HPLC-91301-000	O-RING, 7.47X3.6	E-14-33
HPM3-14744-000	SCREW, TAPPET ADJUSTING	E-9-10-13
HPM3-14775-000	SEAT, VALVE SPRING	E-9-10-18
HPM3-90206-004	NUT, TAPPET ADJUSTING	E-9-10-22
HPM3-90206-004	NUT, TAPPET ADJUSTING (TOKAI TRW)	E-9-10-27
HPM3-90206-004	NUT, TAPPET ADJUSTING (TOKAI TRW)	E-9-10-27
HPM3-90206-004	NUT, TAPPET ADJUSTING (TOKAI TRW)	E-9-10-27
HPNA-91214-014	OIL SEAL, 80X98X10 (ARAI)	E-3-42
HPNA-91302-003	O-RING, 7.45X3.61 (NOK)	E-14-34
HPNA-91307-003	O-RING, 9.5X1.9	E-3-44
HPNA-91307-003	O-RING, 9.5X1.9	E-4-23
HPNA-91307-003	O-RING, 9.5X1.9	EOP-1-19
HPNA-91333-003	O-RING, 15X1.9	E-3-50
HPNB-37500-003	SENSOR ASSY., CRANK	E-3-25
HPP4-90009-E01	BOLT, SEALING, 6MM	E-18-45
HPR3-91319-003	O-RING, 13X1.5 (ARAI)	E-3-48
HPR3-91319-003	O-RING, 13X1.5 (ARAI)	EOP-1-20
HPR7-31105-A01	HOLDER ASSY., BRUSH	E-19-1
HPT0-14744-004	SCREW, TAPPET ADJUSTING	E-9-10-14
HPT0-14744-004	SCREW, TAPPET ADJUSTING	E-9-10-26
HPT0-14744-004	SCREW, TAPPET ADJUSTING	E-9-10-26
HPT0-14744-004	SCREW, TAPPET ADJUSTING	E-9-10-26
HPT0-31111-003	BEARING, RR. GENERATOR	E-19-2
HPT0-31114-013	BEARING, FR. GENERATOR	E-19-3
HPT0-31118-003	BUSH, INSULATION	E-19-4
HPT0-31146-003	SCREW	E-19-9
HPT0-31147-003	SCREW-WASHER	E-19-11
HPT0-31148-003	SCREW, WAVE WASHER	E-19-13
HPT0-90005-003	BOLT-WASHER, 12X163	E-9-11
HPT0-90206-004	NUT, TAPPET ADJUSTING	E-9-10-23
HPT0-90206-004	NUT, TAPPET ADJUSTING	E-9-10-27
HPT0-90206-004	NUT, TAPPET ADJUSTING	E-9-10-27
HPT0-90206-004	NUT, TAPPET ADJUSTING	E-9-10-27
HPT0-90705-000	DOWEL PIN, 16X22	E-9-15
HPT2-91005-N01	BEARING, THRUST (F)	F-5-23
HPT2-91005-N01	BEARING, THRUST (F)	F-5-1-24
HPW5-90701-000	DOWEL PIN, 14X15	E-5-16
HPW5-90701-000	DOWEL PIN, 14X15	E-6-10-42
HPY3-17249-000	SPRING, AIR FLOW TUBE	E-15-6
HPY3-31215-004	GEAR ASSY., PLANETARY	E-21-4
HPY3-31218-004	BALL, STEEL	E-21-6
HPZ1-12210-004	SEAL A, VALVE STEM (NOK)	E-9-4

HPZ1-12211-004	SEAL B, VALVE STEM(NOK)	E-9-6
HR70-14646-A00	WASHER, THRUST	E-9-10-24
HR70-14646-A00	WASHER, THRUST	E-9-10-24
HR70-14646-A00	WASHER, THRUST	E-9-10-24
HR70-15280-A00	BODY, OIL JET	E-3-13
HR70-37840-A01	SENSOR ASSY., TDC	E-13-10-6
HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM	E-9-10-8
HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM	E-9-10-8
HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM	E-9-10-8
HRCA-17055-A01	GASKET, FR. INJECTOR BASE	E-14-17
HRCA-17055-A01	GASKET, FR. INJECTOR BASE	EOP-1-7
HRCA-17065-A01	GASKET, RR. INJECTOR BASE	E-14-19
HRCA-17065-A01	GASKET, RR. INJECTOR BASE	EOP-1-8
HRCA-90014-A01	BOLT-WASHER, 11X105	E-3-31
HRCA-90704-A00	KEY, 4.5X24	E-13-28
HRDV-14610-J00	ARM ASSY., FR. INTAKE ROCKER	E-9-10-3
HRDV-14631-J00	SHAFT COMP., FR. INTAKE ROCKER	E-9-10-7
HRDV-14646-J00	WASHER, THRUST	E-9-10-10
HRDV-14765-J00	RETAINER, VALVE SPRING	E-9-10-17
HRGM-14781-A01	COTTER, VALVE(FUJI VALVE)	E-9-10-19
HRJA-14711-000	VALVE, IN.	E-9-10-11
HRJA-14721-E00	VALVE, EX.	E-9-10-12
HRJA-15290-000	BOLT COMP., OIL JET	E-3-14
HRJA-90017-003	BOLT-WASHER, 16X49	E-13-22
HRKG-13210-000	ROD COMP., CONNECTING	E-7-6
HRKG-14761-003	SPRING, VALVE(PINK)	E-9-10-15
HRKG-91213-003	OIL SEAL, 39X53X8(NOK)	E-9-16
HRMA-16723-E00	JOINT, FUEL FEED HOSE	E-18-10-6
HRNA-37260-A01	SENSOR, OIL PRESSURE	E-3-24
HRNA-37830-A01	SENSOR ASSY., MAP	E-14-10-6
HRTA-15400-003	CARTRIDGE, OIL FILTER	E-3-10-4
HRTA-15400-003	CARTRIDGE, OIL FILTER (MAHLE TENNEX)	FOP-18-4
HRTA-15400-003	CARTRIDGE, OIL FILTER (MAHLE TENNEX)	FOP-18-4
HRYE-13211-A01	BEARING A, CONNECTING ROD	E-7-7
HRYE-13212-A01	BEARING B, CONNECTING ROD	E-7-7
HRYE-13213-A01	BEARING C, CONNECTING ROD	E-7-7
HRYE-13214-A01	BEARING D, CONNECTING ROD	E-7-7
HRYE-13215-A01	BEARING E, CONNECTING ROD	E-7-7
HSOA-91541-003	CLIP, HARNESS BAND(BLACK)	F-2-45
HSOA-91541-003	CLIP, HARNESS BAND(BLACK)	F-7-9
HSOA-91541-003	CLIP, HARNESS BAND(BLACK)	F-7-9
HSOA-91541-003	CLIP, HARNESS BAND(BLACK)	F-7-10-26
HSOX-17711-931	RETAINER(BLUE GREEN)(TOKAI)	E-14-22
HSOX-46392-A01	CLIP, BRAKE PIPE	E-15-14
HSAO-90683-003	CLIP, WIRE HARNESS, 25MM	E-1-15
HSAO-90683-003	CLIP, WIRE HARNESS, 25MM	E-20-10-11
HSB2-90650-003	CLIP, WIRE HARNESS, 10MM	E-14-31
HSC2-90649-003	BAND, WIRE HARNESS(NATURAL)	FOP-5-3-23

HSC2-90649-003	BAND, WIRE HARNESS (NATURAL)	FOP-5-4-19
HSD4-91356-952	O-RING, 31.5X2.4 (ARAI)	E-4-24
HSDA-39794-004	RELAY ASSY., FUEL PUMP (DENSO)	F-7-20-5
HSE0-53740-953	CLIP, SENSOR HOSE	E-18-10-24
HSF4-89216-000	WRENCH, PLUG	F-13-3
HSK7-91566-003	CLIP D, WASHER TUBE	E-1-19
HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128.6MM)	FOP-3-5-54
HSTK-91540-003	CLIP, HARNESS BAND (BLACK)	E-18-1-18
HSTK-91540-003	CLIP, HARNESS BAND (BLACK)	FOP-7-5
HVMO-16965-771	CLAMP, HOSE	E-14-15
HVMO-16965-771	CLAMP, HOSE	E-18-10-16
HZ2E-87117-000	LABEL, FUSE (3A)	FOP-3-5-33
HZB7-90691-003	CLIP, HARNESS	E-18-52
HZC0-63515-700	CAP, L. SIDE COVER	F-3-20-34
HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	E-6-12
HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	EOP-1-14
HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	FOP-18-15
HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	FOP-18-15
HZV0-41122-000	PIN, VERTICAL SHAFT	E-13-19
HZV0-90604-000	CLIP, TUBE (B12)	E-18-1-17
HZV0-90604-000	CLIP, TUBE (B12)	E-18-10-28
HZV1-24210-010	SPRING COMP., CLICK	F-10-4
HZV4-12155-A00	METAL, ANODE	E-3-4
HZV4-12155-A00	METAL, ANODE	E-3-4
HZV4-12155-A00	METAL, ANODE	E-3-4
HZV4-12155-A01	METAL, ANODE	E-3-4
HZV4-12155-A01	METAL, ANODE	E-3-4
HZV4-12155-A01	METAL, ANODE	E-3-4
HZV4-17704-010	BAND, TUBE CLIP, 12.5MM	F-13-2
HZV4-24221-010	SPRING, CLICK ASSIST	F-10-5
HZV4-36182-651	CORD COMP., EMERGENCY	FOP-3-3-39
HZV4-36182-651	CORD COMP., EMERGENCY	FOP-5-3-11
HZV4-36182-651	CORD COMP., EMERGENCY	FOP-5-4-8
HZV4-36187-652	CLIP, EMERGENCY LOCK	FOP-5-3-12
HZV4-36187-652	CLIP, EMERGENCY LOCK	FOP-5-4-9
HZV4-90127-000	BOLT, HEX., 6X16	E-6-10
HZV4-90302-000	NUT, SELF-LOCK, 5MM	F-3-17
HZV4-90502-000	WASHER, PLAIN, 5MM	FOP-3-4-43
HZV4-90506-000	WASHER, PLAIN, 6MM	F-8-10
HZV4-90512-000	WASHER, PLAIN, 6MM	F-2-38
HZV4-90512-000	WASHER, PLAIN, 6MM	F-10-62
HZV4-90514-000	WASHER, 10MM	F-10-63
HZV4-90605-000	CLIP, TUBE (B12.5)	E-6-10-41
HZV4-90605-000	CLIP, TUBE (B12.5)	F-3-20-47
HZV4-90605-000	CLIP, TUBE (B12.5)	F-3-20-47
HZV4-90605-000	CLIP, TUBE (B12.5)	F-3-20-47
HZV4-90605-000	CLIP, TUBE (B12.5)	F-3-20-47
HZV4-90605-000	CLIP, TUBE (B12.5)	F-3-20-47

HZV4-90605-000	CLIP, TUBE (B12. 5)	F-3-20-47
HZV4-90605-000	CLIP, TUBE (B12. 5)	E-6-10-55
HZV4-90605-000	CLIP, TUBE (B12. 5)	E-6-10-55
HZV4-90605-000	CLIP, TUBE (B12. 5)	E-6-10-55
HZV5-12155-000	METAL, ANODE	E-4-1
HZV5-12155-000	METAL, ANODE	E-4-1
HZV5-12155-000	METAL, ANODE	E-4-1
HZV5-12155-000	METAL, ANODE	FOP-18-1-2
HZV5-12155-000	METAL, ANODE	FOP-18-1-2
HZV5-12155-000	METAL, ANODE	FOP-18-1-2
HZV5-12155-000	METAL, ANODE	FOP-18-1-2
HZV5-12155-000	METAL, ANODE	FOP-18-1-2
HZV5-12155-010	METAL, ANODE	E-4-1
HZV5-12155-010	METAL, ANODE	E-4-1
HZV5-12155-010	METAL, ANODE	E-4-1
HZV5-12155-010	METAL, ANODE	FOP-18-1-2
HZV5-12155-010	METAL, ANODE	FOP-18-1-2
HZV5-12155-010	METAL, ANODE	FOP-18-1-2
HZV5-12155-010	METAL, ANODE	FOP-18-1-2
HZV5-12155-010	METAL, ANODE	FOP-18-1-2
HZV5-12214-000	WASHER, SEALING (22MM)	E-3-8
HZV5-12214-000	WASHER, SEALING (22MM)	E-3-10-3
HZV5-32823-003	PLUG, INNER CONNECTOR	FOP-3-3-32
HZV5-32823-003	PLUG, INNER CONNECTOR	FOP-5-6
HZV5-32823-003	PLUG, INNER CONNECTOR	FOP-5-1-6
HZV5-32823-003	PLUG, INNER CONNECTOR	FOP-5-2-6
HZV5-32823-003	PLUG, INNER CONNECTOR	FOP-5-3-7
HZV5-32823-003	PLUG, INNER CONNECTOR	FOP-5-4-4
HZV5-32824-003	PLUG, OUTER CONNECTOR	FOP-3-3-33
HZV5-32824-003	PLUG, OUTER CONNECTOR	FOP-5-7
HZV5-32824-003	PLUG, OUTER CONNECTOR	FOP-5-1-7
HZV5-32824-003	PLUG, OUTER CONNECTOR	FOP-5-2-7
HZV5-32824-003	PLUG, OUTER CONNECTOR	FOP-5-3-8
HZV5-32824-003	PLUG, OUTER CONNECTOR	FOP-5-4-5
HZV5-36136-821	SPRING, MOTOR	F-11-9
HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	FOP-3-3-38
HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	FOP-5-3-10
HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	FOP-5-4-7
HZV5-38410-003	BUZZER COMP., WARNING	FOP-3-3-42
HZV5-38410-003	BUZZER COMP., WARNING	FOP-5-3-16
HZV5-38410-003	BUZZER COMP., WARNING	FOP-5-4-12
HZV5-40102-000	GROMMET, UNDER CASE	E-15-13
HZV5-40102-000	GROMMET, UNDER CASE	F-3-30-1
HZV5-41171-000	END, NIPPLE	F-10-10
HZV5-41172-000	NIPPLE, SENSOR	F-10-11
HZV5-41172-000	NIPPLE, SENSOR	F-10-12
HZV5-50214-003	BUSH, SWIVEL CASE	F-11-12
HZV5-56117-821	RING, BACK UP	F-11-19

HZVK-16400-003	THROTTLE BODY ASSY.	E-15-3
HZVK-16400-013	THROTTLE BODY ASSY.	E-15-3
HZVK-16400-023	THROTTLE BODY ASSY.	E-15-3
HZVK-34750-901	CONTROL UNIT, ELECTRONIC	E-20-10-6
HZVK-34750-902	CONTROL UNIT, ELECTRONIC	E-20-10-6
HZVK-34750-903	CONTROL UNIT, ELECTRONIC	E-20-10-6
HZVK-87121-P00	MARK, RR. (BFT225)	F-12-3
HZVK-87301-P00	MARK, FR. (BFT225)	F-12-7
HZVL-06115-010	GASKET KIT (BF175/200/225/250)	EOP-1-1
HZVL-06126-000	BOLT KIT, SEALING (22MM)	E-3-55
HZVL-06160-000	STRAINER ASSY., FUEL (HIGH)	E-14-36
HZVL-06160-010	STRAINER ASSY., FUEL (HIGH)	FOP-18-1
HZVL-06160-010	STRAINER ASSY., FUEL (HIGH)	FOP-18-1
HZVL-06161-000	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-000	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-000	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-000	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-000	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400)	FOP-18-1-1
HZVL-06328-601	CABLE KIT, INTERFACE (10FT)	FOP-7-1
HZVL-06328-701	CABLE KIT, INTERFACE (16FT)	FOP-7-1
HZVL-06328-800	CONNECTOR KIT, TERMINATOR	FOP-10-1
HZVL-06510-010	MAINTENANCE KIT (200)	FOP-18-3
HZVL-06510-010	MAINTENANCE KIT (200)	FOP-18-3
HZVL-11100-900	CRANKCASE COMP.	E-3-10-1
HZVL-11100-900	CRANKCASE COMP.	E-3-10-1
HZVL-11100-900	CRANKCASE COMP.	E-3-10-1
HZVL-11100-901	CRANKCASE COMP.	E-3-10-1
HZVL-11100-901	CRANKCASE COMP.	E-3-10-1
HZVL-11100-901	CRANKCASE COMP.	E-3-10-1
HZVL-11200-000	COVER ASSY., CRANKCASE UPPER	E-3-1
HZVL-11200-000	COVER ASSY., CRANKCASE UPPER	E-3-1
HZVL-11200-000	COVER ASSY., CRANKCASE UPPER	E-3-1
HZVL-11200-010	COVER ASSY., CRANKCASE UPPER	E-3-1
HZVL-11200-010	COVER ASSY., CRANKCASE UPPER	E-3-1
HZVL-11200-010	COVER ASSY., CRANKCASE UPPER	E-3-1
HZVL-11310-000ZA	PAN ASSY., OIL	E-6-1
HZVL-11381-003	PACKING, OIL PAN	E-6-2
HZVL-11381-003	PACKING, OIL PAN	EOP-1-2
HZVL-11820-000	COVER ASSY., R. TIMING BELT	E-13-10-2
HZVL-11840-000	COVER ASSY., L. TIMING BELT	E-13-10-3
HZVL-11861-000	PLATE, L. TIMING BELT COVER	E-13-10-4
HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3
HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3

HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3
HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3
HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3
HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3
HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3
HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3
HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	E-3-3
HZVL-12210-000ZA	HEAD COMP., CYLINDER	E-9-5
HZVL-12210-000ZA	HEAD COMP., CYLINDER	E-9-5
HZVL-12210-000ZA	HEAD COMP., CYLINDER	E-9-5
HZVL-12210-010ZA	HEAD COMP., CYLINDER	E-9-5
HZVL-12210-010ZA	HEAD COMP., CYLINDER	E-9-5
HZVL-12210-010ZA	HEAD COMP., CYLINDER	E-9-5
HZVL-12231-000	COVER, R. CAMSHAFT THRUST	E-9-7
HZVL-12310-405ZA	COVER COMP., CYLINDER HEAD (R.)	E-1-1
HZVL-12320-405ZA	COVER COMP., CYLINDER HEAD (L.)	E-1-3
HZVL-13622-000	PLATE, CRANK PULSER	E-13-2
HZVL-14270-000	PULLEY COMP., L. TIMING BELT	E-13-5
HZVL-14526-415ZA	BASE COMP., TIMING BELT TENSIONER *NH8* DARK GRAY	E-13-10
HZVL-14553-003	BOLT, TIMING BELT IDLER	E-13-14
HZVL-14553-003	BOLT, TIMING BELT IDLER	E-13-14
HZVL-14553-003	BOLT, TIMING BELT IDLER	E-13-14
HZVL-14553-013	BOLT, TIMING BELT IDLER	E-13-14
HZVL-14553-013	BOLT, TIMING BELT IDLER	E-13-14
HZVL-14553-013	BOLT, TIMING BELT IDLER	E-13-14
HZVL-14626-700	ARM COMP. A, EX. ROCKER	E-9-10-5
HZVL-14626-700	ARM COMP. A, EX. ROCKER	E-9-10-5
HZVL-14626-700	ARM COMP. A, EX. ROCKER	E-9-10-5
HZVL-14627-700	ARM COMP. B, EX. ROCKER	E-9-10-6
HZVL-14627-700	ARM COMP. B, EX. ROCKER	E-9-10-6
HZVL-14627-700	ARM COMP. B, EX. ROCKER	E-9-10-6
HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM	E-9-10-8
HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM	E-9-10-8
HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM	E-9-10-8
HZVL-14645-700	SPRING, ROCKER ARM	E-9-10-9
HZVL-14645-700	SPRING, ROCKER ARM	E-9-10-9
HZVL-14645-700	SPRING, ROCKER ARM	E-9-10-9
HZVL-14646-700	WASHER, THRUST	E-9-10-25
HZVL-14646-700	WASHER, THRUST	E-9-10-25
HZVL-14646-700	WASHER, THRUST	E-9-10-25
HZVL-15100-000ZA	PUMP ASSY., OIL	E-5-1
HZVL-15100-000ZA	PUMP ASSY., OIL	E-5-1
HZVL-15100-000ZA	PUMP ASSY., OIL	E-5-1
HZVL-15100-010ZA	PUMP ASSY., OIL	E-5-1
HZVL-15100-010ZA	PUMP ASSY., OIL	E-5-1
HZVL-15100-010ZA	PUMP ASSY., OIL	E-5-1
HZVL-15655-000	GAUGE COMP., OIL LEVEL	E-3-15
HZVL-15656-000	COVER, OIL LEVEL GAUGE	E-3-16

HZVL-15810-003ZA	VALVE ASSY., SPOOL	E-3-18
HZVL-16015-000	BODY	E-18-3
HZVL-16020-003	COVER COMP.	E-18-4
HZVL-16030-003	PUMP UNIT SET A, FUEL	E-18-7
HZVL-16700-003	PUMP ASSY., FUEL	E-18-27
HZVL-16710-000	RUBBER, FUEL PUMP	E-18-30
HZVL-16725-000	STAY COMP. A, FUEL PUMP	E-18-35
HZVL-16726-000	STAY COMP. B, FUEL PUMP	E-18-36
HZVL-16730-023	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16730-023	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16730-023	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16730-033	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16730-033	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16730-033	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16730-043	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16730-043	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16730-043	SEPARATOR ASSY., VAPOR	E-18-37
HZVL-16748-000	TUBE, PRESSURE REGULATOR	E-14-8
HZVL-16755-003	HOSE COMP., FUEL	E-14-10
HZVL-16760-003	VALVE COMP., RELIEF	E-18-10-7
HZVL-16765-003	HOSE COMP. B, FUEL	E-14-12
HZVL-16770-000	TUBE, RELIEF	E-18-10-8
HZVL-16805-003	CUP SET, WATER SEPARATER	E-18-1-19
HZVL-16840-000	TUBE COMP. A, FUEL	E-18-1-2
HZVL-16841-000	STAY, FUEL TUBE	E-18-1-3
HZVL-16850-000	TUBE COMP. B, FUEL	E-18-1-4
HZVL-16860-000	TUBE COMP. C, FUEL	E-18-10-9
HZVL-16870-000	TUBE D, FUEL	E-18-10-10
HZVL-16875-000	JOINT, THREE WAY	E-18-10-11
HZVL-16880-000	TUBE E, FUEL	E-18-10-12
HZVL-16890-000	TUBE F, FUEL	E-18-10-13
HZVL-16900-003	STRAINER ASSY., FUEL (LOW)	E-18-1-6
HZVL-16910-003	STRAINER COMP., FUEL (HIGH)	E-14-13
HZVL-16914-000	STAY A, FUEL STRAINER	E-18-1-9
HZVL-16916-000	STAY B, FUEL STRAINER	E-1-6
HZVL-16917-000	SUSPENSION, STRAINER	E-14-14
HZVL-17110-003	MANIFOLD COMP., INLET	E-14-10-3
HZVL-17131-000ZA	COVER, INTAKE MANIFOLD UPPER	E-14-10-4
HZVL-17877-900	PLATE, REMOTE CONTROL CABLE	F-2-2
HZVL-17878-900	COVER, REMOTE CONTROL CABLE	F-2-3
HZVL-17910-003	CABLE COMP., THROTTLE	E-15-9
HZVL-17932-900	SHAFT, THROTTLE ARM	F-2-5
HZVL-18110-000ZA	MANIFOLD COMP., R. EX.	E-4-2
HZVL-18120-000ZA	MANIFOLD COMP., L. EX.	E-4-4
HZVL-18333-003	GASKET, EX. PIPE	E-6-4
HZVL-18333-003	GASKET, EX. PIPE	EOP-1-12
HZVL-19241-000	HOUSING, WATER PUMP	F-4-6
HZVL-19241-000	HOUSING, WATER PUMP	F-4-6

HZVL-19241-010	HOUSING, WATER PUMP	F-4-6
HZVL-19255-010	TUBE, R. WATER RETURN	E-4-6
HZVL-19255-010	TUBE, R. WATER RETURN	E-4-6
HZVL-19255-020	TUBE, R. WATER RETURN	E-4-6
HZVL-19255-020	TUBE, R. WATER RETURN	E-4-6
HZVL-19255-020	TUBE, R. WATER RETURN	E-4-6
HZVL-19257-000	TUBE, WATER	E-6-10-7
HZVL-19274-000	SEAT, WATER JOINT	F-3-20-5
HZVL-19313-010ZA	SPACER, THERMOSTAT COVER	E-4-12
HZVL-19315-010ZA	COVER, THERMOSTAT	E-4-13
HZVL-19361-010	COVER, R. WATER JACKET	E-6-10-21
HZVL-19362-000	PACKING, WATER JACKET COVER	E-6-10-22
HZVL-19366-010	COVER, L. WATER JACKET	E-6-10-23
HZVL-19540-000	COVER ASSY., COOLING FAN	E-15-10
HZVL-19540-000	COVER ASSY., COOLING FAN	E-15-10
HZVL-19540-000	COVER ASSY., COOLING FAN	E-15-10
HZVL-19540-010	COVER ASSY., COOLING FAN	E-15-10
HZVL-19540-010	COVER ASSY., COOLING FAN	E-15-10
HZVL-19540-010	COVER ASSY., COOLING FAN	E-15-10
HZVL-23170-020ZA	CASE COMP., MOUNT	E-6-10-24
HZVL-23172-003	GASKET, MOUNT CASE	E-6-10-25
HZVL-23172-003	GASKET, MOUNT CASE	EOP-1-13
HZVL-24621-000	PIVOT, THROTTLE	F-2-17
HZVL-24622-000	PLATE, LOCK	F-2-18
HZVL-24627-900	GUIDE, SHIFT LINK(MECH)	F-2-20
HZVL-24628-900	BRACKET, SHIFT LINK(MECH)	F-2-21
HZVL-24640-900	LINK ASSY., SHIFT	F-2-48
HZVL-30416-000	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30416-000	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30416-000	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30416-010	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30416-010	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30416-010	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30416-020	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30416-020	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30416-020	CASE, ELECTRONIC PARTS	E-20-10-1
HZVL-30520-003	COIL ASSY., PLUG TOP	E-20-1
HZVL-30525-000	STAY COMP., PLUG TOP COIL	E-20-2
HZVL-30531-000	GUARD, R. PLUG TOP COIL SIDE	E-20-8
HZVL-30536-000	GUARD, L. PLUG TOP COIL SIDE	E-20-9
HZVL-31575-000	HARNESS ASSY., POWER	F-7-10-27
HZVL-31575-000	HARNESS ASSY., POWER	F-7-10-27
HZVL-31575-000	HARNESS ASSY., POWER	F-7-10-27
HZVL-31575-000	HARNESS ASSY., POWER	F-7-10-27
HZVL-31575-010	HARNESS ASSY., POWER	F-7-10-27
HZVL-31575-010	HARNESS ASSY., POWER	F-7-10-27
HZVL-31575-010	HARNESS ASSY., POWER	F-7-10-27
HZVL-31575-010	HARNESS ASSY., POWER	F-7-10-27

HZVL-31575-010	HARNESS ASSY., POWER	F-7-10-27
HZVL-31576-000	CORD ASSY., EXTENSION POWER	FOP-10-6
HZVL-31637-000	STAY, A. C. GENERATOR	E-19-16
HZVL-32100-900	HARNESS ASSY., MAIN WIRE	F-7-1
HZVL-32101-000	BRACKET, A. C. GENERATOR FUSE	E-20-10-3
HZVL-32102-000	BRACKET, COUPLER A	E-20-10-4
HZVL-32103-000	BRACKET, COUPLER C	F-7-10-2
HZVL-32104-000	BRACKET, FUEL PUMP COUPLER	E-1-8
HZVL-32106-000	BRACKET, JUNCTION CONNECTOR	F-7-2
HZVL-32108-003	DUMMY, WATER PROOF CONNECTOR	F-7-3
HZVL-32111-000	BRACKET, COUPLER D	E-13-18
HZVL-32114-000	BRACKET, CLIP B	E-1-9
HZVL-32114-000	BRACKET, CLIP B	E-3-21
HZVL-32193-000	CORD, SWITCH	E-3-22
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	F-7-10-3
HZVL-32421-000	PLATE, STARTER CABLE	F-7-10-8
HZVL-32580-900	CABLE ASSY., PANEL INDICATOR	FOP-10-2
HZVL-32580-910	CABLE ASSY., PANEL INDICATOR	FOP-10-2
HZVL-32580-920	CABLE ASSY., PANEL INDICATOR	FOP-10-2
HZVL-32590-900	CABLE ASSY., CONVERSION (6FT)	FOP-10-5
HZVL-32590-900	CABLE ASSY., CONVERSION (6FT)	FOP-10-5
HZVL-32590-900	CABLE ASSY., CONVERSION (6FT)	FOP-10-5
HZVL-32590-901	CABLE ASSY., CONVERSION (6FT)	FOP-10-5
HZVL-32590-901	CABLE ASSY., CONVERSION (6FT)	FOP-10-5
HZVL-32590-910	CABLE ASSY., CONVERSION (10FT)	FOP-10-5
HZVL-32590-910	CABLE ASSY., CONVERSION (10FT)	FOP-10-5
HZVL-32590-910	CABLE ASSY., CONVERSION (10FT)	FOP-10-5
HZVL-32590-910	CABLE ASSY., CONVERSION (10FT)	FOP-10-5
HZVL-32590-911	CABLE ASSY., CONVERSION (10FT)	FOP-10-5
HZVL-32590-911	CABLE ASSY., CONVERSION (10FT)	FOP-10-5
HZVL-32800-600	CABLE ASSY., INTERFACE (10FT)	FOP-7-2
HZVL-32800-700	CABLE ASSY., INTERFACE (16FT)	FOP-7-2
HZVL-32806-000	TERMINATOR (M)	FOP-10-3
HZVL-32807-000	TERMINATOR (F)	FOP-10-4
HZVL-32815-000	CABLE ASSY., NETWORK (6FT)	FOP-10-7
HZVL-32815-600	CABLE ASSY., NETWORK (16FT)	FOP-10-7
HZVL-32815-700	CABLE ASSY., NETWORK (32FT)	FOP-10-7
HZVL-32815-800	CABLE ASSY., NETWORK (49FT)	FOP-10-7

HZVL-34750-901	CONTROL UNIT, ELECTRONIC	E-20-10-6
HZVL-34750-902	CONTROL UNIT, ELECTRONIC	E-20-10-6
HZVL-34750-903	CONTROL UNIT, ELECTRONIC	E-20-10-6
HZVL-34754-000	CASE, ELECTRONIC CONTROL UNIT	E-20-10-7
HZVL-35477-000	COVER, NEUTRAL SWITCH	F-2-25
HZVL-36104-000	TUBE, SPIRAL (12X14.6)	F-11-4
HZVL-37831-000	STAY, MAP SENSOR	E-14-10-7
HZVL-37832-000	COLLAR, 5.5X6.8	E-14-10-8
HZVL-37832-000	COLLAR, 5.5X6.8	E-14-10-8
HZVL-37832-000	COLLAR, 5.5X6.8	E-14-10-8
HZVL-37832-010	COLLAR, 5.5X6.8	E-14-10-8
HZVL-37832-010	COLLAR, 5.5X6.8	E-14-10-8
HZVL-37832-010	COLLAR, 5.5X6.8	E-14-10-8
HZVL-38216-901	COVER ASSY., FUSE (3A)	FOP-3-5-30
HZVL-38550-003	RELAY ASSY., POWER TILT	F-7-10-10
HZVL-40100-000	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-000	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-000	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-000	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-000	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-000	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-010	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-010	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-010	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-010	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-010	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40100-010	CASE ASSY., ENGINE UNDER	F-3-20-10
HZVL-40102-000	SEAL A, UNDER CASE	F-3-20-11
HZVL-40103-000	SEAL B, UNDER CASE	F-3-20-12
HZVL-40105-900	GROMMET, UNDER CASE (MECH)	F-3-20-13
HZVL-40110-000	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-000	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-000	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-000	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-000	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-000	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-010	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-010	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-010	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-010	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-010	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-010	STAY COMP., HARNESS	F-3-20-14
HZVL-40110-010	STAY COMP., HARNESS	F-3-20-14
HZVL-40116-000	PORT, IDLE EXHAUST	F-3-20-15
HZVL-40151-000	COVER, SEPARATE	F-3-20-16
HZVL-40154-000	BRACKET, UNDER CASE FR.	F-3-20-17
HZVL-40201-000	CASE, EXTENSION (XL)	F-3-20-18
HZVL-40201-900	CASE, EXTENSION (L)	F-3-20-19
HZVL-40209-000	RUBBER, DRAIN PLUG	F-3-20-20

HZVL-41100-000ZA	CASE ASSY., GEAR (XL)	F-3-10-1
HZVL-41100-020ZA	CASE ASSY., GEAR (XL)	F-3-10-1
HZVL-41100-020ZA	CASE ASSY., GEAR (XL)	F-3-10-1
HZVL-41100-020ZA	CASE ASSY., GEAR (XL)	F-3-10-1
HZVL-41100-030ZA	CASE ASSY., GEAR (XL)	F-3-10-1
HZVL-41100-030ZA	CASE ASSY., GEAR (XL)	F-3-10-1
HZVL-41100-030ZA	CASE ASSY., GEAR (XL)	F-3-10-1
HZVL-41100-700ZA	CASE ASSY., GEAR (XL)	F-3-10-1
HZVL-41100-701ZA	CASE ASSY., GEAR (XL) (COUNTER ROTATION)	F-3-10-1
HZVL-41100-702ZA	CASE ASSY., GEAR (XL) (COUNTER ROTATION)	F-3-10-1
HZVL-41100-702ZA	CASE ASSY., GEAR (XL) (COUNTER ROTATION)	F-3-10-1
HZVL-41100-703ZA	CASE ASSY., GEAR (XL) (COUNTER ROTATION)	F-3-10-1
HZVL-41100-703ZA	CASE ASSY., GEAR (XL) (COUNTER ROTATION)	F-3-10-1
HZVL-41100-900ZA	CASE ASSY., GEAR (L)	F-3-10-1
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-1-12
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-1-12
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-1-12
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-11
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-11
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-11
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-1-12
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-1-12
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	F-5-1-12
HZVL-50100-000	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING (XL)	F-10-13
HZVL-50100-900	FRAME COMP., MOUNTING (L)	F-10-13
HZVL-50100-901	FRAME COMP., MOUNTING (L)	F-10-13
HZVL-50109-000	HOUSING, UPPER MOUNTING	F-10-14
HZVL-50166-000	COVER, UPPER MOUNT	F-10-18
HZVL-50166-000	COVER, UPPER MOUNT	F-10-18
HZVL-50166-000	COVER, UPPER MOUNT	F-10-18
HZVL-50166-000	COVER, UPPER MOUNT	F-10-18
HZVL-50166-000	COVER, UPPER MOUNT	F-10-18
HZVL-50166-000	COVER, UPPER MOUNT	F-10-18
HZVL-50166-000	COVER, UPPER MOUNT	F-10-18

HZVL-50166-000	COVER, UPPER MOUNT	F-10-18
HZVL-50166-010	COVER, UPPER MOUNT	F-10-18
HZVL-50166-010	COVER, UPPER MOUNT	F-10-18
HZVL-50166-010	COVER, UPPER MOUNT	F-10-18
HZVL-50166-010	COVER, UPPER MOUNT	F-10-18
HZVL-50166-010	COVER, UPPER MOUNT	F-10-18
HZVL-50201-000ZA	CASE, SWIVEL (XL)	F-10-19
HZVL-50201-900ZA	CASE, SWIVEL (L)	F-10-19
HZVL-50222-000	BRACKET, TILT LIMIT SWITCH	F-10-22
HZVL-50311-000ZA	BRACKET, L. STERN	F-10-26
HZVL-50381-000	SHAFT, TILTING	F-10-27
HZVL-50381-000	SHAFT, TILTING	F-10-27
HZVL-50381-000	SHAFT, TILTING	F-10-27
HZVL-50381-000	SHAFT, TILTING	F-10-27
HZVL-50381-000	SHAFT, TILTING	F-10-27
HZVL-50381-010	SHAFT, TILTING	F-10-27
HZVL-50381-010	SHAFT, TILTING	F-10-27
HZVL-50381-010	SHAFT, TILTING	F-10-27
HZVL-50381-010	SHAFT, TILTING	F-10-27
HZVL-50381-010	SHAFT, TILTING	F-10-27
HZVL-50529-000	STOPPER, TILT	F-10-30
HZVL-56539-000	SHAFT, LOWER CYLINDER	F-10-34
HZVL-63100-P01ZA	COVER ASSY., ENGINE	F-8-1
HZVL-63107-000	BRACKET, HOOK FR.	F-8-2
HZVL-63108-000	GROMMET, LOCK HOOK	F-8-3
HZVL-63109-000	ROLLER, HOOK	F-8-4
HZVL-63112-000	BRACKET, HOOK R.	F-8-5
HZVL-63117-000	BRACKET, HOOK L.	F-8-6
HZVL-63119-000	SPRING, LEVER RETURN	F-3-20-26
HZVL-63210-000	LEVER, COVER LOCK FR.	F-3-20-27
HZVL-63212-000	HOOK COMP., COVER LOCK R.	F-3-20-28
HZVL-63213-000	COLLAR A, COVER LOCK	F-3-20-29
HZVL-63214-000	COLLAR B, COVER LOCK	F-3-20-30
HZVL-63220-000	LEVER, COVER LOCK R.	F-3-20-31
HZVL-63222-000	HOOK COMP., COVER LOCK L.	F-3-20-32
HZVL-63230-000	LEVER, COVER LOCK L.	F-3-20-33
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	F-3-30-3

HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R.	F-3-30-4
HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. (XL)	F-3-30-5
HZVL-63715-900ZA	COVER COMP., ENGINE UNDER L.	F-3-30-6
HZVL-63721-000	COVER, RR.	F-3-30-7
HZVL-63721-000	COVER, RR.	F-3-30-7
HZVL-63721-000	COVER, RR.	F-3-30-7
HZVL-63730-000	COVER COMP., RR.	F-3-30-7
HZVL-63730-000	COVER COMP., RR.	F-3-30-7
HZVL-82873-000	GROMMET, WATER CHECK	F-3-20-35
HZVL-87117-L00	LABEL, FUSE & OIL CAUTION(EF)	F-12-1
HZVL-87121-P00	MARK, RR. (BFT250)	F-12-4
HZVL-87132-P00	MARK, SIDE STRIPE	F-12-5
HZVL-87301-P00	MARK, FR. (BFT250)	F-12-8
HZVL-87302-P01	MARK, FR. EMBLEM	F-12-9
HZVL-90001-000	BOLT, FLANGE, 12X95	E-3-26
HZVL-90001-000	BOLT, FLANGE, 12X95	E-3-26
HZVL-90001-000	BOLT, FLANGE, 12X95	E-3-26
HZVL-90001-010	BOLT, FLANGE, 12X95	E-3-26
HZVL-90001-010	BOLT, FLANGE, 12X95	E-3-26
HZVL-90001-010	BOLT, FLANGE, 12X95	E-3-26
HZVL-90003-000	BOLT, FLANGE, 10X110	E-21-19
HZVL-90003-000	BOLT, FLANGE, 10X110	E-21-19
HZVL-90003-000	BOLT, FLANGE, 10X110	E-21-19
HZVL-90003-010	BOLT, FLANGE, 10X110	E-21-19
HZVL-90003-010	BOLT, FLANGE, 10X110	E-21-19
HZVL-90003-010	BOLT, FLANGE, 10X110	E-21-19
HZVL-90004-000	BOLT-WASHER, 5X16	E-13-10-7
HZVL-90004-000	BOLT-WASHER, 5X16	E-13-10-7
HZVL-90004-000	BOLT-WASHER, 5X16	E-13-10-7
HZVL-90004-010	BOLT-WASHER, 5X16	E-13-10-7
HZVL-90004-010	BOLT-WASHER, 5X16	E-13-10-7
HZVL-90004-010	BOLT-WASHER, 5X16	E-13-10-7
HZVL-90005-000	BOLT, FLANGE, 10X90	E-21-20
HZVL-90005-000	BOLT, FLANGE, 10X90	E-21-20
HZVL-90005-000	BOLT, FLANGE, 10X90	E-21-20
HZVL-90005-010	BOLT, FLANGE, 10X90	E-21-20
HZVL-90005-010	BOLT, FLANGE, 10X90	E-21-20
HZVL-90005-010	BOLT, FLANGE, 10X90	E-21-20
HZVL-90006-003	BOLT-WASHER, 10X109	E-3-27

HZVL-90006-003	BOLT-WASHER, 10X109	E-3-27
HZVL-90006-003	BOLT-WASHER, 10X109	E-3-27
HZVL-90006-013	BOLT-WASHER, 10X109	E-3-27
HZVL-90006-013	BOLT-WASHER, 10X109	E-3-27
HZVL-90006-013	BOLT-WASHER, 10X109	E-3-27
HZVL-90007-000	BOLT, TIMING BELT COVER	E-13-10-8
HZVL-90008-003	BOLT-WASHER, 10X60	E-3-28
HZVL-90008-003	BOLT-WASHER, 10X60	E-3-28
HZVL-90008-003	BOLT-WASHER, 10X60	E-3-28
HZVL-90008-013	BOLT-WASHER, 10X60	E-3-28
HZVL-90008-013	BOLT-WASHER, 10X60	E-3-28
HZVL-90008-013	BOLT-WASHER, 10X60	E-3-28
HZVL-90009-003	BOLT-WASHER, 10X80	E-3-29
HZVL-90009-003	BOLT-WASHER, 10X80	E-3-29
HZVL-90009-003	BOLT-WASHER, 10X80	E-3-29
HZVL-90009-013	BOLT-WASHER, 10X80	E-3-29
HZVL-90009-013	BOLT-WASHER, 10X80	E-3-29
HZVL-90009-013	BOLT-WASHER, 10X80	E-3-29
HZVL-90011-000	BOLT, SPECIAL ADJUSTER	E-19-22
HZVL-90013-000	BOLT-WASHER, 5X12	E-14-10-11
HZVL-90013-000	BOLT-WASHER, 5X12	E-14-10-11
HZVL-90013-000	BOLT-WASHER, 5X12	E-14-10-11
HZVL-90013-010	BOLT-WASHER, 5X12	E-14-10-11
HZVL-90013-010	BOLT-WASHER, 5X12	E-14-10-11
HZVL-90013-010	BOLT-WASHER, 5X12	E-14-10-11
HZVL-90014-000	BOLT-WASHER, 5X28	E-14-10-12
HZVL-90014-000	BOLT-WASHER, 5X28	E-14-10-12
HZVL-90014-000	BOLT-WASHER, 5X28	E-14-10-12
HZVL-90014-010	BOLT-WASHER, 5X28	E-14-10-12
HZVL-90014-010	BOLT-WASHER, 5X28	E-14-10-12
HZVL-90014-010	BOLT-WASHER, 5X28	E-14-10-12
HZVL-90015-000	BOLT-WASHER, 6X27	E-20-5
HZVL-90015-000	BOLT-WASHER, 6X27	E-20-10-8
HZVL-90015-010	BOLT-WASHER, 6X27	F-7-10-14
HZVL-90017-701	SCREW, TAPPET ADJUSTING	E-9-10-26
HZVL-90017-701	SCREW, TAPPET ADJUSTING	E-9-10-26
HZVL-90017-701	SCREW, TAPPET ADJUSTING	E-9-10-26
HZVL-90020-000	BOLT, FLANGE, 8X50	E-3-34
HZVL-90020-000	BOLT, FLANGE, 8X50	E-3-34
HZVL-90020-000	BOLT, FLANGE, 8X50	E-3-34
HZVL-90020-010	BOLT, FLANGE, 8X50	E-3-34
HZVL-90020-010	BOLT, FLANGE, 8X50	E-3-34
HZVL-90020-010	BOLT, FLANGE, 8X50	E-3-34
HZVL-90020-010	BOLT, FLANGE, 8X50	E-14-10-15
HZVL-90020-010	BOLT, FLANGE, 8X50	E-14-10-15
HZVL-90020-010	BOLT, FLANGE, 8X50	E-14-10-15
HZVL-90023-000	BOLT, FLANGE, 6X22	E-14-10-13
HZVL-90028-000	BOLT, FLANGE, 6X18	E-3-35

HZVL-90028-000	BOLT, FLANGE, 6X18	E-3-35
HZVL-90028-000	BOLT, FLANGE, 6X18	E-3-35
HZVL-90028-010	BOLT, FLANGE, 6X18	E-3-35
HZVL-90028-010	BOLT, FLANGE, 6X18	E-3-35
HZVL-90028-010	BOLT, FLANGE, 6X18	E-3-35
HZVL-90034-000	BOLT, FLANGE, 6X60	E-4-17
HZVL-90035-000	BOLT, FLANGE, 8X28	E-9-13
HZVL-90037-000	BOLT, FLANGE, 8X65	E-15-17
HZVL-90038-000	BOLT, FLANGE, 8X75	E-3-37
HZVL-90038-000	BOLT, FLANGE, 8X75	E-3-37
HZVL-90038-000	BOLT, FLANGE, 8X75	E-3-37
HZVL-90038-010	BOLT, FLANGE, 8X75	E-3-37
HZVL-90038-010	BOLT, FLANGE, 8X75	E-3-37
HZVL-90038-010	BOLT, FLANGE, 8X75	E-3-37
HZVL-90039-000	BOLT, FLANGE, 10X40	E-13-26
HZVL-90039-000	BOLT, FLANGE, 10X40	E-13-26
HZVL-90039-000	BOLT, FLANGE, 10X40	E-13-26
HZVL-90039-010	BOLT, FLANGE, 10X40	E-13-26
HZVL-90039-010	BOLT, FLANGE, 10X40	E-13-26
HZVL-90039-010	BOLT, FLANGE, 10X40	E-13-26
HZVL-90040-000	BOLT, FLANGE, 10X43	E-13-27
HZVL-90041-000	BOLT, FLANGE, 10X55	E-3-10-10
HZVL-90043-000	BOLT, STUD, 8X28	E-14-28
HZVL-90043-000	BOLT, STUD, 8X28	E-14-28
HZVL-90043-000	BOLT, STUD, 8X28	E-14-28
HZVL-90043-010	BOLT, STUD, 8X28	E-14-28
HZVL-90043-010	BOLT, STUD, 8X28	E-14-28
HZVL-90043-010	BOLT, STUD, 8X28	E-14-28
HZVL-90045-000	BOLT, STUD, 10X45	E-6-10-33
HZVL-90045-000	BOLT, STUD, 10X45	E-6-10-33
HZVL-90045-000	BOLT, STUD, 10X45	E-6-10-33
HZVL-90045-010	BOLT, STUD, 10X45	E-6-10-33
HZVL-90045-010	BOLT, STUD, 10X45	E-6-10-33
HZVL-90045-010	BOLT, STUD, 10X45	E-6-10-33
HZVL-90046-000	BOLT, FLANGE, 8X120	E-6-10-34
HZVL-90049-000	BOLT, FLANGE, 8X30	E-6-10-35
HZVL-90049-000	BOLT, FLANGE, 8X30	E-6-10-35
HZVL-90049-000	BOLT, FLANGE, 8X30	E-6-10-35
HZVL-90049-010	BOLT, FLANGE, 8X30	E-6-10-35
HZVL-90049-010	BOLT, FLANGE, 8X30	E-6-10-35
HZVL-90049-010	BOLT, FLANGE, 8X30	E-6-10-35
HZVL-90055-010	BOLT, TENSIONER	E-19-24
HZVL-90055-010	BOLT, TENSIONER	E-19-24
HZVL-90055-010	BOLT, TENSIONER	E-19-24
HZVL-90063-000	BOLT, FLANGE, 6X37	E-3-10-12
HZVL-90063-000	BOLT, FLANGE, 6X37	E-3-10-12
HZVL-90063-000	BOLT, FLANGE, 6X37	E-3-10-12
HZVL-90063-010	BOLT, FLANGE, 6X37	E-3-10-12

HZVL-90063-010	BOLT, FLANGE, 6X37	E-3-10-12
HZVL-90063-010	BOLT, FLANGE, 6X37	E-3-10-12
HZVL-90070-000	BOLT-WASHER, 8X35 (SUS)	E-6-8
HZVL-90070-000	BOLT-WASHER, 8X35 (SUS)	E-6-8
HZVL-90070-000	BOLT-WASHER, 8X35 (SUS)	E-6-8
HZVL-90070-010	BOLT-WASHER, 8X35 (SUS)	E-6-8
HZVL-90070-010	BOLT-WASHER, 8X35 (SUS)	E-6-8
HZVL-90070-010	BOLT-WASHER, 8X35 (SUS)	E-6-8
HZVL-90071-000	BOLT-WASHER, 8X28 (SUS)	E-6-9
HZVL-90072-000	BOLT-WASHER, 6X60	E-15-18
HZVL-90101-000	BOLT, SOCKET, 6X25	F-8-7
HZVL-90102-000	BOLT-WASHER, 10X35	F-3-20-37
HZVL-90103-000	BOLT-WASHER, 12X50	F-3-20-39
HZVL-90105-000	BOLT, STUD, 10X28	F-10-42
HZVL-90107-000	BOLT-WASHER, 8X35	F-3-20-41
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-20-38
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-20-38
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-20-38
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-20-38
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-20-38
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-20-38
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-20-42
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-30-8
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-30-8
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-30-8
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-30-8
HZVL-90109-000	BOLT, FLANGE, 6X25	F-3-30-8
HZVL-90110-000	BOLT, WASHER, 6X25	F-3-30-13
HZVL-90110-000	BOLT, WASHER, 6X25	F-3-30-13
HZVL-90110-000	BOLT, WASHER, 6X25	F-3-30-13
HZVL-90110-000	BOLT, WASHER, 6X25	F-3-30-13
HZVL-90110-000	BOLT, WASHER, 6X25	F-3-30-13
HZVL-90110-000	BOLT, WASHER, 6X25	F-3-30-13
HZVL-90129-000	BOLT, HEX., 12X150	F-10-48
HZVL-90203-010	NUT, FLANGE, 8MM	E-19-25
HZVL-90203-010	NUT, FLANGE, 8MM	E-19-25
HZVL-90203-010	NUT, FLANGE, 8MM	E-19-25
HZVL-90204-000	NUT, FLANGE CAP, 10MM	E-3-10-16
HZVL-90512-000	WASHER, PLAIN, 6MM	F-3-30-10
HZVL-90512-000	WASHER, PLAIN, 6MM	F-3-30-10
HZVL-90512-000	WASHER, PLAIN, 6MM	F-3-30-10
HZVL-90512-000	WASHER, PLAIN, 6MM	F-3-30-10
HZVL-90512-000	WASHER, PLAIN, 6MM	F-3-30-10
HZVL-90512-000	WASHER, PLAIN, 6MM	F-3-30-10
HZVL-90601-000	CLAMP, TUBE (D12.5)	E-4-26
HZVL-90601-000	CLAMP, TUBE (D12.5)	E-4-26
HZVL-90601-000	CLAMP, TUBE (D12.5)	E-4-26

HZVL-90751-000	PIN, SPRING, 6X22	F-3-20-49
HZVL-90752-000	PIN, LOCK SPRING	F-3-20-50
HZVL-90756-000	DOWEL PIN, 6X10	F-4-24
HZVL-90756-000	DOWEL PIN, 6X10	F-4-24
HZVL-90756-000	DOWEL PIN, 6X10	F-4-24
HZVL-90756-000	DOWEL PIN, 6X10	F-4-24
HZVL-90756-000	DOWEL PIN, 6X10	F-4-24
HZVL-90756-000	DOWEL PIN, 6X10	F-4-24
HZVL-90756-000	DOWEL PIN, 6X10	FOP-2-17
HZVL-90756-000	DOWEL PIN, 6X10	FOP-2-17
HZVL-90756-000	DOWEL PIN, 6X10	FOP-18-17
HZVL-90756-000	DOWEL PIN, 6X10	FOP-18-17
HZVL-91303-000	O-RING, 8.8X1.9	E-3-43
HZVL-91356-003	O-RING, 31.5X2.4 (ARAI)	EOP-1-22
HZVL-91451-000	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-000	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-000	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-000	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-000	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-010	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-010	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-010	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-010	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-010	TUBE, WATER JOINT	F-3-20-52
HZVL-91451-010	TUBE, WATER JOINT	F-3-20-52
HZVL-91508-000	COLLAR, TIMING BELT COVER	E-13-10-10
HZVL-91551-000	COLLAR, 12X6.5	E-15-20
HZVL-91551-000	COLLAR, 12X6.5	E-15-20
HZVL-91551-000	COLLAR, 12X6.5	E-15-20
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-000	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-010	COLLAR, 12X6.5	E-15-20
HZVL-91551-010	COLLAR, 12X6.5	E-15-20
HZVL-91551-010	COLLAR, 12X6.5	E-15-20
HZVL-91551-010	COLLAR, 12X6.5	E-20-7
HZVL-91551-010	COLLAR, 12X6.5	E-20-7
HZVL-91551-010	COLLAR, 12X6.5	E-20-7

HZVL-91551-010	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-11
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-010	COLLAR, 12X6.5	F-3-30-12
HZVL-91551-010	COLLAR, 12X6.5	E-20-10-12
HZVL-91551-010	COLLAR, 12X6.5	E-20-10-12
HZVL-91551-010	COLLAR, 12X6.5	E-20-10-12
HZVP-06411-000	METAL KIT, ANODE	F-10-81
HZVP-50116-000	METAL, ANODE	F-10-82
HZVP-50117-000	PLATE, ANODE METAL	F-10-83
HZW1-06411-020	METAL KIT, ANODE	F-10-1
HZW1-06411-020	METAL KIT, ANODE	FOP-18-2
HZW1-06411-020	METAL KIT, ANODE	FOP-18-2
HZW1-19286-B00	PLATE, RUBBER SETTING	F-3-1
HZW1-24210-010	SPRING COMP., CLICK	F-2-7
HZW1-24327-000	RING, STOPPER	F-2-9
HZW1-24343-B02	HOLDER, SHIFT ROD	F-4-12
HZW1-24629-000	HOLDER, SEAL	F-2-22
HZW1-38551-000	GROMMET, RELAY	F-7-10-11
HZW1-40107-700	GROMMET, UNDER CASE(C)	F-11-10
HZW1-41102-B00	GROMMET, GEAR CASE	F-3-3
HZW1-41109-B00	METAL COMP., ANODE	F-3-8
HZW1-41109-B00	METAL COMP., ANODE	FOP-18-11
HZW1-41109-B00	METAL COMP., ANODE	FOP-18-11
HZW1-56110-701	ROD COMP., PISTON(B)	F-11-15
HZW1-56113-701	JOINT, DRIVE	F-11-16
HZW1-56116-701	FILTER B	F-11-18
HZW1-56130-702	PISTON COMP., FREE	F-11-22
HZW1-56180-701	VALVE COMP., RESERVOIR	F-11-24
HZW1-56851-703	TANK, OIL	F-11-27
HZW1-56860-701	CAP COMP., OIL TANK	F-11-28
HZW1-90102-000	BOLT, 1/4-28UNF	F-10-37
HZW1-90107-004	SCREW, PAN, 5X8	E-21-21
HZW1-90113-702	BOLT, RECESSED	F-11-29
HZW1-90114-702	BOLT, SOCKET (A)	F-11-30
HZW1-90115-702	BOLT, SOCKET (B)	F-11-31
HZW1-90116-702	BOLT, HEX.	F-11-32
HZW1-90203-000	NUT-WASHER, 8MM	F-7-10-18
HZW1-90301-B00	NUT, CASTLE, 18MM	F-5-14

HZW1-90301-B00	NUT, CASTLE, 18MM • • • • •	F-5-1-14
HZW1-90308-003	NUT, SELF-LOCK, 12MM • • • • •	F-3-18
HZW1-90652-702	CIRCLIP, INTERNAL • • • • •	F-11-34
HZW1-90758-B00	PIN, SPLIT, 4.0 • • • • •	F-5-22
HZW1-90758-B00	PIN, SPLIT, 4.0 • • • • •	F-5-1-23
HZW1-90758-B00	PIN, SPLIT, 4.0 • • • • •	FOP-17-2
HZW1-90758-B00	PIN, SPLIT, 4.0 • • • • •	FOP-18-18
HZW1-90758-B00	PIN, SPLIT, 4.0 • • • • •	FOP-18-18
HZW1-91207-013	O-RING, 2.0X70.5 • • • • •	F-11-36
HZW1-91353-703	O-RING, 1.9X11 • • • • •	F-11-40
HZW1-91354-701	O-RING, 3.5X35.7 • • • • •	F-11-41
HZW1-91355-701	O-RING, 3.5X41.7 • • • • •	F-11-42
HZW1-91357-701	O-RING SET, 3.5X31.7 • • • • •	F-11-43
HZW1-91361-701	PACKING • • • • •	F-11-45
HZW1-91557-701	COLLAR, ORIFICE • • • • •	F-11-46
HZW1-91557-701	COLLAR, ORIFICE • • • • •	F-11-46
HZW1-91557-701	COLLAR, ORIFICE • • • • •	F-11-46
HZW1-91557-701	COLLAR, ORIFICE • • • • •	F-11-46
HZW1-91557-701	COLLAR, ORIFICE • • • • •	F-11-46
HZW1-91557-701	COLLAR, ORIFICE • • • • •	F-11-46
HZW4-90156-000	BOLT, FLANGE, 8X50 • • • • •	E-14-10-15
HZW4-90156-000	BOLT, FLANGE, 8X50 • • • • •	E-14-10-15
HZW4-90156-000	BOLT, FLANGE, 8X50 • • • • •	E-14-10-15
HZW4-90306-003	NUT, FLANGE, 10MM • • • • •	F-10-52
HZW4-90401-000	WASHER, PLAIN, 4MM • • • • •	F-10-54
HZW4-91301-003	O-RING, 6.9X1.45 • • • • •	F-3-21
HZW4-91301-003	O-RING, 6.9X1.45 • • • • •	FOP-17-6
HZW4-91301-003	O-RING, 6.9X1.45 • • • • •	FOP-18-19
HZW4-91301-003	O-RING, 6.9X1.45 • • • • •	FOP-18-19
HZW5-16081-010	SCREW-WASHER • • • • •	E-18-20
HZW5-16086-000	COLLAR, SET • • • • •	E-18-23
HZW5-16087-000	WASHER, PLAIN • • • • •	E-18-24
HZW5-16715-023	COVER, PUMP (A) • • • • •	E-18-31
HZW5-16733-000	GROMMET, VAPOR SEPARATOR • • • • •	E-18-38
HZW5-16915-000	SUSPENSION, STRAINER • • • • •	E-18-10-15
HZW5-19291-000	VALVE, RELIEF • • • • •	E-6-10-11
HZW5-19292-000	SPRING, RELIEF VALVE • • • • •	E-6-10-13
HZW5-19297-000	PACKING, RELIEF VALVE • • • • •	E-6-10-17
HZW5-24810-U01	HOUSING ASSY., L. INNER (TOP MOUNT) • • • • •	FOP-3-2
HZW5-24810-U01	HOUSING ASSY., L. INNER • • • • •	FOP-3-2-2
HZW5-24810-U11	HOUSING ASSY., R. INNER • • • • •	FOP-3-2-3
HZW5-24811-U01	HANDLE, REMOTE CONTROL • • • • •	FOP-3-3
HZW5-24811-U01	HANDLE, REMOTE CONTROL • • • • •	FOP-3-2-4
HZW5-24812-U01	COVER, L. GRIP • • • • •	FOP-3-4
HZW5-24812-U01	COVER, L. GRIP • • • • •	FOP-3-2-5
HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE • • • • •	FOP-3-5
HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE • • • • •	FOP-3-2-6
HZW5-24813-U21	COVER, DUAL GRIP • • • • •	FOP-3-2-7

HZW5-24814-U01	CAP, GRIP	FOP-3-6
HZW5-24814-U01	CAP, GRIP	FOP-3-2-8
HZW5-24815-U01	CAP, SWITCH	FOP-3-7
HZW5-24816-U01	BUTTON, THROTTLE	FOP-3-8
HZW5-24816-U01	BUTTON, THROTTLE	FOP-3-1-8
HZW5-24816-U01	BUTTON, THROTTLE	FOP-3-2-9
HZW5-24817-U01	PLATE, HANDLE	FOP-3-9
HZW5-24817-U01	PLATE, HANDLE	FOP-3-2-10
HZW5-24817-U01	PLATE, HANDLE	FOP-3-4-8
HZW5-24817-U01	PLATE, HANDLE	FOP-3-5-9
HZW5-24818-U01	PLATE, CABLE CLAMP	FOP-3-10
HZW5-24818-U01	PLATE, CABLE CLAMP	FOP-3-2-11
HZW5-24818-U01	PLATE, CABLE CLAMP	FOP-3-4-9
HZW5-24818-U01	PLATE, CABLE CLAMP	FOP-3-5-10
HZW5-24819-U01	BRACKET, REMOTE CONTROL HOUSING	FOP-3-11
HZW5-24819-U01	BRACKET, REMOTE CONTROL	FOP-3-2-12
HZW5-24825-U01	HOUSING, LEAD	FOP-3-13
HZW5-24825-U01	HOUSING, LEAD	FOP-3-2-14
HZW5-24826-U01	PLATE, DWELL	FOP-3-14
HZW5-24826-U01	PLATE, DWELL	FOP-3-1-10
HZW5-24826-U01	PLATE, DWELL	FOP-3-2-15
HZW5-24826-U01	PLATE, DWELL	FOP-3-4-15
HZW5-24826-U01	PLATE, DWELL	FOP-3-5-16
HZW5-24831-U01	TERMINAL, CABLE	FOP-3-15
HZW5-24831-U01	TERMINAL, CABLE	FOP-3-1-12
HZW5-24831-U01	TERMINAL, CABLE	FOP-3-2-16
HZW5-24831-U01	TERMINAL, CABLE (LOOSE PARTS)	FOP-3-4-19
HZW5-24831-U01	TERMINAL, CABLE (LOOSE PARTS)	FOP-3-5-19
HZW5-24832-U01	SPACER, CABLE CLAMP	FOP-3-16
HZW5-24832-U01	SPACER, CABLE CLAMP	FOP-3-1-13
HZW5-24832-U01	SPACER, CABLE CLAMP	FOP-3-2-17
HZW5-24832-U01	SPACER, CABLE CLAMP (LOOSE PARTS)	FOP-3-4-20
HZW5-24832-U01	SPACER, CABLE CLAMP (LOOSE PARTS)	FOP-3-5-20
HZW5-24834-U01	PACKING, SINGLE	FOP-3-17
HZW5-24834-U01	PACKING, SINGLE (LOOSE PARTS)	FOP-3-4-22
HZW5-24834-U21	PACKING, DUAL	FOP-3-2-18
HZW5-32168-003	BAND	E-18-44
HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT (A)	FOP-3-19
HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	FOP-3-2-21
HZW5-35370-U12	SWITCH ASSY., POWER TRIM-TILT	FOP-3-2-22
HZW5-35665-003	SENSOR ASSY., AIR TEMPERATURE	E-15-11
HZW5-90002-013	BOLT, SPECIAL, 8MM	E-5-14
HZW5-90101-U00	SCREW, PAN, 5X16	FOP-3-21
HZW5-90101-U00	SCREW, PAN, 5X16	FOP-3-1-20
HZW5-90101-U00	SCREW, PAN, 5X16	FOP-3-2-24
HZW5-90101-U00	SCREW, PAN, 5X16	FOP-3-4-25
HZW5-90101-U00	SCREW, PAN, 5X16	FOP-3-5-35
HZW5-90102-U00	SCREW, PAN, 5X10	FOP-3-22

HZW5-90102-U00	SCREW, PAN, 5X10	FOP-3-2-25
HZW5-90103-U01	SCREW, PAN, 5X20	FOP-3-23
HZW5-90103-U01	SCREW, PAN, 5X20	FOP-3-2-26
HZW5-90104-U00	SCREW, PAN, 5X18	FOP-3-24
HZW5-90104-U00	SCREW, PAN, 5X18	FOP-3-2-27
HZW5-90104-U00	SCREW, PAN, 5X18	FOP-3-4-28
HZW5-90104-U00	SCREW, PAN, 5X18	FOP-3-5-38
HZW5-90105-U01	SCREW, PAN, 4X10	FOP-3-25
HZW5-90105-U01	SCREW, PAN, 4X10	FOP-3-2-28
HZW5-90106-U00	SCREW, PAN, 6X18	FOP-3-26
HZW5-90106-U00	SCREW, PAN, 6X18	FOP-3-2-29
HZW5-90106-U00	SCREW, PAN, 6X18	FOP-3-4-30
HZW5-90106-U00	SCREW, PAN, 6X18	FOP-3-5-40
HZW5-90107-U00	SCREW, PAN, 5X40	FOP-3-27
HZW5-90107-U00	SCREW, PAN, 5X40	FOP-3-2-30
HZW5-90107-U00	SCREW, PAN, 5X40 (LOOSE PARTS)	FOP-3-4-32
HZW5-90107-U00	SCREW, PAN, 5X40 (LOOSE PARTS)	FOP-3-5-42
HZW5-90108-U00	SCREW, PAN, 5X55	FOP-3-2-31
HZW5-90108-U00	SCREW, PAN, 5X55	FOP-3-5-43
HZW5-90109-000	SCREW, PAN, 5X40	FOP-5-15
HZW5-90109-000	SCREW, PAN, 5X40	FOP-5-1-15
HZW5-90109-000	SCREW, PAN, 5X40	FOP-5-2-15
HZW5-90109-000	SCREW, PAN, 5X40	FOP-5-3-18
HZW5-90109-000	SCREW, PAN, 5X40	FOP-5-3-18
HZW5-90109-000	SCREW, PAN, 5X40	FOP-5-4-14
HZW5-90203-010	NUT, FLANGE, 8MM	E-19-25
HZW5-90203-010	NUT, FLANGE, 8MM	E-19-25
HZW5-90203-010	NUT, FLANGE, 8MM	E-19-25
HZW5-90301-U00	NUT, HEX., 5MM	FOP-3-28
HZW5-90301-U00	NUT, HEX., 5MM	FOP-3-2-32
HZW5-90301-U00	NUT, HEX., 5MM (LOOSE PARTS)	FOP-3-4-35
HZW5-90301-U00	NUT, HEX., 5MM (LOOSE PARTS)	FOP-3-5-46
HZW5-90302-003	NUT, FLANGE, 12MM	F-10-50
HZW5-90302-U21	NUT, HEX., 5MM	FOP-3-2-33
HZW5-90302-U21	NUT, HEX., 5MM	FOP-3-5-48
HZW5-90501-U00	WASHER, LOCK, 5MM	FOP-3-29
HZW5-90501-U00	WASHER, LOCK, 5MM	FOP-3-1-26
HZW5-90501-U00	WASHER, LOCK, 5MM	FOP-3-2-34
HZW5-90501-U00	WASHER, LOCK, 5MM	FOP-3-4-37
HZW5-90501-U00	WASHER, LOCK, 5MM	FOP-3-5-49
HZW5-90502-U00	WASHER, LOCK, 6MM	FOP-3-30
HZW5-90502-U00	WASHER, LOCK, 6MM	FOP-3-2-35
HZW5-90502-U00	WASHER, LOCK, 6MM	FOP-3-4-38
HZW5-90502-U00	WASHER, LOCK, 6MM	FOP-3-5-50
HZW5-90503-U00	WASHER, PLAIN, 5MM	FOP-3-31
HZW5-90503-U00	WASHER, PLAIN, 5MM	FOP-3-2-36
HZW5-90503-U00	WASHER, PLAIN, 5MM (LOOSE PARTS)	FOP-3-4-39
HZW5-90503-U00	WASHER, PLAIN, 5MM (LOOSE PARTS)	FOP-3-5-51

HZW5-90509-711	WASHER, THRUST BEARING	F-5-16
HZW5-90509-711	WASHER, THRUST BEARING	F-5-1-16
HZW5-90601-030	CLAMP, TUBE (D10. 7)	E-18-10-25
HZW5-90602-030	CLAMP, TUBE (D12)	E-18-1-16
HZW5-90602-030	CLAMP, TUBE (D12)	E-18-10-27
HZW5-90652-003	CLAMP, 6MM-12MM	E-18-10-29
HZW5-91201-003	OIL SEAL, 46X60X9	E-5-17
HZW5-91202-003	SEAL, WATER, 22X35X7	E-6-10-44
HZW5-91251-003	OIL SEAL, 14X26X6	F-2-42
HZW7-24810-U01	HOUSING ASSY., R. INNER	FOP-3-1-2
HZW7-24811-U01	HANDLE, REMOTE CONTROL	FOP-3-1-3
HZW7-24812-U01	COVER, GRIP	FOP-3-1-4
HZW7-24813-U01	ARM, NEUTRAL LOCK	FOP-3-1-5
HZW7-24814-U01	COVER, LOCK ARM	FOP-3-1-6
HZW7-24815-U01	SPRING, NEUTRAL LOCK ARM	FOP-3-1-7
HZW7-24817-U01	SHAFT, THROTTLE BUTTON	FOP-3-1-9
HZW7-24832-U01	HOLDER, NEUTRAL LOCK	FOP-3-1-14
HZW7-24833-U01	BASE	FOP-3-1-15
HZW7-32530-U00	SUB HARNESS ASSY., POWER TRIM-TILT (A)	FOP-3-18
HZW7-32530-U00	SUB HARNESS ASSY., POWER	FOP-3-2-19
HZW7-32530-U10	SUB HARNESS ASSY., POWER	FOP-3-2-20
HZW7-32530-U20	SUB HARNESS ASSY., POWER	FOP-3-1-16
HZW7-35370-U02	SWITCH ASSY., POWER TRIM-TILT	FOP-3-1-17
HZW7-87703-U00	MARK, FLUSH MOUNT	FOP-3-1-19
HZW7-90101-U01	SCREW, TRUSS, 4X12	FOP-3-1-21
HZW7-90102-U01	SCREW, PAN, 5X30	FOP-3-1-22
HZW7-90103-U01	SCREW, PAN, 6X35	FOP-3-1-23
HZW7-90104-U01	SCREW, TAPPING, 6X30	FOP-3-1-24
HZW7-90301-U01	NUT, HEX., 6MM	FOP-3-1-25
HZW7-90502-U00	WASHER, PLAIN, 6MM	FOP-3-1-27
HZW9-19279-010	SPRING, FLUSH VALVE	E-6-10-10
HZW9-19291-000	VALVE, FLASH	E-6-10-12
HZW9-19297-010	PACKING, FLASH VALVE	E-6-10-18
HZW9-32117-000	BRACKET, COUPLER D	E-20-10-5
HZW9-90005-030	BOLT, FLANGE, 6X20	F-10-35
HZW9-90009-000	BOLT, FLANGE, 6X23	F-10-36
HZW9-90101-003	BOLT, OIL CHECK	F-3-10
HZW9-90101-003	BOLT, OIL CHECK	FOP-18-12
HZW9-90101-003	BOLT, OIL CHECK	FOP-18-12
HZW9-90102-000	BOLT, FLANGE, 6X12	F-3-20-38
HZW9-90102-000	BOLT, FLANGE, 6X12	F-3-20-38
HZW9-90102-000	BOLT, FLANGE, 6X12	F-3-20-38
HZW9-90102-000	BOLT, FLANGE, 6X12	F-3-20-38
HZW9-90102-000	BOLT, FLANGE, 6X12	F-3-20-38
HZW9-90102-000	BOLT, FLANGE, 6X12	F-3-20-38
HZW9-90102-000	BOLT, FLANGE, 6X12	F-10-38
HZW9-90102-M00	BOLT, FLANGE, 6X12	F-7-10-30
HZW9-90103-010	BOLT, FLANGE, 6X12	F-10-39

HZW9-90105-000	BOLT, FLANGE, 6X20	F-10-43
HZX1-90101-R00	BOLT, SOCKET, 6X20	F-8-8
HZX2-06125-C01	CASE KIT, GEAR	FOP-17-1
HZX2-06192-C00	PUMP KIT, IMPELLER	FOP-2-1
HZX2-06192-C01	PUMP KIT, IMPELLER	FOP-2-15
HZX2-06192-C02	PUMP KIT, IMPELLER	FOP-2-15
HZX2-06192-C02	PUMP KIT, IMPELLER	FOP-2-15
HZX2-06193-C00	PUMP KIT, IMPELLER	FOP-2-2
HZX2-06193-C01	PUMP KIT, IMPELLER	FOP-2-16
HZX2-06193-C02	PUMP KIT, IMPELLER	FOP-2-16
HZX2-06193-C02	PUMP KIT, IMPELLER	FOP-2-16
HZX2-06400-C00	GEAR KIT	F-5-34
HZX2-06400-E01	GEAR KIT	F-5-1-36
HZX2-11911-000	HANGER, ENGINE	E-3-10-2
HZX2-11911-000	HANGER, ENGINE	E-3-10-2
HZX2-11911-000	HANGER, ENGINE	E-3-10-2
HZX2-11911-010	HANGER, ENGINE	E-3-10-2
HZX2-11911-010	HANGER, ENGINE	E-3-10-2
HZX2-11911-010	HANGER, ENGINE	E-3-10-2
HZX2-13010-000	RING SET, PISTON (STD.) (RIKEN)	E-7-1
HZX2-13011-000	RING SET, PISTON (0.25) (RIKEN)	E-7-1
HZX2-13101-000	PISTON	E-7-2
HZX2-13102-000	PISTON (0.25)	E-7-2
HZX2-13310-000	CRANKSHAFT COMP.	E-7-8
HZX2-13321-003	BEARING A, MAIN UPPER (BLACK)	E-7-9
HZX2-13322-003	BEARING B, MAIN UPPER (BROWN)	E-7-9
HZX2-13323-003	BEARING C, MAIN UPPER (GREEN)	E-7-9
HZX2-13324-003	BEARING D, MAIN UPPER (YELLOW)	E-7-9
HZX2-13325-003	BEARING E, MAIN UPPER (PINK)	E-7-9
HZX2-13326-003	BEARING F, MAIN UPPER (RED)	E-7-9
HZX2-13341-003	BEARING A, MAIN LOWER (BLACK)	E-7-11
HZX2-13342-003	BEARING B, MAIN LOWER (BROWN)	E-7-11
HZX2-13343-003	BEARING C, MAIN LOWER (GREEN)	E-7-11
HZX2-13344-003	BEARING D, MAIN LOWER (YELLOW)	E-7-11
HZX2-13345-003	BEARING E, MAIN LOWER (PINK)	E-7-11
HZX2-13346-003	BEARING F, MAIN LOWER (RED)	E-7-11
HZX2-13392-000	SEAT, SPRING (250)	E-7-13
HZX2-13811-000	PULLEY, CRANKSHAFT	E-13-3
HZX2-14111-000	CAMSHAFT, R.	E-9-10-1
HZX2-14211-000	CAMSHAFT, L.	E-9-10-2
HZX2-16404-000	SPACER, THROTTLE BODY	E-15-4
HZX2-16701-003	CASE COMP., PUMP	E-18-28
HZX2-17374-000	GROMMET, SILENCER	E-15-8
HZX2-19234-C00	GASKET B, IMPELLER	F-4-5
HZX2-19234-C00	GASKET B, IMPELLER	FOP-2-7
HZX2-19234-C00	GASKET B, IMPELLER	FOP-18-8
HZX2-19234-C00	GASKET B, IMPELLER	FOP-18-8
HZX2-19300-003	THERMOSTAT ASSY.	E-4-10

HZX2-19300-003	THERMOSTAT ASSY.	FOP-18-10
HZX2-19300-003	THERMOSTAT ASSY.	FOP-18-10
HZX2-19303-003	RUBBER, RING	E-4-11
HZX2-19511-000	FAN, COOLING	E-13-16
HZX2-24101-C00	SHIFTER, CLUTCH	F-5-1
HZX2-24101-C00	SHIFTER, CLUTCH	F-5-1-1
HZX2-30280-003	BREAKER ASSY.	F-11-1
HZX2-30280-003	BREAKER ASSY.	F-11-1
HZX2-30280-003	BREAKER ASSY.	F-11-1
HZX2-30280-003	BREAKER ASSY.	F-11-1
HZX2-30280-003	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-31106-003	BRUSH ASSY.	F-11-2
HZX2-31106-003	BRUSH ASSY.	F-11-2
HZX2-31106-003	BRUSH ASSY.	F-11-2
HZX2-31106-003	BRUSH ASSY.	F-11-2
HZX2-31106-003	BRUSH ASSY.	F-11-2
HZX2-31106-013	BRUSH ASSY.	F-11-2
HZX2-31106-013	BRUSH ASSY.	F-11-2
HZX2-31106-013	BRUSH ASSY.	F-11-2
HZX2-31106-013	BRUSH ASSY.	F-11-2
HZX2-31106-013	BRUSH ASSY.	F-11-2
HZX2-31106-013	BRUSH ASSY.	F-11-2
HZX2-31110-000ZA	FLYWHEEL COMP.	E-5-11
HZX2-31916-003	PLUG, SPARK (ZFR6K-11E) (NGK)	E-20-3
HZX2-32166-003	HARNESS COMP.	E-18-43
HZX2-32414-300	COVER B, TERMINAL (L)	F-7-10-5
HZX2-32415-000	CABLE ASSY., POWER TILT RELAY	F-7-10-7
HZX2-32435-000	CORD, A. C. GENERATOR	F-7-10-9
HZX2-35470-013	SWITCH ASSY., NEUTRAL	F-2-23
HZX2-36120-013	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-023	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-023	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-023	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-023	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36120-023	MOTOR ASSY., POWER TILT	F-11-5
HZX2-36122-003	BRACKET ASSY.	F-11-6
HZX2-36122-003	BRACKET ASSY.	F-11-6
HZX2-36122-003	BRACKET ASSY.	F-11-6
HZX2-36122-003	BRACKET ASSY.	F-11-6
HZX2-36122-003	BRACKET ASSY.	F-11-6

HZX2-36122-003	BRACKET ASSY.	F-11-6
HZX2-36122-013	BRACKET ASSY.	F-11-6
HZX2-36122-013	BRACKET ASSY.	F-11-6
HZX2-36122-013	BRACKET ASSY.	F-11-6
HZX2-36122-013	BRACKET ASSY.	F-11-6
HZX2-36122-013	BRACKET ASSY.	F-11-6
HZX2-36122-013	BRACKET ASSY.	F-11-6
HZX2-36122-023	BRACKET ASSY.	F-11-6
HZX2-36122-023	BRACKET ASSY.	F-11-6
HZX2-36122-023	BRACKET ASSY.	F-11-6
HZX2-36122-023	BRACKET ASSY.	F-11-6
HZX2-36122-023	BRACKET ASSY.	F-11-6
HZX2-36129-003	YOKE ASSY.	F-11-8
HZX2-38228-003	FUSE, BLOCK (150A)	F-7-20-3
HZX2-38552-000	CASE, POWER TILT RELAY	F-7-10-12
HZX2-41101-C01ZC	CASE, GEAR	F-3-2
HZX2-41102-E00ZC	COVER, GEAR CASE	F-3-4
HZX2-41107-C00ZC	TAB, TRIM	F-3-7
HZX2-41110-305ZB	CASE COMP., GEAR	F-3-9
HZX2-41112-C00	SHAFT, VERTICAL (L)	F-4-14
HZX2-41112-C10	SHAFT, VERTICAL (XL)	F-4-14
HZX2-41131-C00	GEAR, PINION	F-5-35
HZX2-41131-E00	GEAR, PINION (COUNTER ROTATION)	F-5-1-37
HZX2-41140-C00	GEAR COMP., BEVEL (FORWARD)	F-5-8
HZX2-41141-E00	GEAR, BEVEL (FORWARD) (24T)	F-5-1-8
HZX2-41150-E00	GEAR COMP., BEVEL (REVERSE)	F-5-1-9
HZX2-41151-C00	GEAR, BEVEL (REVERSE) (24T)	F-5-9
HZX2-41161-C00	SHAFT, PROPELLER	F-5-10
HZX2-41161-E00	SHAFT, PROPELLER	F-5-1-10
HZX2-41200-E00	HOLDER ASSY., BEARING	F-5-1-11
HZX2-41202-C00	HOLDER, BEARING	F-5-12
HZX2-56000-043	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-043	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-043	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-043	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-043	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-043	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-053	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-053	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-053	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-053	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-053	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13

HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-073	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-073	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-073	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-073	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-073	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56000-073	TRIM-TILT ASSY., POWER	F-11-13
HZX2-56532-C00	PIN, UPPER CYLINDER	F-11-26
HZX2-58130-T01	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58130-T11	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58130-T21	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58130-T31	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58130-T41	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58130-T51	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58130-T61	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58180-T01	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58180-T11	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58180-T21	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58180-T31	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58180-T41	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58180-T51	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-58180-T61	PROPELLER COMP., THREE BLADES	FOP-15-1
HZX2-90001-000	BOLT, 12MM	E-5-13
HZX2-90002-000	BOLT, FLANGE, 10X90	E-19-21
HZX2-90002-000	BOLT, FLANGE, 10X90	E-19-21
HZX2-90002-000	BOLT, FLANGE, 10X90	E-19-21
HZX2-90002-010	BOLT, FLANGE, 10X90	E-19-21
HZX2-90002-010	BOLT, FLANGE, 10X90	E-19-21
HZX2-90002-010	BOLT, FLANGE, 10X90	E-19-21
HZX2-90004-000	BOLT, FLANGE, 6X18	E-4-25
HZX2-90004-000	BOLT, FLANGE, 6X18	E-4-25
HZX2-90004-000	BOLT, FLANGE, 6X18	E-4-25
HZX2-90101-C00	BOLT-WASHER, 6X16	F-2-28
HZX2-90105-C00	BOLT-WASHER, 8X60	F-4-17
HZX2-90105-C00	BOLT-WASHER, 8X60	FOP-2-9
HZX2-90107-C00	BOLT-WASHER, 10X47	F-3-13
HZX2-90129-000	BOLT, HEX., 12X130	F-10-48
HZX2-90301-C00	NUT, LOCK, 68MM	F-4-19
HZX2-90303-C00	NUT, HEX., 18MM	F-4-20
HZX2-90504-C00	WASHER, UPPER MOUNTING STOPPER	F-10-59
HZX2-90506-C00	WASHER, PROPELLER THRUST	F-5-15
HZX2-90506-C00	WASHER, PROPELLER THRUST	F-5-1-15
HZX2-90512-C00	WASHER, PROPELLER	F-5-17
HZX2-90512-C00	WASHER, PROPELLER	F-5-1-17
HZX2-90518-C00	SHIM A, GEAR (0.10)	F-4-22
HZX2-90519-C00	SHIM B, GEAR (0.15)	F-4-22
HZX2-90520-C00	SHIM C, GEAR (0.30)	F-4-22

HZX2-90521-C00	SHIM D, GEAR (0.50)	F-4-22
HZX2-90528-C00	SHIM A, BEVEL (0.10)	F-5-18
HZX2-90528-C00	SHIM A, BEVEL (0.10)	F-5-1-18
HZX2-90528-E00	SHIM A, BEVEL (0.10)	F-5-1-19
HZX2-90529-C00	SHIM B, BEVEL (0.15)	F-5-18
HZX2-90529-C00	SHIM B, BEVEL (0.15)	F-5-1-18
HZX2-90529-E00	SHIM B, BEVEL (0.15)	F-5-1-19
HZX2-90530-C00	SHIM C, BEVEL (0.30)	F-5-18
HZX2-90530-C00	SHIM C, BEVEL (0.30)	F-5-1-18
HZX2-90530-E00	SHIM C, BEVEL (0.30)	F-5-1-19
HZX2-90531-C00	SHIM D, BEVEL (0.50)	F-5-18
HZX2-90531-C00	SHIM D, BEVEL (0.50)	F-5-1-18
HZX2-90531-E00	SHIM D, BEVEL (0.50)	F-5-1-19
HZX2-90541-E01	WASHER, THRUST, 85X110X2	F-5-1-20
HZX2-90542-E01	WASHER, THRUST, 48X74X3	F-5-1-21
HZX2-90651-C00	RING, SETTING (39)	F-5-21
HZX2-90683-003	CLIP, WIRE HARNESS	F-7-10-23
HZX2-91051-C01	BEARING, TAPER ROLLER,	F-5-24
HZX2-91053-C01	BEARING, NEEDLE, 30.5X47X37	F-4-25
HZX2-91054-E01	BEARING, THRUST NEEDLE,	F-5-1-26
HZX2-91055-C01	BEARING, RADIAL BALL,	F-5-25
HZX2-91055-C01	BEARING, RADIAL BALL,	F-5-1-27
HZX2-91056-C01	BEARING, TAPER ROLLER,	F-4-26
HZX2-91351-C00	O-RING, 121X3.1	F-5-30
HZX2-91351-C00	O-RING, 121X3.1	F-5-1-32
HZX2-91351-C00	O-RING, 121X3.1	FOP-17-8
HZX2-91352-003	O-RING, 1.68X7.25	F-11-39
HZX2-91358-003	SEAL, WATER	F-11-44
HZX2-91358-C00	O-RING, WATER PUMP HOUSING	F-4-31
HZX2-91358-C00	O-RING, WATER PUMP HOUSING	FOP-2-12
HZX2-91359-C00	O-RING, 65.4X2.4	F-4-32
HZX2-91359-C00	O-RING, 65.4X2.4	FOP-2-13
HZX2-91557-003	COLLAR, ORIFICE	F-11-46
HZX2-91557-003	COLLAR, ORIFICE	F-11-46
HZX2-91557-003	COLLAR, ORIFICE	F-11-46
HZX2-91557-003	COLLAR, ORIFICE	F-11-46
HZX2-91557-003	COLLAR, ORIFICE	F-11-46
HZX2-91557-003	COLLAR, ORIFICE	F-11-46
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-2-31
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-2-31
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-2-31
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-2-31
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-2-31
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-2-31
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-3-16
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-8-9
HZY1-90205-000	NUT, SELF-LOCK, 6MM	F-10-49
HZY1-90205-000	NUT, SELF-LOCK, 6MM	FOP-18-14

HZY1-90205-000	NUT, SELF-LOCK, 6MM	FOP-18-14
HZY1-90650-003	TIE, CABLE	FOP-7-4
HZY2-15810-000ZA	VALVE ASSY., SPOOL	E-3-18
HZY2-15825-000	FILTER ASSY., SPOOL VALVE	E-3-19
HZY3-06177-U02	HOSE KIT, RIGGING	FOP-1-1
HZY3-06532-U00	ROD KIT, STEERING	F-10-2
HZY3-11300-C00	CASE ASSY., OIL SEAL	E-3-2
HZY3-11871-000	PLATE, R. TIMING BELT COVER	E-13-10-5
HZY3-11911-010	HANGER, ENGINE	E-9-1
HZY3-12155-000	METAL, ANODE	E-3-5
HZY3-12155-000	METAL, ANODE	E-3-5
HZY3-12155-000	METAL, ANODE	E-3-5
HZY3-12155-000	METAL, ANODE	E-6-10-1
HZY3-12155-000	METAL, ANODE	E-6-10-1
HZY3-12155-000	METAL, ANODE	E-6-10-1
HZY3-12155-010	METAL, ANODE	E-3-5
HZY3-12155-010	METAL, ANODE	E-3-5
HZY3-12155-010	METAL, ANODE	E-6-10-1
HZY3-12155-010	METAL, ANODE	E-6-10-1
HZY3-12155-010	METAL, ANODE	E-6-10-1
HZY3-12160-000	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM	E-3-54
HZY3-12160-000	BOLT ASSY., SEALING, 22MM	E-3-54
HZY3-12160-000	BOLT ASSY., SEALING, 22MM	E-3-54
HZY3-12160-010	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM	FOP-18-1-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM	E-3-54
HZY3-12160-010	BOLT ASSY., SEALING, 22MM	E-3-54
HZY3-12160-010	BOLT ASSY., SEALING, 22MM	E-3-54
HZY3-12164-000	BOLT, SEALING, 22MM	E-3-6
HZY3-12171-305	WASHER, SEALING, 22MM	E-3-7
HZY3-12171-305	WASHER, SEALING, 22MM	FOP-18-1-4
HZY3-12171-305	WASHER, SEALING, 22MM	FOP-18-1-4
HZY3-12241-000	COVER, L. CAMSHAFT THRUST	E-9-8
HZY3-12251-A01	GASKET COMP., CYLINDER HEAD	E-9-9
HZY3-12251-A01	GASKET COMP., CYLINDER HEAD	EOP-1-3
HZY3-12312-000	PACKING, HEAD COVER	E-1-2
HZY3-12312-000	PACKING, HEAD COVER	EOP-1-4
HZY3-13331-A06	WASHER, THRUST	E-7-10
HZY3-13391-010	RETAINER, SPRING	E-7-12

HZY3-13398-003	SPRING, SUPPORT	E-7-14
HZY3-13621-C01	PULLEY, TIMING BELT DRIVE	E-13-1
HZY3-14261-C00	PULLEY COMP., R. TIMING BELT	E-13-4
HZY3-14510-003	TENSIONER COMP., TIMING BELT	E-13-7
HZY3-14515-000	CAP, TIMING BELT TENSIONER	E-13-8
HZY3-14520-000	SPRING COMP., TIMING BELT	E-13-9
HZY3-14529-000	O-RING, TIMING BELT TENSIONER	E-13-11
HZY3-14529-000	O-RING, TIMING BELT TENSIONER	EOP-1-5
HZY3-14550-003	IDLER, TIMING BELT (KOYO SEIKO)	E-13-12
HZY3-14555-003	IDLER B, TIMING BELT	E-13-15
HZY3-15112-013	PACKING, OIL PUMP BODY	E-5-2
HZY3-15112-013	PACKING, OIL PUMP BODY	EOP-1-6
HZY3-15113-000	RUBBER, OIL PUMP	E-5-3
HZY3-15121-000	COVER, OIL PUMP	E-5-4
HZY3-15131-405	ROTOR, OIL PUMP INNER	E-5-5
HZY3-15132-405	ROTOR, OIL PUMP OUTER	E-5-6
HZY3-15220-020	STRAINER COMP., OIL	E-5-7
HZY3-15425-010	TUBE, OIL	E-1-5
HZY3-15657-000	PACKING, OIL LEVEL GAUGE	E-3-17
HZY3-15825-003	FILTER ASSY., SPOOL VALVE	E-3-19
HZY3-16011-A01	VALVE SET, FLOAT	E-18-1
HZY3-16013-000	FLOAT SET	E-18-2
HZY3-16016-003	SCREW SET	E-15-1
HZY3-16024-000	SCREW SET, DRAIN	E-18-5
HZY3-16026-000	JOINT SET	E-18-6
HZY3-16031-010	STAY, PLATE	E-18-8
HZY3-16031-010	STAY, PLATE	E-18-8
HZY3-16031-010	STAY, PLATE	E-18-8
HZY3-16031-020	STAY, PLATE	E-18-8
HZY3-16031-020	STAY, PLATE	E-18-8
HZY3-16031-020	STAY, PLATE	E-18-8
HZY3-16036-003	PUMP UNIT SET B, FUEL	E-18-9
HZY3-16041-000	PLATE	E-18-10
HZY3-16042-000	HOLDER	E-18-11
HZY3-16061-010	COVER, WATER JACKET	E-18-12
HZY3-16072-000	O-RING	E-18-13
HZY3-16073-000	O-RING	E-18-14
HZY3-16074-000	O-RING	E-18-15
HZY3-16075-000	O-RING	E-18-16
HZY3-16076-000	O-RING	E-18-17
HZY3-16077-000	O-RING	E-18-18
HZY3-16078-000	O-RING	E-18-19
HZY3-16082-000	SCREW, PAN	E-18-21
HZY3-16083-000	SCREW, WASHER	E-18-22
HZY3-16087-000	WASHER, PLAIN	E-18-25
HZY3-16088-000	COLLAR	E-18-26
HZY3-16176-000	GASKET, THROTTLE BODY	E-15-2
HZY3-16193-A00	CLAMP, CHECK VALVE	E-18-10-1

HZY3-16196-A00	TUBE, CHECK VALVE	E-18-10-2
HZY3-16197-000	TUBE A, AIR VENT	E-18-10-3
HZY3-16198-A00	TUBE B, AIR VENT	E-18-10-4
HZY3-16199-A00	TUBE COMP., AIR VENT	E-18-10-5
HZY3-16400-A01	THROTTLE BODY ASSY.	E-15-3
HZY3-16400-A02	THROTTLE BODY ASSY.	E-15-3
HZY3-16400-A03	THROTTLE BODY ASSY.	E-15-3
HZY3-16400-A03	THROTTLE BODY ASSY.	E-15-3
HZY3-16405-000	GASKET, EAC VALVE	E-15-5
HZY3-16451-000	CLIP, INJECTOR	E-14-2
HZY3-16611-A00	PIPE, R. FUEL	E-14-3
HZY3-16620-A00	PIPE COMP., L. FUEL	E-14-5
HZY3-16708-000	COVER, PUMP	E-18-29
HZY3-16721-000	INSULATOR	E-18-33
HZY3-16733-000	GROMMET, VAPOR SEPARATOR	E-18-39
HZY3-16734-000	STAY, PLATE	E-18-40
HZY3-16735-004	PUMP UNIT, FUEL	E-18-41
HZY3-16740-A01	REGULATOR ASSY., PRESSURE	E-14-6
HZY3-16752-000	JOINT, FUEL PIPE	E-18-42
HZY3-16752-A00	JOINT, FUEL PIPE	E-14-9
HZY3-16757-003	HOSE COMP., FUEL JOINT	E-14-11
HZY3-16818-003	O-RING	E-18-1-1
HZY3-16901-003	STRAINER, FUEL	E-18-1-7
HZY3-16901-003	STRAINER, FUEL	FOP-18-1-5
HZY3-16901-003	STRAINER, FUEL	FOP-18-1-5
HZY3-16904-003	SCREW, PAN, 5X12	E-18-1-8
HZY3-16915-010	SUSPENSION, STRAINER	E-18-1-10
HZY3-16918-003	O-RING	E-18-1-11
HZY3-16918-003	O-RING	FOP-18-1-6
HZY3-16918-003	O-RING	FOP-18-1-6
HZY3-16919-003	PLATE	E-18-1-12
HZY3-17051-A00	BASE, R. INJECTOR	E-14-16
HZY3-17061-A00	BASE, L. INJECTOR	E-14-18
HZY3-17105-004	GASKET, INTAKE MANIFOLD	E-14-10-1
HZY3-17108-000	SPACER, INTAKE MANIFOLD	E-14-21
HZY3-17109-004	PACKING, THROTTLE BODY	E-14-10-2
HZY3-17138-004	PACKING, INTAKE MANIFOLD UP	E-14-10-5
HZY3-17721-000	JOINT, FUEL RETURN	E-18-10-17
HZY3-17723-A01	HOSE A, PRESSURE REGULATOR	E-18-10-18
HZY3-17724-010	HOSE B, PRESSURE REGULATOR	E-18-10-19
HZY3-17738-000	PLUG, FUEL TUBE	E-18-1-13
HZY3-17748-U01	CLAMP	FOP-1-2
HZY3-17749-U01	SCREW, TAPPING	FOP-1-3
HZY3-17931-000	ARM, THROTTLE	F-2-4
HZY3-18115-003	GASKET, R. EX. MANIFOLD	E-4-3
HZY3-18115-003	GASKET, R. EX. MANIFOLD	EOP-1-10
HZY3-18115-003	GASKET, R. EX. MANIFOLD	FOP-18-1-7
HZY3-18115-003	GASKET, R. EX. MANIFOLD	FOP-18-1-7

HZY3-18125-003	GASKET, L. EX. MANIFOLD	E-4-5
HZY3-18125-003	GASKET, L. EX. MANIFOLD	EOP-1-11
HZY3-18125-003	GASKET, L. EX. MANIFOLD	FOP-18-1-8
HZY3-18125-003	GASKET, L. EX. MANIFOLD	FOP-18-1-8
HZY3-18141-A00ZA	GUIDE, R. EX.	E-6-10-3
HZY3-18148-003	SEAL, EXHAUST GUIDE	E-6-10-4
HZY3-18149-A01	SEAL B, EX. GUIDE	E-6-10-5
HZY3-18151-A00ZA	GUIDE, L. EX.	E-6-10-6
HZY3-18330-020	PIPE COMP., R. EX.	E-6-3
HZY3-18340-020	PIPE COMP., L. EX.	E-6-5
HZY3-19210-003	IMPELLER, PUMP	FOP-2-3
HZY3-19210-003	IMPELLER, PUMP	FOP-18-5
HZY3-19210-003	IMPELLER, PUMP	FOP-18-5
HZY3-19221-010	HOUSING, IMPELLER	F-4-2
HZY3-19221-010	HOUSING, IMPELLER	FOP-2-4
HZY3-19223-000	LINER, PUMP	F-4-3
HZY3-19223-000	LINER, PUMP	FOP-2-5
HZY3-19223-000	LINER, PUMP	FOP-18-6
HZY3-19223-000	LINER, PUMP	FOP-18-6
HZY3-19231-000	COVER, IMPELLER	F-4-4
HZY3-19231-000	COVER, IMPELLER	FOP-2-6
HZY3-19231-000	COVER, IMPELLER	FOP-18-7
HZY3-19231-000	COVER, IMPELLER	FOP-18-7
HZY3-19251-000	TUBE, WATER (L)	F-4-7
HZY3-19251-611	TUBE, WATER (XL)	F-4-7
HZY3-19252-000	GROMMET, WATER TUBE	E-6-6
HZY3-19253-000	RING, WATER TUBE SEAL	F-4-8
HZY3-19253-000	RING, WATER TUBE SEAL	FOP-2-8
HZY3-19253-000	RING, WATER TUBE SEAL	FOP-18-9
HZY3-19253-000	RING, WATER TUBE SEAL	FOP-18-9
HZY3-19254-000	PLATE, WATER TUBE	E-6-7
HZY3-19256-010	TUBE, WATER RELIEF	E-4-7
HZY3-19257-010	TUBE, WATER	E-4-8
HZY3-19258-010	TUBE, WATER IN.	E-18-10-20
HZY3-19259-000	TUBE, WATER OUTLET	E-18-10-21
HZY3-19261-000	TUBE, L. WATER RETURN	E-4-9
HZY3-19270-000	NUT, WATER MOUTH	F-3-20-2
HZY3-19271-000	JOINT, WATER HOSE	F-3-20-3
HZY3-19272-000	SEAT, WATER MOUTH	F-3-20-4
HZY3-19277-000ZA	COVER, FLUSH VALVE	E-6-10-8
HZY3-19278-000	CASE, FLUSH VALVE	E-6-10-9
HZY3-19289-000	CAP, WATER JOINT	F-3-20-6
HZY3-19294-000ZB	SPACER, R. RELIEF VALVE	E-6-10-14
HZY3-19295-000	COVER, R. RELIEF VALVE	E-6-10-15
HZY3-19296-000	PACKING, RELIEF VALVE COVER	E-6-10-16
HZY3-19297-000	COVER, L. RELIEF VALVE	E-6-10-19
HZY3-19298-000ZB	SPACER, L. RELIEF VALVE	E-6-10-20
HZY3-23173-010	RUBBER, MOUNT CASE SEAL	F-3-20-7

HZY3-24102-000	PIN, SHIFTER, 8X50	F-5-2
HZY3-24102-000	PIN, SHIFTER, 8X50	F-5-1-2
HZY3-24103-000	RING, CROSS PIN	F-5-3
HZY3-24103-000	RING, CROSS PIN	F-5-1-3
HZY3-24113-A01	SLIDER COMP., SHIFT	F-5-4
HZY3-24113-A01	SLIDER COMP., SHIFT	F-5-1-4
HZY3-24122-A01	SLIDER, SHIFT	F-5-5
HZY3-24122-A01	SLIDER, SHIFT	F-5-1-5
HZY3-24123-000	SPRING, SHIFT	F-5-6
HZY3-24123-000	SPRING, SHIFT	F-5-1-6
HZY3-24124-310	PLATE, SHIFT	F-5-7
HZY3-24124-310	PLATE, SHIFT	F-5-1-7
HZY3-24221-000	SPRING, CLICK ASSIST	F-2-8
HZY3-24310-C00	ROD COMP., SHIFT	F-4-9
HZY3-24310-E00	ROD COMP., SHIFT	F-4-9
HZY3-24318-000	SPRING, SHIFT ROD	F-4-10
HZY3-24610-A00	SHAFT COMP., SHIFT(A)	F-2-10
HZY3-24617-000	COLLAR, SHIFT SLIDER	F-2-13
HZY3-24618-000	PIVOT, SHIFT	F-2-14
HZY3-24619-000	PLATE, LOCK	F-2-15
HZY3-24620-000	SHAFT COMP., SHIFT(B)	F-2-16
HZY3-31116-000	BOSS, FLYWHEEL	E-5-12
HZY3-31200-003	MOTOR ASSY., STARTER	E-21-1
HZY3-31216-003	YOKE COMP.	E-21-5
HZY3-31226-003	BRUSH SET	E-21-7
HZY3-31232-003	HOLDER COMP., BRUSH	E-21-10
HZY3-31235-003	BRACKET, FR.	E-21-11
HZY3-31236-003	BRACKET, RR.	E-21-12
HZY3-31241-003	SWITCH ASSY., MAGNET	E-21-13
HZY3-31243-003	SHAFT ASSY., CLUTCH	E-21-15
HZY3-31250-003	LEVER SET	E-21-17
HZY3-31251-003	GEAR ASSY., INTERNAL	E-21-18
HZY3-31630-013	GENERATOR ASSY., A. C.	E-19-14
HZY3-31631-003	ROTOR ASSY.	E-19-15
HZY3-31638-003	BELT, A. C. GENERATOR	E-13-17
HZY3-31639-003	END COVER, RR.	E-19-17
HZY3-31694-003	BUSH, INSULATION	E-19-18
HZY3-31710-003	RECTIFIER ASSY.	E-19-19
HZY3-31750-003	REGULATOR ASSY.	E-19-20
HZY3-32112-000	BRACKET, HARNESS CLIP A	E-14-23
HZY3-32129-000	BRACKET C, HARNESS CLIP	E-1-10
HZY3-32370-H01	BOX ASSY., JUNCTION	F-7-20-1
HZY3-32371-H01	COVER COMP., FUSE	F-7-20-2
HZY3-32411-003	COVER, STARTER TERMINAL	F-7-10-4
HZY3-35476-010	BRACKET, NEUTRAL SWITCH	F-2-24
HZY3-35640-013	SWITCH ASSY., POWER TILT	F-3-20-8
HZY3-35660-003	SENSOR ASSY., TRIM ANGLE	F-10-7
HZY3-35673-003	SENSOR ASSY., WATER	E-3-23

HZY3-35673-003	SENSOR ASSY., WATER	E-4-14
HZY3-36123-013	ARMATURE COMP.	F-11-7
HZY3-36550-003	VALVE ASSY., EAC	E-15-12
HZY3-40204-000	GROMMET, EXTENSION CASE	F-4-13
HZY3-40210-610	BUSH COMP., VERTICAL SHAFT	F-3-20-21
HZY3-40219-023	WIRE, LEAD(1.5X116MM)	F-10-9
HZY3-40219-023	WIRE, LEAD(1.5X116MM)	F-11-11
HZY3-41104-C01	SCREEN, R. WATER	F-3-5
HZY3-41105-C01	SCREEN, L. WATER	F-3-6
HZY3-41116-000	SLINGER, OIL	F-4-15
HZY3-50111-020	HOUSING, LOWER MOUNTING	F-3-20-22
HZY3-50151-000	MOUNT COMP., UPPER RUBBER	F-10-15
HZY3-50153-000	RUBBER, UPPER MOUNT STOPPER	F-10-16
HZY3-50155-000	MOUNT COMP., LOWER RUBBER	F-3-20-23
HZY3-50157-010	STOPPER, LOWER MOUNT	F-3-20-24
HZY3-50161-000ZD	HOUSING, LOWER CENTER MOUNTING	F-10-17
HZY3-50161-610	HOUSING, LOWER CENTER MOUNTING	F-10-17
HZY3-50211-000	LINER, SWIVEL CASE	F-10-20
HZY3-50214-000	BUSH, SWIVEL CASE	F-10-21
HZY3-50301-030ZC	BRACKET, R. STERN	F-10-25
HZY3-50388-U00	PLATE SET, TRIM ADJUST	FOP-14-1
HZY3-50388-U10	PLATE SET, TRANSOM(5.5MM FLAT)	FOP-14-2
HZY3-50522-000	BUSH, TILT ARM	F-10-28
HZY3-50527-000	BRACKET, TILTING	F-10-29
HZY3-56100-013	PUMP ASSY.	F-11-14
HZY3-56100-013	PUMP ASSY.	F-11-14
HZY3-56100-013	PUMP ASSY.	F-11-14
HZY3-56100-013	PUMP ASSY.	F-11-14
HZY3-56100-013	PUMP ASSY.	F-11-14
HZY3-56100-013	PUMP ASSY.	F-11-14
HZY3-56100-023	PUMP ASSY.	F-11-14
HZY3-56100-023	PUMP ASSY.	F-11-14
HZY3-56100-023	PUMP ASSY.	F-11-14
HZY3-56100-023	PUMP ASSY.	F-11-14
HZY3-56100-023	PUMP ASSY.	F-11-14
HZY3-56100-023	PUMP ASSY.	F-11-14
HZY3-56100-023	PUMP ASSY.	F-11-14
HZY3-56100-023	PUMP ASSY.	F-11-14
HZY3-56120-023	ROD COMP., PISTON	F-11-21
HZY3-56170-013	VALVE COMP., MANUAL	F-11-23
HZY3-56170-013	VALVE COMP., MANUAL	F-11-23
HZY3-56170-013	VALVE COMP., MANUAL	F-11-23
HZY3-56170-013	VALVE COMP., MANUAL	F-11-23
HZY3-56170-013	VALVE COMP., MANUAL	F-11-23
HZY3-56170-013	VALVE COMP., MANUAL	F-11-23
HZY3-56170-023	VALVE COMP., MANUAL	F-11-23
HZY3-56170-023	VALVE COMP., MANUAL	F-11-23
HZY3-56170-023	VALVE COMP., MANUAL	F-11-23
HZY3-56170-023	VALVE COMP., MANUAL	F-11-23
HZY3-56170-023	VALVE COMP., MANUAL	F-11-23
HZY3-56170-023	VALVE COMP., MANUAL	F-11-23

HZY3-56170-023	VALVE COMP., MANUAL	F-11-23
HZY3-56516-A00	RECEIVER, THRUST	F-10-31
HZY3-56518-A00	BUSH A, THRUST RECEIVE	F-10-32
HZY3-56519-A00	BUSH B, THRUST RECEIVE	F-10-33
HZY3-90010-000	BOLT, HEX., 12X120	E-6-10-27
HZY3-90011-000	BOLT, HEX., 12X65	E-6-10-28
HZY3-90013-000	BOLT, HEX., 10X85	E-6-10-29
HZY3-90015-000	BOLT, HEX., 10X60	E-6-10-30
HZY3-90031-000	BOLT, FLANGE, 6X32	E-14-10-14
HZY3-90031-000	BOLT, FLANGE, 6X32	E-14-10-14
HZY3-90031-000	BOLT, FLANGE, 6X32	E-14-10-14
HZY3-90044-000	BOLT, STUD, 8X45	E-14-29
HZY3-90044-000	BOLT, STUD, 8X45	E-14-29
HZY3-90044-000	BOLT, STUD, 8X45	E-14-29
HZY3-90044-010	BOLT, STUD, 8X45	E-14-29
HZY3-90044-010	BOLT, STUD, 8X45	E-14-29
HZY3-90044-010	BOLT, STUD, 8X45	E-14-29
HZY3-90055-000	BOLT, TENSIONER	E-19-24
HZY3-90055-000	BOLT, TENSIONER	E-19-24
HZY3-90055-000	BOLT, TENSIONER	E-19-24
HZY3-90059-000	BOLT-WASHER, 6X29	E-6-10-36
HZY3-90082-003	CAP, BOLT, 10MM	E-3-10-14
HZY3-90104-010	BOLT, HEX., 12X200	F-10-41
HZY3-90105-010	BOLT, HEX., 14X180	F-3-20-40
HZY3-90106-A00	BOLT, FLANGE, 8X22	F-10-44
HZY3-90107-000	BOLT, FLANGE, 8X18	F-7-10-17
HZY3-90111-000	BOLT, SPECIAL, 6X17	F-3-30-9
HZY3-90111-000	BOLT, SPECIAL, 6X17	F-3-30-9
HZY3-90117-000	BOLT, 3/8-24UNF	F-10-46
HZY3-90120-000	BOLT, DRAIN PLUG	F-3-14
HZY3-90120-000	BOLT, DRAIN PLUG	FOP-18-13
HZY3-90120-000	BOLT, DRAIN PLUG	FOP-18-13
HZY3-90123-000	BOLT, HEX., 12X45	F-5-13
HZY3-90123-000	BOLT, HEX., 12X45	F-5-1-13
HZY3-90124-000	BOLT, STUD, 12X40	F-3-15
HZY3-90136-003	SCREW, 4X16	F-11-48
HZY3-90136-003	SCREW, 4X16	F-11-48
HZY3-90205-000	NUT, FLANGE, 8MM	E-14-10-16
HZY3-90302-000	NUT, SELF-LOCK, 14MM	F-3-20-44
HZY3-90304-000	NUT-WASHER, 6MM	F-7-10-19
HZY3-90405-000	WASHER, PLAIN, 8MM	F-7-10-20
HZY3-90501-A00	WASHER, WAVE, 12MM	F-10-56
HZY3-90503-610	WASHER, 30MM	F-3-20-45
HZY3-90509-000	WASHER, 7/8"	F-10-60
HZY3-90511-000	WASHER, PLAIN, 14MM	F-3-20-46
HZY3-90548-000	SHIM A, THRUST(2.75)	F-5-19
HZY3-90549-000	SHIM B, THRUST(2.80)	F-5-19
HZY3-90550-000	SHIM C, THRUST(2.85)	F-5-19

HZY3-90551-000	SHIM D, THRUST (2. 90)	F-5-19
HZY3-90552-000	SHIM E, THRUST (2. 95)	F-5-19
HZY3-90553-000	SHIM F, THRUST (3. 00)	F-5-19
HZY3-90554-000	SHIM G, THRUST (3. 05)	F-5-19
HZY3-90555-000	SHIM H, THRUST (3. 10)	F-5-19
HZY3-90556-000	SHIM I, THRUST (2. 70)	F-5-19
HZY3-90557-000	SHIM J, THRUST (2. 65)	F-5-19
HZY3-90558-000	SHIM K, THRUST (2. 60)	F-5-19
HZY3-90559-000	SHIM L, THRUST (2. 55)	F-5-19
HZY3-90560-000	SHIM M, THRUST (2. 50)	F-5-19
HZY3-90601-030	CLAMP, TUBE (D10. 5)	E-4-19
HZY3-90601-030	CLAMP, TUBE (D10. 5)	E-4-26
HZY3-90601-030	CLAMP, TUBE (D10. 5)	E-4-26
HZY3-90601-030	CLAMP, TUBE (D10. 5)	E-4-26
HZY3-90601-030	CLAMP, TUBE (D10. 5)	E-6-10-40
HZY3-90601-030	CLAMP, TUBE (D10. 5)	E-18-10-26
HZY3-90602-020	CLAMP, TUBE (D32. 5)	E-1-14
HZY3-90603-020	CLAMP, TUBE (D29)	E-4-20
HZY3-90604-020	CLAMP, TUBE (D21)	E-4-21
HZY3-90652-000	CIRCLIP, INTERNAL, 43	F-3-20-48
HZY3-90653-003	CLIP, WIRE HARNESS	F-7-8
HZY3-90741-000	KEY, SPECIAL	E-13-29
HZY3-90751-000	PIN, LINK	F-2-40
HZY3-90752-003	KEY, WOODRUFF	F-4-23
HZY3-90752-003	KEY, WOODRUFF	FOP-2-10
HZY3-90752-003	KEY, WOODRUFF	FOP-18-16
HZY3-90752-003	KEY, WOODRUFF	FOP-18-16
HZY3-91001-003	BEARING, NEEDLE, 20X28X13	E-6-10-43
HZY3-91056-711	BEARING, NEEDLE, 28X39X30	F-5-26
HZY3-91056-711	BEARING, NEEDLE, 28X39X30	F-5-1-28
HZY3-91057-003	BEARING, NEEDLE, 32X42X30	F-5-27
HZY3-91057-003	BEARING, NEEDLE, 32X42X30	F-5-1-29
HZY3-91151-000	ROLLER, 3X13. 8	F-5-28
HZY3-91151-000	ROLLER, 3X13. 8	F-5-1-30
HZY3-91152-003	RING, INNER (15X20X23)	F-2-41
HZY3-91212-003	OIL SEAL, 41X66X8	E-3-41
HZY3-91251-C01	SEAL, WATER, 26X42X7	F-4-27
HZY3-91251-C01	SEAL, WATER, 26X42X7	FOP-17-3
HZY3-91254-003	SEAL, WATER, 12X21X6	F-4-28
HZY3-91254-003	SEAL, WATER, 12X21X6	FOP-17-5
HZY3-91255-003	SEAL, WATER (14X26X8)	F-2-43
HZY3-91301-003	O-RING, 66. 4X3. 1	E-4-22
HZY3-91301-003	O-RING, 66. 4X3. 1	EOP-1-16
HZY3-91301-003	O-RING, 66. 4X3. 1	FOP-18-1-9
HZY3-91301-003	O-RING, 66. 4X3. 1	FOP-18-1-9
HZY3-91303-000	O-RING, 59. 4X3. 1	E-21-22
HZY3-91303-000	O-RING, 59. 4X3. 1	EOP-1-18
HZY3-91304-000	O-RING, 49. 4X3. 1	E-6-10-46

HZY3-91305-003	O-RING, 33. 5X2	E-6-10-47
HZY3-91306-003	O-RING, 23. 5X2	E-6-10-48
HZY3-91356-003	O-RING, WATER PUMP	F-4-30
HZY3-91356-003	O-RING, WATER PUMP	FOP-2-11
HZY3-91356-003	O-RING, WATER PUMP	FOP-18-20
HZY3-91356-003	O-RING, WATER PUMP	FOP-18-20
HZY3-91401-A00	TUBE COMP. A, BREATHER	E-1-16
HZY3-91402-030	TUBE B, BREATHER	E-1-17
HZY3-91403-000	TUBE C, BREATHER	E-1-18
HZY3-91405-000	TUBE, FLUSH VALVE	E-6-10-49
HZY3-91551-000	COLLAR, DISTANCE	F-4-33
HZY3-91551-000	COLLAR, DISTANCE	FOP-2-14
HZY3-91556-000	COLLAR, DISTANCE, 6. 5X9X3	F-8-11
HZY3-91560-000	COLLAR, STEERING ROD	F-10-70
HZY6-06240-R90	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE)	FOP-3-4-1
HZY6-06240-R91	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE)	FOP-3-4-1
HZY6-06240-R91	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE)	FOP-3-4-1
HZY6-06240-S90	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL)	FOP-3-5-1
HZY6-06240-S91	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL)	FOP-3-5-1
HZY6-06240-S91	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL)	FOP-3-5-1
HZY6-06241-U10	SPACER KIT, REMOTE CONTROL BOX (TOP MOUNT SINGLE)	FOP-3-4-42
HZY6-06323-R01	PANEL KIT, SWITCH (SINGLE)	FOP-5-1
HZY6-06323-R11	PANEL KIT, SWITCH (TWIN)	FOP-5-1-1
HZY6-06323-R21	PANEL KIT, SWITCH (TRIPLE)	FOP-5-2-1
HZY6-06323-R31	PANEL KIT, SWITCH (TRIPLE)	FOP-5-2-1
HZY6-06323-R81	PANEL KIT, SWITCH (SINGLE)	FOP-5-1
HZY6-06323-R91	PANEL KIT, SWITCH (TWIN)	FOP-5-1-1
HZY6-16450-003	INJECTOR ASSY., FUEL	E-14-1
HZY6-16718-013	INSULATOR COMP.	E-18-32
HZY6-16723-003	RING	E-18-34
HZY6-19269-000	T-JOINT	E-18-10-22
HZY6-24320-000	ROD COMP. A, SHIFT (L)	F-4-11
HZY6-24320-610	ROD COMP. A, SHIFT (XL)	F-4-11
HZY6-24810-U11	HOUSING ASSY., L. INNER (TOP MOUNT)	FOP-3-4-2
HZY6-24810-U11	HOUSING ASSY., L. INNER (TOP MOUNT)	FOP-3-5-2
HZY6-24810-V11	HOUSING ASSY., R. INNER (TOP MOUNT)	FOP-3-5-3
HZY6-24811-U11	HANDLE, REMOTE CONTROL	FOP-3-4-3
HZY6-24811-U11	HANDLE, REMOTE CONTROL	FOP-3-5-4
HZY6-24812-U11	COVER, GRIP	FOP-3-4-4
HZY6-24812-U11	COVER, GRIP	FOP-3-5-5
HZY6-24812-U12	COVER, GRIP	FOP-3-4-4
HZY6-24812-U12	COVER, GRIP	FOP-3-4-4
HZY6-24812-U12	COVER, GRIP	FOP-3-5-5
HZY6-24812-U12	COVER, GRIP	FOP-3-5-5
HZY6-24813-U11	GRIP, REMOTE CONTROL HANDLE	FOP-3-4-5
HZY6-24813-U11	GRIP, REMOTE CONTROL HANDLE	FOP-3-5-6
HZY6-24813-U12	GRIP, REMOTE CONTROL HANDLE	FOP-3-4-5
HZY6-24813-U12	GRIP, REMOTE CONTROL HANDLE	FOP-3-4-5

HZY6-24813-U12	GRIP, REMOTE CONTROL HANDLE	FOP-3-5-6
HZY6-24813-U12	GRIP, REMOTE CONTROL HANDLE	FOP-3-5-6
HZY6-24814-U11	COVER, LEVER	FOP-3-4-6
HZY6-24814-U11	COVER, LEVER	FOP-3-5-7
HZY6-24816-U11	BUTTON, THROTTLE	FOP-3-4-7
HZY6-24816-U11	BUTTON, THROTTLE	FOP-3-5-8
HZY6-24819-U11	BRACKET, REMOTE CONTROL HOUSING	FOP-3-4-10
HZY6-24819-V11	BRACKET, REMOTE CONTROL HOUSING	FOP-3-5-11
HZY6-24820-U11	HOUSING, SINGLE REMOTE CONTROL BOX	FOP-3-4-11
HZY6-24820-V11	HOUSING, DUAL REMOTE CONTROL BOX	FOP-3-5-12
HZY6-24821-U11	PLUG, SINGLE HOUSING	FOP-3-4-12
HZY6-24821-V11	PLUG, DUAL HOUSING	FOP-3-5-13
HZY6-24824-U11	GUIDE, SINGLE WATER	FOP-3-4-13
HZY6-24824-V11	GUIDE, DUAL WATER	FOP-3-5-14
HZY6-24825-U11	HOUSING, LEAD	FOP-3-4-14
HZY6-24825-U11	HOUSING, LEAD	FOP-3-5-15
HZY6-24826-R11	COVER, HOUSING SIDE	FOP-3-4-16
HZY6-24827-U11	RING, SNAP	FOP-3-4-17
HZY6-24827-U11	RING, SNAP	FOP-3-5-17
HZY6-24828-U11	GROMMET	FOP-3-4-18
HZY6-24828-U11	GROMMET	FOP-3-5-18
HZY6-24832-U91	CAP, BLANK	FOP-3-4-21
HZY6-24832-U91	CAP, BLANK	FOP-3-5-21
HZY6-24832-V11	CAP, POWER TRIM-TILT BLANK	FOP-3-5-22
HZY6-24834-V11	PACKING, DUAL (LOOSE PARTS)	FOP-3-5-23
HZY6-24835-U11	BAND, TY-RAP	FOP-3-5-24
HZY6-32340-R01	PANEL ASSY., CONTROL (SINGLE)	FOP-5-2
HZY6-32340-R11	PANEL ASSY., CONTROL (TWIN)	FOP-5-1-2
HZY6-32340-R21	PANEL ASSY., CONTROL (TRIPLE)	FOP-5-2-2
HZY6-32340-R31	PANEL ASSY., CONTROL (TRIPLE)	FOP-5-2-2
HZY6-32340-R81	PANEL ASSY., CONTROL (SINGLE)	FOP-5-2
HZY6-32340-R91	PANEL ASSY., CONTROL (TWIN)	FOP-5-1-2
HZY6-32346-R01	PANEL, CONTROL (SINGLE)	FOP-5-3
HZY6-32346-R11	PANEL, CONTROL (TWIN)	FOP-5-1-3
HZY6-32346-R21	PANEL, CONTROL (TRIPLE)	FOP-5-2-3
HZY6-32346-R31	PANEL, CONTROL (TRIPLE)	FOP-5-2-3
HZY6-32346-R81	PANEL, CONTROL (SINGLE)	FOP-5-3
HZY6-32346-R91	PANEL, CONTROL (TWIN)	FOP-5-1-3
HZY6-32414-640	COVER B, TERMINAL	F-7-10-6
HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	FOP-5-4
HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	FOP-5-1-4
HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	FOP-5-2-4
HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	FOP-5-5
HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	FOP-5-1-5
HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	FOP-5-2-5
HZY6-35100-R01	SWITCH ASSY., COMBINATION	FOP-5-8
HZY6-35100-R01	SWITCH ASSY., COMBINATION	FOP-5-1-8
HZY6-35100-R01	SWITCH ASSY., COMBINATION	FOP-5-2-8

HZY6-35370-U11	SWITCH ASSY., POWER TRIM-TILT	FOP-3-4-23
HZY6-35370-U11	SWITCH ASSY., POWER TRIM-TILT	FOP-3-5-25
HZY6-35370-V11	SWITCH ASSY., POWER TRIM-TILT (PORT)	FOP-3-5-26
HZY6-35370-V21	SWITCH ASSY., POWER TRIM-TILT (STAR)	FOP-3-5-27
HZY6-35375-V90	CABLE ASSY., POWER TRIM-TILT	FOP-3-5-28
HZY6-36135-003	VALVE, CHECK	E-18-10-23
HZY6-36180-003	SWITCH ASSY., EMERGENCY STOP	FOP-5-9
HZY6-36180-612	SWITCH ASSY., EMERGENCY STOP	FOP-5-2-9
HZY6-36180-712	SWITCH ASSY., EMERGENCY STOP	FOP-5-1-9
HZY6-36182-003	CORD COMP., EMERGENCY	FOP-5-10
HZY6-36182-003	CORD COMP., EMERGENCY	FOP-5-1-10
HZY6-36182-003	CORD COMP., EMERGENCY	FOP-5-2-10
HZY6-36187-003	CLIP, EMERGENCY LOCK	FOP-5-11
HZY6-36187-003	CLIP, EMERGENCY LOCK	FOP-5-1-11
HZY6-36187-003	CLIP, EMERGENCY LOCK	FOP-5-2-11
HZY6-38235-004	PULLER, MINI FUSE	F-7-20-4
HZY6-38414-003	BRACKET	FOP-5-14
HZY6-38414-003	BRACKET	FOP-5-1-14
HZY6-38414-003	BRACKET	FOP-5-2-14
HZY6-38580-V11	RELAY ASSY., CONTROL	FOP-3-5-31
HZY6-38581-V11	HOLDER, RELAY	FOP-3-5-32
HZY6-39794-003	RELAY ASSY., POWER (12V-20A)	F-7-20-6
HZY6-87703-R11	MARK, REMOTE CONTROL (SINGLE)	FOP-3-4-24
HZY6-87703-S11	MARK, REMOTE CONTROL (DUAL)	FOP-3-5-34
HZY6-90102-U11	SCREW, TRUSS, 5X10	FOP-3-4-26
HZY6-90102-U11	SCREW, TRUSS, 5X10	FOP-3-5-36
HZY6-90103-000	BOLT-WASHER, 10X32	F-3-12
HZY6-90103-000	BOLT-WASHER, 10X32	F-10-40
HZY6-90103-U11	SCREW, TRUSS, 5X16 (TAPPING)	FOP-3-4-27
HZY6-90103-U11	SCREW, TRUSS, 5X16 (TAPPING)	FOP-3-5-37
HZY6-90104-U11	SCREW, PAN, 5X14 (TAPPING)	FOP-3-4-29
HZY6-90104-U11	SCREW, PAN, 5X14 (TAPPING)	FOP-3-5-39
HZY6-90106-U11	SCREW, PAN, 5X14 (TAPPING)	FOP-3-4-31
HZY6-90106-U11	SCREW, PAN, 5X14 (TAPPING)	FOP-3-5-41
HZY6-90111-U11	BOLT, STOPPER (F)	FOP-3-4-33
HZY6-90111-U11	BOLT, STOPPER (F)	FOP-3-5-44
HZY6-90112-U11	BOLT, STOPPER (R)	FOP-3-4-34
HZY6-90112-U11	BOLT, STOPPER (R)	FOP-3-5-45
HZY6-90135-004	SCREW-WASHER, 5X15	F-7-20-8
HZY6-90302-003	NUT	FOP-5-17
HZY6-90302-003	NUT	FOP-5-1-17
HZY6-90302-003	NUT	FOP-5-2-17
HZY6-90651-000	CLIP B1, TUBE	F-3-20-47
HZY6-90651-000	CLIP B1, TUBE	F-3-20-47
HZY6-90651-000	CLIP B1, TUBE	F-3-20-47
HZY6-90651-000	CLIP B1, TUBE	F-3-20-47
HZY6-90651-000	CLIP B1, TUBE	F-3-20-47
HZY6-90651-000	CLIP B1, TUBE	F-3-20-47

HZY6-90651-000	CLIP B1, TUBE	E-6-10-55
HZY6-90651-000	CLIP B1, TUBE	E-6-10-55
HZY6-90651-000	CLIP B1, TUBE	E-6-10-55
HZY6-91541-V11	CLIP, HARNESS BAND	FOP-3-5-55
HZY9-15600-M00	CAP ASSY., OIL FILLER	E-3-10-5
HZY9-15631-000	EXTENSION, OIL FILLER	E-3-10-6
HZY9-16896-003	CLAMP B, FUEL TUBE	E-18-1-5
HZY9-17315-M00	BAND, AIR FLOW	E-15-7
HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	E-20-10-2
HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	F-7-10-1
HZY9-31207-H01	CLUTCH COMP., OVERRUNNING	E-21-3
HZY9-31226-H01	SCREW, PAN, 6X22	E-21-8
HZY9-31229-H01	STOPPER SET, SLEEVE	E-21-9
HZY9-31246-H01	SHAFT ASSY., GEAR	E-21-16
HZY9-35645-000	STAY, POWER TILT SWITCH	F-3-20-9
HZY9-38410-A01	BUZZER COMP., WARNING	FOP-5-13
HZY9-38410-A01	BUZZER COMP., WARNING	FOP-5-1-13
HZY9-38410-A01	BUZZER COMP., WARNING	FOP-5-2-13
HZY9-38553-003	GROMMET, RELAY BRACKET	E-20-4
HZY9-56115-023	GUIDE COMP., ROD	F-11-17
HZY9-87538-U80	LABEL, WARNING OPERATOR (EU)	F-12-10
HZY9-90014-M00	BOLT-WASHER, 8X35	E-18-46
HZY9-90026-M00	BOLT, FLANGE, 8X20	E-9-12
HZY9-90027-M00	BOLT, FLANGE, 8X60	E-4-16
HZY9-90042-M00	BOLT, FLANGE, 6X10	E-14-27
HZY9-90042-M00	BOLT, FLANGE, 6X10	E-14-27
HZY9-90042-M00	BOLT, FLANGE, 6X10	E-14-27
HZY9-90042-M01	BOLT, FLANGE, 6X10	E-14-27
HZY9-90042-M01	BOLT, FLANGE, 6X10	E-14-27
HZY9-90042-M01	BOLT, FLANGE, 6X10	E-14-27
HZY9-90054-M00	BOLT, FLANGE, 8X35	E-3-38
HZY9-90054-M00	BOLT, FLANGE, 8X35	E-3-38
HZY9-90054-M00	BOLT, FLANGE, 8X35	E-3-38
HZY9-90054-M01	BOLT, FLANGE, 8X35	E-3-38
HZY9-90054-M01	BOLT, FLANGE, 8X35	E-3-38
HZY9-90054-M01	BOLT, FLANGE, 8X35	E-3-38
HZY9-90205-M00	NUT, FLANGE, 8MM	E-14-30
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-15-20
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-15-20
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-15-20
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-20-7
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-20-7
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-20-7
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-20-10-12
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-20-10-12
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	E-20-10-12
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	F-7-10-25

HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M00	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91503-M01	COLLAR, C. D. I. UNIT CASE	F-7-10-25
HZY9-91504-M00	COLLAR, 8.5X14.5	E-18-54
HZY9-91504-M00	COLLAR, 8.5X14.5	E-18-54
HZY9-91504-M00	COLLAR, 8.5X14.5	E-18-54
HZY9-91504-M00	COLLAR, 8.5X14.5	F-3-20-53
HZY9-91504-M01	COLLAR, 8.5X14.5	E-18-54
HZY9-91504-M01	COLLAR, 8.5X14.5	E-18-54
HZY9-91504-M01	COLLAR, 8.5X14.5	E-18-54
HZZ0-90101-000	SCREW, FLAT, 5X55	F-3-11
HZZ0-90101-M00	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M00	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M00	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M00	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M00	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M00	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M01	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M01	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M01	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M01	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M01	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90101-M01	BOLT, FLANGE, 6X11	F-2-29
HZZ0-90102-M00	BOLT, TORX (M6X20)	E-20-10-9
HZZ0-90102-M00	BOLT, TORX (M6X20)	E-20-10-9
HZZ0-90102-M00	BOLT, TORX (M6X20)	E-20-10-9
HZZ0-90102-M01	BOLT, TORX (M6X20)	E-20-10-9
HZZ0-90102-M01	BOLT, TORX (M6X20)	E-20-10-9
HZZ0-90102-M01	BOLT, TORX (M6X20)	E-20-10-9
HZZ0-90103-M00	BOLT, FLANGE, 6X10	E-18-1-15
HZZ0-90103-M00	BOLT, FLANGE, 6X10	E-18-1-15
HZZ0-90103-M00	BOLT, FLANGE, 6X10	E-18-1-15
HZZ0-90103-M00	BOLT, FLANGE, 6X10	E-20-10-10
HZZ0-90103-M00	BOLT, FLANGE, 6X10	E-20-10-10
HZZ0-90103-M00	BOLT, FLANGE, 6X10	E-20-10-10
HZZ0-90103-M00	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M00	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M00	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M00	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M00	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M00	BOLT, FLANGE, 6X10	F-7-10-15

HZZ0-90103-M01	BOLT, FLANGE, 6X10	E-18-1-15
HZZ0-90103-M01	BOLT, FLANGE, 6X10	E-18-1-15
HZZ0-90103-M01	BOLT, FLANGE, 6X10	E-18-1-15
HZZ0-90103-M01	BOLT, FLANGE, 6X10	E-20-10-10
HZZ0-90103-M01	BOLT, FLANGE, 6X10	E-20-10-10
HZZ0-90103-M01	BOLT, FLANGE, 6X10	E-20-10-10
HZZ0-90103-M01	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M01	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M01	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M01	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M01	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90103-M01	BOLT, FLANGE, 6X10	F-7-10-15
HZZ0-90151-M00	BOLT, FLANGE, 8X25	E-3-10-15
HZZ0-90151-M00	BOLT, FLANGE, 8X25	E-3-10-15
HZZ0-90151-M00	BOLT, FLANGE, 8X25	E-3-10-15
HZZ0-90151-M01	BOLT, FLANGE, 8X25	E-3-10-15
HZZ0-90151-M01	BOLT, FLANGE, 8X25	E-3-10-15
HZZ0-90151-M01	BOLT, FLANGE, 8X25	E-3-10-15
HZZ0-91601-M00	GROMMET, 1WAY	F-3-20-54
HZZ3-06240-R31	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE) (R.)	FOP-3-1
HZZ3-06240-R41	BOX KIT, REMOTE CONTROL	FOP-3-1-1
HZZ3-06240-R61	BOX KIT, REMOTE CONTROL	FOP-3-2-1
HZZ3-06323-R04	PANEL KIT, SWITCH(B) (4-LED)	FOP-5-3-1
HZZ3-06323-R14	PANEL KIT, SWITCH(4-LED)	FOP-5-4-1
HZZ3-06323-R24	PANEL KIT, SWITCH(B) (4-LED)	FOP-5-3-1
HZZ3-06323-R34	PANEL KIT, SWITCH(4-LED)	FOP-5-4-1
HZZ3-06328-764	KIT, CABLE (NMEA) (6FT)	FOP-7-1
HZZ3-24800-P04	BOX ASSY., REMOTE CONTROL	FOP-3-3-1
HZZ3-24800-P14	BOX ASSY., REMOTE CONTROL	FOP-3-3-1
HZZ3-24820-R12	HOUSING COMP., REMOTE CONTROL BOX	FOP-3-12
HZZ3-24820-R22	HOUSING COMP., REMOTE CONTROL	FOP-3-2-13
HZZ3-24830-R42	COVER ASSY.	FOP-3-1-11
HZZ3-32127-000	SUSPENSION, COUPLER	F-7-4
HZZ3-32341-R02	PANEL ASSY., SWITCH	FOP-5-3-3
HZZ3-32341-R32	PANEL ASSY., SWITCH	FOP-5-3-3
HZZ3-32346-R02	PANEL, CONTROL	FOP-5-3-4
HZZ3-32346-R12	PANEL, CONTROL	FOP-5-4-2
HZZ3-32346-R22	PANEL, CONTROL	FOP-5-3-4
HZZ3-32346-R32	PANEL, CONTROL	FOP-5-4-2
HZZ3-32347-R02	PANEL, CONTROL	FOP-5-3-5
HZZ3-32800-000	CABLE ASSY., INTERFACE(6FT)	FOP-7-2
HZZ3-32805-000	CONNECTOR(T)	FOP-7-3
HZZ3-35100-R12	SWITCH ASSY., COMBINATION	FOP-3-3-34
HZZ3-35100-R12	SWITCH ASSY., COMBINATION	FOP-5-3-9
HZZ3-35100-R12	SWITCH ASSY., COMBINATION	FOP-5-4-6
HZZ3-35645-A41	PLATE, SWITCH	FOP-3-3-36
HZZ3-35745-743	SWITCH ASSY., TILT LIMIT	F-10-8
HZZ3-37205-R03	PANEL ASSY., INDICATOR(4-LED)	FOP-5-3-13

HZZ3-38216-003	COVER ASSY., FUSE (40A)	F-7-10-29
HZZ3-38216-003	COVER ASSY., FUSE (40A)	F-7-10-29
HZZ3-38216-003	COVER ASSY., FUSE (40A)	F-7-10-29
HZZ3-38216-003	COVER ASSY., FUSE (40A)	F-7-10-29
HZZ3-38216-003	COVER ASSY., FUSE (40A)	F-7-10-29
HZZ3-38216-003	COVER ASSY., FUSE (40A)	F-7-10-29
HZZ3-50223-000	CAM A, TILT LIMIT ANGLE	F-10-23
HZZ3-50224-000	CAM B, TILT LIMIT ANGLE	F-10-24
HZZ3-87701-R41	MARK, HANDLE FLUSH MOUNT	FOP-3-1-18
HZZ3-87703-R02	MARK, REMOTE CONTROL (DUAL)	FOP-3-2-23
HZZ3-87703-R82	MARK, REMOTE CONTROL (SINGLE)	FOP-3-20
HZZ3-91252-003	SEAL, WATER, 30X45X7	F-5-29
HZZ3-91252-003	SEAL, WATER, 30X45X7	F-5-1-31
HZZ3-91252-003	SEAL, WATER, 30X45X7	FOP-17-4
HZZ5-06352-M01	SWITCH KIT, LIGHT	FOP-5-3-2
HZZ5-24810-D01	PLATE ASSY.	FOP-3-3-2
HZZ5-24811-D01	LEVER, HAND	FOP-3-3-3
HZZ5-24812-D01	ARM, NEUTRAL LOCK	FOP-3-3-4
HZZ5-24813-D01	GRIP	FOP-3-3-5
HZZ5-24814-D01	COVER, LEVER	FOP-3-3-6
HZZ5-24815-D01	ARM ASSY., BRAKE	FOP-3-3-7
HZZ5-24816-D01	SPRING (2)	FOP-3-3-8
HZZ5-24817-D01	CLIP, DETENT	FOP-3-3-9
HZZ5-24818-D01	SPACER (1)	FOP-3-3-10
HZZ5-24819-D01	BRACKET	FOP-3-3-11
HZZ5-24821-D01	HOUSING, FR.	FOP-3-3-12
HZZ5-24822-D01	HOUSING, RR.	FOP-3-3-13
HZZ5-24823-D01	PANEL, BACK	FOP-3-3-14
HZZ5-24824-D01	BRACKET, WIRE CLAMP	FOP-3-3-15
HZZ5-24826-D01	CAP, RUBBER	FOP-3-3-16
HZZ5-24827-D01	ADJUSTER	FOP-3-3-17
HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	FOP-3-3-18
HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	FOP-3-3-19
HZZ5-24829-D01	SEAL, RUBBER	FOP-3-3-20
HZZ5-24831-D01	HOLDER, NEUTRAL LOCK	FOP-3-3-21
HZZ5-24832-D01	GROMMET, WIRE (14)	FOP-3-3-22
HZZ5-24833-D01	CAP, TROLLING CONTROL SWITCH	FOP-3-3-23
HZZ5-24845-D01	GEAR ASSY., SHIFT	FOP-3-3-24
HZZ5-24850-D01	GEAR, DRIVE	FOP-3-3-25
HZZ5-24855-D01	TERMINAL, CABLE	FOP-3-3-26
HZZ5-24875-D01	DRUM ASSY., FREE THROTTLE	FOP-3-3-27
HZZ5-24876-D01	SPRING (1)	FOP-3-3-28
HZZ5-24878-D01	LEVER, FREE THROTTLE	FOP-3-3-29
HZZ5-24883-D01	SPRING, DETENT	FOP-3-3-30
HZZ5-32530-D01	CABLE ASSY., REMOTE CONTROL (B)	FOP-3-3-31
HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	FOP-5-3-6
HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	FOP-5-4-3
HZZ5-35370-D02	SWITCH ASSY., POWER TRIM-TILT	FOP-3-3-35

HZZ5-35701-D01	BAND, WIRE	FOP-3-3-37
HZZ5-37210-713	LAMP ASSY., INDICATION (4-LED)	FOP-5-4-10
HZZ5-37210-763	LAMP ASSY., INDICATION (4-LED)	FOP-5-3-14
HZZ5-37210-D02	LAMP ASSY., INDICATION	FOP-3-3-40
HZZ5-38414-003	BRACKET, BUZZER	FOP-5-3-17
HZZ5-38414-003	BRACKET, BUZZER	FOP-5-4-13
HZZ5-87701-D00	MARK, FAST IDLE	FOP-3-3-44
HZZ5-87702-A00	MARK, EMERGENCY STOP (US)	FOP-3-3-45
HZZ5-87702-A00	MARK, EMERGENCY STOP (US)	FOP-3-3-46
HZZ5-87702-D00	MARK, EMERGENCY STOP	FOP-3-3-45
HZZ5-87702-D00	MARK, EMERGENCY STOP	FOP-3-3-47
HZZ5-87703-P01	MARK, EMBLEM	FOP-3-3-48
HZZ5-87704-D01	LABEL, SIGP	FOP-3-3-49
HZZ5-90011-M00	BOLT, FLANGE, 6X14 (CT200)	E-1-12
HZZ5-90011-M00	BOLT, FLANGE, 6X14 (CT200)	E-13-20
HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTING	E-13-21
HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTING	E-13-21
HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTING	E-13-21
HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTING	E-13-21
HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTING	E-13-21
HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTING	E-13-21
HZZ5-90013-M00	BOLT-WASHER, 6X25	E-15-15
HZZ5-90013-M00	BOLT-WASHER, 6X25	E-15-15
HZZ5-90013-M00	BOLT-WASHER, 6X25	E-15-15
HZZ5-90013-M01	BOLT-WASHER, 6X25	E-15-15
HZZ5-90013-M01	BOLT-WASHER, 6X25	E-15-15
HZZ5-90013-M01	BOLT-WASHER, 6X25	E-15-15
HZZ5-90013-M01	BOLT-WASHER, 6X25	F-7-10-13
HZZ5-90014-M00	BOLT, FLANGE, 6X25	E-3-10-7
HZZ5-90014-M00	BOLT, FLANGE, 6X25	E-14-24
HZZ5-90014-M00	BOLT, FLANGE, 6X25	E-18-47
HZZ5-90014-M00	BOLT, FLANGE, 6X25	E-18-47
HZZ5-90014-M00	BOLT, FLANGE, 6X25	E-18-47
HZZ5-90014-M01	BOLT, FLANGE, 6X25	E-18-47
HZZ5-90014-M01	BOLT, FLANGE, 6X25	E-18-47
HZZ5-90014-M01	BOLT, FLANGE, 6X25	E-18-47
HZZ5-90016-M00	BOLT, FLANGE, 6X28	E-18-48
HZZ5-90016-M00	BOLT, FLANGE, 6X28	E-18-48
HZZ5-90016-M00	BOLT, FLANGE, 6X28	E-18-48
HZZ5-90016-M01	BOLT, FLANGE, 6X28	E-18-48
HZZ5-90016-M01	BOLT, FLANGE, 6X28	E-18-48
HZZ5-90016-M01	BOLT, FLANGE, 6X28	E-18-48
HZZ5-90017-M00	BOLT, FLANGE, 6X16	E-3-32
HZZ5-90017-M00	BOLT, FLANGE, 6X16	E-13-23
HZZ5-90017-M00	BOLT, FLANGE, 6X16	E-18-49
HZZ5-90017-M00	BOLT, FLANGE, 6X16	E-18-49
HZZ5-90017-M00	BOLT, FLANGE, 6X16	E-18-49
HZZ5-90017-M00	BOLT, FLANGE, 6X16	E-19-23

HZZ5-90017-M00	BOLT, FLANGE, 6X16	F-2-26
HZZ5-90017-M01	BOLT, FLANGE, 6X16	E-18-49
HZZ5-90017-M01	BOLT, FLANGE, 6X16	E-18-49
HZZ5-90017-M01	BOLT, FLANGE, 6X16	E-18-49
HZZ5-90018-M00	BOLT, FLANGE, 6X20	E-20-6
HZZ5-90018-M01	BOLT, FLANGE, 6X20	F-7-20-7
HZZ5-90019-M00	BOLT, FLANGE, 6X35	E-1-13
HZZ5-90019-M00	BOLT, FLANGE, 6X35	E-3-33
HZZ5-90019-M00	BOLT, FLANGE, 6X35	E-4-15
HZZ5-90019-M00	BOLT, FLANGE, 6X35	E-14-25
HZZ5-90019-M00	BOLT, FLANGE, 6X35	E-14-25
HZZ5-90019-M00	BOLT, FLANGE, 6X35	E-14-25
HZZ5-90019-M01	BOLT, FLANGE, 6X35	E-14-25
HZZ5-90019-M01	BOLT, FLANGE, 6X35	E-14-25
HZZ5-90019-M01	BOLT, FLANGE, 6X35	E-14-25
HZZ5-90021-M00	BOLT, FLANGE, 6X14 (CT200)	E-3-30
HZZ5-90021-M00	BOLT, FLANGE, 6X14 (CT200)	E-3-30
HZZ5-90021-M00	BOLT, FLANGE, 6X14 (CT200)	E-3-30
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-14-26
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-14-26
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-14-26
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-18-50
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-18-50
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-18-50
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-18-1-14
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-18-1-14
HZZ5-90021-M00	BOLT, FLANGE, 6X14	E-18-1-14
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M00	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M01	BOLT, FLANGE, 6X14 (CT200)	E-3-30
HZZ5-90021-M01	BOLT, FLANGE, 6X14 (CT200)	E-3-30
HZZ5-90021-M01	BOLT, FLANGE, 6X14 (CT200)	E-3-30
HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-14-26
HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-14-26
HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-14-26
HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-18-50
HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-18-50
HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-18-50

HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-18-1-14
HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-18-1-14
HZZ5-90021-M01	BOLT, FLANGE, 6X14	E-18-1-14
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-2-27
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90021-M01	BOLT, FLANGE, 6X14	F-7-6
HZZ5-90030-M00	BOLT, FLANGE, 6X22	E-3-36
HZZ5-90030-M00	BOLT, FLANGE, 6X22	E-6-10-31
HZZ5-90030-M00	BOLT, FLANGE, 6X22	E-13-24
HZZ5-90030-M00	BOLT, FLANGE, 6X22	E-15-16
HZZ5-90032-M00	BOLT, FLANGE, 6X32	E-3-10-9
HZZ5-90032-M00	BOLT, FLANGE, 6X32	E-3-10-9
HZZ5-90032-M00	BOLT, FLANGE, 6X32	E-3-10-9
HZZ5-90032-M00	BOLT, FLANGE, 6X32	E-6-10-32
HZZ5-90032-M00	BOLT, FLANGE, 6X32	E-6-10-32
HZZ5-90032-M00	BOLT, FLANGE, 6X32	E-6-10-32
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-3-10-9
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-3-10-9
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-3-10-9
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-6-10-32
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-6-10-32
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-6-10-32
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-14-10-14
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-14-10-14
HZZ5-90032-M01	BOLT, FLANGE, 6X32	E-14-10-14
HZZ5-90047-M00	BOLT, FLANGE, 6X55	E-3-10-11
HZZ5-90047-M00	BOLT, FLANGE, 6X55	E-3-10-11
HZZ5-90047-M00	BOLT, FLANGE, 6X55	E-3-10-11
HZZ5-90047-M01	BOLT, FLANGE, 6X55	E-3-10-11
HZZ5-90047-M01	BOLT, FLANGE, 6X55	E-3-10-11
HZZ5-90047-M01	BOLT, FLANGE, 6X55	E-3-10-11
HZZ5-90051-M00	BOLT, FLANGE, 8X18	F-3-20-36
HZZ5-90055-M00	BOLT, FLANGE, 8X40	E-4-18
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-3-39
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-3-39
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-3-39
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-3-10-13
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-3-10-13
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-3-10-13

HZZ5-90081-M00	BOLT, SEALING, 22MM	E-3-10-13
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-3-10-13
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-5-15
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-5-15
HZZ5-90081-M00	BOLT, SEALING, 22MM	E-5-15
HZZ5-90081-M01	BOLT, SEALING, 22MM	E-3-39
HZZ5-90081-M01	BOLT, SEALING, 22MM	E-3-39
HZZ5-90081-M01	BOLT, SEALING, 22MM	E-3-39
HZZ5-90081-M01	BOLT, SEALING, 22MM	E-3-10-13
HZZ5-90081-M01	BOLT, SEALING, 22MM	E-5-15
HZZ5-90081-M01	BOLT, SEALING, 22MM	E-5-15
HZZ5-90081-M01	BOLT, SEALING, 22MM	E-5-15
HZZ5-90101-D01	SCREW, 5X18	FOP-3-3-50
HZZ5-90102-D01	SCREW, 4X6	FOP-3-3-51
HZZ5-90103-D01	SCREW, 5X10	FOP-3-3-52
HZZ5-90104-D01	SCREW, 4X10	FOP-3-3-53
HZZ5-90105-M00	BOLT, FLANGE, 6X12	F-7-7
HZZ5-90105-M00	BOLT, FLANGE, 6X12	F-7-10-16
HZZ5-90106-D01	SCREW, 5X12	FOP-3-3-54
HZZ5-90107-D01	SCREW, 6X90	FOP-3-3-55
HZZ5-90108-D01	BOLT, 8X50	FOP-3-3-56
HZZ5-90109-D01	BOLT, 5X25	FOP-3-3-57
HZZ5-90201-M00	NUT, FLANGE, 6MM	F-2-31
HZZ5-90201-M00	NUT, FLANGE, 6MM	F-2-31
HZZ5-90201-M00	NUT, FLANGE, 6MM	F-2-31
HZZ5-90201-M00	NUT, FLANGE, 6MM	F-2-31
HZZ5-90201-M00	NUT, FLANGE, 6MM	F-2-31
HZZ5-90201-M00	NUT, FLANGE, 6MM	F-2-31
HZZ5-90301-D01	NUT, 6MM	FOP-3-3-58
HZZ5-90301-D01	NUT, 6MM	FOP-3-4-36
HZZ5-90301-D01	NUT, 6MM	FOP-3-5-47
HZZ5-90301-M00	NUT, FLANGE, 5MM	E-14-10-17
HZZ5-90301-M00	NUT, FLANGE, 5MM	E-14-10-17
HZZ5-90301-M00	NUT, FLANGE, 5MM	E-14-10-17
HZZ5-90301-M01	NUT, FLANGE, 5MM	E-14-10-17
HZZ5-90301-M01	NUT, FLANGE, 5MM	E-14-10-17
HZZ5-90301-M01	NUT, FLANGE, 5MM	FOP-5-16
HZZ5-90301-M01	NUT, FLANGE, 5MM	FOP-5-1-16
HZZ5-90301-M01	NUT, FLANGE, 5MM	FOP-5-2-16
HZZ5-90301-M01	NUT, FLANGE, 5MM	FOP-5-3-19
HZZ5-90301-M01	NUT, FLANGE, 5MM	FOP-5-3-19
HZZ5-90301-M01	NUT, FLANGE, 5MM	FOP-5-4-15
HZZ5-90302-D01	NUT, 5MM	FOP-3-3-60
HZZ5-90501-D01	BEARING (1)	FOP-3-3-61
HZZ5-90501-M00	WASHER, PLAIN, 5MM	E-14-10-18
HZZ5-90501-M00	WASHER, PLAIN, 5MM	E-14-10-18
HZZ5-90501-M00	WASHER, PLAIN, 5MM	E-14-10-18

HZZ5-90501-M01	WASHER, PLAIN, 5MM	E-14-10-18
HZZ5-90501-M01	WASHER, PLAIN, 5MM	E-14-10-18
HZZ5-90501-M01	WASHER, PLAIN, 5MM	E-14-10-18
HZZ5-90501-M01	WASHER, PLAIN, 5MM	FOP-5-18
HZZ5-90501-M01	WASHER, PLAIN, 5MM	FOP-5-1-18
HZZ5-90501-M01	WASHER, PLAIN, 5MM	FOP-5-2-18
HZZ5-90501-M01	WASHER, PLAIN, 5MM	FOP-5-3-21
HZZ5-90501-M01	WASHER, PLAIN, 5MM	FOP-5-3-21
HZZ5-90501-M01	WASHER, PLAIN, 5MM	FOP-5-4-17
HZZ5-90502-D01	WASHER (3)	FOP-3-3-62
HZZ5-90502-M01	WASHER, SPRING, 5MM	FOP-5-19
HZZ5-90502-M01	WASHER, SPRING, 5MM	FOP-5-1-19
HZZ5-90502-M01	WASHER, SPRING, 5MM	FOP-5-2-19
HZZ5-90502-M01	WASHER, SPRING, 5MM	FOP-5-3-22
HZZ5-90502-M01	WASHER, SPRING, 5MM	FOP-5-3-22
HZZ5-90502-M01	WASHER, SPRING, 5MM	FOP-5-4-18
HZZ5-90503-D01	WASHER (4)	FOP-3-3-63
HZZ5-90504-D01	WASHER (5)	FOP-3-3-64
HZZ5-90506-D01	WASHER, 8MM	FOP-3-3-65
HZZ5-90507-D01	WASHER (7)	FOP-3-3-66
HZZ5-90508-D01	WASHER, WAVE	FOP-3-3-67
HZZ5-90508-M00	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M00	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M00	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M00	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M01	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M01	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M01	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M01	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M01	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M01	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90508-M01	WASHER, PLAIN, 6MM	F-2-36
HZZ5-90509-D01	SPACER (2)	FOP-3-3-68
HZZ5-90651-D01	E-RING, 6MM	FOP-3-3-69
HZZ5-90651-D01	E-RING, 6MM (LOOSE PARTS)	FOP-3-4-40
HZZ5-90651-D01	E-RING, 6MM	FOP-3-4-41
HZZ5-90651-D01	E-RING, 6MM (LOOSE PARTS)	FOP-3-5-52
HZZ5-90651-D01	E-RING, 6MM	FOP-3-5-53
HZZ5-91151-D01	ROLLER, DRIVE GEAR CAM	FOP-3-3-70
HZZ5-91152-D01	ROLLER	FOP-3-3-71
HZZ5-91153-D01	BEARING (2)	FOP-3-3-72
HZZ5-91154-D01	BEARING (3)	FOP-3-3-73
HZZ5-91156-D01	ROLLER, FREE THROTTLE	FOP-3-3-74
HZZ5-91157-D01	CLIP, ROLLER	FOP-3-3-75
HZZ5-91501-010	COLLAR, MOUNTING (6MM)	F-7-10-24

2025PARTS CATALOG

BFT 200D
BFT 225D
BFT 250D
Models
EU

TOHATSU CORPORATION

5-4, Azusawa 3-Chome, Itabashi-Ku
Tokyo 174-0051, Japan

Tel: +81-3-3966-3117 Fax: +81-3-3966-2951

www.tohatsu.com

